SANDIA REPORT

2008-2876
Unlimited Release
Printed May 2008

Adagio 2.9 User's Guide

SIERRA Solid Mechanics Team
Computational Solid Mechanics and Structural Dynamics Department
Engineering Sciences Center

Prepared by
Sandia National Laboratories
Albuquerque, New Mexico 87185 and Livermore, California 94550

Sandia is a multiprogram laboratory operated by Sandia Corporation,
a Lockheed Martin Company, for the United States Department of Energy's
National Nuclear Security Administration under Contract DE-AC04-94-AL85000.

Approved for public release; further dissemination unlimited.

Sandia National Laboratories

Issued by Sandia National Laboratories, operated for the United States Department of Energy by Sandia Corporation.

NOTICE: This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government, nor any agency thereof, nor any of their employees, nor any of their contractors, subcontractors, or their employees, make any warranty, express or implied, or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represent that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government, any agency thereof, or any of their contractors or subcontractors. The views and opinions expressed herein do not necessarily state or reflect those of the United States Government, any agency thereof, or any of their contractors.

Printed in the United States of America. This report has been reproduced directly from the best available copy.

Available to DOE and DOE contractors from
U.S. Department of Energy
Office of Scientific and Technical Information
P.O. Box 62
Oak Ridge, TN 37831

Telephone: (865) 576-8401
Facsimile: (865) 576-5728
E-Mail: reports@adonis.osti.gov
Online ordering: http://www.osti.gov/bridge

Available to the public from
U.S. Department of Commerce
National Technical Information Service
5285 Port Royal Rd
Springfield, VA 22161

Telephone: (800) 553-6847
Facsimile: (703) 605-6900
E-Mail: orders@ntis.fedworld.gov
Online ordering: http://www.ntis.gov/help/ordermethods.asp?loc=7-4-0#online

2008-2876
Unlimited Release
Printed May 2008

Adagio 2.9 User's Guide

SIERRA Solid Mechanics Team
Computational Solid Mechanics and Structural Dynamics Department
Engineering Sciences CenterSandia National Laboratories
Box 5800
Albuquerque, NM 87185-0380

Abstract

Adagio is a Lagrangian, three-dimensional, implicit code for the analysis of solids and structures. It uses a multi-level iterative solver, which enables it to solve problems with large deformations, nonlinear material behavior, and contact. It also has a versatile library of continuum and structural elements, and an extensive library of material models. Adagio is written for parallel computing environments, and its solvers allow for scalable solutions of very large problems. Adagio uses the SIERRA Framework, which allows for coupling with other SIERRA mechanics codes. This document describes the functionality and input structure for Adagio.

Acknowledgments

This document is the result of the collective effort of a number of individuals. The development team responsible for Adagio and Presto, the SIERRA Solid Mechanics codes, includes Manoj K. Bhardwaj, Nathan K. Crane, Arne S. Gullerud, Jason D. Hales, Martin W. Heinstein, J. Richard Koteras, Alex Lindblad Kendall H. Pierson, Vicki L. Porter, Gregory D. Sjaardema, and Benjamin W. Spencer. This document is written and maintained by this team.

Outside the core development team, there are number of other individuals who have contributed to this manual. William Scherzinger, Gerald W. Wellman, Daniel C. Hammerand, and Jakob T. Ostien provided descriptions of the material models or reviewed the descriptions of these models. Daniel C. Hammerand also contributed heavily to the section on control stiffness.

Rhonda K. Reinert of Technically Write guided the overall style and editing of the document and has written various parts of the document. Ms. Reinert has also made many valuable suggestions for improving the organization and clarity of the document.

Contents

1 Introduction **23**

1.1 Document Overview 24

1.2 Overall Input Structure 26

1.3 Conventions for Command Descriptions 29

1.3.1 Key Words 29

1.3.2 User-Specified Input 29

1.3.3 Optional Input 30

1.3.4 Default Values 30

1.3.5 Multiple Options for Values 30

1.3.6 Set of Command Lines 31

1.3.7 Known Issues and Warnings 31

1.4 Style Guidelines 33

1.4.1 Comments 33

1.4.2 Continuation Lines 33

1.4.3 Case 33

1.4.4 Commas and Tabs 33

1.4.5 Blank Spaces 34

1.4.6 General Format of the Command Lines 34

1.4.7 Delimiters 35

1.4.8 Order of Commands 35

1.4.9 Abbreviated END Specifications 35

1.4.10 Indentation 36

1.5 Naming Conventions Associated with the Exodus II Database 37

1.6 Major Scope Definitions for an Input File 38

1.7 Input/Output Files . . . 39
1.8 Obtaining Support . . . 41
1.9 References . . . 42

2 General Commands **45**
2.1 Domain Scope . . . 45
2.1.1 SIERRA Command Block . . . 45
2.1.2 Title . . . 46
2.1.3 Restart Control . . . 46
2.1.3.1 Restart Time . . . 47
2.1.3.2 Automatic Restart . . . 47
2.1.4 User Subroutine Identification . . . 47
2.1.5 Functions . . . 48
2.1.6 Axes, Directions, and Points . . . 52
2.1.7 Orientation . . . 54
2.2 Procedure and Region . . . 59
2.2.1 Procedure . . . 59
2.2.2 Time Control . . . 59
2.2.3 Region . . . 60
2.3 Use Finite Element Model . . . 61
2.4 Activation/Deactivation of Functionality . . . 62

3 Solver, Time Stepping, and Implicit Dynamics **63**
3.1 Conjugate Gradient Solver . . . 65
3.1.1 Convergence Commands . . . 66
3.1.2 Preconditioner Commands . . . 68
3.1.3 Line Search Command . . . 70
3.1.4 Diagnostic Output Commands . . . 71
3.1.5 CG Algorithm Commands . . . 72
3.2 Full Tangent Preconditioner . . . 74
3.2.1 Solver Selection Commands . . . 75
3.2.2 Matrix Formation Commands . . . 76
3.2.3 Reset and Iteration Commands . . . 77

3.2.4 Fall-Back Strategy Commands . . . 79
3.3 FETI Equation Solver . . . 80
3.3.1 Convergence Commands . . . 81
3.3.2 Memory Usage Commands . . . 81
3.3.3 Solver Commands . . . 82
3.4 Multilevel Solver . . . 83
3.4.1 Level Predictor . . . 85
3.5 Control Contact . . . 86
3.5.1 Convergence Commands . . . 89
3.5.2 Level Selection Command . . . 90
3.5.3 Diagnostic Output Commands . . . 90
3.6 Control Stiffness . . . 92
3.6.1 Convergence Commands . . . 98
3.6.2 Level Selection Command . . . 100
3.6.3 Diagnostic Output Commands . . . 101
3.7 Control Modes . . . 102
3.7.1 Control Modes Region . . . 103
3.7.1.1 Model Setup Commands . . . 104
3.7.1.2 Solver Commands . . . 104
3.7.1.3 Kinematic Boundary Condition Commands . . . 105
3.8 Predictors . . . 106
3.8.1 Loadstep Predictor . . . 106
3.8.1.1 Predictor Type . . . 106
3.8.1.2 Scale Factor . . . 107
3.8.1.3 Slip Scale Factor . . . 107
3.9 JAS3D Compatibility Mode . . . 109
3.10 Time Step Control . . . 110
3.10.1 Command Blocks for Time Control and Time Stepping . . . 110
3.10.1.1 Time Increment . . . 112
3.10.1.2 Number of Time Steps . . . 112
3.10.1.3 Time Increment Function . . . 112
3.10.2 Adaptive Time Stepping . . . 113

3.10.2.1 Cutback Factor . . . 113
3.10.2.2 Growth Factor . . . 114
3.10.2.3 Maximum Failure Cutbacks . . . 114
3.10.2.4 Maximum Multiplier . . . 114
3.10.2.5 Minimum Multiplier . . . 115
3.10.2.6 Active Periods . . . 115
3.10.3 Time Control Example . . . 115
3.11 Implicit Dynamic Time Integration . . . 117
3.11.1 Implicit Dynamics . . . 117
3.11.1.1 Active Periods . . . 117
3.11.1.2 Use HHT Integration . . . 118
3.11.1.3 HHT Parameters . . . 118
3.11.1.4 Implicit Dynamic Adaptive Time Stepping . . . 118
3.12 References . . . 120

4 Materials **121**
4.1 General Material Commands . . . 125
4.1.1 Density Command . . . 125
4.1.2 Thermal Strain Behavior . . . 125
4.1.2.1 Defining Thermal Strains . . . 125
4.1.2.2 Activating Thermal Strains . . . 128
4.2 Model Specifications . . . 129
4.2.1 Elastic Model . . . 130
4.2.2 Elastic Fracture Model . . . 132
4.2.3 Elastic-Plastic Model . . . 134
4.2.4 Elastic-Plastic Power-Law Hardening Model . . . 136
4.2.5 Ductile Fracture Model . . . 138
4.2.6 Multilinear EP Hardening Model . . . 140
4.2.7 Multilinear EP Hardening Model with Failure . . . 142
4.2.8 Johnson-Cook Model . . . 145
4.2.9 BCJ Model . . . 147
4.2.10 Soil and Crushable Foam Model . . . 149
4.2.11 Foam Plasticity Model . . . 152

4.2.12 Elastic Three-Dimensional Orthotropic Model 154
4.2.13 Orthotropic Crush Model 156
4.2.14 Orthotropic Rate Model 159
4.2.15 Elastic Laminate Model 162
4.2.16 Fiber Membrane Model 164
4.2.17 Incompressible Solid Model 167
4.2.18 Mooney-Rivlin Model 170
4.2.19 NLVE 3D Orthotropic Model 173
4.2.20 Stiff Elastic 177
4.2.21 Swanson Model 179
4.2.22 Viscoelastic Swanson Model 182
4.3 References 186

5 Elements **189**
5.1 Finite Element Model 189
5.1.1 Identification of Mesh File 192
5.1.1.1 Alias 193
5.1.1.2 Omit Block 193
5.1.1.3 Component Separator Character 194
5.1.2 Descriptors of Element Blocks 194
5.1.2.1 Material Property 196
5.1.2.2 Section 196
5.1.2.3 Linear and Quadratic Bulk Viscosity 197
5.1.2.4 Hourglass Control 198
5.1.2.5 Effective Moduli Model 198
5.1.2.6 Element Numerical Formulation 199
5.1.2.7 Activation/Deactivation of Element Blocks by Time 200
5.2 Element Sections 201
5.2.1 Solid Section 201
5.2.2 Shell Section 203
5.2.3 Membrane Section 208
5.2.4 Truss Section 210
5.2.5 Point Mass Section 211

5.3 Element-like Functionality . . . 213
5.3.1 Rigid Body . . . 213
5.4 Mass Property Calculations . . . 218
5.4.1 Block Set Commands . . . 218
5.4.2 Structure Command . . . 219
5.5 References . . . 219

6 Boundary Conditions and Initial Conditions 221
6.1 General Boundary Condition Concepts . . . 222
6.1.1 Mesh-Entity Assignment Commands . . . 222
6.1.2 Methods for Specifying Boundary Conditions . . . 224
6.2 Initial Variable Assignment . . . 225
6.2.1 Mesh-Entity Set Commands . . . 226
6.2.2 Variable Identification Commands . . . 226
6.2.3 Specification Command . . . 227
6.2.4 Input Mesh Command . . . 227
6.2.5 User Subroutine Commands . . . 228
6.2.6 Additional Command . . . 228
6.3 Kinematic Boundary Conditions . . . 230
6.3.1 Fixed Displacement Components . . . 230
6.3.1.1 Node Set Commands . . . 230
6.3.1.2 Specification Commands . . . 231
6.3.1.3 Additional Command . . . 231
6.3.2 Prescribed Displacement . . . 232
6.3.2.1 Node Set Commands . . . 233
6.3.2.2 Specification Commands . . . 233
6.3.2.3 User Subroutine Commands . . . 234
6.3.2.4 Additional Commands . . . 235
6.3.3 Prescribed Velocity . . . 236
6.3.3.1 Node Set Commands . . . 237
6.3.3.2 Specification Commands . . . 237
6.3.3.3 User Subroutine Commands . . . 238
6.3.3.4 Additional Commands . . . 239

6.3.4 Prescribed Acceleration 240
6.3.4.1 Node Set Commands 241
6.3.4.2 Specification Commands 241
6.3.4.3 User Subroutine Commands 242
6.3.4.4 Additional Commands 243
6.3.5 Fixed Rotation 244
6.3.5.1 Node Set Commands 244
6.3.5.2 Specification Commands 245
6.3.5.3 Additional Command 245
6.3.6 Prescribed Rotation 246
6.3.6.1 Node Set Commands 247
6.3.6.2 Specification Commands 247
6.3.6.3 User Subroutine Commands 248
6.3.6.4 Additional Commands 249
6.3.7 Subroutine Usage for Kinematic Boundary Conditions 250
6.4 Initial Velocity Conditions 251
6.4.1 Node Set Commands 252
6.4.2 Direction Specification Commands 252
6.4.3 Angular Velocity Specification Commands 253
6.4.4 User Subroutine Commands 253
6.5 Force Boundary Conditions 255
6.5.1 Pressure 255
6.5.1.1 Surface Set Commands 256
6.5.1.2 Specification Commands 256
6.5.1.3 User Subroutine Commands 257
6.5.1.4 External Pressure Sources 258
6.5.1.5 Output Command 259
6.5.1.6 Additional Commands 259
6.5.2 Traction 260
6.5.2.1 Surface Set Commands 261
6.5.2.2 Specification Commands 261
6.5.2.3 User Subroutine Commands 261

6.5.2.4 Additional Commands . . . 263
6.5.3 Prescribed Force . . . 264
6.5.3.1 Node Set Commands . . . 265
6.5.3.2 Specification Commands . . . 265
6.5.3.3 User Subroutine Commands . . . 266
6.5.3.4 Additional Commands . . . 267
6.5.4 Prescribed Moment . . . 268
6.5.4.1 Node Set Commands . . . 269
6.5.4.2 Specification Commands . . . 269
6.5.4.3 User Subroutine Commands . . . 270
6.5.4.4 Additional Commands . . . 271
6.6 Gravity . . . 271
6.7 Prescribed Temperature . . . 273
6.7.1 Block Set Commands . . . 274
6.7.2 Specification Command . . . 274
6.7.3 User Subroutine Commands . . . 274
6.7.4 Read Variable Commands . . . 275
6.7.5 Additional Commands . . . 276
6.8 References . . . 277

7 Contact **279**
7.1 Contact Definition Block . . . 283
7.2 Enforcement . . . 285
7.3 Descriptions of Contact Surfaces . . . 286
7.3.1 Contact Surface Command Line . . . 288
7.3.2 Contact Surface Command Block . . . 288
7.3.3 Contact Node Set . . . 289
7.4 Surface Normal Smoothing . . . 291
7.5 Shell Lofting . . . 292
7.6 Values for Interactions . . . 294
7.6.1 Surface Identification . . . 294
7.6.2 Tolerances . . . 295
7.6.3 Tension Release . . . 296

7.6.4 Tension Release Function . . . 296
7.6.5 Friction Coefficient . . . 296
7.6.6 Friction Coefficient Function . . . 296
7.7 Legacy Contact . . . 297
7.8 Examples . . . 298
7.8.1 Example 1 . . . 298
7.8.2 Example 2 . . . 299
7.9 References . . . 301

8 Output **303**
8.1 Results Output . . . 304
8.1.1 Exodus Results Output File . . . 305
8.1.1.1 Output Nodal Variables . . . 307
8.1.1.2 Output Node Set Variables . . . 308
8.1.1.3 Output Face Variables . . . 310
8.1.1.4 Output Element Variables . . . 312
8.1.1.5 Output Mesh Selection . . . 317
8.1.1.6 Component Separator Character . . . 317
8.1.1.7 Output Global Variables . . . 318
8.1.1.8 Set Begin Time for Results Output . . . 318
8.1.1.9 Adjust Interval for Time Steps . . . 319
8.1.1.10 Output Interval Specified by Time Increment . . . 319
8.1.1.11 Additional Times for Output . . . 319
8.1.1.12 Output Interval Specified by Step Increment . . . 319
8.1.1.13 Additional Steps for Output . . . 319
8.1.1.14 Set End Time for Results Output . . . 320
8.1.1.15 Use Output Scheduler . . . 320
8.1.1.16 Write Results If System Error Encountered . . . 320
8.1.2 User-Defined Output . . . 321
8.1.2.1 Mesh-Entity Set Commands . . . 322
8.1.2.2 Compute Global Result Command . . . 323
8.1.2.3 User Subroutine Commands . . . 324
8.1.2.4 Copy Command . . . 326

8.1.2.5 Compute at Every Step Command 327
8.1.2.6 Additional Command 327
8.2 History Output 328
8.2.1 Output Variables 330
8.2.1.1 Global Output Variables 330
8.2.1.2 Mesh Entity Output Variables 331
8.2.1.3 Nearest Point Output Variables 331
8.2.2 Outputting History Data on a Node Set 333
8.2.3 Set Begin Time for History Output 333
8.2.4 Adjust Interval for Time Steps 333
8.2.5 Output Interval Specified by Time Increment 334
8.2.6 Additional Times for Output 334
8.2.7 Output Interval Specified by Step Increment 334
8.2.8 Additional Steps for Output 334
8.2.9 Set End Time for History Output 335
8.2.10 Use Output Scheduler 335
8.2.11 Write History If System Error Encountered 335
8.3 Heartbeat Output 337
8.3.1 Output Variables 339
8.3.1.1 Global Output Variables 339
8.3.1.2 Mesh Entity Output Variables 339
8.3.1.3 Nearest Point Output Variables 340
8.3.2 Outputting Heartbeat Data on a Node Set 342
8.3.3 Set Begin Time for Heartbeat Output 342
8.3.4 Adjust Interval for Time Steps 342
8.3.5 Output Interval Specified by Time Increment 343
8.3.6 Additional Times for Output 343
8.3.7 Output Interval Specified by Step Increment 343
8.3.8 Additional Steps for Output 343
8.3.9 Set End Time for Heartbeat Output 344
8.3.10 Use Output Scheduler 344
8.3.11 Write Heartbeat On Signal 344

8.3.12 Heartbeat Output Formatting Commands 345
8.3.12.1 Specify floating point precision 345
8.3.12.2 Specify Labelling of Heartbeat Data 346
8.3.12.3 Specify Existance of Legend for Heartbeat Data 346
8.3.12.4 Specify format of timestamp 347
8.3.13 Monitor Output Events 347
8.4 Restart Data 349
8.4.1 Restart Options 350
8.4.1.1 Automatic Read and Write of Restart Files 351
8.4.1.2 User-Controlled Read and Write of Restart Files 354
8.4.1.3 Overwriting Restart Files 357
8.4.1.4 Recovering from a Corrupted Restart 358
8.4.2 Overwrite Command in Restart 358
8.4.3 Set Begin Time for Restart Writes 358
8.4.4 Adjust Interval for Time Steps 359
8.4.5 Restart Interval Specified by Time Increment 359
8.4.6 Additional Times for Restart 359
8.4.7 Restart Interval Specified by Step Increment 359
8.4.8 Additional Steps for Restart 360
8.4.9 Set End Time for Restart Writes 360
8.4.10 Overlay Count 360
8.4.11 Cycle Count 361
8.4.12 Use Output Scheduler 362
8.4.13 Write Restart If System Error Encountered 362
8.5 Output Scheduler 363
8.5.1 Output Scheduler Command Block 363
8.5.1.1 Set Begin Time for Output Scheduler 364
8.5.1.2 Adjust Interval for Time Steps 364
8.5.1.3 Output Interval Specified by Time Increment 364
8.5.1.4 Additional Times for Output 364
8.5.1.5 Output Interval Specified by Step Increment 364
8.5.1.6 Additional Steps for Output 365

8.5.1.7 Set End Time for Output Scheduler 365
8.5.2 Example of Using the Output Scheduler 365
8.6 Registered Variables 367
8.6.1 Global, Nodal, and Element Registered Variables 367
8.6.2 Registered Variables for Material Models 371
8.6.2.1 State Variable Output by Index for Native Solid Material Models 371
8.6.2.2 State Variable Output by Name for Native Solid Material Models 372
8.6.2.3 State Variable Output for LAME Solid Material Models 372
8.6.2.4 State Variable Tables for Solid Material Models 373
8.6.2.5 Registered Variables for Shell/Membrane Material Models . . . 383
8.7 References 385

9 User Subroutines **387**
9.1 User Subroutines: Programming 391
9.1.1 Subroutine Interface 392
9.1.2 Query Functions 392
9.1.2.1 Parameter Query 394
9.1.2.2 Function Data Query 398
9.1.2.3 Time Query 398
9.1.2.4 Field Variables 398
9.1.2.5 Global Variables 405
9.1.2.6 Topology Extraction 409
9.1.3 Miscellaneous Query Functions 415
9.2 User Subroutines: Command File 417
9.2.1 Subroutine Identification 417
9.2.2 User Subroutine Command Lines 417
9.2.2.1 Type 417
9.2.2.2 Debugging 418
9.2.2.3 Parameters 418
9.2.3 Time Step Initialization 420
9.2.3.1 Mesh-Entity Set Commands 420
9.2.3.2 User Subroutine Commands 421
9.2.3.3 Additional Command 422

9.2.4 User Variables 423
9.3 User Subroutines: Compilation and Execution 425
9.4 User Subroutines: Examples 426
9.4.1 Pressure as a Function of Space and Time 426
9.4.2 Error Between a Computed and an Analytic Solution 429
9.4.3 Transform Output Stresses to a Cylindrical Coordinate System 433
9.5 User Subroutines: Library 439
9.5.1 aupst_cyl_transform 439
9.5.2 aupst_rec_transform 440

10 Example Problem **443**

11 Command Summary **453**

Index **497**

List of Figures

1.1 Input/output files 39

2.1 Piecewise linear and piecewise constant functions 49
2.2 Adjacent shell elements with nonaligned local coordinate systems 54
2.3 Rectangular coordinate system 55
2.4 Z-Rectangular coordinate system. 56
2.5 Cylindrical coordinate system. 56
2.6 Spherical coordinate system. 57
2.7 Rotation about 1 58

3.1 Reaching convergence with controls and the multilevel solver. 83
3.2 Contact configuration at the beginning of the contact update. 87
3.3 Contact gap removal (after contact search). 87
3.4 Contact slip calculations. 88
3.5 Control stiffness softening behavior in the first model problem. 94
3.6 Control stiffness softening behavior in the second model problem. 94
3.7 Control stiffness stiffening behavior in the first model problem. 95
3.8 Control stiffness stiffening behavior in the second model problem. 96
3.9 Control stiffness softening behavior convergence 97

5.1 Association between command lines and command block. 197
5.2 Location of geometric plane of shell for various lofting factors. 206
5.3 Local *rst* coordinate system for a shell element. 206
5.4 Rotation of 30 degrees about the 1-axis (X'-axis). 207

7.1 Two blocks at time step n before contact. 280
7.2 Two blocks at time step $n + 1$, after penetration. 281

7.3 Illustration of normal and tangential tolerances. 295
7.4 Problem with two blocks coming into contact. 298
7.5 Problem with three blocks coming into contact. 300

9.1 Overview of components required to implement functionality. 390

10.1 Eraser schematic 443
10.2 Complete eraser mesh 444

List of Tables

8.1 Derived Stress Output for Elements 315
8.2 Derived Log Strain Output for Solid Elements 316
8.3 Derived Strain Output for Shell Elements 317
8.4 Selection of Component Number 325
8.5 Variables Registered on Nodes (Variable and Type) 368
8.6 Element Variables Registered for All Elements 368
8.7 Element Variables Registered for Solid Elements 368
8.8 Element Variables Registered for Membranes 369
8.9 Nodal Variables Registered for Shells 369
8.10 Element Variables Registered for Shells 369
8.11 Element Variables Registered for Truss 369
8.12 Global Registered Variables 370
8.13 State Variables for DUCTILE FRACTURE Model 373
8.14 State Variables for ELASTIC Model 373
8.15 State Variables for ELASTIC FRACTURE Model 373
8.16 State Variables for ELASTIC PLASTIC Model 374
8.17 State Variables for EP POWER HARD Model 374
8.18 State Variables for FOAM PLASTICITY Model 374
8.19 State Variables for HONEYCOMB Model 374
8.20 State Variables for HYPERFOAM Model 375
8.21 State Variables for JOHNSON COOK Model 375
8.22 State Variables for LOW DENSITY FOAM Model 375
8.23 State Variables for MOONEY RIVLIN Model 376
8.24 State Variables for MULTILINEAR EP Model 376
8.25 State Variables for ML EP FAIL Model 377

8.26 State Variables for NEO HOOKEAN Model 377
8.27 State Variables for ORTHOTROPIC CRUSH Model 377
8.28 State Variables for ORTHOTROPIC RATE Model 377
8.29 State Variables for PIEZO Model 378
8.30 State Variables for POWER LAW CREEP Model 378
8.31 State Variables for SHAPE MEMORY Model 378
8.32 State Variables for SOIL FOAM Model 378
8.33 State Variables for SWANSON Model 379
8.34 State Variables for THERMO EP POWER Model 379
8.35 State Variables for THERMO EP POWER WELD Model 380
8.36 State Variables for UNIVERSAL POLYMER Model 380
8.37 State Variables for VISCOELASTIC SWANSON Model 381
8.38 State Variables for VISCOPLASTIC Model 382
8.39 State Variables for Elastic-Plastic Model for Shells 383
8.40 State Variables for Elastic-Plastic Power-Law Hardening Model for Shells 383
8.41 State Variables for Multilinear Elastic-Plastic Hardening Model for Shells 383
8.42 State Variables for Multilinear Elastic-Plastic Hardening Model w/Failure for Shells 384

9.1 Subroutine Input Parameters 392
9.2 Subroutine Output Parameters 393
9.3 aupst_get_real_param Arguments 395
9.4 aupst_get_integer_param Arguments 396
9.5 aupst_get_string_param Arguments 397
9.6 aupst_evaluate_function Arguments 398
9.7 aupst_get_time Argument 398
9.8 aupst_check_node_var Arguments 400
9.9 aupst_check_elem_var Arguments 401
9.10 aupst_get_node_var Arguments 402
9.11 aupst_get_elem_var Arguments 403
9.12 aupst_put_node_var Arguments 404
9.13 aupst_put_elem_var Arguments 405
9.14 aupst_check_global_var Arguments 407
9.15 aupst_get_global_var Arguments 407

9.16 aupst_put_global_var Arguments 408
9.17 aupst_local_put_global_var Arguments 409
9.18 Topologies Used by Adagio 410
9.19 aupst_get_elem_topology Arguments 411
9.20 aupst_get_elem_nodes Arguments 412
9.21 aupst_get_face_topology Arguments 413
9.22 aupst_get_face_nodes Arguments 414
9.23 aupst_get_one_elem_centroid Arguments 415
9.24 aupst_get_point Arguments 416
9.25 aupst_get_proc_num Arguments 416

Chapter 1

Introduction

This document is a user's guide for the code Adagio. Adagio is a three-dimensional, implicit solid mechanics code with a versatile element library, nonlinear material models, and capabilities for modeling large deformation and contact. Adagio is a parallel code, and its nonlinear solver and contact capabilities enable scalable solutions of large problems. It is built on the SIERRA Framework [1, 2]. SIERRA provides a data management framework in a parallel computing environment that allows the addition of capabilities in a modular fashion.

The *Adagio 2.9 User's Guide* provides information about the functionality in Adagio and the command structure required to access this functionality in a user input file. This document is divided into chapters based primarily on functionality. For example, the command structure related to the use of various element types is grouped in one chapter; descriptions of material models are grouped in another chapter.

The input and usage of Adagio is similar to that of the code Presto [3]. Presto, like Adagio, is a solid mechanics code built on the SIERRA Framework. The primary difference between the two codes is that Presto uses explicit time integration for transient dynamics analysis, whereas Adagio is an implicit code.

Because of the similarities in input and usage between Adagio and Presto, the user's guides for the two codes are structured in the same manner and share common material. (Once you have mastered the input structure for one code, it will be easy to master the syntax structure for the other code.) To maintain the commonality between the two user's guides, we have used a variety of techniques. For example, references to Presto may be found in the Adagio user's guide and vice versa, and the chapter order across the two guides is the same.

On the other hand, each of the two user's guides is expressly tailored to the features of the specific code and documents the particular functionality for that code. For example, though both Presto and Adagio have contact functionality, the content of the chapter on contact in the two guides differs.

Important references for both Adagio and Presto are given in the references section at the end of this chapter. Adagio was preceded by the codes JAC and JAS3D; JAC is described in Reference 4; JAS3D is described in Reference 5. Presto was preceded by the code Pronto3D. Pronto3D is described in References 6 and 7. Some of the fundamental nonlinear technology used by both Presto and Adagio are described in References 8, 9, and 10. Currently, both Presto and Adagio

use the Exodus II database and the XDMF database; Exodus II is more commonly used than XDMF. (Other options may be added in the future.) The Exodus II database format is described in Reference 11, and the XDMF database format is described in Reference 12. Important information about contact is provided in the reference document for ACME [13]. ACME is a third-party library for contact.

One of the key concepts for the command structure in the input file is a concept referred to as *scope*. A detailed explanation of scope is provided in Section 1.2. Most of the command lines in Chapter 2 are related to a certain scope rather than to some particular functionality.

1.1 Document Overview

This document describes how to create an input file for Adagio. Highlights of the document contents are as follows:

- Chapter 1 presents the overall structure of the input file, including conventions for the command descriptions, style guidelines for file preparation, and naming conventions for input files that reference the Exodus II database [11]. The chapter also gives an example of the general structure of an input file that employs the concept of scope.

- Chapter 2 explains some of the commands that are general to various applications based on the SIERRA Framework. These commands let you define scopes, functions, and coordinate systems, and they let you set up some of the main time control parameters (begin time, end time, time blocks) for your analysis. (Time control and time step control are discussed in more detail in Chapter 3.) Other capabilities documented in this chapter are available for calculating element distortion and for activating and deactivating functionality at different times throughout an analysis.

- Chapter 3 discusses the multilevel, nonlinear iterative solver in Adagio. This chapter also describes how to set start time, end time, and time blocks for an analysis.

- Chapter 4 describes material models that can be used in conjunction with the elements in Presto and Adagio. Most of the material models have an interface that allows the models to be used by the elements in both codes. Even though a material model can be used by both codes, it may be that the use of the material model is better suited for one code rather than for the other code. For example, a material model set up to characterize behavior over a long time would be better suited for use in Adagio than in Presto. If a material model is better suited for one of the two codes, this information will be noted for the material model. In some cases, a material model may only be included in one of the two user's guides. For example, there is a class of material models referred to as equation-of-state models. These models are designed for an explicit, transient dynamics code. The equation-of-state models are included in the Presto user's guide but not in the Adagio user's guide. Chapter 4 also discusses the application of temperature to a mesh, the computation of thermal strains (isotropic and anisotropic), and, for Presto, the deposition of energy for the equation-of-state material models.

- Chapter 5 lists the elements in Presto and Adagio and describes how to set up commands to use the various options for the elements. Most elements can be used in either Presto or Adagio. If an element is available in one code but not the other, this information will be noted for the element. In some cases, an element may only be included in one of the two user's guides. For example, Presto has a special element implementation referred to as smoothed particle hydrodynamics (SPH). The Presto user's guide contains a section on SPH, but the Adagio user's guide does not. Chapter 5 also includes descriptions of the commands for mass property calculations. An "element-like" capability is discussed in Chapter 5—rigid bodies. Although rigid bodies exhibit element-like behavior, they are really implemented as boundary conditions. From a user's point of view, it is best to discuss the rigid-body capabilities with elements.

- Chapter 6 documents how to use kinematic boundary conditions, force boundary conditions, initial conditions, and specialized boundary conditions.

- Chapter 7 discusses how to define interactions of contact surfaces.

- Chapter 8 details the various options for obtaining output.

- Chapter 9 provides an overview of the user subroutine functionality.

- Chapter 10 provides a sample input file from an analysis of an eraser being pulled across a surface. This problem emphasizes large deformation and contact.

- Chapter 11 gives all the permissible Adagio input lines in their proper scope.

- The index allows you to find information about command blocks and command lines. In general, single-level entries identify the page where the command syntax appears, with discussion following soon thereafter—on the same page or on a subsequent page. Page ranges are not provided in this index. Some entries consist of two or more levels. Such entries are typically based on context, including such information as the command blocks in which a command line appears, the location of the discussion related to a particular command line, and tips on usage. The PDF version of this document contains hyperlinked entries from the page numbers listed in the index to the text in the body of the document.

Note that all references cited within the text of Chapters 1 through 11 are listed at the end of the respective chapters rather than in a separate references chapter. The reference sections in the chapters are not necessarily edited so that they are specific to Adagio or Presto. Some chapters will have exactly the same set of references (even if not all are cited for a particular user's guide), and some chapters will have the references tailored to the specific user's guide.

1.2 Overall Input Structure

Adagio is one of many mechanics codes built on the SIERRA Framework. The SIERRA Framework provides the capability to perform multiphysics analyses by coupling together SIERRA codes appropriate for the mechanics of interest. Input files may be set up for analyses using only Adagio, or they may be set up to couple Adagio and one or more other SIERRA analysis codes. For example, you might run Adagio to compute a stress state, and then use the results of this analysis as initial conditions for a Presto analysis. For a multiphysics analysis using Presto and Adagio, the time-step control, the mesh-related definitions, and the boundary conditions for both Presto and Adagio will all be in the same input file. Therefore, the input for Adagio reflects the fact that it could be part of a multiphysics analysis. (Note that not all codes built on the SIERRA Framework can be coupled. Consult with the authors of this document to learn about the codes that can be coupled with Adagio.)

To create files defining multiphysics analyses, the input files use a concept called "scope." Scope is used to group similar commands; a scope can be nested inside another scope. The broadest scope in the input file is the domain scope. The domain scope contains information that can be shared among different physics. Examples of physics information that can be shared are definitions of functions and materials. Thus, in our above example of a coupled Presto/Adagio multiphysics analysis, both Adagio and Presto could reference functions to define such things as time histories for boundary conditions or stress-strain curves. Some of the functions could even be shared by these two applications. Both Presto and Adagio could also share information about materials.

Within the domain scope are two other important scopes: the procedure scope and the region scope. The region is nested inside the procedure, and the procedure is nested inside the domain. The procedure scope controls the overall analysis from the start time to the end time; the region scope controls a single time step. For a multiphysics analysis, the domain scope could contain several different procedures and several different regions.

Inside the procedure scope (but outside of the region scope) are commands that set the start time and the end time for the analysis.

Inside the region scope for Adagio are such things as definitions for boundary conditions and contact. In a multiphysics analysis, there would be more than one region. In our Presto/Adagio example, there would be both a Presto region and an Adagio region, each within its respective procedures. The definitions for boundary conditions and contact and the mesh specification for Presto would appear in the Presto region; the definitions for boundary conditions and contact and the mesh specification for Adagio would appear in the Adagio region.

The input for Adagio consists of command blocks and command lines. The command blocks define a scope. These command blocks group command lines or other command blocks that share a similar functionality. A command block will begin with an input line that has the word "begin"; the command block will end with an input line that has the word "end". The domain scope, for example, is defined by a command block that begins with an input line of the following form:

```
BEGIN SIERRA my_problem
```

The two character strings `BEGIN` and `SIERRA` are the key words for this command block. An input line defining a command block or a command line will have one or more key words. The string

`my_problem` is a user-specified name for this domain scope. The domain scope is terminated by an input line of the following form:

```
END SIERRA my_problem
```

In the above input line, `END` and `SIERRA` are the key words to end this command block. The domain scope can also be terminated simply by using the following key word:

```
END
```

The above abbreviated command line will be discussed in more detail in later chapters. There are similar input lines used to define the procedure and region scopes. Boundary conditions are another example where a scope is defined. A particular instance of a boundary condition for a prescribed displacement boundary condition is defined with a command block. The command block for the boundary condition begins with an input line of the form:

```
BEGIN PRESCRIBED DISPLACEMENT
```

and ends with an input line of either of the following forms:

```
END PRESCRIBED DISPLACEMENT
```

```
END
```

Command lines appear within the command blocks. The command lines typically have the form `keyword = value`, where `value` can be a real, an integer, or a string. In the previous example of the prescribed displacement boundary condition, there would be command lines inside the command block that are used to set various values. For example, the boundary condition might apply to all nodes in node set 10, in which case there would be a command line of the following form:

```
NODE SET = nodelist_10
```

If the prescribed displacement were to be applied along a given component direction, there would be a command line of this form:

```
COMPONENT = X
```

The form above would specify that the prescribed displacement would be in the x-direction. Finally, if the displacement magnitude is described by a time history function with the name `cosine_curve`, there would be a command line of this form:

```
FUNCTION = cosine_curve
```

The command block for the boundary condition with the appropriate command lines would appear as follows:

```
BEGIN PRESCRIBED DISPLACEMENT
  NODE SET = nodelist_10
  COMPONENT = X
  FUNCTION = cosine_curve
END PRESCRIBED DISPLACEMENT
```

It is possible to have a command line with the same key words appearing in different scopes. For example, we might have a command line identified by the word `TYPE` in two or more different

scopes. The command line would perform different functions based on the scope in which it appeared, and the associated value could be different in the two locations.

The input lines are read by a parser that searches for recognizable key words. If the key words in an input line are not in the list of key words used by Adagio to describe command blocks and command lines, the parser will generate an error. A set of key words defining a command line or command block for Adagio that is not in the correct scope will also cause a parser error. For example, the key words `STEP INTERVAL` define a valid command line in the scope of the `TIME CONTROL` command block. However, if this command line was to appear in the scope of one of the boundary conditions, it would not be in the proper scope, and the parser would generate an error. Once the parser has an input line with any recognizable key words in the proper scope, a method can be called that will handle the input line.

There is an initial parsing phase that checks only the parser syntax. If the parser encounters a command line it cannot parse within a certain scope, the parser will indicate it cannot recognize the command line and will list the various command lines that can appear within that scope. The initial parsing phase will catch errors such as the one described in the previous paragraph (a command line in the wrong scope). It will also catch misspelled key words. The initial parsing does not catch some other types of errors, however. If you have specified a value on a command line that is out of a specified range for that command line, the initial parsing will not catch this error. If you have some combination of command lines within a command block that is not allowed, the initial parsing will not catch this error. These other errors are caught after the initial parsing phase and are handled one error at a time.

1.3 Conventions for Command Descriptions

The conventions below are used to describe the input commands for Adagio. A number of the individual command lines discussed in the text appear on several text lines. In the text of this document, the continuation symbols that are used to continue lines in an actual input file (`\#` and `\$`, Section 1.4.2) are not used for those instances where the description of the command line appears on several text lines. The description of command lines will clearly indicate all the key words, delimiters, and values that constitute a complete command line. As an example, the `DEFINE POINT` command line (Section 2.1.6) is presented in the text as follows:

```
DEFINE POINT <string>point_name WITH COORDINATES
     <real>value_1 <real>value_2 <real>value_3
```

If the `DEFINE POINT` command line were used as a command line in an input file and spread over two input lines, it would appear, with actual values, as follows:

```
DEFINE POINT center WITH COORDINATES \#
  10.0 144.0 296.0
```

In the above example, the `\#` symbol implies the first line is continued onto the second line.

1.3.1 Key Words

The key word or key words for a command are shown in uppercase letters. For actual input, you can use all uppercase letters for the key words, all lowercase letters for the key words, or some combination of uppercase and lowercase letters for the key words.

1.3.2 User-Specified Input

The input that you supply is typically shown in lowercase letters. (Occasionally, uppercase letters may be used for user input for purposes of clarity or in examples.) The user-supplied input may be a real number, an integer, a string, or a string list. For the command descriptions, a type appears before the user input. The type (real, integer, string, string list) description is enclosed by angle brackets, `<>`, and precedes the user-supplied input. For example:

```
<real>value
```

indicates that the quantity `value` is a real number. For the description of an input command, you would see the following:

```
FUNCTION = <string>function_name
```

Your input would be

```
FUNCTION = my_name
```

if you have specified a function name called `my_name`.

Valid user input consists of the following:

`<integer>`	Integer data is a single integer number.
`<real>`	Real data is a single real number. It may be formatted with the usual conventions, such as `1234.56` or `1.23456e+03`.
`<string>`	String data is a single string.
`<string list>`	A string list consists of multiple strings separated by white space, a comma, a tab, or white space combined with a comma or a tab.

1.3.3 Optional Input

Anything in an input line that is enclosed by square brackets, [ ], represents optional input within the line. Note, however, that this convention is not used to identify optional input lines. Any command line that is optional (in its entirety) will be described as such within the text.

1.3.4 Default Values

A value enclosed by parentheses, (), appearing after the user input denotes the default value. For example:

```
SCALE FACTOR = <real>scale_factor(1.0)
```

implies the default value for `scale_factor` is 1.0. Any value you specify will overwrite the default.

For your actual input file, you may simply omit a command line if you want to use the default value associated with the command line. For example, there is a `TIME STEP SCALE FACTOR` command line used to set one of the time control parameters; the parameter for this command line has a default value of 1.0. If you want to use the default value of 1.0 for this parameter, you do not have to include the `TIME STEP SCALE FACTOR` command line in the `TIME CONTROL` command block.

1.3.5 Multiple Options for Values

Quantities separated by the `|` symbol indicate that one and only one of the possible choices must be selected. For example:

```
EXPANSION RADIUS = <string>SPHERICAL|CYLINDRICAL
```

implies that expansion radius must be defined as `SPHERICAL` or `CYLINDRICAL`. One of the values must appear. This convention also applies to some of the command options within a begin/end block. For example:

```
SURFACE = <string>surface_name|
     NODE SET = <string>nodelist_name
```

in a command block specifies that either a surface or a node set must be specified.

Quantities separated by the `/` symbol can appear in any combination, but any one quantity in the sequence can appear only once. For example,

```
COMPONENTS = <string>X/Y/Z
```

implies that components can equal any combination of X, Y, and Z. Any value (X or Y or Z) can appear at most once, and at least one value of X, Y, or Z must appear. Some examples of valid expressions in this case are as follows:

```
COMPONENTS = Z

COMPONENTS = Z X

COMPONENTS = Y X Z

COMPONENTS = Z Y X
```

An example of an invalid expression would be the following:

```
COMPONENTS = Y Y Z
```

1.3.6 Set of Command Lines

In some of the command blocks, it may be possible to select from a set of command lines to activate some functionality within the command block. In the boundary conditions, a boundary condition may be applied to a group of nodes. This group of nodes can be defined by some collection of command lines that are Boolean operations to add or delete nodes to the group. The command lines that are the Boolean operations to define the group of nodes are described in detail in the introduction to the chapter on boundary conditions, e.g., in Section 6.1.1. In the description of the command blocks for the boundary conditions, we denote this set of command lines by enclosing a name for the set of command lines in curly braces, `{}`. Therefore, the description of a command block for a kinematic boundary condition may have a line of the form:

```
{node set commands}
```

to indicate that the user can insert some arbitrary combination of command lines from the set of command lines defined as `node set commands`.

We will use `{}` to enclose some named set of command lines or some description of a set of command lines.

1.3.7 Known Issues and Warnings

Where there are known issues with the code, these are documented in the following manner:

Known Issue: A description of the known issue with the code would be provided here.

Similarly, warnings regarding usage of code features that are not defective, but must be used with care because of their nature, are documented as follows:

Warning: A description of the warning related to the usage of a code feature would be provided here.

1.4 Style Guidelines

This section gives information that will affect the overall organization and appearance of your input file. It also contains recommendations that will help you construct input files that are readable and easy to proof.

1.4.1 Comments

A comment is anything between the `#` symbol or the `$` symbol and the end-of-line. If the first nonblank character in a line is a `#` or `$`, the entire line is a comment line. You can also place a `#` or `$` (preceded by a blank space) after the last character in an input line used to define a command block or command line.

1.4.2 Continuation Lines

An input line can be continued by placing a `\#` pair of characters (or `\$`) at the end of the line. The following line is then taken to be a continuation of the preceding line that was terminated by the `\#` or `\$`. Note that everything after the line-continuation pair of characters is discarded, including the end-of-line.

1.4.3 Case

Almost all the character strings in the input lines are case insensitive. For example, the `BEGIN SIERRA` key words could appear as one of the following:

```
BEGIN SIERRA
begin sierra
Begin Sierra
```

You could specify a `SIERRA` command block with:

```
BEGIN SIERRA BEAM
```

and terminate the command block with this input line:

```
END SIERRA beam
```

Case is important only for file name specifications. If you have defined a restart file with uppercase and lowercase letters and want to use this file for a restart, the file name you use to request this restart file must exactly match the original definition you chose.

1.4.4 Commas and Tabs

Commas and tabs in input lines are ignored.

1.4.5 Blank Spaces

We highly recommend that everything be separated by blank spaces. For example, a command line of the form

```
node set = nodelist_10
```

is recommended over the following forms:

```
node set= nodelist_10
node set =nodelist_10
```

Both of the above two lines are correct, but it is easier to check the first form (the equal sign surrounded by blank space) in a large input file.

The parser will accept the following line:

```
BEGIN SIERRABEAM
```

However, it is harder to check this line for the correct spelling of the key words and the intended domain name than this line:

```
BEGIN SIERRA BEAM
```

It is possible to introduce hard-to-detect errors because of the way in which the blank spaces are handled by the command parser. Suppose you type

```
begin definition for functions my_func
```

rather than the following correct form:

```
begin definition for function my_func
```

For the incorrect form of this command line (in which `functions` is used rather than `function`), the parser will generate a string name of

```
s my_func
```

for the function name rather than the following expected name:

```
my_func
```

If you attempt to use a function named `my_func`, the parser will generate an error because the list of function names will include `s my_func` but not `my_func`.

1.4.6 General Format of the Command Lines

In general, command lines have the following form:

```
keyword = value
```

This pattern is not always followed, but it describes the vast majority of the command lines.

1.4.7 Delimiters

The delimiter used throughout this document is "=" (the equal sign). Typically, but not always, the = separates key words from input values in a command line. Consider the following command line:

```
COMPONENTS = X
```

Here, the key word `COMPONENTS` is separated from its value, a string in this case, by the =. Some command lines do allow for other delimiters. The use of these alternate delimiters is not consistent, however, throughout the various command lines. (This lack of consistency has the potential for introducing errors in this document as well as in your input.) The = provides a strong visual cue for separating key words from values. By using the = as a delimiter, it is much easier to proof your input file. It also makes it easier to do "cut and paste" operations. If you accidentally delete =, it is much easier to detect than accidentally removing part of one of the other delimiters that could be used.

1.4.8 Order of Commands

There are no requirements for ordering the commands. Both the input sequence:

```
BEGIN PRESCRIBED DISPLACEMENT
  NODE SET = nodelist_10
  COMPONENT = X
  FUNCTION = cosine_curve
END PRESCRIBED DISPLACEMENT
```

and the input sequence:

```
BEGIN PRESCRIBED DISPLACEMENT
  FUNCTION = cosine_curve
  COMPONENT = X
  NODE SET = nodelist_10
END PRESCRIBED DISPLACEMENT
```

are valid, and they produce the same result. Remember, that command lines and command blocks must appear in the proper scope.

1.4.9 Abbreviated END Specifications

It is possible to terminate a command block without including the key word or key words that identify the block. You could define a specific instance of the prescribed displacement boundary condition with:

```
BEGIN PRESCRIBED DISPLACEMENT
```

and terminate it simply with:

```
END
```

as opposed to the following specification:

```
END PRESCRIBED DISPLACEMENT
```

Both the short termination (`END` only) and the long termination (`END` followed by identification, or name, of the command block) are valid. It is recommended that the long termination be used for any command block that becomes large. The `RESULTS OUTPUT` command block described in later chapters can become fairly lengthy, so this is probably a good place to use the long termination. For most boundary conditions, the command block will typically consist of five lines. In such cases, the short termination can be used. Using the long termination for the larger command blocks will make it easier to proof your input files. If you use the long termination, the text following the `END` key word must exactly match the text following the `BEGIN` key word. You could not have `BEGIN PRESCRIBED DISPLACEMENT` paired with an `END PRESCRIBED DISPL` to define the beginning and ending of a command block.

1.4.10 Indentation

When constructing an input file, it is useful, but not required, to indent a scope that is nested inside another scope. Command lines within a command block should also be indented in relation to the lines defining the command block. This will make it easier to construct the input file with everything in the correct scope and with all the command blocks in the correct structure.

1.5 Naming Conventions Associated with the Exodus II Database

When the mesh file has an Exodus II format, there are three basic conventions that apply to user input for various command lines. First, for a mesh file with the Exodus II format, the Exodus II side set is referenced as a surface. In SIERRA, a surface consists of element faces plus all the nodes and edges associated with these faces. A surface definition can be used not only to select a group of faces but also to select a group of edges or a group of nodes that are associated with those faces. In the case of boundary conditions, a surface definition can be used not only to apply boundary conditions that typically use surface specifications (pressure) but also to apply boundary conditions for what are referred to as nodal boundary conditions (fixed displacement components). For nodal boundary conditions that use the surface specification, all the nodes associated with the faces on a specific surface will have this boundary condition applied to them. The specification for a surface identifier in the following chapters is `surface_name`. It typically has the form `surface_integerid`, where `integerid` is the integer identifier for the surface. If the side set identifier is 125, the value of `surface_name` would be `surface_125`. It is also possible to generate an alias for the side set[1] and use this for `surface_name`. If `surface_125` is aliased to `outer_skin`, then `surface_name` becomes `outer_skin` in the actual input line. It is also possible to name a surface in some mesh generation programs and that name can be used in the input file.

Second, for a mesh file with the Exodus II format, the Exodus II node set is still referenced as a node set. A node set can be used only for cases where a group of nodes needs to be defined. The specification for a node set identifier in the following chapters is `nodelist_name`. It typically has the form `nodelist_integerid`, where `integerid` is the integer identifier for the node set. If the node set number is 225, the value of `nodelist_name` would be `nodelist_225`. It is also possible to generate an alias for the node set and use this for `nodelist_name`. If `nodelist_225` is aliased to `inner_skin`, then `nodelist_name` becomes `inner_skin` in the actual input line. It is also possible to name a nodelist in some mesh generation programs and that name can be used in the input file.

Third, an element block is referenced as a block. The specification for an element block identifier in the following chapters is `block_name`. It typically has the form `block_integerid`, where `integerid` is the integer identifier for the block. If the element block number is 300, the value of `block_name` would be `block_300`. It is also possible to generate an alias for the block and use this for `block_name`. If `block_300` is aliased to `big_chunk`, then `block_name` becomes `big_chunk` in the actual input line. It is also possible to name an element block in some mesh generation programs and that name can be used in the input file.

A group of elements can also be used to select other mesh entities. In SIERRA, a block consists of elements plus all the faces, edges, and nodes associated with the elements. The block and surface concepts are similar in that both have associated derived quantities. Chapters 6 and 7 show how this concept of derived quantities is used in the input command structure.

[1] See the `ALIAS` command in Section 5.1.1.1

1.6 Major Scope Definitions for an Input File

The typical input file will have the structure shown below. The major scopes—domain, procedure, and region—are delineated with input lines for command blocks. Comment lines are included that indicate some of the key scopes that will appear within the major scopes. Note the indentation used for this example.

```
BEGIN SIERRA <string>some_name
  #
  # All command blocks and command lines in the domain
  # scope appear here. The PROCEDURE ADAGIO command
  # block is the beginning of the next scope.
  #
  # function definitions
  # material descriptions
  # description of mesh file
  #
  BEGIN PROCEDURE ADAGIO <string>procedure_name
    #
    # time step control
    #
    BEGIN REGION ADAGIO <string>region_name
      #
      # All command blocks and command lines in the
      # region scope appear here
      #
      # solver commands
      # specification for output of result
      # specification for restart
      # boundary conditions
      # definition of contact
      #
    END [REGION ADAGIO <string>region_name]
  END [PROCEDURE ADAGIO <string>procedure_name]
END [SIERRA <string>some_name]
```

1.7 Input/Output Files

The primary user input to Adagio is the input file introduced in this chapter. Throughout this document, we explain how to construct a valid input file. It is important to be aware that Adagio also processes a number of other types of input files and produces a variety of output files. These additional files are also discussed in this document where applicable. Figure 1.1 presents a simple schematic diagram of the various input and output files in Adagio. Both Adagio and Presto use the same file structure. Therefore, in Figure 1.1, we indicate that the code (graphically represented by the central cylinder) can be either Presto or Adagio.



Figure 1.1: Input/output files

As shown in Figure 1.1, Adagio uses the input file, mesh files, restart files, and user subroutine files. The input file, which is required, is a set of valid Adagio command lines. Another required input is a mesh file, which provides a description of the finite element mesh for the object being analyzed. Restart and user subroutine files are optional inputs. The restart functionality lets you break an analysis from the start time to the termination time into a sequence of runs. The files generated by the restart functionality contain a complete state description for a problem at various analysis times, which we will refer to as restart times. You can restart Adagio at any of these restart times because the complete state description is known (see Chapter 8). The user subroutine files let you build and incorporate specialized functionality into Adagio (Chapter 9).

As also shown in Figure 1.1, Adagio can generate a number of files. These include results files, history files, restart files, a log file, and an output file. Typically, only the log file and the output file are produced automatically. Generation of the other types of files is based on user settings in the input file for the particular kinds of output desired. Results files provide the values of global variables, element variables, and node variables at specified times (see Chapter 8). History files will also provide values of global variables, element variables, and node variables at specified times (see Chapter 8). History files are set up to provide a specific value at a specific node, for example, whereas results files provide a nodal value for large subsets of nodes or, more typically, all nodes. History files provide a much more limited set of information than results files. As noted above, restart files can be generated at various analysis times. The log file contains a variety of information

such as the Adagio version number, a listing of the input file, initialization information, some model information (mass, critical time steps for element blocks, etc.), and information at various time steps. At every nth step, where n is user selected, the log file gives the current analysis time; the current time step; the kinetic, internal, and external energies; the error in the energy; and computing time information. You can monitor step information in the log file to gain information about how your analysis is progressing. The output file contains error information.

1.8 Obtaining Support

Support for all SIERRA Mechanics codes, including Adagio, can be obtained by contacting the SIERRA Mechanics user support hotline by email at sierra-help@sandia.gov, or by telephone at (505)845-1234.

1.9 References

1. Edwards, H. C., and J. R. Stewart. "SIERRA: A Software Environment for Developing Complex Multi-Physics Applications." In *First MIT Conference on Computational Fluid and Solid Mechanics*, edited by K. J. Bathe, 1147–1150. Amsterdam: Elsevier, 2001.

2. Mitchell, J. A., A. S. Gullerud, W. M. Scherzinger, J. R. Koteras, and V. L. Porter. "ADAGIO: Non-Linear Quasi-Static Structural Response Using the SIERRA Framework." In *First MIT Conference on Computational Fluid and Solid Mechanics*, edited by K. J. Bathe, 361–364. Amsterdam: Elsevier, 2001.

3. Koteras, J. R., A. S. Gullerud, V. L. Porter, W. M. Scherzinger, and K. H. Brown. "PRESTO: Impact Dynamics with Scalable Contact Using the SIERRA Framework." In *First MIT Conference on Computational Fluid and Solid Mechanics*, edited by K. J. Bathe, 294–296. Amsterdam: Elsevier, 2001.

4. Biffle, J. H. *JAC – A Two-Dimensional Finite Element Computer Program for the Non-Linear Quasi-Static Response of Solids with the Conjugate Gradient Method*, SAND81-0998. Albuquerque, NM: Sandia National Laboratories, April 1984.

5. Blanford, M. L., M. W. Heinstein, and S. W. Key. *JAS3D – A Multi-Strategy Iterative Code for Solid Mechanics Analysis Users' Instructions, Release 2.0*, Draft SAND report. Albuquerque, NM: Sandia National Laboratories, September 2001.

6. Taylor, L. M. and D. P. Flanagan. *Pronto3D: A Three-Dimensional Transient Solid Dynamics Program*, SAND87-1912. Albuquerque, NM: Sandia National Laboratories, March 1989.

7. Attaway, S. W., K. H. Brown, F. J. Mello, M. W. Heinstein, J. W. Swegle, J. A. Ratner, and R. I. Zadoks. *PRONTO3D User's Instructions: A Transient Dynamic Code for Nonlinear Structural Analysis*, SAND98-1361. Albuquerque, NM: Sandia National Laboratories, June 1998.

8. Laursen, T. A., S. W. Attaway, and R. I. Zadoks. *SEACAS Theory Manuals: Part I. Problem Formulation in Nonlinear Solid Mechanics*, SAND98-1760/1. Albuquerque, NM: Sandia National Laboratories, August 1998.

9. Laursen, T. A., S. W. Attaway, and R. I. Zadoks. *SEACAS Theory Manuals: Part II. Nonlinear Continuum Mechanics*, SAND98-1760/2. Albuquerque, NM: Sandia National Laboratories, September 1998.

10. Laursen, T. A., S. W. Attaway, and R. I. Zadoks. *SEACAS Theory Manuals: Part III. Finite Element Analysis in Nonlinear Solid Mechanics*, SAND98-1760/3. Albuquerque, NM: Sandia National Laboratories, March 1999.

11. Schoof, L. A., and V. R. Yarberry. *EXODUS II: A Finite Element Data Model*, SAND92-2137. Albuquerque, NM: Sandia National Laboratories, September 1994. See also new draft documentation available at http://sourceforge.net/projects/exodusii.

12. The eXtensible Data Model and Format (XDMF). . . . http://www.xdmf.org (Accessed March 17, 2008).

13. Brown, K. H., R. M. Summers, M. W. Glass, A. S. Gullerud, M. W. Heinstein, and R. E. Jones. *ACME: Algorithms for Contact in a Multiphysics Environment*, API Version, 1.0. Albuquerque, NM: Sandia National Laboratories, October 2001.

Chapter 2

General Commands

The commands described in this section appear in the domain or procedure scope or control some general functionality in Adagio.

2.1 Domain Scope

These commands are used to set up some of the fundamentals of the Adagio input. The commands are physics independent, or at least can be shared between physics. The commands lie in the domain scope, not in the procedure or region scope.

2.1.1 SIERRA Command Block

```
BEGIN SIERRA <string>name
  #
  # All other command blocks and command lines
  # appear within the domain scope defined by
  # begin/end sierra.
  #
END [SIERRA <string>name]
```

All input commands must occur within a `SIERRA` command block. The syntax for beginning the command block is:

```
BEGIN SIERRA <string>name
```

and for terminating the command block is as follows:

```
END [SIERRA <string>name]
```

In these input lines, `name` is a name for the `SIERRA` command block. All other commands for the analysis must be within this command block structure. The name for the `SIERRA` command block is often a descriptive name that identifies the analysis. The name is not currently used anywhere else in the file and is completely arbitrary.

2.1.2 Title

```
TITLE <string list>title
```

To permit a fuller description of the analysis, the input has a `TITLE` command line for the analysis, where `title` is a text description of the analysis. The title is transferred to the results file.

2.1.3 Restart Control

The restart capability in Adagio allows a user to run an analysis up to a certain time, stop the analysis at this time, and then restart the analysis from this time. Restart can be used to break a long-running analysis into several smaller runs so that the user can examine intermediate results before proceeding with the next step. Restart can also be used in case of abnormal termination. If a restart file has been written at various intervals throughout the analysis up to the point where the abnormal termination has occurred, you can pick a restart time before the abnormal termination and restart the problem from there. Thus, users do not have to go back to the beginning of the analysis, but can continue the analysis at some time well into the analysis. With the restart capability, you will generate a sequence of restart runs. Each run can have its own set of restart, results, and history files.

When using the restart capability, you can reset a number of the parameters in the input file. However, not all parameters can be reset. Users should exercise care in resetting parameters in the input file for a restart. You will want to change parameters if you have encountered an abnormal termination. You may want to change certain parameters, hourglass control for example, to see whether you can prevent the abnormal termination and continue the analysis past the abnormal termination time you had previously encountered.

The use of the restart capability involves commands in **both the domain scope and the region scope**. One of two restart command lines, `RESTART` or `RESTART TIME`, appears in the domain scope. A command block in the region scope, the `RESTART DATA` command block, specifies restart file names and the frequency at which the restart files will be written. The `RESTART DATA` command block is described in Section 8.4. This section gives a brief discussion of the command lines that appear in the domain scope. For a full discussion of all the command lines used for restart, consult with Chapter 8. The use of some of the command lines in the `RESTART DATA` command block depends on the command line, either `RESTART` or `RESTART TIME`, you select in the domain scope.

If you specify a time from a specific restart file for the restart, you will use the `RESTART TIME` command line described in Section 2.1.3.1. If you select the automatic restart option, you will use the `RESTART` command line described in Section 2.1.3.2. The command lines for both of these methods are in the **domain scope**. All other commands for restart are in the **region scope** in the `RESTART DATA` command block.

For restarts specified with a restart time from a specific restart file, you will have to be concerned about overwriting information in existing files. The issue of overwriting information is discussed in Chapter 8. In general, you will want to have a restart file (or files in the case of parallel runs)

for each run in a sequence of runs you create with the restart option. You will want to preserve all restart files you have written prior to any given run in a sequence of restart runs. The easiest way to preserve prior restart information is with the use of the `RESTART` command line. How you preserve previous restart information is discussed in detail in Chapter 8.

The amount of data written at a restart time is quite large. The restart data written at a given time is a complete description of the state for the problem at that time. The restart data includes not only information such as displacement, velocity, and acceleration, but also information such as element stresses and all the state variables for the material model associated with each element.

2.1.3.1 Restart Time

```
RESTART TIME = <real>restart_time
```

The `RESTART TIME` command line is used to specify a time from a specific restart file for the restart run. This restart option will pick the restart time on the restart file that is closest to the user-specified time on the `RESTART TIME` command line. If the user specifies a restart time greater than the last time written to a restart file, then the last time written to the restart file is picked as the restart time. Use of this command line can result in previous restart information being overwritten. To prevent the overwriting of existing restart files, you can specify both an input restart file and an output restart file (and rename the results and history files) for the various restarts. The use of the `RESTART TIME` command line requires the user to be more active in the management of the file names to prevent the overwriting of restart, results, and history files. The automatic restart feature (e.g., the `RESTART` command line in Section 2.1.3.2) prevents the overwriting of restart, results, and history files. Consult with Section 8.4 for a full discussion of implementing the restart capability.

2.1.3.2 Automatic Restart

```
RESTART = AUTOMATIC
```

The `RESTART` command line automatically selects for restart the last restart time written to the last restart file. The automatic restart feature lets the user restart runs with minimal changes to the input file. The only quantity that must be changed to move from one restart to another is the termination time. The `RESTART` command line manages the restart files so as not to write over any previous restart files. It also manages the results and history files so as not to write over any previous results or history files. Consult with Section 8.4 for a full discussion of implementing the restart capability.

2.1.4 User Subroutine Identification

```
USER SUBROUTINE FILE = <string>file_name
```

This command line is a part of a set of commands that are used to implement the user subroutine functionality. The string `file_name` identifies the name of the file that contains the FORTRAN code of one or more user subroutines.

To understand how this command line is used, see Chapter 9.

2.1.5 Functions

```
BEGIN DEFINITION FOR FUNCTION <string>function_name
  TYPE = <string>CONSTANT|PIECEWISE LINEAR|
    PIECEWISE CONSTANT|ANALYTIC
  ABSCISSA = <string>abscissa_label
  ORDINATE = <string>ordinate_label
  BEGIN VALUES
    <real>value_1   [<real>value_2
    <real>value_3    <real>value_4
    ...              <real>value_n]
  END [VALUES]
  AT DISCONTINUITY EVALUATE TO <string>LEFT|RIGHT
  EVALUATE EXPRESSION = <string>Ťanalytic_expression1;Ť
    analytic_expression2;...Ť
END [DEFINITION FOR FUNCTION <string>function_name]
```

A number of Adagio features are driven by a user-defined description of the dependence of one variable on another. For instance, the prescribed displacement boundary condition requires the definition of a time-versus-displacement relation, and the thermal strain computations require the definition of a thermal-strain-versus-temperature relation. SIERRA provides a general method of defining these relations as functions using the `DEFINITION FOR FUNCTION` command block, as shown above.

There is no limit to the number of functions that can be defined. All function definitions must appear within the domain scope.

A description of the various parts of the `DEFINITION FOR FUNCTION` command block follows:

- The string `function_name` is a user-selected name for the function that is unique to the function definitions within the input file. This name is used to refer to this function in other locations in the input file.
- The `TYPE` command line has four options to define the type of function. The value of this string can be `CONSTANT`, `PIECEWISE LINEAR`, `PIECEWISE CONSTANT`, or `ANALYTIC`.
- The `ABSCISSA` command line provides a descriptive label for the independent variable (x-axis) with the string `abscissa_label`. This command line is optional.
- The `ORDINATE command` line provides a descriptive label for the dependent variable (y-axis) with the string `ordinate_label`. This command line is optional.

- The `VALUES` command block consists of the real values `value_1` through `value_n`, which describe the function. This command block must be used if the value on the `TYPE` command line is `CONSTANT`, `PIECEWISE LINEAR`, or `PIECEWISE CONSTANT`. For a `CONSTANT` function, only one value is needed. For a `PIECEWISE LINEAR` or `PIECEWISE CONSTANT` function, the values are (x, y) pairs of data that describe the function. The values are nested inside the `VALUES` command block.



(a) piecewise linear function (b) piecewise constant function

Figure 2.1: Piecewise linear and piecewise constant functions

A `PIECEWISE LINEAR` function performs linear interpolations between the provided value pairs; a `PIECEWISE CONSTANT` function is constant valued between provided value pairs. Figure 2.1 (a) shows an example of a piecewise linear function, and Figure 2.1 (b) shows an example of a piecewise constant function.

In the case of a `PIECEWISE LINEAR` or `PIECEWISE CONSTANT` function, for any abscissa value passed to the function that is greater than the last abscissa value in the `VALUES` command block, the last ordinate value is used for the function value. For example, suppose a piecewise linear function named `my_func` describes a time history for a pressure load where the pressure increases from 0 to 50,000 psi from time 0.0 sec to time 1.0×10^{-3} sec. The last time specified in the function is 1.0×10^{-3}. Now, suppose our final analysis time is 2.0×10^{-3} sec. Then, from the time 1.0×10^{-3} to the time 2.0×10^{-3}, the value for this function (`my_func`) will be 50,000 psi.

- For a piecewise constant function, a constant value segment ends on the left hand side of an abscissa value and a new constant value segment begins on the right hand side of the same abscissa value. (This transition from one constant value to another is indicated by the dotted line in Figure 2.1 (b).) When an abscissa falls at a point where there are two ordinate values, the function returns, by default, the ordinate of the value pair that has the lower-valued abscissa. The `AT DISCONTINUITY EVALUATE TO` overrides this default behavior at an abscissa with two ordinate values. The command line can have a value of either `LEFT` or `RIGHT`. If `LEFT` is specified, the ordinate value to the left of the abscissa is used; if `RIGHT` is specified, the ordinate value to the right of the abscissa is used.

- The `EVALUATE EXPRESSION` command line consists of one or more user-supplied algebraic

expressions. This command line must be used if the value on the `TYPE` command line is `ANALYTIC`. See the rules and options for composing algebraic expressions discussed below.

Importantly, a `DEFINITION FOR FUNCTION` command block cannot contain both a `VALUES` command block and an `EVALUATE EXPRESSION` command line.

Rules and options for composing algebraic expressions. If you choose to use the `EVALUATE EXPRESSION` command line, you will need to write the algebraic expressions. The algebraic expressions are written using a C-like format. Each algebraic expression is terminated by a semi-colon(;). The entire set of algebraic expressions, whether a single expression or several, is enclosed in a single set of double quotes(" ").

An expression is evaluated with `x` as the independent variable. We first provide several simple examples and then list the options available in the algebraic expressions.

Example: Return `sin(x)` as the value of the function.

```
begin definition for function fred
  type is analytic
  evaluate expression is ``sin(x);''
end definition for function fred
```

In this example, the commented out table is equivalent to the evaluated expression:

```
begin definition for function pressure
  type is analytic
  evaluate expression is ``x <= 0.0 ? 0.0 : (x < 0.5 ? x*200.0
    : 100.0);''
    #     begin values
    #       0.0      0.0
    #       0.5    100.0
    #       1.0    100.0
    #     end values
end definition for function pressure
```

The following functionality is currently implemented for the expressions:

Operators

```
+ - * / == != > < >= <= ! & | && || ? :
```

Parentheses

```
()
```

Math functions

```
abs(x), absolute value of x
mod(x, y), modulus of x|y
ipart(x), integer part of x
fpart(x), fractional part of x
```

Power functions

```
pow(x, y), x to the y power
pow10(x), x to the 10 power
sqrt(x), square root of x
```

Trigonometric functions

```
acos(x), arccosine of x
asin(x), arcsine of x
atan(x), arctangent of x
atan2(y, x), arctangent of y/x, signs of x and y
  determine quadrant (see atan2 man page)
cos(x), cosine of x
cosh(x), hyperbolic cosine of x
sin(x), sine of x
sinh(x), hyperbolic sine of x
tan(x), tangent of x
tanh(x), hyperbolic tangent of x
```

Logarithm functions

```
log(x), natural logarithm of x
ln(x), natural logarithm of x
log10(x), the base 10 logarithm of x
exp(x), e to the x power
```

Rounding functions

```
ceil(x), smallest integral value not less than x
floor(x), largest integral value not greater than x
```

Random functions

```
rand(), random number between 0.0 and 1.0, not including 1.0
randomize(), random number between 0.0 and 1.0, not
  including 1.0
srand(x), seeds the random number generator
```

Conversion functions

```
deg(x), converts radians to degrees
rad(x), converts degrees to radians
recttopolr(x, y), magnitude of vector x, y
recttopola(x, y), angle of vector x, y
poltorectx(r, theta), x coordinate of angle theta at
  distance r
poltorecty(r, theta), y coordinate of angle theta at
  distance r
```

Constants. There are two predefined constants that may be used in an expression. These two constants are `e` and `pi`.

e = e = 2.7182818284...
pi = π = 3.1415926535...

2.1.6 Axes, Directions, and Points

```
DEFINE POINT <string>point_name WITH COORDINATES
  <real>value_1 <real>value_2 <real>value_3
DEFINE DIRECTION <string>direction_name WITH VECTOR
  <real>value_1 <real>value_2 <real>value_3
DEFINE AXIS <string>axis_name WITH POINT
  <string>point_1 POINT <string>point_2
DEFINE AXIS <string>axis_name WITH POINT
  <string>point DIRECTION <string>direction
```

A number of Adagio features require the definition of geometric entities. For instance, the prescribed displacement boundary condition requires a direction definition, and the cylindrical velocity initial condition requires an axis definition. Currently, Adagio input permits the definition of points, directions, and axes. Definition of these geometric entities occurs in the domain scope.

The `DEFINE POINT` command line is used to define a point:

```
DEFINE POINT <string>point_name WITH COORDINATES
  <real>value_1 <real>value_2 <real>value_3
```

where

- The string `point_name` is a name for this point. This name must be unique to all other points defined in the input file.
- The real values `value_1`, `value_2`, and `value_3` are the x, y, and z coordinates of the point.

The `DEFINE DIRECTION` command line is used to define a direction:

```
DEFINE DIRECTION <string>direction_name WITH VECTOR
  <real>value_1 <real>value_2 <real>value_3
```

where

- The string `direction_name` is a name for this direction. This name must be unique to all other directions defined in the input file.
- The real values `value_1`, `value_2`, and `value_3` are the x, y, and z magnitudes of the direction vector.

There are two command lines that can be used to define an axis. The first `DEFINE AXIS` command line uses two points:

```
DEFINE AXIS <string>axis_name WITH POINT
  <string>point_1 POINT <string>point_2
```

where

- The string `axis_name` is a name for this axis. This name must be unique to all other axes defined in the input file.
- The strings `point_1` and `point_2` are the names for two points defined in the input file via a `DEFINE POINT` command line.

The second `DEFINE AXIS` command line uses a point and a direction:

```
DEFINE AXIS <string>axis_name WITH POINT
  <string>point DIRECTION <string>direction
```

where

- The string `axis_name` is a name for this axis. This name must be unique to all other axes defined in the input file.
- The string `point` is the name of a point defined in the input file via a `DEFINE POINT` command line.
- The string `direction` is the name of a direction defined in the input file via a `DEFINE DIRECTION` command line.

2.1.7 Orientation

```
BEGIN ORIENTATION <string>orientation_name
  SYSTEM = <string>RECTANGULAR|Z RECTANGULAR|CYLINDRICAL|
    SPHERICAL(RECTANGULAR)
  #
  POINT A = <real>global_ax <real>global_ay <real>global_az
  POINT B = <real>global_bx <real>global_by <real>global_bz
  #
  ROTATION ABOUT <integer> 1|2|3(1) = <real>theta(0.0)
END [ORIENTATION <string>orientation_name]
```

The `ORIENTATION` command block is currently used in Adagio to define a local coordinate system for output of shell stresses. In the future, the `ORIENTATION` command block will be used with other functionality in Adagio.

A local coordinate system is defined at the particular location at which it is required. For example, suppose we want to define a local coordinate system for a shell element. This local coordinate system will be used for output of stresses in the element. For shell elements, the centroid of the element is where we want to define the local coordinates for output of stresses. When we use orientation with a shell element, the centroid of the shell element becomes the particular location at which we want to define a local coordinate system. (When we associate an orientation with a block of shell elements, the orientation will generate a local coordinate system for each element in the block.)



Figure 2.2: Adjacent shell elements with nonaligned local coordinate systems

To understand why we would want to specify the local coordinate system for shell elements, consider the example of two adjacent shell elements, as shown in Figure 2.2. A common notation system for a local coordinate system for a shell element defines the 1-axis as an axis lying in the shell; the 1-axis passes through the centroid of the shell. The 3-axis is normal to the shell at the centroid of the shell. The 2-axis is the cross-product of the 3-axis and 1-axis—3×1. The orientation of the 1-2-3 coordinate system for a shell element is determined by the connectivity for a shell element and the geometric location of the nodes. In Figure 2.2, the default local coordinate

systems for the two elements do not align (the 1-axis in one element parallel to the 1-axis in the other element, the 2-axis in one element parallel to the 2-axis in the other element).

In general, for a shell element mesh, there is no guarantee that the default local system for one element will be reasonably aligned with its neighboring elements. The local coordinates for adjacent shell elements need to show a reasonable alignment to make it easier to interpret stress results, especially for graphical representations. Take the case of a cylindrical object modeled with shell elements. We might want the local 2-axis of each element to align with the cylindrical axis of the cylinder. We would want the local 1-axis of each element to be tangent to the cylinder and normal to the cylindrical axis. The `ORIENTATION` option gives us the ability to control the orientation for the local coordinate system for each element and align each one of these local coordinate systems so that it is easier to interpret stress information for shells.

The `SYSTEM` command line gives you several options for constructing a local coordinate system. The options on this command line are `RECTANGULAR`, `Z RECTANGULAR`, `CYLINDRICAL`, and `SPHERICAL`. The `SYSTEM` command line is optional. If you do not include a `SYSTEM` command line in the `ORIENTATION` command block, the default system is the `RECTANGULAR` system.

The `ORIENTATION` command actually generates two local coordinate systems. The first local system constructed at a particular location will always be a Cartesian system designated as $X'Y'Z'$. How this system is constructed depends on the choice for the `SYSTEM` option. Regardless of what system option you choose, the command lines `POINT A` and `POINT B` are required. The details of constructing a local coordinate system for each of the different `SYSTEM` options is described below.



Figure 2.3: Rectangular coordinate system

- `RECTANGULAR` option: The command line `POINT A` defines a point a that lies on the X'-axis. The command line `POINT B` defines a point b that lies in the $X'Y'$-plane (Figure 2.3). Let the coordinates of a define a vector $\vec{A}$ and the coordinates of b define a vector $\vec{B}$. The normalized value of $\vec{A}$, $\vec{A}/\parallel\vec{A}\parallel$, defines a unit vector along the X'-axis, which we denote as $\vec{X}'$. The normalized cross-product of $\vec{A}\times\vec{B}$ is a unit vector defining the Z'-axis, which we denote as $\vec{Z}'$. We can obtain a unit vector along the Y'-axis, $\vec{Y}'$, from a cross-product of $\vec{Z}'$ and $\vec{X}'$. The three unit vectors $\vec{X}'$, $\vec{Y}'$, and $\vec{Z}'$ give us our local coordinate system $X'Y'Z'$.



Figure 2.4: Z-Rectangular coordinate system.

- `Z RECTANGULAR` option: The command line `POINT A` defines a point a that lies on the Z'-axis. The command line `POINT B` defines a point b that lies in the $X'Z'$-plane (Figure 2.4). Let the coordinates of a define a vector $\vec{A}$ and the coordinates of b define a vector $\vec{B}$. The normalized value of $\vec{A}$, $\vec{A}/\parallel\vec{A}\parallel$, defines a unit vector along the Z'-axis, which we denote as $\vec{Z}'$. The normalized cross-product of $\vec{A}\times\vec{B}$ is a unit vector defining the Y'-axis, which we denote as $\vec{Y}'$. We can obtain a unit vector along the X'-axis, $\vec{X}'$, from a cross-product of $\vec{Y}'$ and $\vec{Z}'$. The three unit vectors $\vec{X}'$, $\vec{Y}'$, and $\vec{Z}'$ give us our local coordinate system $X'Y'Z'$.



Figure 2.5: Cylindrical coordinate system.

- `CYLINDRICAL` option: The point a defined by the command line `POINT A` and the point b defined by the command line `POINT B` define a cylindrical axis (Figure 2.5). The local coordinate system always has the Z'-axis parallel to this cylindrical axis and in the direction from a to b. The vector $\vec{Z}'$ is a unit vector defining the Z'-axis. The X'-axis lies along a line that is normal to the cylindrical axis and passes through the origin of our local coordinate system. (e.g., if we are defining a local system for shell stress output, the origin of our local system is the centroid of the element.) The vector $\vec{X}'$ is a unit vector defining the X'-axis. We can obtain the Y'-axis from the cross-product of the $\vec{Z}'$ and $\vec{X}'$ vectors. The three unit

vectors $\vec{X}'$, $\vec{Y}'$, and $\vec{Z}'$ give us our local coordinate system $X'Y'Z'$.



Figure 2.6: Spherical coordinate system.

- `SPHERICAL` option: The point a, from the `POINT A` command line, defines the center of a sphere. The point b, from the `POINT B` command line, defines a polar axis for the sphere. (See Figure 2.6.) The X'-axis lies along a line passing through the origin of the sphere, point a, and the origin of our local coordinate system. (e.g., if we are defining a local system for shell stress output, the origin of our local system is the centroid of the element.) The vector $\vec{X}'$ is a unit vector defining the X'-axis. A cross-product of the polar axis for the sphere and the vector $\vec{X}'$ gives the $\vec{Y}'$ vector. The vector $\vec{Y}'$ is a unit vector defining the Y'-axis. We can obtain the Z'-axis from the cross-product of the $\vec{X}'$ and $\vec{Y}'$ vectors. The three unit vectors $\vec{X}'$, $\vec{Y}'$, and $\vec{Z}'$ give us our local coordinate system $X'Y'Z'$.

The second local coordinate system constructed at a particular location is defined by use of the `ROTATION ABOUT` command line. This second local coordinate system is always a Cartesian system that is designated as $X''Y''Z''$. The `ROTATION ABOUT` command line has the following form:

```
ROTATION ABOUT 1|2|3(1) = <real>theta(0.0)
```

The second local coordinate system, $X''Y''Z''$, is obtained by specifying some rotation, the `theta` parameter, about an axis, which is specified with an integer value of 1, 2, or 3. (The 1, 2, and 3 notation used in this command line should not be confused with the axes of the 1-2-3 local coordinate system. The 1 in this command line implies rotation about X', the 2 implies rotation about Y', and the 3 implies rotation about Z'.) The parameter `theta` has units of degrees. The manner in which the $X''Y''Z''$ is generated is as follows:

- Rotation about the X'-axis (`ROTATION ABOUT 1`): If the `ROTATION ABOUT` command line uses a value of 1, then the $X''Y''Z''$ coordinate system is obtained by a transformation that rotates the $X'Y'Z'$ coordinate system by `theta` degrees about the X'-axis. The local origin for $X''Y''Z''$ is the same as that for $X'Y'Z'$. For shell elements, the Y''-axis is projected onto the shell element to form the local 1-axis for the shell element. The 3-axis is the normal to the shell at the centroid. The 2-axis is the cross-product of the 3-axis and the 1-axis.



Figure 2.7: Rotation about 1

For this case, `ROTATION ABOUT 1`, of the `ROTATION ABOUT` command line, an example is shown in Figure 2.7. After the rotation about the X'-axis, the X' and X'' axes coincide. Both the Y'' and Z'' axes are rotated and both axes remain in the original $Y'Z'$-plane. Similar patterns exist for the cases of `ROTATION ABOUT 2` and `ROTATION ABOUT 3`.

- Rotation about the Y'-axis (`ROTATION ABOUT 2`): If the `ROTATION ABOUT` command line uses a value of 2, then the $X''Y''Z''$ coordinate system is obtained by a transformation that rotates the $X'Y'Z'$ coordinate system by `theta` degrees about the Y'-axis. The local origin for $X''Y''Z''$ is the same as that for $X'Y'Z'$. For shell elements, the Z''-axis is projected onto the shell element to form the local 1-axis for the shell element. The 3-axis is the normal to the shell at the centroid. The 2-axis is the cross-product of the 3-axis and the 1-axis.

- Rotation about the Z'-axis (`ROTATION ABOUT 3`): If the `ROTATION ABOUT` command line uses a value of 3, then the $X''Y''Z''$ coordinate system is obtained by a transformation that rotates the $X'Y'Z'$ coordinate system by `theta` degrees about the Z'-axis. The local origin for $X''Y''Z''$ is the same as that for $X'Y'Z'$. For shell elements, the X''-axis is projected onto the shell element to form the local 1-axis for the shell element. The 3-axis is the normal to the shell at the centroid. The 2-axis is the cross-product of the 3-axis and the 1-axis.

If the `ROTATION ABOUT` command line is not included in the `ORIENTATION` command block, the $X''Y''Z''$ coordinate system is generated with a rotation about the X'-axis of zero degree, e.g., the `ROTATION ABOUT` command line defaults to a value of 1 with the value of the parameter `theta` set to zero `0.0`. The default values imply that the Y''-axis is projected on the shell element to determine the local 1-axis.

2.2 Procedure and Region

The Adagio procedure scope is nested within the domain scope, and the Adagio region scope is nested within the procedure scope. (See Section 1.2 for more information about scope.) To create the scopes for the Adagio procedure and Adagio region, use the following commands:

```
BEGIN ADAGIO PROCEDURE <string>adagio_procedure_name
  #
  # TIME CONTROL command block
  #
  BEGIN ADAGIO REGION <string>adagio_region_name
    #
    # command blocks and command lines that appear in the
    # region scope
    #
  END [ADAGIO REGION <string>adagio_region_name]
END [ADAGIO PROCEDURE <string>adagio_region_name]
```

The `TIME CONTROL` command block also appears within the `ADAGIO PROCEDURE` command block but outside of the `ADAGIO REGION` command block. These three command blocks (procedure, time control, and region) are discussed below.

Many command blocks and command lines fall within the region scope. These command blocks and command lines are described in other sections of this document.

2.2.1 Procedure

The analysis time, from the initial time to the termination time, is controlled within the procedure scope defined by the `ADAGIO PROCEDURE` command block. The command block begins with an input line of the form

```
BEGIN ADAGIO PROCEDURE <string>adagio_procedure_name
```

and is terminated with an input line of the following form:

```
END [ADAGIO PROCEDURE <string>adagio_procedure_name]
```

The string `adagio_procedure_name` is the name for the Adagio procedure.

2.2.2 Time Control

Within the procedure scope, there is a `TIME CONTROL` command block. This command block lets the user set the initial time and the termination time for an analysis. This block also allows the user to control the size of the time step.

In an implicit code such as Adagio, a solver is used to find a converged solution at every time step. The time steps can be arbitrarily large, although errors due to time discretization are larger

with larger time steps. In addition, for nonlinear problems, it is often more difficult to obtain a converged solution with large time steps. The time step size is controlled by the user, although Adagio has a capability to optionally modify the time step based on the effort required by the nonlinear solver.

The `TIME CONTROL` block contains the basic commands used to control the time step size. To use adaptive time stepping, an `ADAPTIVE TIME STEPPING` command block is placed in the Adagio region scope. In addition, for all Adagio analyses, commands to control the solver are required in the Adagio region scope. The details of the commands related to time stepping and the nonlinear solver are documented in Chapter 3.

2.2.3 Region

Individual time steps are controlled within the region scope. The region scope is defined by a `ADAGIO REGION` command block that begins with an input line of the form

```
BEGIN ADAGIO REGION <string>adagio_region_name
```

and is terminated with an input line of the following form:

```
END [ADAGIO REGION <string>adagio_region_name]
```

The string `adagio_region_name` is the name for the Adagio region.

The region, as indicated previously, determines what happens at each time step. In the procedure, we set the begin time and end time for the analysis. Time is incremented in the region. It is in the region where we set information about what occurs at various time steps. The output of results, for example, is set by command blocks in the region. If we want results output at certain times or certain steps in the analysis, this information is set in command blocks in the region. The region also contains command blocks for the boundary conditions. A boundary condition can have a time-varying component. The region determines the value of the component for the current time step.

Two of the major types of command blocks, those for results output and boundary conditions, have already been mentioned. Other major types of command blocks in the region are those for restart control and contact. The region is also where the user selects the analysis model (finite element mesh). For Adagio, the command blocks for the solver are in the region. These blocks are discussed in Chapter 3.

The region makes use of information in the procedure and the domain. For example, the specific element type used for an element block in the analysis model is defined in the domain. This information about the element type is collected into an analysis model. The region then references this analysis model. As another example, the boundary condition command blocks can reference a function. The function will be defined in the domain.

2.3 Use Finite Element Model

```
USE FINITE ELEMENT MODEL <string>model_name
```

The model specification occurs within the region scope. To specify the model (finite element mesh), use this command line. The string `model_name` must match a name used in a `FINITE ELEMENT MODEL` command block described in Section 5.1. If one of these command blocks uses the name `penetrator` in the command-block line and this is the model we wish to use in the region scope, then we would enter the command line as follows:

```
USE FINITE ELEMENT MODEL penetrator
```

2.4 Activation/Deactivation of Functionality

```
ACTIVE PERIODS = <string list>period_names
```

The ACTIVE PERIODS command line can be used to activate or deactivate functionality in the code at various points during an analysis. This functionality can include such things as boundary conditions, element blocks, and user subroutines. In the command line, the string list period_names is a list of the time periods defined in TIME STEPPING BLOCK command blocks (see Section 3.10) during which the particular functionality is considered to be active. Each such period_name must match a name used in a TIME STEPPING BLOCK command block, e.g., time_block_name. Each defined time period runs from that period's

start time to the next period's start time. Note that if the ACTIVE PERIODS command line is present, the functionality will be treated as inactive for any time periods that are not listed. If this command line is absent, then by default, the functionality is active during all time periods. Various other command blocks in Adagio will indicate whether they can be used with the ACTIVE PERIODS command line.

Chapter 3

Solver, Time Stepping, and Implicit Dynamics

Nonlinear solvers are a core part of any implicit finite element code. Adagio's solution strategy is based on iterative solution techniques, and builds on the capabilities pioneered in the JAS3D code [1]. Adagio uses a nonlinear preconditioned conjugate gradient (CG) algorithm [2] to iteratively find a solution that satisfies equilibrium within a user-specified error tolerance at each load step.

The nonlinear CG algorithm iterates to find a solution by computing a series of search direction vectors that are successively added to the trial velocity vector. In each iteration, the residual is multiplied by a preconditioning matrix to obtain a gradient direction. The gradient direction is used to compute the next search direction in a way that ensures that each new search direction is orthogonal to the previous search directions. A line search is used to compute a scaling factor that when applied to the search direction results in a minimized residual.

The performance of the CG algorithm is highly dependent on the conditioning of the problem, which is affected by the choice of preconditioner. Using the inverse of the full tangent stiffness matrix as a preconditioner minimizes the number of CG iterations required, but this can be computationally expensive. An alternative is to use the inverse of a diagonalized stiffness matrix as a preconditioner. This requires much lower computational and memory resources, per iteration, but may require many more iterations.

Adagio provides several preconditioner options that can be categorized in two general types. These enable the efficient solution of a wide variety of problems using available resources. The first type of preconditioner is the nodal preconditioner. There are several different variants of nodal preconditioners available. These include the diagonal preconditioners that were available in JAS3D, in addition to other options. The second type of preconditioner provided by Adagio is the full tangent preconditioner. This option uses the FETI parallel scalable linear solver to solve the full tangent matrix for use as a preconditioner in the CG algorithm.

In addition to using a preconditioner, conditioning of a problem can be improved by using a multilevel solver. Rather than directly solving the potentially ill-posed full problem with the CG solver, Adagio forms a series of "model problems" and solves them with the core CG solver. Features of

the model that make it ill-posed are either adjusted or held constant for a model problem. After each model problem is solved, the multilevel solver updates the quantities that were controlled. The process of forming model problems and updating is iterative, as with the core solver, and convergence must be achieved both in the core solver and in the multilevel controls. Adagio provides two types of controls for the multilevel solver: "control contact" and "control stiffness." Control contact must be used for all problems that have sliding contact, but is not needed for tied contact. Control stiffness is used to solve problems that are difficult because of extreme differences in the stiffness of various modes of material response. For instance, control stiffness is beneficial for nearly incompressible materials where the bulk response is much stiffer than the shear response. Control stiffness is also useful for oriented materials where the material response is much stiffer in some directions than it is in others. In addition, using control stiffness can greatly speed the iterative solution process when a model contains several materials that have extreme differences in stiffness.

Adagio also provides a geometric multi-grid algorithm called "control modes," which uses a coarse grid to solve for the low mode response. To use the control modes algorithm, a user must supply a coarse mesh that overlays the actual problem mesh. This algorithm works well for solving problems that are dominated by bending of slender members.

This chapter discusses the commands in Adagio for specifying solver options, for controlling time stepping, and for solving implicit dynamic problems. Section 3.1 discusses the `CG` command block, which controls Adagio's nonlinear preconditioned CG solver. An option in the `CG` command block is to use a full tangent preconditioner. The command block to control the behavior of this option is discussed in Section 3.2. The recommended linear solver for use as a full tangent preconditioner is FETI, whose command block is presented in Section 3.3. Adagio's CG solver can either be used alone or as the core solver within a multilevel solver. Section 3.4 presents the characteristics and structure of the `MULTILEVEL SOLVER` command block. The two types of controls, control contact and control stiffness, that can be used within the multilevel solver are presented in Sections 3.5 and 3.6, respectively. Section 3.7 explains how to activate the multigrid control modes solution method. This feature greatly increases the effectiveness of the CG algorithm for solving slender, bending-dominated problems. Section 3.8 describes another feature in Adagio, that of predictors, which are used to generate an initial trial solution for a load step or for a multilevel-solver model problem. As explained in Section 3.9, Adagio also has an option that allows it to use the same algorithms as the JAS3D solver. Adagio's approaches for controlling time stepping and for performing implicit solutions on quasi-static and dynamic problems are described in Sections 3.10 and 3.11, respectively. Finally, Section 3.12 provides references for this chapter.

3.1 Conjugate Gradient Solver

The core nonlinear preconditioned conjugate gradient solver is controlled through the `CG` command block. This command block must appear in the standard Adagio region scope (i.e., in the `ADAGIO REGION` command block) if it is to be used without multilevel controls. If the CG solver is to be used as a core solver within the multilevel solver, the `CG` command block must appear in the `MULTILEVEL SOLVER` command block. Note that the `MULTILEVEL SOLVER` command block, if used, must appear in the `ADAGIO REGION` command block.

```
BEGIN CG
  #
  # convergence commands
  TARGET RESIDUAL = <real>target_resid
    [DURING <string list>period_names]
  TARGET RELATIVE RESIDUAL = <real>target_rel_resid
    [DURING <string list>period_names]
  ACCEPTABLE RESIDUAL = <real>accept_resid
    [DURING <string list>period_names]
  ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
    [DURING <string list>period_names]
  REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
    [DURING <string list>period_names]
  MINIMUM RESIDUAL IMPROVEMENT  =  <real>resid_improvement
    [DURING <string list>period_names]
  MINIMUM ITERATIONS  = <integer>min_iter(0)
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS  = <integer>max_iter
    [DURING <string list>period_names]
  #
  # preconditioner commands
  PRECONDITIONER = BLOCK|BLOCK_INITIAL|DIAGONAL|
    DIAGSCALING|ELASTIC|IDENTITY|PROBE|SCHUR|TANGENT
    [<real>scaling_factor]
  BALANCE PROBE = <integer>balance_probe
  NODAL PROBE FACTOR = <real>probe_factor(1.0e-6)
  BEGIN FULL TANGENT PRECONDITIONER
    #
    # Parameters for full tangent preconditioner
    #
  END [FULL TANGENT PRECONDITIONER]
  #
  # line search command
  LINE SEARCH ACTUAL|SECANT|TANGENT [<real>scale_factor]
  #
  # diagnostic output commands
  ITERATION PRINT = <integer>iter_print
    [DURING <string list>period_names]
```

```
  ITERATION PLOT = <integer>iter_plot
    [DURING <string list>period_names]
  ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
  #
  # cg algorithm commands
  ITERATION RESET = <integer>iter_reset(10000)
    [DURING <string list>period_names]
  ORTHOGONALITY MEASURE FOR RESET = <real>ortho_reset(0.5)
    [DURING <string list>period_names]
  RESET LIMITS <integer>iter_start <integer>iter_reset
    <real>reset_growth <real>reset_orthogonality
    [DURING <string list>period_names]
  BETA METHOD = FletcherReeves|PolakRibiere|
    PolakRibierePlus(FletcherReeves)
    [DURING <string list>period_names]
END [CG]
```

Sections 3.1.1 through 3.1.5 describe the components of the CG command block.

3.1.1 Convergence Commands

```
TARGET RESIDUAL = <real>target_resid
  [DURING <string list>period_names]
TARGET RELATIVE RESIDUAL = <real>target_rel_resid
  [DURING <string list>period_names]
ACCEPTABLE RESIDUAL = <real>accept_resid
  [DURING <string list>period_names]
ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
  [DURING <string list>period_names]
REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
  [DURING <string list>period_names]
MINIMUM RESIDUAL IMPROVEMENT = <real>resid_improvement
  [DURING <string list>period_names]
MINIMUM ITERATIONS = <integer>min_iter(0)
  [DURING <string list>period_names]
MAXIMUM ITERATIONS = <integer>max_iter
  [DURING <string list>period_names]
```

The nonlinear preconditioned CG solver iterates to decrease the residual until the residual is deemed to be sufficiently small, based on user-specified convergence criteria. The command lines listed above are placed in the CG command block and used to control these convergence criteria.

Solver convergence is measured by computing the L^2 norm of the residual and comparing that residual norm with target convergence criteria specified by the user. Convergence can be monitored either directly in terms of the residual norm, or in terms of a relative residual, which is the residual norm divided by a reference quantity that is indicative of the current loading conditions on a model.

Basing convergence on the relative residual is often helpful because doing so ensures that the convergence target is meaningful for the model. There are some situations, however, when it is better to check for convergence based on the actual residual rather than on the relative residual. This approach is especially helpful when the model passes through a stage during which there are no loads. Note that the actual residual, the relative residual, or both of these residuals can be used for checking convergence at the same time.

All the convergence command lines in the `CG` command block can have different values for different time periods by using the `DURING` specification. This specification consists of the key word `DURING` followed by a list of time periods, and is appended to the end of the command line. Each of the time periods included in the list must correspond to the name of a `TIME STEPPING` command block (i.e., `time_block_name`) specified in the `TIME CONTROL` command block. If the `DURING` specification is omitted from the command line, the value of the parameter in the command line is applicable for the entire analysis. This default value can be overwritten for specific periods by repeating the same command line and using the `DURING` specification on each repeated line. In other words, multiple occurrences of the same command line can be included in the command block, one without a `DURING` specification and each of the others with a unique `DURING` specification for its applicable time periods.

The `TARGET RESIDUAL` command line specifies the target convergence criterion in terms of the actual residual norm. The `TARGET RELATIVE RESIDUAL` command line specifies a convergence criterion in terms of the relative residual. If both command lines are included in the `CG` command block, the solver will accept the solution as converged if either the target residual or the target relative residual is below the specified values. Note that use of the term "target" in this discussion means "desired."

The solver also allows the user to define acceptable convergence criteria. If the solution has not converged to the specified targets before the maximum number of iterations of the solver is reached, the residual is checked against the acceptable convergence criteria. These criteria are specified via the `ACCEPTABLE RESIDUAL` and `ACCEPTABLE RELATIVE RESIDUAL` command lines. The concepts of residual and relative residual are the same as those used for the target limits, i.e., in the `TARGET RESIDUAL` and `TARGET RELATIVE RESIDUAL` command lines. If the solution has not met the target criteria but has met the acceptable criteria, the solution is allowed to proceed. The default value for each acceptable criterion command line is 10 times the value of its corresponding target criterion command line, e.g., if the value of `target_resid` was 1.0e-6, the value of `accept_resid` would be 1.0e-5. Solutions that meet only the acceptable criteria are noted in the log file. If the acceptable criteria are not met, the solution at that load step has failed to converge, and the solver exits. If adaptive time stepping, as discussed in Section 3.10.2, is active, a solution of the load step may be attempted with a smaller time step. Otherwise, the code will exit at this point with an error.

If relative residuals are given in the convergence criteria, the `REFERENCE` command line can be used to select the method for computing the reference load. This command line has three options: `EXTERNAL`, `INTERNAL`, and `RESIDUAL`. When the `EXTERNAL` option, which is the default, is selected, the reference load is computed by taking the L^2 norm of the current external load. If the model has force boundary conditions, the external force vector used for this norm is composed of the nodal forces resulting from those boundary conditions. If there are no prescribed forces, the

reaction forces at all prescribed kinematic boundary conditions are used instead. The `INTERNAL` option uses the norm of the internal forces as the reference load. This option is helpful in situations where a structure has no externally applied boundary conditions, such as in the case of a thermally loaded structure. Finally, the `RESIDUAL` option denotes that the residual from the initial residual should be used as the reference quantity. The initial residual is computed from the first iteration of the solver.

The `MINIMUM RESIDUAL IMPROVEMENT` command line stipulates that the CG solver must reduce the initial residual by a specified amount to obtain convergence. If this command line is included in the `CG` command block, the improvement condition must be met in addition to the standard target residual criteria. The parameter `resid_improvement` is a real number between 0.0 and 1.0 that specifies the amount by which the residual must be improved as a fraction of the initial residual in the current model problem. Thus, to stipulate that the residual must be smaller than 10% of the initial residual, one would set the value of `resid_improvement` equal to 0.9. The `MINIMUM RESIDUAL IMPROVEMENT` command line is primarily useful in the context of the multilevel solver. The model problems presented to the core solver sometimes begin with very low residuals and require very few iterations to converge. This command line forces the core solver to further improve the residual, which can accelerate the convergence of the other solver levels.

The `MAXIMUM ITERATIONS` and `MINIMUM ITERATIONS` command lines are used to specify the maximum and minimum number of core solver iterations, respectively. These limits apply for a load step if the CG solver is used in the stand-alone mode, or for a model problem if the CG solver is used as the core solver in the multilevel solver. The default value for the minimum number of iterations, `min_iter`, is zero. If a number greater than zero is specified, the solver will iterate at least that many times, regardless of whether the convergence criteria have been met.

3.1.2 Preconditioner Commands

```
PRECONDITIONER = BLOCK|BLOCK_INITIAL|DIAGONAL|
  DIAGSCALING|ELASTIC|IDENTITY|PROBE|SCHUR|TANGENT
  [<real>scaling_factor]
BALANCE PROBE = <integer>balance_probe
NODAL PROBE FACTOR = <real>probe_factor(1.0e-6)
BEGIN FULL TANGENT PRECONDITIONER
#
#  Parameters for full tangent preconditioner
#
END [FULL TANGENT PRECONDITIONER]
```

The command lines listed above are used to select the type of preconditioner used by the CG algorithm, as well as the method used to form the preconditioner for some types of preconditioners. The preconditioner is applied to the residual vector to obtain a gradient direction, which in turn is used to find a search direction. The most effective preconditioner is one that closely approximates the effect of multiplying by the inverse of the tangent stiffness matrix.

There are two basic types of preconditioners available: nodal and full tangent. The nodal preconditioners provide only the diagonal terms of the full tangent stiffness matrix or 3-by-3-block diagonal

matrices along the diagonal of the stiffness matrix. The diagonal nature of a nodal preconditioner allows it to be inverted very inexpensively and also use very little memory. Nodal preconditioners are so termed because they only account for the stiffness at each node in isolation and ignore the coupling between nodes that is accounted for in the off-diagonal terms of a full stiffness matrix. The result of this approximation is that with a nodal preconditioner, in a single iteration, the equilibration of a residual at a node can only cause movement in nodes that are directly connected by an element to that node. Thus, as the model size increases, the number of iterations also increases. Nodal preconditioners require many iterations, but they are often very efficient because the iterations are very inexpensive, especially if the problem is "blocky" in nature.

With the `PRECONDITIONER` command line, the user selects the nodal preconditioner. As defined below, this command line has several options. Some options are synonyms for other options.

- The `BLOCK` and `ELASTIC` options, which are synonyms, specify the default preconditioner. These options provide a nodal preconditioner with 3-by-3-block matrices that are computed based on the elastic material properties. These matrices are updated at every model problem to account for the current geometry.
- The `BLOCK_INITIAL` option, which is a variant of the `BLOCK` preconditioner, forms the preconditioner at the beginning of the analysis but never recomputes it for efficiency.
- The `DIAGONAL` preconditioner is formed in the same way as the `BLOCK` preconditioner, but only uses the terms on the diagonal.
- The `PROBE` option forms a 3-by-3-block diagonal preconditioner by probing the stiffness of nodes rather than by using the elastic stiffness.
- The `SCHUR` option, a variant of the `PROBE` preconditioner, uses a Schur Complement to approximate the coupling effects between translational and rotational degrees of freedom at a node.
- The `IDENTITY` option uses an identity matrix for the preconditioner, meaning that the residual is used as the gradient direction. This option is only of academic interest and is included for completeness.
- The `DIAGSCALING` option uses the identity matrix multiplied by the parameter `scaling_factor`. This is the only option for which the `scaling_factor` parameter is applicable. This option is also only of academic interest.

The `BALANCE PROBE` and `NODAL PROBE FACTOR` command lines control the behavior of the probing algorithm that is used to obtain the stiffness for the probe preconditioner (selected via the `PROBE` option in the `PRECONDITIONER` command line). For the probe preconditioner, the tangent stiffness K is approximated using finite differences:

$$K_{ij} = \frac{\partial F_i^{int}}{\partial x_j}, \tag{3.1}$$

where F^{int} is the internal force and x is the displacement. The nodal probe preconditioner only computes the 3-by-3-block diagonal version of the stiffness matrix. The `NODAL PROBE FACTOR`

command line controls the probing distance, with the value of `probe_factor` defaulting to 1.0e-6. The probe factor controls the probing distance relative to element size. Smaller values may give a better tangent approximation, but these values could result in the generation of round-off errors.

The `BALANCE PROBE` command line selects the type of finite differencing scheme used to probe for the stiffness. The value of `balance_probe` can be set to 0, 1, or 2, as explained below.

- Setting `balance_probe` to 0, the default for the nodal probe preconditioner, causes the preconditioner to be formed by forward finite differencing. Probing occurs in only one direction, resulting in zero-order accuracy in the preconditioner. The stiffness computed when `balance_probe` is set to 0 appears as

$$K_{ij} = \frac{\partial F_i^{int}(x+\delta e_j) - F_i^{int}(x)}{\delta}, \tag{3.2}$$

  where δ is the probing distance, controlled by the `NODAL PROBE FACTOR` command line, and e_j is a unit vector in the jth equation direction.

- Setting `balance_probe` to 1, the default for the full tangent preconditioner, causes the preconditioner to be formed with central differencing. Probing at each element degree of freedom is performed in both positive and negative directions, leading to a first-order accurate estimate of the tangent stiffness. This approach can be necessary in problems with material nonlinearity, where a probe that stretches rather than compresses the element can result in orders of magnitude differences in estimated stiffness. The stiffness computed when `balance_probe` is set to 1 appears as

$$K_{ij} = \frac{\partial F_i^{int}(x+\delta e_j) - F_i^{int}(x-\delta e_j)}{2\delta}. \tag{3.3}$$

- The value of `balance_probe` may also be set to 2, which allows the full tangent preconditioner to obtain central finite differencing with fourth-order error. This approach requires twice the work as central differencing but is more accurate. The stiffness computed when `balance_probe` is set to 2 appears as

$$K_{ij} = \frac{\partial F_i^{int}(x+2\delta e_j) + 8F^{int}(x+\delta e_j) - 8F^{int}(x+\delta e_j) - F_i^{int}(x-2\delta e_j)}{12\delta}. \tag{3.4}$$

The `FULL TANGENT PRECONDITIONER` command block enables the full tangent preconditioner and specifies options that apply specifically to that type of preconditioner. See Section 3.2 for a description of the options available. The `FULL TANGENT PRECONDITIONER` command block cannot be used with the `PRECONDITIONER` command line in a `CG` command block. The user must select only one type of preconditioner for an analysis.

3.1.3 Line Search Command

```
LINE SEARCH ACTUAL|SECANT|TANGENT [<real>scale_factor]
```

During each CG iteration, once the search direction is computed, a line search is used to find an optimal scaling factor that when applied to the search vector will result in a minimized residual. The line search algorithm is controlled with the `LINE SEARCH` command line. Three line search types are available: `ACTUAL`, `SECANT`, and `TANGENT`. The optional `scale_factor` can be used with any of the three options.

- The `ACTUAL` line search is a single-step quadratic line search that is equivalent to the corresponding JAS3D line search option. The line search requires an additional evaluation for each iteration of the element internal forces and thus the material response. For a given search direction s, residual r, and velocity v, the step length α is computed as

$$\alpha = -\frac{s^T r(v)}{s^T \left(F_{int}(v+s) - F_{int}(v)\right)}, \tag{3.5}$$

  where the residual is computed based on the internal force F_{int} and on the external force F_{ext} as $r = F_{int}(v) - F_{ext}(v)$.

- The `SECANT` line search is a slight variation of the `ACTUAL` line search described above. Like the `ACTUAL` line search, this line search requires an additional internal force evaluation for each iteration. The step length α is computed as

$$\alpha = -\frac{s^T r(v)}{s^T \left(r(v+s) - r(v)\right)}. \tag{3.6}$$

  The `SECANT` line search is recommended for problems in which the external force is highly nonlinear (e.g., a beam-bending problem with a pressure distribution).

- The `TANGENT` line search avoids the additional internal force calculation that is inherent in the other line search types by using the tangent modulus computed in the last call to the material subroutine for each element. The step length α is computed as

$$\alpha = -\frac{s^T r(v)}{s^T K s}, \tag{3.7}$$

  where K is the tangent stiffness.

The optional `scale_factor` can be used with all three line search types. This parameter is used to scale the search direction s. If `scale_factor` is omitted, no scaling is done. If `scale_factor` is provided on the command line, s is scaled by the product of `scale_factor` and the dimension of the smallest element. Supplying a small value for `scale_factor` can help to avoid element inversion during the line search.

3.1.4 Diagnostic Output Commands

```
ITERATION PRINT = <integer>iter_print
  [DURING <string list>period_names]
ITERATION PLOT = <integer>iter_plot
  [DURING <string list>period_names]
ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
```

The command lines listed above can be used to control the output of diagnostic information from the CG solver. The `ITERATION PRINT` and `ITERATION PLOT` command lines can be appended with the `DURING` specification, as discussed in Section 3.1.1.

The `ITERATION PRINT` command line controls the frequency at which the convergence information line is printed to the log file. The default value of `iter_print` is 25 if a nodal preconditioner is used, and it is 1 if a full tangent preconditioner is used.

The `ITERATION PLOT` command line allows plots of the current state of the model to be written to the output database during the CG iterations. The value supplied in `iter_plot` specifies the frequency of such plots. The default behavior is not to produce such plots. The plots are generated with a fictitious time step. Every time such a plot is generated, a message is sent to the log file. This feature is useful for debugging, but it should be used with care. Note that the `ITERATION PLOT` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

The output produced by iteration plots is sent by default to every active results output file, as specified by a `RESULTS OUTPUT` command block. The `ITERATION PLOT OUTPUT BLOCKS` command line can optionally be used to supply a list of output block names to which iteration plots should be written. Each of the output block names listed in `plot_blocks`, must match the name of a `RESULTS OUTPUT` command block (see Section 8.1.1). The `ITERATION PLOT OUTPUT BLOCKS` command line can be useful for directing iteration plots to separate output files so that these plots are separated from the converged solution output. It can also be used to send output plots for different levels of the multilevel solver to different files.

3.1.5 CG Algorithm Commands

```
ITERATION RESET = <integer>iter_reset(10000)
  [DURING <string list>period_names]
ORTHOGONALITY MEASURE FOR RESET = <real>ortho_reset(0.5)
  [DURING <string list>period_names]
RESET LIMITS <integer>iter_start <integer>iter_reset
  <real>reset_growth <real>reset_orthogonality
  [DURING <string list>period_names]
BETA METHOD = FletcherReeves|PolakRibiere|
  PolakRibierePlus(FletcherReeves)
  [DURING <string list>period_names]
```

The behavior of the CG algorithm can be changed using the command lines listed above. The CG algorithm orthogonalizes the current search direction and the previous search direction at each iteration. During an iteration where a reset occurs, the orthogonalization is skipped, resulting in a search in the steepest descent direction. Note that all of these command lines can be appended with the `DURING` specification, as discussed in Section 3.1.1.

The `ITERATION RESET` command line specifies that the CG algorithm be reset after every `iter_reset` iterations. The default is to reset the algorithm after every 10,000 iterations.

For the CG algorithm to work well, each new search direction must be sufficiently orthogonal to the previous search directions. If the current search direction has a significant component in one of

the previous search directions, error can be introduced that will not be corrected in future iterations. At every iteration, the relative lack of orthogonality between the current gradient direction and the previous search direction is computed. The `ORTHOGONALITY MEASURE FOR RESET` command line specifies that a reset will occur if the lack of orthogonality exceeds the value of `ortho_reset`. The default value of 0.5 results in few resets. Setting `ortho_reset` to a value as tight as 0.01 can result in many resets and potentially improved convergence on some problems.

The `RESET LIMITS` command line is also used to control CG resets. This command line is provided to achieve compatibility with JAS3D, and it behaves exactly the same as its JAS3D counterpart. The command line, however, should not be used when either the `ITERATION RESET` command line or the `ORTHOGONALITY MEASURE FOR RESET` command line is included in the `CG` command block. Up to four parameters can optionally be specified in the `RESET LIMITS` command line. The first, `iter_start`, sets the number of iterations to wait before looking for a minimum residual. The second, `iter_reset`, sets the number of iterations to allow between finding a minimum and restarting the iterative algorithm. The third, `reset_growth`, sets the amount of growth in the residual norm that would indicate divergence and thus trigger a reset. Finally, `reset_orthogonality` sets the relative lack of orthogonality between the current gradient direction and the previous search direction that would trigger a reset.

The `BETA METHOD` command line allows different formulas to be used in computing the β scalar in the CG algorithm. If set to `FletcherReeves`, the β scalar is computed as

$$\beta_k = \frac{r_k^T g_k}{r_{k-1}^T g_{k-1}}. \tag{3.8}$$

If set to `PolakRibiere` (the default), β is computed as

$$\beta_k = \frac{r_k^T (g_k - g_{k-1})}{r_{k-1}^T g_{k-1}}. \tag{3.9}$$

With the `PolakRibierePlus` option, β is computed as

$$\beta_k = \max(\beta_k^{PR}, 0). \tag{3.10}$$

In the above equations, r_k is the current iteration's residual vector, r_{k-1} is the previous iteration's residual vector, g_k is the current iteration's gradient vector, and g_{k-1} is the previous iteration's gradient vector. The `PolakRibierePlus` formula forces beta to be positive. A steepest descent direction is taken when beta becomes negative.

3.2 Full Tangent Preconditioner

In addition to the nodal preconditioners, Adagio provides the capability to use a full tangent preconditioner in the CG algorithm. The full tangent preconditioner employs a scalable parallel linear solver to solve for the gradient direction using the full tangent stiffness matrix. Although the full tangent preconditioner is significantly more costly per CG iteration than are the nodal preconditioners, it can solve problems in a very small number of iterations. Full tangent preconditioners are especially effective in solving poorly conditioned problems that are often very difficult to solve using the CG algorithm with nodal preconditioners, such as those problems that involve the bending response of long, slender members.

Using a full tangent preconditioner requires that two command blocks be added to the input file. First, the `FULL TANGENT PRECONDITIONER` command block, described in this section, must be added to the `CG` command block. The `FULL TANGENT PRECONDITIONER` command block is used instead of the `PRECONDITIONER` command line in the `CG` command block. Second, a command block for a linear solver must be defined in the domain scope, as described in Section 3.3. That command block for the linear solver must be referenced within the `FULL TANGENT PRECONDITIONER` command block, instructing the CG algorithm to use the specified linear solver. The command block to enable the full tangent preconditioner is as follows:

Known Issue: Deactivation of element blocks (see Section 5.1.2.7) does not currently work in conjunction with the full tangent preconditioner in Adagio. To use this capability, one of the nodal preconditioners must be used.

```
BEGIN FULL TANGENT PRECONDITIONER
  #
  # solver selection commands
  LINEAR SOLVER = <string>linear_solver_name
  NODAL PRECONDITIONER METHOD = ELASTIC|PROBE|DIAGONAL
    (ELASTIC)
  #
  # matrix formation commands
  PROBE FACTOR = <real>probe_factor(1.0e-6)
  BALANCE PROBE = <integer>balance_probe(1)
  CONSTRAINT ENFORCEMENT = SOLVER|PENALTY(PENALTY)
  PENALTY FACTOR = <real>penalty_factor(100.0)
  SHELL DRILLING STIFFNESS = <real>shell_drill_stiff
  #
  # reset and iteration commands
  MAXIMUM RESETS FOR MODELPROBLEM = <integer>max_mp_resets
    [DURING <string list>period_names]
  MAXIMUM RESETS FOR LOADSTEP = <integer>max_ls_resets
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS FOR MODELPROBLEM
    = <integer>max_mp_iter
```

```
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS FOR LOADSTEP = <integer>max_ls_iter
    [DURING <string list>period_names]
  ITERATION UPDATE = <integer>iter_update
    [DURING <string list>period_names]
  SMALL NUMBER OF ITERATIONS = <integer>small_num_iter
    [DURING <string list>period_names]
  NUMBER OF SMOOTHING ITERATIONS
    = <integer>num_smooth_iter
    [DURING <string list>period_names]
  #
  # fall-back strategy commands
  STAGNATION THRESHOLD = <real>stagnation(1.0e-12)
    [DURING <string list>period_names]
  MINIMUM CONVERGENCE RATE = <real>min_conv_rate(1.0e-4)
    [DURING <string list>period_names]
  ADAPTIVE STRATEGY = SWITCH|UPDATE(SWITCH)
    [DURING <string list>period_names]
END [FULL TANGENT PRECONDITIONER]
```

The `FULL TANGENT PRECONDITIONER` command block contains all command lines related to the interaction of Adagio with the linear solver. There are command lines to control selection of the linear solver, formation of the matrices passed into the linear solver, CG iteration strategies, updating strategies, and strategies for dealing with poor convergence. Reasonable defaults have been set for most problems. The only required command line in this command block is the `LINEAR SOLVER` command line, which is used to select the linear solver. The command lines in this command block are described in Sections 3.2.1 through 3.2.4.

3.2.1 Solver Selection Commands

```
LINEAR SOLVER = <string>linear_solver_name
NODAL PRECONDITIONER METHOD = ELASTIC|PROBE|DIAGONAL(ELASTIC)
```

The command lines listed above are used in selecting a linear solver for use with the full tangent preconditioner and in selecting a nodal preconditioner. The `LINEAR SOLVER` command line is the only required command line in the `FULL TANGENT PRECONDITIONER` command block. This command line specifies the name of the solver that will be used to compute the action of the preconditioner by solving the linear system. Linear solvers are defined in the domain scope. Although several linear-solver packages are available for use as preconditioners in Adagio, we recommend that the FETI equation solver be used in production analyses. The FETI equation solver is actively maintained and tested by the Adagio development team. The `FETI EQUATION SOLVER` command block is documented in Section 3.3.

An arbitrary number of equation solver command blocks can be included in the input file to define various sets of solver options. Each equation solver command block must be given a name, which

is referenced in the `linear_solver_name` parameter of the `LINEAR SOLVER` command line. This name instructs Adagio to use the specified linear solver as a preconditioner for the CG solver.

When Adagio uses a full tangent preconditioner, it also forms a nodal preconditioner. This nodal preconditioner is used in contact calculations, as a fall-back preconditioner if the full tangent preconditioner does not perform well, and optionally for performing a specified number of smoothing iterations prior to use of the full tangent preconditioner.

The nodal preconditioner is selected with the `NODAL PRECONDITIONER METHOD` command line. Three options are available: `ELASTIC`, `PROBE`, and `DIAGONAL`. The `ELASTIC` option is the default. These options have the same meaning as the corresponding options given for the nodal preconditioner in the `CG` command block, as documented in Section 3.1.2.

3.2.2 Matrix Formation Commands

```
PROBE FACTOR = <real>probe_factor(1.0e-6)
BALANCE PROBE = <integer>balance_probe(1)
CONSTRAINT ENFORCEMENT = SOLVER|PENALTY(PENALTY)
PENALTY FACTOR = <real>penalty_factor(100.0)
SHELL DRILLING STIFFNESS = <real>shell_drill_stiff
```

The command lines listed above can be used to optionally control the way the stiffness matrix is formed. This matrix is formed by assembling contributions from all active elements. These element stiffness matrices are formed by finite differencing.

The `PROBE FACTOR` command line controls the probing distance relative to element size The default value of `probe_factor` is 1.0e-6. Smaller values may give a better tangent approximation, but they may also generate round-off errors.

The `BALANCE PROBE` command line selects the type of finite-differencing scheme used to probe for the stiffness. The value of `balance_probe` can be set to 0, 1, or 2. Setting `balance_probe` to 0 causes the preconditioner to be formed by forward finite differencing. Probing occurs in only one direction, resulting in zero-order accuracy in the preconditioner. Setting `balance_probe` to 1, the default for the full tangent preconditioner, causes the preconditioner to be formed with central differencing. Probing at each element degree of freedom is performed in both positive and negative directions, leading to a first-order accurate estimate of the tangent stiffness. The value of `balance_probe` may also be set to 2, which allows the full tangent preconditioner to obtain central finite differencing with fourth-order error. This scheme requires twice the work as the central-differencing scheme but is more accurate. See Section 3.1.2 for a more detailed discussion of these options.

The `CONSTRAINT ENFORCEMENT` command line controls the way multipoint constraints (i.e. contact, rigid body, and periodic BC) are enforced in the linear system. Two options are available: `SOLVER` and `PENALTY`. Specifying `SOLVER` results in the constraints being passed to the solver, thus allowing the solver to handle constraint enforcement internally. Specifying `PENALTY` results in the constraints being converted to penalty "elements" whose stiffness is contributed to the linear system before it is passed to the linear solver. If the `PENALTY` option is used, the penalty stiffness

is controlled by the PENALTY FACTOR command line.

Although some of the available linear-solver packages support internal constraint enforcement, these packages often perform poorly in parallel. Thus, we recommend that CONSTRAINT ENFORCEMENT be set to PENALTY for all analyses. The errors caused by penalty compliance are corrected in each CG iteration, so the converged solution will not have errors that are due to penalty compliance. This strategy has proven to be very effective for dealing with constraints.

The PENALTY FACTOR command line is used to specify the penalty stiffness. At each constraint, the diagonal tangent stiffness of the slave degree of freedom is multiplied by the value of the penalty_factor parameter. The default value for this parameter is 100.0, which is reasonable for most problems. Assigning a high value (greater than about 1.0e+8) can cause poor conditioning of the linear system and also cause the linear solver to perform poorly. Assigning a low value (less than about 10) could require more CG iterations due to the correction of errors resulting from penalty compliance.

3.2.3 Reset and Iteration Commands

```
MAXIMUM RESETS FOR MODELPROBLEM = <integer>max_mp_resets
  [DURING <string list>period_names]
MAXIMUM RESETS FOR LOADSTEP = <integer>max_ls_resets
  [DURING <string list>period_names]
MAXIMUM ITERATIONS FOR MODELPROBLEM = <integer>max_mp_iter
  [DURING <string list>period_names]
MAXIMUM ITERATIONS FOR LOADSTEP = <integer>max_ls_iter
  [DURING <string list>period_names]
ITERATION UPDATE = <integer>iter_update
  [DURING <string list>period_names]
SMALL NUMBER OF ITERATIONS = <integer>small_num_iter(0)
  [DURING <string list>period_names]
NUMBER OF SMOOTHING ITERATIONS = <integer>num_smooth_iter(0)
  [DURING <string list>period_names]
```

When a linear solver is used as a preconditioner, the efficiency of the solution can often be dramatically affected by the frequency at which the preconditioner is updated. The computational expense of updating the preconditioner, which involves forming and factorizing the stiffness matrix, is often much higher than the cost of applying the preconditioner, which involves only a back-solve, during a CG iteration. If the stiffness does not dramatically change from iteration to iteration, it is often much more efficient to re-use the preconditioner for a number of iterations, or even load steps, than it is to update it at every iteration.

The command lines listed above can be used to control when the preconditioner is updated. As Adagio allows for the nodal preconditioner to be used in place of the full tangent preconditioner in some situations, these command lines also control this behavior. Note that all of these command lines can be appended with the DURING specification, as discussed in Section 3.1.1.

The MAXIMUM RESETS FOR MODELPROBLEM command line limits the number of times that the

preconditioner can be reset (updated) during a model problem. By default, there is no limit on the number of updates that can occur during a model problem. The `MAXIMUM RESETS FOR LOADSTEP` command line limits the updates that can occur during a load step. By default, there is also no limit on the number of updates that can occur during a load step.

The `MAXIMUM ITERATIONS FOR LOADSTEP` and `MAXIMUM ITERATIONS FOR MODELPROBLEM` command lines can be used to limit the number of CG iterations that will be performed using the full tangent preconditioner per model problem or load step, respectively. The values of the parameters `max_mp_iter` and `max_ls_iter` are both unlimited by default. If one of these iteration limits is reached, the CG solver will continue to iterate using the fall-back nodal preconditioner until either the CG solver iteration limit is reached or convergence is achieved. It can be useful to limit the iterations taken by the full tangent preconditioner. If the full tangent preconditioner is performing poorly, the nodal preconditioner may work better in some cases.

The `ITERATION UPDATE` command line controls the frequency at which the full tangent preconditioner is updated. By default, it is only updated at the first iteration of each model problem. If this command line is used, the preconditioner will be updated at the frequency specified by `iter_update`. If a model experiences highly nonlinear behavior over the course of a model problem, it may be useful to use this command line to cause more frequent preconditioner updates. Such problems may converge better when `iter_update` is set to about 10. It is important to realize that frequent updates may reduce the number of CG iterations but dramatically increase the computational cost.

It can often be efficient to update the preconditioner very infrequently. The `SMALL NUMBER OF ITERATIONS` command line is used to "freeze" the preconditioner, or prevent updates, until a model problem requires more iterations than the number specified in `small_num_iter`. The default value of `small_num_iter` is 0, meaning that the preconditioner is never re-used for the next model problem unless the `SMALL NUMBER OF ITERATIONS` command line is used. It is often beneficial to set `small_num_iter` to 10. This can often result in the re-use of the preconditioner over many load steps. When this command line is used, the CG solver often converges in a very small number of iterations immediately following a preconditioner update; however, over the course of several load steps, the iteration counts slowly increase because the preconditioner is out of date. At a certain point, the iteration count exceeds `small_num_iter`, and the preconditioner is reset. This solution strategy is very efficient because it allows re-use of the preconditioner while it is still relatively effective.

In some cases it is beneficial to perform a number of CG iterations using the nodal preconditioner prior to applying the full tangent preconditioner. The iterations with the nodal preconditioner are used as a "smoother" to put the model in a better state for the full tangent preconditioner. This behavior can be enabled using the `NUMBER OF SMOOTHING ITERATIONS` command line. By default, this feature is disabled. If this command line is present, the `num_smooth_iter` parameter specifies the number of smoothing iterations to be taken. This feature can also be used in cases where the nodal preconditioner may be effective enough to achieve convergence with relatively few iterations, but occasionally the nodal preconditioner is not effective. If `num_smooth_iter` is set to a relatively high number, many load steps can be solved without ever using the full tangent preconditioner, but this preconditioner is used on the more difficult steps that require more

iterations.

Another use of the NUMBER OF SMOOTHING ITERATIONS command line is for switching between the nodal preconditioner and the full tangent preconditioner for certain time periods. This command line, as all the other command lines discussed above, can be set on a period-specific basis by appending it with the DURING keyword, followed by a list of periods. To use the nodal preconditioner on some periods, the user can set num_smooth_iter to a high number for those periods and leave the default value of 0 for the periods in which the full tangent preconditioner is desired.

3.2.4 Fall-Back Strategy Commands

```
STAGNATION THRESHOLD = <real>stagnation(1.0e-12)
MINIMUM CONVERGENCE RATE = <real>min_conv_rate(1.0e-4)
ADAPTIVE STRATEGY = SWITCH|UPDATE(SWITCH)
```

Occasionally, the full tangent preconditioner may stagnate, failing to significantly reduce the residual from one CG iteration to the next. At each iteration, Adagio checks for slow convergence, and attempts to remedy poor convergence if such is detected. The commands listed above can optionally be added to the FULL TANGENT PRECONDITIONER command block.

The STAGNATION THRESHOLD and MINIMUM CONVERGENCE RATE command lines are used to set the stagnation and min_conv_rate parameters, respectively. These parameters are used in a strategy that attempts to remedy slow convergence. The method for remedying slow convergence is controlled with the ADAPTIVE STRATEGY command line, which can have a value of SWITCH or UPDATE. The default strategy is SWITCH. The convergence rate is computed as the absolute value of the relative difference between residuals after successive CG iterations. In the SWITCH strategy, if the convergence rate is less than the value of min_conv_rate but greater than the value of stagnation, the CG solver will switch to using the fall-back nodal preconditioner. In the UPDATE strategy, the full tangent preconditioner would be updated instead. In either case, if the convergence rate is below the value of stagnation, the solver will switch to the nodal preconditioner.

3.3 FETI Equation Solver

FETI is a domain-decomposition-based parallel iterative linear solver that can be used as a full tangent preconditioner for Adagio's nonlinear CG solver [3, 4]. FETI uses a direct solver on each domain and iteratively solves for Lagrange multiplier fields at the domain boundaries. Under typical usage, the FETI domains correspond to the portions of the model owned by each processor. If a model is run on a single processor, FETI simply behaves as a direct solver. Because large models are typically run using many processors, FETI uses significantly lower computing resources than a direct solution of the whole problem would require because a large number of small direct solutions are performed in parallel.

Although a number of other linear solvers are available for use as full tangent preconditioners in Adagio's CG solver, it is recommended that FETI be used. FETI is actively maintained and tested by the Adagio development team; its effectiveness as a robust parallel solver has been demonstrated on a wide range of production analyses. The command block for the FETI equation solver is as follows:

```
BEGIN FETI EQUATION SOLVER <string>name
  #
  # convergence commands
  MAXIMUM ITERATIONS = <integer>max_iter(500)
  RESIDUAL NORM TOLERANCE = <real>resid_tol(1.0e-6)
  #
  # memory usage commands
  PARAM-STRING "precision" VALUE <string>"single"|"double"
    ("double")
  PRECONDITIONING METHOD = NONE|LUMPED|DIRICHLET(DIRICHLET)
  MAXIMUM ORTHOGONALIZATION = <integer>max_orthog(500)
  #
  # solver commands
  LOCAL SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
  NUM LOCAL SUBDOMAINS = <integer>num_local_subdomains
  COARSE SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
END [FETI EQUATION SOLVER <string>name]
```

The command lines used to control FETI all reside in the `FETI EQUATION SOLVER` command block, where `name` identifies the particular command block. This command block, as with all equation solver command blocks, must be placed in the domain scope and must be referenced by `name` when it is used. Although a number of command lines are available to control the behavior of FETI, the default settings generally work well for the vast majority of problems. Thus, it is recommended that all default settings be used unless special behavior is desired because of the unique features of a specific model. The command lines in the `FETI EQUATION SOLVER` command block are described in Sections 3.3.1 through 3.3.3.

3.3.1 Convergence Commands

```
MAXIMUM ITERATIONS = <integer>max_iter(500)
RESIDUAL NORM TOLERANCE = <real>resid_tol(1.0e-6)
```

The command lines listed above provide controls on the convergence of the FETI iterative solver, and belong in the `FETI EQUATION SOLVER` command block.

The `MAXIMUM ITERATIONS` command line sets the maximum number of iterations allowed per FETI solution. The default value of the parameter `max_iter` is 500. A FETI solution occurs for every CG iteration in which FETI is used as a full tangent preconditioner. The `RESIDUAL NORM TOLERANCE` command line sets the convergence criterion for the FETI solver. The default value of the parameter `resid_tol` is 1.0e-6. If convergence is not reached before the iteration count exceeds `max_iter`, FETI will simply return the current gradient direction to the CG solver, which will continue iterating. The code will not exit with an error. The default settings for both of these command lines are reasonable for most models and typically should not be modified.

3.3.2 Memory Usage Commands

```
PARAM-STRING "precision" VALUE <string>"single"|"double"
  ("double")
PRECONDITIONING METHOD = NONE|LUMPED|DIRICHLET(DIRICHLET)
MAXIMUM ORTHOGONALIZATION = <integer>max_orthog(500)
```

The command lines listed above can be placed in the `FETI EQUATION SOLVER` command block to enable optional memory-saving features of the FETI solver. All these features will adversely affect the performance of this solver to some degree, but they can be useful if the memory requirements of a model exceed the capacity of the machine on which the model is run. Before using these features, it is important to consider that on a distributed memory cluster, spreading the model out over more processors can reduce the memory requirements on each processor. For this reason, it is often better to use more processors rather than use the options described here.

FETI has the option of using either single or double precision for storage of internal variables. The default behavior is to use double precision, and this is typically recommended. To select single precision, the user would specify the command line as follows: `PARAM-STRING "precision" VALUE "single"`. Using single-precision variables within FETI can dramatically reduce the memory requirements. This may, however, slightly degrade the performance of the solver, requiring more iterations within FETI or more CG iterations. Using single precision in FETI does not affect the Adagio data structures, which are always double precision, and therefore does not adversely affect solution accuracy.

The `PRECONDITIONING METHOD` command line selects the preconditioning method that is used internally within FETI. The default option, `DIRICHLET`, typically results in the best convergence rate. The `LUMPED` option uses less memory, but it usually results in more iterations within FETI. This option should only be used if there are constraints on memory usage. The `NONE` option uses no preconditioner and is included only for completeness. This option is not of practical interest.

Like Adagio's CG solver, the FETI equation solver stores a set of search directions to ensure that the search direction used in each iteration is orthogonal to previous search directions. The number of search directions stored is controllable with the `MAXIMUM ORTHOGONALIZATION` command line. The default value of 500 for `max_orthog` provides optimal convergence. Setting `max_orthog` to a lower number can decrease memory usage but, as with the other options discussed above, may require more iterations for convergence.

3.3.3 Solver Commands

```
LOCAL SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
NUM LOCAL SUBDOMAINS = <integer>num_local_subdomains
COARSE SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
```

The command lines listed above control the type of solver used by FETI for solving the linear system that arises from the coarse grid and for the local linear system on the actual solution mesh. The default behavior is for FETI to use a sparse direct solver for both of these systems, an approach that works well for most problems. The `LOCAL SOLVER` command line is used to select the solver for the local subdomains. Similarly, the solver for the coarse grid can be selected with the `COARSE SOLVER` command lines. Both of these command lines allow the same three options: `SPARSE`, `SKYLINE`, and `ITERATIVE`, where `SPARSE` is the default.

- The `SPARSE` option uses a sparse matrix storage direct solver. The sparse matrix is factored into an $A = LDL^T$ decomposition, but the code implementation takes advantage of equation orderings to reduce matrix fill-in. The default equation ordering is done by calling METIS's sparse matrix ordering algorithm. This solver is recommended for both speed and memory efficiency.
- The `SKYLINE` option uses a skyline (profile) matrix storage direct solver. The skyline matrix is factored into an $A = LDL^T$ decomposition. This method is very robust, detects rigid-body modes effectively, and includes the reverse Cuthill-McKee (RCM) and Sloan equation orderings. This solver uses much more memory than does the sparse solver.
- The `ITERATIVE` option implements a multiple domain FETI algorithm for the local solver, where the number of domains is either computed based on some heuristics or is input by the user. This option is recommended in special circumstances where memory becomes an issue with the sparse direct solver.

The `NUM LOCAL SUBDOMAINS` command line sets the number of local subdomains for the `ITERATIVE` local solver. This command line is not used for the other local solvers. As the number of local subdomains increases, the size of the local subdomains decreases, thus reducing the memory requirements and the time it takes for the local matrix factorizations. As the number of subdomains increases, the size of the coarse grid increases, thus requiring increased factorization time and memory. A good rule of thumb is to set the number of local subdomains to the total number of elements in the mesh divided by 400. For a serial run, if the `NUM LOCAL SUBDOMAINS` command line is not specified, FETI sets the number of domains to the greater of 2 or the number of elements divided by 400. For parallel runs, FETI uses the same number of domains used by Adagio.

3.4 Multilevel Solver

Adagio allows the conjugate gradient (CG) solver to be used either by itself or as the core solver within a multilevel solver. The multilevel solver improves the ability of the core solver to solve poorly conditioned problems. This is done by holding fixed some variables that would ordinarily be free to change in the fully nonlinear iteration. The multilevel solver algorithm can be used recursively to treat multiple variables by assigning them to multiple solution levels. CG iterations are performed while a variable is held fixed. After convergence is obtained with the controlled variable fixed, a new residual calculation is performed, and the controlled variable is updated. Convergence on a particular level requires that all levels leading up to that level must be converged.

Once all control variables have been established, CG iterations are performed until convergence is obtained on the core "model problem." At this point, the variable controlled at level 1 is adjusted to minimize its residual. This process is known as a "level 1 update." After the level 1 update, the model problem is solved again, and this process is repeated until the core solver and the variable controlled at level 1 have converged. Once a solution has been obtained at level 1, the variable controlled at level 2 is updated. After each level 2 update, the level 1 problem must be solved again. This process can be repeated recursively for many levels. For convergence in the multilevel solver, all updates starting with the lowest level and proceeding to the highest level must be in equilibrium. These concepts are illustrated in Figure 3.1.



Figure 3.1: Reaching convergence with controls and the multilevel solver.

Adagio has two types of controls that can be used within the multilevel solver: control contact and control stiffness. Control contact is used to keep the set of nodes in contact constant during the solution of a model problem. Contact searches are performed during the multilevel solver updates. Control contact must be used for all problems that have sliding contact. It is not required

or beneficial for models that only have tied contact. Control contact is documented in detail in Section 3.5.

Control stiffness is used to improve the conditioning of models that contain widely varying stiffnesses in different modes of material response. Such differences naturally exist for models with nearly incompressible materials where the bulk behavior is much stiffer than the shear behavior, for models with orthotropic and/or anisotropic materials that have much higher stiffnesses in preferred material directions, and for models containing several materials that are vastly different in their overall stiffnesses. Control stiffness works by scaling a given material response up (stiffening) or down (softening) to create a set of better conditioned model problems. For nearly incompressible materials, for instance, the bulk stress increments may be softened and/or the shear stress increments may be stiffened. For oriented materials, the stress increments in certain material directions are softened to create a material response that is more isotropic in nature. Finally, for the case where a material is much stiffer than the surrounding materials, both the bulk and shear stress increments are softened to create a response that has a stiffness much closer to that of the adjacent materials. Ultimately, as the control stiffness model problems progress, the true material response is recovered by building up stresses that correspond to the true material response. There are a number of special material models that are designed to work with this capability.

The following is the basic structure of the `MULTILEVEL SOLVER` command block:

```
BEGIN MULTILEVEL SOLVER
  #
  # cg solver commands
  BEGIN CG
    #
    # Parameters for cg
    #
  END [CG]
  #
  # control contact commands
  BEGIN CONTROL CONTACT [<string>contact_name]
    #
    # Parameters for control contact
    #
  END [CONTROL CONTACT <string>contact_name]
  #
  # control stiffness commands
  BEGIN CONTROL STIFFNESS [<string>stiffness_name]
    #
    # Parameters for control stiffness
    #
  END [CONTROL STIFFNESS <string>stiffness_name]
  #
  # predictor command
  LEVEL 1 PREDICTOR = <string>NONE|DEFAULT(DEFAULT)
END [MULTILEVEL SOLVER]
```

The multilevel solver is used within Adagio by inserting a `MULTILEVEL SOLVER` command block in the `ADAGIO REGION` command block. The `CG` command block (described in Section 3.1) is still required, but it must be placed in the `MULTILEVEL SOLVER` command block rather than in the `ADAGIO REGION` command block, where it is placed when the multilevel solver is not used. In other words, the CG command block can only be used one time in an analysis.

In addition to the `CG` command block, the `MULTILEVEL SOLVER` command block also contains command blocks that describe the controls that will be used. The `MULTILEVEL SOLVER` command block can contain a `CONTROL CONTACT` command block, a `CONTROL STIFFNESS` command block, or both of these command blocks. The `CONTROL CONTACT` command block and the `CONTROL CONTACT` command block are described in Section 3.5 and Section 3.6, respectively. The multilevel solver requires at least one control to function properly. If neither sliding contact nor nearly incompressible material modeling is required, then the CG solver must be used directly, i.e., without the multilevel solver.

Aside from the command blocks for the core solver and the controls, the `MULTILEVEL SOLVER` block contains the `LEVEL 1 PREDICTOR` command line, which is described in Section 3.4.1.

The convergence tolerances for the solver levels are set within either or both of the control blocks (i.e., `CONTROL CONTACT`, `CONTROL STIFFNESS`), while the tolerance of the core CG solver is set within the `CG` command block. The commands within the `CG` command block are used in the same way whether or not the multilevel solver is used. It is, however, important to consider the role of tolerances within the multilevel solver. The convergence of the problem is controlled by the convergence of the highest solver level. For the multilevel solver to converge well, it is important for the core solver (or lower level of the solver, in the case of multiple levels) to reduce the residual by a certain amount during each model problem solution. For this reason, it is recommended that the solution tolerances be set an order of magnitude tighter for each lower level solver. The `MINIMUM RESIDUAL IMPROVEMENT` command in the `CG` command block is helpful for ensuring that the residual is reduced by the core solver during model problems, even though the residual might already be within the convergence tolerances (see Section 3.1.1).

3.4.1 Level Predictor

```
LEVEL 1 PREDICTOR = <string>NONE|DEFAULT(DEFAULT)
```

The `LEVEL 1 PREDICTOR` command line controls the level 1 predictor. Because it is only applicable for the multilevel solver, this command line appears in the `MULTILEVEL SOLVER` command block. The level 1 predictor estimates the solution for the next model problem based on the solution of the previous model problem. The default behavior is to enable this predictor, indicated by `DEFAULT`. The predictor can be turned off by setting it to `NONE`.

3.5 Control Contact

The multilevel solution control scheme used for contact is referred to as control contact. After a set of nodes in contact (a constraint set) is established, a model problem is solved using the CG solver with this constraint set held constant. For frictional contact, slave nodes are fixed to master faces during the CG iterations. For frictionless contact, the slave nodes are fixed in the normal direction but are allowed to slide during the CG iterations. After model problem convergence, the constraint set is updated to reflect the changing contact conditions. This update gives rise to a force imbalance and to another model problem.

Changing or updating the constraint set is referred to as a contact update. Multiple contact updates are typically required before equilibrium is achieved. The contact update consists of a search, a gap removal, an equilibrium query, and a slip calculation if equilibrium is not satisfied.

New constraints are detected in the search phase based on the current deformed configuration of the model. If a node is found to penetrate a master surface, the node is added to the set of constraints. The slave node is moved to the master surface by moving it along the push-back vector. The penetration may be removed at once (the default behavior), or it may be incrementally removed over a number of model problems.

The gap removal phase involves creating or destroying constraints and calculating push-back vectors for slave nodes. For types of surface mechanics in which contacting surfaces are free to separate, a slave node constraint continues to exist as long as there is a compressive force between the slave node and the master surface. The constraint changes during the gap removal phase to reflect changes in the shape and orientation of the master surface. Constraints are destroyed when a tensile force exceeding a known tolerance exists at the master/slave interface.

During the slip portion of the contact update, a residual force is calculated at each node and resolved into normal and tangential components. This force reflects changes in residual due to gap removal that occurred earlier in the update. For frictional contact, the friction coefficient is used to determine the tangential load capacity. If the tangential loads exceed this capacity, nodes will slip.

The procedure for control contact is illustrated in the following sequence of figures. It is assumed that control contact is on level 1, so the model problems are directly solved by the core solver. In this example (Figure 3.2), the model problem has three constraints that are enforced during iterations of the core solver. Nothing prevents other nodes from penetrating surfaces during solution of the model problem, and in this example, one node does penetrate.

Once the model problem has converged, a contact update is performed. In the gap removal portion of the update (Figure 3.3), one of the constraints has accumulated a tensile force large enough that surfaces should separate, thus eliminating this constraint. During the search, one node was found to be penetrating, so a new constraint was formed for this node and a push-back vector was calculated to remove the penetration.

In the second phase of the contact update, slip is allowed to occur along the master/slave interface. After the gaps are removed, the external and internal force vectors are recomputed, and forces are partitioned along normal and tangential directions of the master surface. This process is illustrated in Figure 3.4.



Figure 3.2: Contact configuration at the beginning of the contact update.



Figure 3.3: Contact gap removal (after contact search).



Figure 3.4: Contact slip calculations.

The command block for control contact is as follows:

```
BEGIN CONTROL CONTACT
  #
  # convergence commands
  TARGET RESIDUAL = <real>target_resid
    [DURING <string list>period_names]
  TARGET RELATIVE RESIDUAL = <real>target_rel_resid
    [DURING <string list>period_names]
  ACCEPTABLE RESIDUAL = <real>accept_resid
    [DURING <string list>period_names]
  ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
    [DURING <string list>period_names]
  REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
    [DURING <string list>period_names]
  MINIMUM ITERATIONS  = <integer>min_iter(0)
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS  = <integer>max_iter
    [DURING <string list>period_names]
  #
  # level selection command
  LEVEL = <integer>contact_level(1)
  #
  # diagnostic output commands
  ITERATION PLOT = <integer>iter_plot
    [DURING <string list>period_names]
  ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
END [CONTROL CONTACT]
```

To enable control contact, a `CONTROL CONTACT` command block must exist in the `MULTILEVEL SOLVER` command block. The line commands within the `CONTROL CONTACT` command block are used to control convergence during the contact updates, select the level for the contact control within the multilevel solver, and output diagnostic information. These commands are described in detail in Section 3.5.1 through Section 3.5.3.

3.5.1 Convergence Commands

The command lines listed in this section are placed in the `CONTROL CONTACT` command block to control convergence criteria for contact within the multilevel solver.

```
TARGET RESIDUAL = <real>target_resid
  [DURING <string list>period_names]
TARGET RELATIVE RESIDUAL = <real>target_rel_resid
  [DURING <string list>period_names]
ACCEPTABLE RESIDUAL = <real>accept_resid
  [DURING <string list>period_names]
ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
  [DURING <string list>period_names]
REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
  [DURING <string list>period_names]
MINIMUM ITERATIONS = <integer>min_iter(0)
  [DURING <string list>period_names]
MAXIMUM ITERATIONS = <integer>max_iter
  [DURING <string list>period_names]
```

Solver convergence is monitored for control contact in much the same way as it is done for the core CG solver. The command lines listed above are used for specifying the convergence criteria used in the level 1 updates. These command lines are the same as those used for the core CG solver (described in Section 3.1.1) and have the same meaning. Here, however, these command lines are applied to the contact control. Note that all of these command lines can be appended with the `DURING` specification, as discussed in Section 3.1.1.

Contact convergence is measured by computing the L^2 norm of the residual, and comparing that residual norm with target convergence criteria specified by the user. Convergence can be monitored either directly in terms of the residual norm, or in terms of a relative residual, which is the residual norm divided by a reference quantity that is indicative of the current loading conditions on a model. Either the residual, the relative residual, or both of these residuals can be used for checking convergence at the same time.

The `TARGET RESIDUAL` command line specifies the target convergence criterion in terms of the actual residual norm. The `TARGET RELATIVE RESIDUAL` command line specifies a convergence criterion in terms of the relative residual. If both command lines are specified, the multilevel solver will accept the contact solution as converged if either the target residual or the target relative residual is below the specified values.

The multilevel solver also allows for acceptable convergence criteria to be input for contact convergence. If the solution has not converged to the specified targets before the maximum number of iterations is reached, the residual is checked against the acceptable convergence criteria. These criteria are specified via the `ACCEPTABLE RESIDUAL` and `ACCEPTABLE RELATIVE RESIDUAL` command lines. The concepts of residual and relative residual are the same as those used for the target limits. If the solution has not met the target criteria but has met the acceptable criteria, the solution is allowed to proceed.

If relative residuals are given in the convergence criteria, the `REFERENCE` command line can be used to select the method that will be used to compute the reference load. This command line has three options: `EXTERNAL`, `INTERNAL`, and `RESIDUAL`. The `EXTERNAL` option, which is the default, is computed by taking the L^2 norm of the current external load. The `INTERNAL` option uses the norm of the internal forces as the reference load. Finally, the `RESIDUAL` option denotes that the initial residual should be used as the reference quantity.

The `MAXIMUM ITERATIONS` and `MINIMUM ITERATIONS` command lines specify the maximum and minimum number of contact updates, respectively. The default minimum number of iterations, `min_iter`, is 0. If a number greater than 0 is specified, the multilevel solver will update contact at least that many times, regardless of whether the convergence criteria have been met.

3.5.2 Level Selection Command

```
LEVEL = <integer>contact_level(1)
```

The `LEVEL` command line in the `CONTROL CONTACT` command block is used to specify the level in the multilevel solver at which contact is controlled. The `contact_level` parameter can have a value of either 1 or 2, with 1 being the default.

This command is used when multiple controls (i.e. control contact and control stiffness) are active in the multilevel solver. It is permissible for multiple controls to exist at a given level. The default behavior is for all controls to be at level 1. To have a control at level 2, another control must be active at level 1 because a level in the multilevel solver cannot be skipped. The level of other controls is specified using the `LEVEL` command line in the command blocks associated with those controls.

3.5.3 Diagnostic Output Commands

```
ITERATION PLOT = <integer>iter_plot
  [DURING <string list>period_names]
ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
```

The command lines listed above can be used to control the output of diagnostic information from the contact control within the multilevel solver. The `ITERATION PLOT` command line allows plots of the current state of the model to be written to the output database during the contact updates. The value supplied in `iter_plot` specifies the frequency of such plots. The default behavior is

not to produce such plots. The plots are generated with a fictitious time step. Every time such a plot is generated, a message is sent to the log file. This feature is useful for debugging, but it should be used with care. Note that the `ITERATION PLOT` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

The output produced by iteration plots is sent by default to every active results output file, as specified by a `RESULTS OUTPUT` command block. The `ITERATION PLOT OUTPUT BLOCKS` command line can optionally be used to supply a list of output block names to which iteration plots should be written. Each of the output block names listed in `plot_blocks`, must match the name of a `RESULTS OUTPUT` command block (see Section 8.1.1). The `ITERATION PLOT OUTPUT BLOCKS` command line can be useful for directing iteration plots to separate output files so that these plots are separated from the converged solution output. It can also be used to send output plots for different levels of the multilevel solver to different files.

3.6 Control Stiffness

Control stiffness is an augmented Lagrange iterative solution strategy for solving models that have widely varying stiffnesses in various modes of material response. These differences in stiffness can be between individual materials in a problem or even between the different responses of a single material model. For instance, nearly incompressible materials have a bulk/volumetric response that is much stiffer than the corresponding shear/deviatoric response. A similar case arises for materials that are orthotropic or anisotropic in nature and exhibit widely varying stiffnesses in the principal material directions.

Using control stiffness allows part of the constitutive response of a material to be softened or stiffened to give a tangent response that results in model problems that can be solved more easily by the core solver. This is accomplished by scaling a chosen stress increment up or down in a given model problem and adding it to a saved reference stress to yield a scaled stress that is used for equilibrium evaluations. The reference stress accumulates the model problem stress increments so that the true material response for a time step is obtained after solving a sequence of model problems.

For the case of nearly incompressible materials, a sequence of model problems can be constructed in which the bulk behavior is softened (scaled down) and/or the shear behavior is stiffened (scaled up). For the case of anisotropic materials, the anisotropic part of the material response is scaled down to create a model problem where the material has a more nearly isotropic response. In addition, the isotropic part of the response of some of these orthotropic materials can have its bulk stress increments scaled down and/or its shear/deviatoric stress increments scaled up. Finally, if an isotropic material is much stiffer than its neighbors, all of that material's stress increments can be scaled down.

Scaling a stress increment up or down is akin to using scaled moduli in a model problem. It should be noted that this is only precisely true for the case in which the true material response is linear. For the case of nonlinear materials, the effective scaled moduli are based solely on the difference between the unscaled stresses and the reference stresses. As a result, these effective scaled moduli vary over the course of model problem and core solver iterations. Nevertheless, the control stiffness algorithms are completely general and do not rely on linearity in the true material response.

The degree to which components of a material's response are softened or stiffened to achieve overall minimum computational time is problem dependent and involves a trade-off between the difficulty of solving a model problem and the number of model problems that must be used to achieve the final solution.

For example, consider a nearly incompressible material, such as rubber, for which the model problem solution may be optimized by scaling the bulk and shear behaviors such that the effective tangent response has a bulk modulus that is equal to twice its shear modulus. Adjusting the ratio between the bulk and shear moduli in this manner may minimize the core solver iterations for a given model problem. However, because of the inherently large difference between these two moduli in this material, significant bulk and/or shear scaling would be required to achieve these optimal scaled moduli. Such severe scaling could result in a large number of model problems to achieve the true material response. Choosing less severe scalings (scalings closer to 1), on the other hand,

could result in more core solver iterations in each model problem, but fewer model problems to arrive at the true material response.

Experience has shown that once nearly optimal scaling values have been determined for a class of problems, these can be applied successfully to families of problems with similar characteristics.

A partial explanation of scaling the material response will be given for a simple scalar relation between stress and strain. For example, the true pressure-volume relation for a nearly incompressible material is a scalar relation between pressure and volumetric strain. Appropriate generalizations of the softening and stiffening algorithms to tensor relations are easily achieved by applying the same algorithms for all of the stress quantities individually. Only the calculation of the appropriate error measures is modified to deal with the tensorial nature of the stress-strain response that is being scaled.

There are two strain and three stress quantities of interest in the control stiffness algorithm. The stress quantities are the unscaled stress calculated by the unmodified material model, the scaled stress used for equilibrium evaluation, and a reference stress used to build up stresses to achieve convergence such that the scaled model problem stress is nearly equal to the unscaled stress computed from the material model. The strain quantities of interest are the true strain computed from the kinematics and the strain necessary to achieve the scaled stress using the unmodified material model.

In the equations that follow, the subscripts refer to the particular model problem being solved. Let us begin with the true material response in model problem I given by

$$\sigma_I = f(e_I), \tag{3.11}$$

where σ_I is the true stress corresponding to the kinematic strain e_I determined from the nodal displacements, and $f(\cdot)$ is the function representing the constitutive response. Although the true material response has been written for the hyperelastic case employing total stress and strain quantities, the control stiffness algorithms that are being presented can be equally applied to hypoelastic models where the stress rate is written in terms of the strain rate. The important point here is that the unscaled constitutive equation is used to calculate the unscaled/true stress response. It is not necessary for that relation to be linear or for a particular formulation to be used in terms of total strains or incremental strain rates. However, it should be noted that control stiffness is set up in Adagio to work only with certain material models.

The scaled stress response to use for equilibrium evaluations in a model problem is determined as follows:

$$s_I = r_I + \lambda\left(\sigma_I - r_I\right), \tag{3.12}$$

where s_I is the scaled stress, r_I is the reference stress, and λ is the scaling factor. For softening behavior, λ is less than 1, while for stiffening behavior, it is greater than 1. As noted previously, this scaled stress is what the core solver uses for equilibrium evaluation in a given model problem. It should be noted that the core solver typically requires a number of iterations to find the scaled stress that results in equilibrium. The softening and stiffening control stiffness algorithms differ only in terms of what is used for the reference stress. The reference stress in model problem I is

given by the following:

$$r_I = \begin{cases} s_{I-1} & \lambda < 1 \quad \text{(softening)} \\ \sigma_{I-1} & \lambda > 1 \quad \text{(stiffening)} \end{cases} \tag{3.13}$$

Figures 3.5 and 3.6 provide a graphical presentation of softening the material response, and Figures 3.7 and 3.8 offer a similar presentation of stiffening the material response.



Figure 3.5: Control stiffness softening behavior in the first model problem of a time step.



Figure 3.6: Control stiffness softening behavior in the second model problem of a time step.

When equilibrium is achieved in a model problem, it is necessary to do two things. First, an error measure related to the difference between the unscaled and scaled stress must be determined. Second, the reference stress used in the scaled stress calculations must be updated. The reference



Figure 3.7: Control stiffness stiffening behavior in the first model problem of a time step.

stresses are updated according to Equation (3.13). That is, for the case of softening the material response, the reference stress is updated for the next model problem to be the scaled stress that achieved equilibrium in the current model problem. On the other hand, for the case of stiffening the material response, the reference stress is updated for the next model problem to be the true stress at the end of the current model problem.

The control stiffness updating process is converged when the scaled and unscaled stresses differ by an acceptably small amount. Several different error measures can be used to determine the degree to which the scaled and unscaled stresses differ. These can be categorized into two types: those that consider stress errors, and those that consider strain errors.

The stress convergence measures consider consider the difference between the scaled stress and the unscaled stress. The first of these stress error measures involves taking the L^2 norm of the stress difference:

$$error_I = \|s_I - \sigma_I\|_2 \,. \tag{3.14}$$

A second stress error measure involves normalizing that quantity:

$$error_I = \frac{\|s_I - \sigma_I\|_2}{\|s_I\|_2} \,. \tag{3.15}$$

The strain error convergence measure is based on a strain quantity E_I that is computed as the difference between the scaled stress and the unscaled stress and dividing that value by a modulus:

$$E_I = \frac{|s_I - \sigma_I|}{M} \,, \tag{3.16}$$

where M is an appropriate material modulus that is used to represent the unscaled constitutive response. For the case where the true material response is linear and the scaled stress is computed by stiffening the material response, E_I as defined by Equation (3.16) corresponds exactly to the



Figure 3.8: Control stiffness stiffening behavior in the second model problem of a time step.

difference between the kinematic strain e_I and the strain ε_I needed in the unscaled constitutive equation to give the scaled stress:

$$\varepsilon_I = f^{-1}(s_I) = s_I/M, \tag{3.17}$$

where M would be the real material modulus. Nevertheless, Equation (3.16) is not dependent upon linear behavior, and it can be used in both softening and stiffening types of control stiffness scaling. The strain error quantity used to check convergence is computed by taking a global maximum (an L^∞ norm) as follows:

$$error_I = \left\| \frac{E_I}{E_{ref}} \right\|_\infty, \tag{3.18}$$

where E_{ref} is a reference strain specified in the input parameters for the material whose response is being scaled.

In summary, the user may specify error tolerances to determine convergence of the sequence of model problems solved in the control stiffness algorithm by using one of the error measures defined by Equations (3.14), (3.15), or (3.18). If the user so chooses, error tolerances corresponding to both Equations (3.14) and (3.15) can be specified, and convergence is considered whenever either tolerance is met. Because L^2 norms are computed by summing over all the elements in a mesh, users are cautioned that the tolerance used with Equation (3.14) to achieve a given level of control stiffness convergence is mesh dependent. That is, as the number of elements greatly increases, the L^2 norm of Equation (3.14) naturally increases. In most cases, the relative strain error given in Equation (3.18) is the preferred error measure. In addition to the error measures defined by Equations (3.14), (3.15), or (3.18), it is necessary to determine whether equilibrium is still achieved once the reference stresses have been updated. That is, equilibrium is re-evaluated with σ_{I+1} and s_{I+1} calculated without any additional changes to the fundamental nodal degrees of freedom such that

$$\sigma_{I+1} = \sigma_I \tag{3.19}$$

and

$$s_{I+1} = r_{I+1} + \lambda \left(\sigma_{I+1} - r_{I+1} \right). \tag{3.20}$$

If convergence is achieved both for the difference between the scaled stress and the unscaled stress (either as a direct measure or as a strain error) and for the updated equilibrium evaluation, the time step is considered complete. Note that if control contact is also active, it is necessary that the appropriate contact convergence checks be satisfied as well.

Figure 3.9 shows an example of a linear material that has been softened through control stiffness. In this example, the time step is considered converged immediately after the second model problem update. The third model problem involved no iterations and is thus simply a re-evaluation of equilibrium and control stiffness convergence after the reference stress is updated following the second model problem.



Figure 3.9: Control stiffness softening behavior convergence is achieved after solving two model problems.

The command block for control stiffness is as follows:

```
BEGIN CONTROL STIFFNESS [<string>stiffness_name]
  #
  # convergence commands
  TARGET <string>RESIDUAL|AXIAL FORCE INCREMENT|
    PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
    = <real>target [DURING <string list>period_names]
  TARGET RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
    PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT|
    STRAIN INCREMENT
    = <real>target_rel [DURING <string list>period_names]
  ACCEPTABLE <string>RESIDUAL|AXIAL FORCE INCREMENT|
    PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
```

```
    = <real>accept [DURING <string list>period_names]
  ACCEPTABLE RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
    PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT|
    STRAIN INCREMENT
    = <real>accept_rel [DURING <string list>period_names]
  REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
    [DURING <string list>period_names]
  MINIMUM ITERATIONS  = <integer>min_iter(0)
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS  = <integer>max_iter
    [DURING <string list>period_names]
  #
  # level selection command
  LEVEL = <integer>stiffness_level
  #
  # diagnostic output commands
  ITERATION PLOT = <integer>iter_plot
    [DURING <string list>period_names]
  ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
END [CONTROL STIFFNESS <string>stiffness_name]
```

To enable control stiffness, a `CONTROL STIFFNESS` command block must exist in the `MULTILEVEL SOLVER` command block. The command lines within the `CONTROL STIFFNESS` command block are used to control convergence during the control stiffness updates, select the level for control stiffness within the multilevel solver, and output diagnostic information. These command lines are described in detail in Sections 3.6.1 through 3.6.3.

3.6.1 Convergence Commands

The command lines listed in this section are placed in the `CONTROL STIFFNESS` command block to control convergence criteria for stiffness control within the multilevel solver.

```
TARGET <string>RESIDUAL|AXIAL FORCE INCREMENT|
  PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
  = <real>target [DURING <string list>period_names]
TARGET RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
  PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT|
  STRAIN INCREMENT
  = <real>target_rel [DURING <string list>period_names]
ACCEPTABLE <string>RESIDUAL|AXIAL FORCE INCREMENT|
  PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
  = <real>accept [DURING <string list>period_names]
ACCEPTABLE RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
  PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT|
  STRAIN INCREMENT
  = <real>accept_rel [DURING <string list>period_names]
```

```
REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
  [DURING <string list>period_names]
MINIMUM ITERATIONS = <integer>min_iter(0)
  [DURING <string list>period_names]
MAXIMUM ITERATIONS = <integer>max_iter
  [DURING <string list>period_names]
```

Convergence for problems using control stiffness requires that two criteria be met. The first criterion is that equilibrium must be achieved. The second criterion is that the scaled stress used for equilibrium must be close enough to the unscaled stress that is determined with the unmodified material model as calculated from either Equation (3.14), (3.15), or (3.18).

The command lines listed above for the equilibrium evaluation are similar to those used for the core CG solver, and have similar meaning. Here, however, the command lines are applied as part of determining convergence for the control stiffness series of model problems. Note that some of the command lines have multiple options, e.g., the command line beginning with `TARGET` has five options. This practice has been used for the command lines beginning with `TARGET`, `TARGET RELATIVE`. `ACCEPTABLE`, and `ACCEPTABLE RELATIVE`. Note also that all of these command lines can be appended with the `DURING` specification, as discussed in Section 3.1.1.

Convergence of equilibrium using scaled stresses is measured by computing the L^2 norm of the residual, and comparing that residual norm with target convergence criteria specified by the user. Convergence can be monitored either directly in terms of the residual norm, or in terms of a relative residual, which is the residual norm divided by a reference quantity that is indicative of the current loading conditions on a model. Either the residual, the relative residual, or both of these can be used for checking convergence at the same time. The `TARGET RESIDUAL` command line specifies the target convergence criterion in terms of the actual residual norm. The `TARGET RELATIVE RESIDUAL` command line specifies a convergence criterion in terms of the relative residual. If both absolute and relative criteria are specified for the residual calculation, the equilibrium is accepted if either criterion is met.

The multilevel solver also allows acceptable convergence criteria to be input for residual convergence. If the solution has not converged to the specified targets before the maximum number of iterations is reached, the residual is checked against the acceptable convergence criteria. These criteria are specified via the `ACCEPTABLE RESIDUAL` and `ACCEPTABLE RELATIVE RESIDUAL` command lines. The concepts of absolute and relative values are the same here as discussed for the target limits.

If relative residuals are given in the convergence criteria, the `REFERENCE` command line can be used to select the method for computing the reference load. This command line has three options: `EXTERNAL`, `INTERNAL`, and `RESIDUAL`. With the `EXTERNAL` option, which is the default, the reference is computed by taking the L^2 norm of the current external load. The `INTERNAL` option uses the norm of the internal forces as the reference load. Finally, the `RESIDUAL` option denotes that the initial residual should be used as the reference quantity.

For control stiffness, unlike other controls, the convergence of the series of model problems to obtain the final solution for a time step is also based on other criteria that measure how far apart the scaled and unscaled stress responses are from each other. Either a direct error measure of the

difference of the scaled and unscaled stress is used or a relative strain error computed using the difference between the scaled and unscaled stress and a representative modulus is employed.

There are a number of variants of the `TARGET` command that can be used for the direct stress differences. The `TARGET AXIAL FORCE INCREMENT` command is used to base convergence on the increment of axial force in fiber membrane elements in an update. The `TARGET PRESSURE INCREMENT` and `TARGET SDEV INCREMENT` commands are used to specify convergence for nearly incompressible materials based on the pressure and deviatoric stress increments, respectively. Also, `TARGET STRESS INCREMENT` is used to base convergence on the stress increment for materials which have their entire behavior softened as part of a control stiffness approach. If desired, the `RELATIVE` form of these convergence criteria can be used. If the `TARGET RELATIVE STRAIN INCREMENT` command is specified, the strain error measure between the scaled and unscaled stress will be computed and used.

Any combination of these criteria can be specified. If more than one is specified, all of the criteria must be satisfied. However, each material block contributes either to the direct stress error measures or to the relative strain error measure. If a material block specifies a positive non-zero `REFERENCE STRAIN` in its definition, it will contribute to the relative strain error measure. Otherwise, it will contribute to the direct stress error measures. Finally, acceptable convergence criteria can be input for converging the difference between the scaled and unscaled stress. If the solution has not met the target criteria for equilibrium and the difference between the scaled and unscaled stresses, but meets the acceptable criteria, it is allowed to proceed to the next time step.

The `MAXIMUM ITERATIONS` and `MINIMUM ITERATIONS` command lines specify the maximum and minimum number of control stiffness updates, respectively. The default minimum number of iterations, `min_iter`, is 0. If a number greater than 0 is specified for `min_iter`, the multilevel solver will update stiffness at least that many times, regardless of whether the convergence criteria have been met.

3.6.2 Level Selection Command

```
LEVEL = <integer>stiffness_level
```

The `LEVEL` command line in the `CONTROL STIFFNESS` command block is used to specify the level in the multilevel solver at which stiffness is controlled. The `stiffness_level` parameter can have a value of either 1 or 2, with 1 being the default.

This command is used when multiple controls (i.e. control contact and control stiffness) are active in the multilevel solver. It is permissible for multiple controls to exist at a given level. The default behavior is for all controls to be at level 1. To have a control at level 2, another control must be active at level 1 because a level in the multilevel solver cannot be skipped. The level of other controls is specified using the `LEVEL` command line in the command blocks associated with those controls.

3.6.3 Diagnostic Output Commands

```
ITERATION PLOT = <integer>iter_plot
  [DURING <string list>period_names]
ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
```

The command lines listed above can be used to control the output of diagnostic information from the stiffness control within the multilevel solver. The `ITERATION PLOT` command line allows plots of the current state of the model to be written to the output database during the stiffness control updates. The value supplied in `iter_plot` specifies the frequency of such plots. The default behavior is not to produce such plots. The plots are generated with a fictitious time step. Every time such a plot is generated, a message is sent to the log file. This feature is useful for debugging, but it should be used with care. Note that the `ITERATION PLOT` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

The output produced by iteration plots is sent by default to every active results output file, as specified by a `RESULTS OUTPUT` command block. The `ITERATION PLOT OUTPUT BLOCKS` command line can optionally be used to supply a list of output block names to which iteration plots should be written. Each of the output block names listed in `plot_blocks`, must match the name of a `RESULTS OUTPUT` command block (see Section 8.1.1). The `ITERATION PLOT OUTPUT BLOCKS` command line can be useful for directing iteration plots to separate output files so that these plots are separated from the converged solution output. It can also be used to send output plots for different levels of the multilevel solver to different files.

3.7 Control Modes

The core conjugate gradient solution algorithm used by Adagio typically works very well on "blocky" problems if the nodal preconditioners are used. As the aspect ratios of the structures modeled increase, however, the performance of the CG solver begins to degrade. Because of their lack of coupling terms, the nodal preconditioners only allow for the effects of the residual to be propagated across a single element during an iteration. Consequently, these preconditioners are effective at minimizing high frequency error, but may require many iterations to solve for the low frequency, structural bending modes in slender structures.

The full tangent preconditioners provided by Adagio greatly improve the effectiveness of the CG algorithm for solving models with slender members. However, the memory usage requirements and the computational effort needed to factorize matrices with the full tangent preconditioners can sometimes be significant.

In addition to its other solution strategies, Adagio provides a multigrid solution method within the CG algorithm. This method, known as control modes, greatly increases the effectiveness of the CG algorithm for solving slender, bending-dominated problems. In addition to the actual mesh of the model to be solved, referred to as the "reference mesh," control modes uses a coarse mesh of the model, known as a "constraint mesh," to solve for the low-frequency response. To use control modes, the user must supply both the reference mesh and the constraint mesh. While it does require some additional effort to generate a suitable coarse mesh, control modes provides very efficient solutions with only slightly higher memory usage than would be required by the standard CG solver with a nodal preconditioner.

Control modes functions somewhat like another level in the multilevel solver, although it does not appear as a control type in the `MULTILEVEL SOLVER` command block. The CG algorithm operates alternately on the residual on the coarse mesh and the fine mesh. The coarse residual is computed by performing a restriction operation from the fine mesh to the coarse mesh using the shape functions of the coarse elements. The CG solver is used to minimize the coarse residual until convergence is reached, at which point it switches to operate on the fine mesh to minimize that residual. The fine mesh iterations continue until either the fine mesh has converged or the fine residual is 50% of the coarse residual. The solver alternates between the fine and coarse meshes until convergence is obtained on both meshes.

To use control modes, the user should set up the mesh file and the input file as usual, except that the following additional items must be provided:

- A constraint mesh must be generated. The constraint mesh must be in a separate file from the reference mesh, which is the real model. The constraint mesh should be a coarse representation of the reference mesh. If there are node sets or side sets in the reference mesh that are used to prescribe kinematic boundary conditions, similar mesh entities should be provided in the coarse mesh to prescribe similar boundary conditions.

- A second `FINITE ELEMENT MODEL` command block must be provided in addition to the standard definition for the reference finite element model in the input file. This command block is set up exactly as it normally would be (see Section 5.1), except that the mesh file

referenced is the constraint mesh instead of the reference mesh. Although the constraint mesh is used purely as a solution tool, and does not use any finite elements or material models, each block in the constraint mesh must still be assigned a material model.

- A `CONTROL MODES REGION` command block must appear alongside the standard `ADAGIO REGION` command block within the `ADAGIO PROCEDURE` command block. The presence of the `CONTROL MODES REGION` command block instructs the CG solver to use the control modes logic. There are no commands within the CG solver for the region associated with the reference mesh related to control modes. The `CONTROL MODES REGION` command block is documented in Section 3.7.1. It contains the same commands used within the standard `ADAGIO REGION` command block, except that the commands in the `CONTROL MODES REGION` command block are used to control the control modes algorithm and the boundary conditions on the coarse mesh.

3.7.1 Control Modes Region

```
BEGIN CONTROL MODES REGION
  #
  # model setup
  USE FINITE ELEMENT MODEL <string>model_name
  CONTROL BLOCKS = <string list>control_blocks
  #
  # solver commands
  BEGIN LOADSTEP PREDICTOR
    #
    # Parameters for loadstep predictor
    #
  END [LOADSTEP PREDICTOR]
  BEGIN CG
    #
    # Parameters for CG
    #
  END [CG]
  JAS MODE
  #
  # kinematic boundary condition commands
  BEGIN FIXED DISPLACEMENT
    #
    # Parameters for fixed displacement
    #
  END [FIXED DISPLACEMENT]
  BEGIN PERIODIC
    #
    # Parameters for periodic
    #
  END [PERIODIC]
```

```
END [CONTROL MODES REGION]
```

The CONTROL MODES REGION command block controls the behavior of the control modes algorithm, and is placed alongside a standard ADAGIO REGION command block within the ADAGIO PROCEDURE scope. With the exception of the CONTROL BLOCKS command line, all the commands that can be used in this block are standard commands that appear in the Adagio region. These commands have the same meaning in either context; they simply apply to the constraint mesh or to the reference mesh, depending on the region block in which they appear. Sections 3.7.1.1 through 3.7.1.3 describe the components of the CONTROL MODES REGION command block.

3.7.1.1 Model Setup Commands

```
USE FINITE ELEMENT MODEL <string>model_name
CONTROL BLOCKS = <string list>control_blocks
```

The command lines listed above must appear in the CONTROL MODES REGION command block if control modes is used. The USE FINITE ELEMENT MODEL command line should reference the finite element model for the constraint mesh. This command line is used in the same way that the command line is used for the reference mesh (see Section 2.3).

The CONTROL BLOCKS command line provides a list of blocks in the reference mesh that will be controlled by the constraint mesh in the solver. The block names are listed using the standard method of referencing mesh entities (see Section 1.5). For example, the block with an ID of 1 would be listed as block_1 in this command. Multiple CONTROL BLOCKS command lines may appear to specify a long list of blocks over several lines.

3.7.1.2 Solver Commands

```
BEGIN LOADSTEP PREDICTOR
  #
  # Parameters for loadstep predictor
  #
END [LOADSTEP PREDICTOR]
BEGIN CG
  #
  # Parameters for CG
  #
END [CG]
JAS MODE
```

The constraint mesh must have solver parameters defined using the LOADSTEP PREDICTOR and CG command blocks. The constraint mesh does not have material properties or contact, so the CG command block is used to define the solver on the constraint mesh. The multilevel solver is not used on the constraint mesh, even though the multilevel solver may be used on the reference mesh.

All the command lines that appear in these command blocks in a standard analysis can be used for the parameters of the solver on the constraint mesh. Refer to Section 3.8.1 for a description of the command lines for the load step predictor and to Section 3.1 for a description of the CG solver commands.

The full set of preconditioners that are available on the reference mesh are also available for the constraint mesh. The full tangent preconditioner can be used on the constraint mesh, and provides a very powerful solution strategy. Because the constraint mesh is typically very small compared to the reference mesh, forming and factorizing matrices for the constraint mesh typically requires small computational resources.

The `JAS MODE` command line enables complete compatibility with the JAS3D legacy code. If this mode of operation is desired, the `JAS MODE` command line must be present in both the `CONTROL MODES REGION` command block and the `ADAGIO REGION` command block. See Section 3.9 for more information on this command line.

3.7.1.3 Kinematic Boundary Condition Commands

```
BEGIN FIXED DISPLACEMENT
  #
  # Parameters for fixed displacement
  #
END [FIXED DISPLACEMENT]
BEGIN PERIODIC
  #
  # Parameters for periodic
  #
END [PERIODIC]
```

For the solver to converge well, it is often important to create a node set or a side set on the coarse mesh that coincides geometrically with a node set or a side set on the fine mesh to which a fixed boundary condition is applied. This should be done for fixed boundary conditions, but not for boundary conditions with prescribed nonzero displacements. Any of the kinematic boundary condition command blocks that can appear in a standard Adagio region can also appear in the `CONTROL MODES REGION` command block. However, it is recommended that only `FIXED DISPLACEMENT` and `PERIODIC` boundary conditions be used on the constraint mesh.

The boundary conditions are applied to the specified mesh entities on the constraint mesh. The constraint mesh and the reference mesh can have a node set or a side set with the same identifier. The determination of which entity should be affected by the boundary condition is based on the context of the boundary condition specified. See Section 6.3.1 for details on the `FIXED DISPLACEMENT` command block.

3.8 Predictors

Predictors are an important component of Adagio's nonlinear solution strategy. A predictor is used to generate an initial trial solution for a load step or for a multilevel solver model problem. The goal of the predictor is to generate a trial solution that is as close as possible to the actual converged solution. A good prediction that gives a trial solution close to the actual solution can dramatically reduce the number of iterations required for convergence.

There are two types of predictors used in Adagio: the load step predictor and the level 1 predictor. The load step predictor, documented in Section 3.8.1, estimates a solution at the beginning of a new load step, and is applicable to all types of models. The level 1 predictor estimates the solution at the beginning of a new level 1 model problem in the multilevel solver. This predictor type, documented in Section 3.4.1, is only applicable for the multilevel solver.

3.8.1 Loadstep Predictor

```
BEGIN LOADSTEP PREDICTOR
  TYPE = <string>SCALE_FACTOR|SECANT|EXTERNAL|EXTERNAL_FIRST
    (SECANT)
  SCALE FACTOR = <real>scale_factor(1.0)
    [<real>first_scale_factor]
    [DURING <string list>period_names]
  SLIP SCALE FACTOR = <real>slip_factor(1.0)
    [DURING <string list>period_names]
END [LOADSTEP PREDICTOR]
```

The `LOADSTEP PREDICTOR` command block controls the behavior of the predictor that is used to predict the solution at the beginning of a new load step. This command block is placed in the `ADAGIO REGION` scope.

3.8.1.1 Predictor Type

```
TYPE = <string>SCALE_FACTOR|SECANT|EXTERNAL|EXTERNAL_FIRST
  (SECANT)
```

There are several types of load step predictors available in Adagio that are suitable for different types of analysis. The predictor type is selected using the `TYPE` command line in the `LOADSTEP PREDICTOR` command block.

- The scale factor predictor is selected with the `SCALE_FACTOR` option. This type of predictor extrapolates from the solution of the previous time step using the velocity field from that step, multiplied by a scale factor, to obtain a trial solution. The actual scale factor that is applied can be controlled with the `SCALE FACTOR` command line, which also appears in the `LOADSTEP PREDICTOR` command block. This type of predictor works well with models that have smoothly varying loads.

- The secant predictor is selected with the SECANT option, which is useful for scenarios in which the loading may not be monotonic. This type of predictor uses a line search to compute an optimal scaling factor for use in extrapolating from the previous solution. This type of predictor is the default, and provides good performance without requiring user intervention to select appropriate scale factors.

- The external predictor is selected with the EXTERNAL option. This type of predictor uses the solution from a file to predict the solution at new load steps. Re-using the work done in previous solutions of similar problems can be very helpful. Using this type of predictor requires that the input mesh file be a results file that contains displacement data.

- The EXTERNAL_FIRST option is used to select a special type of predictor that (1) uses the external predictor for the first load step of the solution period and (2) thereafter uses the scale factor predictor for every other load step in the solution period. If this option is chosen, the SCALE FACTOR command line must be included in the LOADSTEP PREDICTOR command block.

3.8.1.2 Scale Factor

```
SCALE FACTOR = <real>scale_factor(1.0)
  [<real>first_scale_factor]
  [DURING <string list>period_names]
```

The SCALE FACTOR command controls the behavior of the SCALE_FACTOR predictor type (and the EXTERNAL_FIRST predictor type in all load steps except the first in a time period). The velocity field of the previous step, multiplied by the value of scale_factor, is used to extrapolate from the previous solution to obtain a trial solution. The default value of 1.0 provides good performance on models that experience smooth loading. Setting the value of scale_factor to 0.0 may improve the convergence of models with discontinuous loading.

The optional first_scale_factor parameter is used as the scale factor for the first step of a time period. If first_scale_factor is omitted, the default behavior is to use scale_factor for all time steps. Models are often subjected to loading that is mostly monotonic, but with discontinuities at the beginning of a new period. Using 1.0 and 0.0 for the values of scale_factor and first_scale_factor, respectively, often gives good performance in such cases.

The SCALE FACTOR command line can be appended with the DURING specification, as discussed in Section 3.1.1.

3.8.1.3 Slip Scale Factor

```
SLIP SCALE FACTOR = <real>slip_factor(1.0)
  [DURING <string list>period_names]
```

The prediction of slip on slave nodes that are currently active in sliding contact can be controlled separately from other nodes in the model by using the SLIP SCALE FACTOR command

line. The parameter `slip_factor` controls the scaling of the predicted slip on these nodes. If `slip_factor` is left at its default value of 1.0, contact slip will be predicted using the same scale factor used for the rest of the model. If the value of `slip_factor` is set to 0.0, the predicted solution will not allow any sliding contact nodes to slip. This command line applies to both the `SCALE_FACTOR` and the `SECANT` types of predictors.

The `SLIP SCALE FACTOR` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.9 JAS3D Compatibility Mode

Adagio's multilevel solver and CG solver are based on the solver used in the legacy JAS3D code [1]. While the solvers in the two codes are very similar, there are some minor implementation differences between the two codes.

```
JAS MODE
```

Adagio provides an option, selectable by inserting the `JAS MODE` command line in the `ADAGIO REGION` command block, to make it use exactly the same algorithms as the JAS3D solver. If control modes is being used, the `JAS MODE` command line must appear both in the `ADAGIO REGION` and in the `CONTROL MODES REGION` command blocks (see Section 3.7.1.2). This option is primarily useful for migrating analyses previously done in JAS3D to Adagio.

The `JAS MODE` command line enables the following behavior:

- Adagio's CG solver and multilevel solver use exactly the same algorithms. There are a number of algorithmic decisions in the solver that were made one way in JAS3D and another way in Adagio. While both methods are valid, the `JAS MODE` command line forces the code to always use the exact JAS3D algorithms.
- Adagio uses the Legacy Contact library instead of the internal Adagio and ACME code for contact search and enforcement. The Legacy Contact library is the same contact code that is used in JAS3D, so contact in Adagio models behaves the same as it would if it was run in JAS3D if this option is chosen.
- The log file output produced by Adagio is formatted in the same manner as JAS3D formats log files, thus facilitating comparisons between the output from JAS3D and Adagio models.

Note that the `JAS MODE` command line only ensures JAS3D compatibility for features that are available in JAS3D. Advanced features such as the full tangent preconditioner are not available in JAS3D. It should also be noted that for those interested in converting JAS3D input files to Adagio input files, there is a program available for this purpose. For more information on this converter program, refer to the Adagio web page or contact an Adagio developer.

3.10 Time Step Control

Time stepping in Adagio is controlled by using a `TIME CONTROL` command block in the procedure scope. In this command block, the user controls the start time, the termination time, and the method by which time is advanced during the analysis. The analysis time can optionally be subdivided into a number of time periods. If the analysis is from time 0 to time T and it is split into three periods, the first period is defined from time 0 to time t_1, the second period is defined from time t_1 to time t_2, and the third period is defined from time t_2 to time T. (The times t_1 and t_2 are set by the user.) The sum of the times for the three periods is T.

There are many reasons for splitting an analysis into multiple time periods. It is usually desirable to start time periods when a change in the model or in the loading conditions occurs that is significant enough to warrant switching to a different set of solver parameters or boundary conditions. Many of Adagio's features can be toggled on or off or changed during different time periods. For example, boundary conditions and contact can be activated during certain time periods. Similarly, many solution parameters can change based on the time period.

Time stepping can be uniform during a solution period, or it can vary during a solution period by using a function to control the time step as a function of analysis time. In Adagio, an automatic time stepping scheme can also be used to automatically take larger time steps at points in the analysis when the solution is relatively easy, and take smaller time steps when it becomes more difficult to solve a time step.

A description of the `TIME CONTROL` command block follows in Section 3.10.1. Section 3.10.2 describes the `ADAPTIVE TIME STEPPING` command block, which allows the user to adapt the size of the time step based on solution difficulty. A simple example of a `TIME CONTROL` command block is presented in Section 3.10.3.

3.10.1 Command Blocks for Time Control and Time Stepping

```
BEGIN TIME CONTROL
  BEGIN TIME STEPPING BLOCK <string>time_block_name
    START TIME = <real>start_time_value
    BEGIN PARAMETERS FOR ADAGIO REGION <string>region_name
      #
      # Time control parameters specific to ADAGIO
      # are set in this command block.
      #
    END [PARAMETERS FOR ADAGIO REGION <string>region_name]
  END [TIME STEPPING BLOCK <string>time_block_name]
  TERMINATION TIME = <real>termination_time
END [TIME CONTROL]
```

Adagio time control resides in a `TIME CONTROL` command block. The command block begins with the input line

```
BEGIN TIME CONTROL
```

and terminates an input line of the following form:

```
END [TIME CONTROL]
```

An arbitrary number of TIME STEPPING BLOCK command blocks can be present to define individual time stepping periods within the TIME CONTROL command block. Each TIME STEPPING BLOCK command block contains the time at which the time stepping starts and a number of parameters that set time-related values for the analysis. Each time period terminates at the start time of the following time period. The start times for the TIME STEPPING BLOCK command blocks must appear in increasing order or an error message will result. The example in Section 3.10.3 shows the overall structure of the TIME CONTROL command block.

In the above input lines, the parameters are as follows:

- The string time_block_name is a name for the time period. Every time period must have a unique name. These names are referenced to control solution parameters or to activate/deactivate functionality.

- The real value start_time_value is the start time for this TIME STEPPING BLOCK command block. A time period goes from its start time until the start time of the next period or the termination time.

- The string region_name is the name of the Adagio region affected by the parameters (see Section 2.2).

The final termination time for the analysis is given by the following command line:

```
TERMINATION TIME = <real>termination_time
```

Here, termination_time is the time at which the analysis will stop. The TERMINATION TIME command line appears inside the TIME CONTROL command block but outside of any TIME STEPPING BLOCK command block.

The TERMINATION TIME command line can appear before the first TIME STEPPING BLOCK command block or after the last TIME STEPPING BLOCK command block. Note that it is permissible to have TIME STEPPING BLOCK command blocks with start times greater than the termination time; in this case, those command blocks that have start times after the termination time are not executed. Only one TERMINATION TIME command line can appear in the TIME CONTROL command block. If more than one of these command lines appears, Adagio gives an error.

Nested inside the TIME STEPPING BLOCK command block is a PARAMETERS FOR ADAGIO REGION command block containing parameters that control the time stepping.

```
BEGIN PARAMETERS FOR ADAGIO REGION <string>region_name
  TIME INCREMENT = <real>time_increment_value
  NUMBER OF TIME STEPS = <integer>nsteps
  TIME INCREMENT FUNCTION = <string>time_function
END [PARAMETERS FOR ADAGIO REGION <string>region_name]
```

These parameters are specific to an Adagio analysis.

The command block begins with an input line of the form

```
BEGIN PARAMETERS FOR ADAGIO REGION <string>region_name
```

and is terminated with an input line of the following form:

```
END [PARAMETERS FOR ADAGIO REGION <string>region_name]
```

As noted previously, the string `region_name` is the name of the Adagio region to which the parameters apply. The command lines nested inside the `PARAMETERS FOR ADAGIO REGION` command block are used to control the way time stepping occurs, and are described in Sections 3.10.1.1 through 3.10.1.3. Only one of these command lines (`TIME INCREMENT`, `NUMBER OF TIME STEPS`, or `TIME INCREMENT FUNCTION`) may be used in a given time period.

3.10.1.1 Time Increment

```
TIME INCREMENT = <real>time_increment_value
```

The `TIME INCREMENT` command line directly specifies the size of a uniform time step that will be used during a time period. The size of the time step is specified with the parameter `time_increment_value`.

3.10.1.2 Number of Time Steps

```
NUMBER OF TIME STEPS = <integer>nsteps
```

The `NUMBER OF TIME STEPS` command line specifies the number of uniform time steps that will be used during a time period. The number of time steps is specified with the parameter `nsteps`. If this command line is used, the time step size is computed by dividing the length of the time period by the specified number of time steps.

3.10.1.3 Time Increment Function

```
TIME INCREMENT FUNCTION = <string>time_function
```

The `TIME INCREMENT FUNCTION` command line allows the time step to be specified as a function of analysis time. The function used to control the time step is referenced by the parameter `time_function`. The actual function is defined within a `DEFINITION FOR FUNCTION` command block within the domain scope. It is often convenient to use a function of the `PIECEWISE CONSTANT` type (see Section 2.1.5) with this command line. Using a function to control time incrementation allows for the time increment to be conveniently switched many times during an analysis without creating a new time block every time the time increment needs to be changed.

3.10.2 Adaptive Time Stepping

```
BEGIN ADAPTIVE TIME STEPPING
  CUTBACK FACTOR = <real>cutback_factor(0.5)
    [DURING <string list>period_names]
  GROWTH FACTOR = <real>growth_factor(1.5)
    [DURING <string list>period_names]
  MAXIMUM FAILURE CUTBACKS = <integer>max_cutbacks(5)
    [DURING <string list>period_names]
  MAXIMUM MULTIPLIER = <real>max_multiplier
    [DURING <string list>period_names]
  MINIMUM MULTIPLIER = <real>min_multiplier
    [DURING <string list>period_names]
  ACTIVE PERIODS = <string list>period_names
END [ADAPTIVE TIME STEPPING]
```

Adagio has the capability to adapt the time step size during an analysis based on solution difficulty. This capability is enabled by inserting an `ADAPTIVE TIME STEPPING` command block in the region scope. If this command block is not present in the Adagio region, the time stepping specified in the `TIME CONTROL` command block will be used. In addition to adjusting the size of time steps as the analysis proceeds, the adaptive time stepping algorithm can attempt to solve a load step by using a smaller time step if a solution fails to converge.

The adaptive time stepping algorithm works by computing a multiplier that is applied to the time step specified in the `TIME CONTROL` command block. Thus, even if adaptive time stepping is used, the time step must be specified for all loading periods in the `TIME CONTROL` command block. For the initial load step in each solution period, Adagio always uses the prescribed time step. In subsequent steps, the adaptive time stepping algorithm computes a factor that is multiplied by the prescribed time step to adjust the time step based on solution difficulty.

The command lines nested within the `ADAPTIVE TIME STEPPING` command are used to control the behavior of this feature and are described in Sections 3.10.2.1 through 3.10.2.6.

Many of these command lines can optionally be set for a specific time period. To set a parameter for a specific time period, the user can append the `DURING` keyword followed by a list of applicable period names to a command line (see Section 3.1.1. Multiple instances of these command lines can exist to set the parameter differently for different periods. If a command line is not appended with the `DURING` specification, it is used to set the default behavior for all time periods. Setting a default in this way does not preclude setting a period-specific value for that parameter with another instance of the same command line.

3.10.2.1 Cutback Factor

```
CUTBACK FACTOR = <real>cutback_factor(0.5)
  [DURING <string list>period_names]
```

The `CUTBACK FACTOR` command line controls the amount by which the next time step is reduced

if the solution is difficult. The parameter `cutback_factor`, which has a default value of 0.5, specifies the multiplier that is applied to the current time step with each cutback. The parameter also controls the amount that the current time step is cut back if a solution fails. Note that the `CUTBACK FACTOR` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.10.2.2 Growth Factor

```
GROWTH FACTOR = <real>growth_factor(1.5)
  [DURING <string list>period_names]
```

The `GROWTH FACTOR` command line controls the amount by which the next time step is increased if the solution is easy. The parameter `growth_factor`, which has a default value of 0.5, specifies the multiplier that is applied to the current time step each time the time step is increased. Note that the `GROWTH FACTOR` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.10.2.3 Maximum Failure Cutbacks

```
MAXIMUM FAILURE CUTBACKS = <integer>max_cutbacks(5)
  [DURING <string list>period_names]
```

The `MAXIMUM FAILURE CUTBACKS` command line controls how many cutbacks to a time step can be taken if a solution fails to converge. The The parameter `max_cutbacks` has a default value of 5 if adaptive time stepping is enabled. If an `ADAPTIVE TIME STEPPING` command block is not present, the code will exit rather than attempting to cut back in the event of an unsuccessful solution. Note that the `MAXIMUM FAILURE CUTBACKS` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.10.2.4 Maximum Multiplier

```
MAXIMUM MULTIPLIER = <real>max_multiplier
  [DURING <string list>period_names]
```

Time steps are adaptively adjusted by updating a multiplier that is applied to the base time step specified in the `TIME CONTROL` command block. By default, there are no limits on the size of this multiplier. The `MAXIMUM MULTIPLIER` command line can be used to limit the growth of the time step. The parameter `max_multiplier` specifies the upper bound for the multiplier. The largest possible time step in an analysis is the product of `max_multiplier` and the baseline time step size. This baseline size is specified in the `TIME CONTROL` command block. Note that the `MAXIMUM MULTIPLIER` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.10.2.5 Minimum Multiplier

```
MINIMUM MULTIPLIER = <real>max_multiplier
  [DURING <string list>period_names]
```

Time steps are adaptively adjusted by updating a multiplier that is applied to the base time step specified in the `TIME CONTROL` command block. By default, there are no limits on the size of this multiplier. The `MINIMUM MULTIPLIER` command line can be used to limit the shrinkage of the time step. The parameter `min_multiplier` specifies the lower bound for the multiplier. The smallest possible time step in an analysis is the product of `min_multiplier` and the baseline time step size. Note that the `MINIMUM MULTIPLIER` command line can be appended with the `DURING` specification, as discussed in Section 3.1.1.

3.10.2.6 Active Periods

```
ACTIVE PERIODS = <string list>period_names
```

Adaptive time stepping can be activated or deactivated for specific time periods with the `ACTIVE PERIODS` command line. If the `ADAPTIVE TIME STEPPING` command block is present in the standard Adagio region, it is active for all periods by default. If the `ACTIVE PERIODS` command line is present in the `ADAPTIVE TIME STEPPING` command block, adaptive time stepping is only active during the specified time periods.

3.10.3 Time Control Example

The following is a simple example of a `TIME CONTROL` command block:

```
BEGIN TIME CONTROL
  BEGIN TIME STEPPING BLOCK p1
    START TIME = 0.0
    BEGIN PARAMETERS FOR ADAGIO REGION adagio_region
      NUMBER OF TIME STEPS = 10
    END
  END
  BEGIN TIME STEPPING BLOCK p2
    START TIME = 1.0
    BEGIN PARAMETERS FOR ADAGIO REGION adagio_region
      TIME INCREMENT = 0.2
    END
  END
  TERMINATION TIME = 2.0
END
```

The first `TIME STEPPING BLOCK`, `p1`, begins at time 0.0, the initial start time, and terminates at time 1.0. The second `TIME STEPPING BLOCK`, `p2`, begins at time 1.0 and terminates at time 2.0,

the time listed on the `TERMINATION TIME` command line. The `TIME STEPPING BLOCK` names `p1` and `p2` can be referenced elsewhere to activate boundary conditions or control the solver in different ways during the two periods.

3.11 Implicit Dynamic Time Integration

Adagio has the ability to perform implicit solutions on both quasistatic and dynamic problems. In quasistatic calculations, the solution for static equilibrium is obtained at each step, ignoring the inertial terms of the equations of motion. In dynamic problems, the inertial forces are included, and the HHT time integrator [5] is used to integrate the equations of motion in time. The behavior of the HHT integrator is controlled with three parameters: α, β, and γ. With proper selection of these parameters, the HHT integrator is unconditionally stable. If $\alpha = 0$, this reduces to the Newmark method [7]. The trapezoidal rule is recovered if $\alpha = 0$, $\beta = 0.25$, and $\gamma = 0.5$. For a detailed discussion of the theory of implicit time integrators, see Reference 6.

3.11.1 Implicit Dynamics

```
BEGIN IMPLICIT DYNAMICS
  ACTIVE PERIODS = <string list>period_names
  USE HHT INTEGRATION
  ALPHA = <real>alpha(0.0) [DURING <string list>period_names]
  GAMMA = <real>beta(0.5) [DURING <string list>period_names]
  BETA = <real>beta(0.25) [DURING <string list>period_names]
  TIME INTEGRATION CONTROL = <string>ADAPTIVE|COMPUTERESIDUAL|
    IGNORE(IGNORE) [DURING <string list>period_names]
  INCREASE ERROR THRESHOLD = <real>increase_threshold(0.02)
    [DURING <string list>period_names]
  HOLD ERROR THRESHOLD = <real>hold_threshold(0.10)
    [DURING <string list>period_names]
  DECREASE ERROR THRESHOLD = <real>decrease_threshold(0.25)
    [DURING <string list>period_names]
END [IMPLICIT DYNAMICS]
```

The `IMPLICIT DYNAMICS` command block enables implicit dynamics and contains commands to control the behavior of implicit time integration. This command block is placed in the `ADAGIO REGION` command block. Note that prior versions of Adagio required an Andante region to use implicit dynamics. The Andante region has been eliminated, and this capability has all been moved to the Adagio region, which gives the analyst much more flexibility. Formerly, it was necessary to create a new procedure for switching between implicit dynamics and quasistatics in an analysis. Now, these different analysis types can all be done within a single region, and the command lines in the `IMPLICIT DYNAMICS` command block can be used to enable or disable implicit dynamics for specific time periods within a single region. Sections 3.11.1.1 through 3.11.1.4 describe the command lines in this command block.

3.11.1.1 Active Periods

```
ACTIVE PERIODS = <string list>period_names
```

Implicit dynamics can be activated or deactivated for specific time periods with the `ACTIVE PERIODS` command line. If the `IMPLICIT DYNAMICS` command block is present in the Adagio region, it is active for all periods by default. If the `ACTIVE PERIODS` command line is present in the `IMPLICIT DYNAMICS` command block, implicit dynamics is only active during the specified time periods.

3.11.1.2 Use HHT Integration

```
USE HHT INTEGRATION
```

Adagio currently only supports the HHT algorithm for implicit time integration. The `USE HHT INTEGRATION` command line is provided as a placeholder to allow for other time integrators in the future, but currently this command line has no effect.

3.11.1.3 HHT Parameters

```
ALPHA = <real>alpha(0.0) [DURING <string list>period_names]
BETA = <real>beta(0.5) [DURING <string list>period_names]
GAMMA = <real>gamma(0.25) [DURING <string list>period_names]
```

The `ALPHA`, `BETA`, and `GAMMA` command lines specify the HHT integration parameters. These parameters can all be specified for the entire analysis, or they can vary by solution period by appending them with the optional `DURING` specification (see Section 3.1.1).

- The `ALPHA` command line specifies α, which is the dissipation factor applied to the internal force vector. The value of `alpha` controls numerical damping and must always be less than or equal to zero. Its default value of 0.0 results in no numerical damping. To maintain second-order accuracy, the value of `alpha` should not be less than $-\frac{1}{3}$.
- The `GAMMA` command line specifies γ, which is the dissipation factor for Newmark time integrators. The default value of `gamma` is 0.25. It should have a value of $0.5-\alpha$ to maintain second-order accuracy.
- The `BETA` command line specifies β, which is the stability parameter for time integrators in the Newmark family. The default value of `beta` is 0.5. It should have a value of $0.25(\gamma+0.5)^2$ to maintain second-order accuracy.

3.11.1.4 Implicit Dynamic Adaptive Time Stepping

```
TIME INTEGRATION CONTROL = <string>ADAPTIVE|COMPUTERESIDUAL|
  IGNORE(IGNORE) [DURING <string list>period_names]
INCREASE ERROR THRESHOLD = <real>increase_threshold(0.02)
  [DURING <string list>period_names]
HOLD ERROR THRESHOLD = <real>hold_threshold(0.10)
```

```
  [DURING <string list>period_names]
DECREASE ERROR THRESHOLD = <real>decrease_threshold(0.25)
  [DURING <string list>period_names]
```

Adagio provides an adaptive time stepping capability that adjusts the time step based on the error due to time discretization with implicit time integration. If this capability is activated, after a solution is obtained for each time step, an interpolated solution for the half step is computed based on the assumption that acceleration is constant over the time step. The residual is computed using this interpolated solution. The residual is indicative of the error introduced due to the time step, and is used to adjust the time step. The residual is always evaluated relative to the reference load. If the residual is low, the size of the next time step is increased. If the residual is high, the size of the next time step is decreased.

The command lines for adaptive time stepping can all be optionally used in the `IMPLICIT DYNAMICS` command block. These command lines control the behavior of the implicit time integrator's algorithm for adaptive time stepping. All the parameters specified by these command lines can vary by period by appending the command lines with the optional `DURING` specification (see Section 3.1.1).

- The `TIME INTEGRATION CONTROL` command line controls whether the algorithm for adaptive time stepping should be used. Three options are available: `ADAPTIVE`, `COMPUTERESIDUAL`, and `IGNORE`. If the option is set to `ADAPTIVE`, the midstep residuals are computed and the time step is adjusted based on the residuals. If the option is set to `COMPUTERESIDUAL`, the midstep residual is computed and reported in the log file, but the time step is not adjusted. If the option is set to `IGNORE`, the default, no midstep residuals are computed, and the time step is not adjusted.

- The `INCREASE ERROR THRESHOLD` command line controls when the time step is increased. If the relative midstep residual is below the specified value, the next time step will be increased. The default value of `increase_threshold` is 0.02.

- The `HOLD ERROR THRESHOLD` command line controls when the time step is held constant. If the relative midstep residual is below the hold threshold and greater than the increase threshold, the next time step will be held constant. The default value of `hold_threshold` is 0.10, which must be greater than the value of `increase_threshold`.

- The `DECREASE ERROR THRESHOLD` command line controls when the time step is decreased. If the relative midstep residual is below the decrease threshold and greater than the hold threshold, the current time step is accepted but the next time step will be decreased. If the relative midstep residual is greater than the decrease threshold, the current solution is rejected and recomputed with a smaller time step. The default value of `decrease_threshold` is 0.25, which must be greater than `hold_threshold`.

3.12 References

1. Blanford, M. L., M. W. Heinstein, and S. W. Key. *JAS3D – A Multi-Strategy Iterative Code for Solid Mechanics Analysis Users' Instructions, Release 2.0*, Draft SAND report. Albuquerque, NM: Sandia National Laboratories, September 2001.

2. Fletcher, R., and C. M. Reeves. "Function Minimization by Conjugate Gradients." *The Computer Journal* 7 (1964): 149–154.

3. Farhat, C., M. Lesoinne, and K. Pierson. "A Scalable Dual-Primal Domain Decomposition Method." *Numerical Linear Algebra with Applications* 7 (2000): 687–714.

4. Farhat, C., M. Lesoinne, P. LeTallec, K. Pierson, and D. Rixen. "FETI-DP: A Dual-Primal Unified FETI Method – Part I: A Faster Alternative to the Two-Level FETI Method." *International Journal for Numerical Methods in Engineering* 50 (2001): 1523–1544.

5. Hilber, H. M., T. J. R. Hughes, and R. L. Taylor. "Improved Numerical Dissipation for Time Integration Algorithms in Structural Dynamics." *Earthquake Engineering and Structural Dynamics* 5 (1977): 283–292.

6. Hughes, T. J. R. *The Finite Element Method: Linear Static and Dynamic Finite Element Analysis*. Englewood Cliffs, NJ: Prentice-Hall, 1987.

7. Newmark, N. M. "A Method of Computation for Structural Dynamics." *Journal of the Engineering Mechanics Division*, ASCE 85, no. EM3 (1959): 67–94.

Chapter 4

Materials

This chapter describes material models that can be used in conjunction with the elements in Presto and Adagio. Most of the material models have an interface that allows them to be used by the elements in both codes. Even though a material model can be used by both codes, usage of the model may be better suited for the type of problems solved by one code rather than the type of problems solved by the other code. For example, a material model that was built to characterize behavior over a long time would be better suited for use in Adagio than in Presto. If a particular material model is better suited for one code rather than the other, this usage information is provided in the description of that model. Furthermore, there is a class of material models that are referred to as *equation-of-state* models. These models are designed for an explicit, transient dynamics code, and, as such are applicable only for use in Presto. Hence, descriptions of the equation-of-state models and any associated calculations that are used with these models, such as energy deposition, are included in the chapter on material models in the Presto user's guide but not in the corresponding chapter on material models of the Adagio user's guide.

The material models described in this chapter are, in general, applicable to solid elements. The structural elements, such as shells and beams, have a much more limited set of material models. You should consult with Chapter 5, which discusses the element library, to determine what material models are available for the various elements. The introduction to Chapter 5 summarizes all the element types in Presto and Adagio. For each element type, a list of available material models is provided.

When using the nonlinear material models, you may want to output state variables that are associated with these models. See Section 8.6.2 to learn how to output the state variables for the various nonlinear material models.

Most material models for solid elements are available in two libraries. The newer library is the LAME library [12], but it is not the default. The line command to activate the LAME material library for a particular section is described in Section 5.2.1.

General Model Form. `PROPERTY SPECIFICATION FOR MATERIAL` command blocks appear in the domain scope in the general form shown below.

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
```

```
    #
    # Command lines and command blocks for material
    # models appear in this scope.
    #
  END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

`PROPERTY SPECIFICATION FOR MATERIAL` command blocks are physics independent in the sense that the information in them can be shared by more than one application. For example, some of the `PROPERTY SPECIFICATION FOR MATERIAL` command blocks contain density information that can be shared among several applications.

The command block begins with an input line of the form:

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
```

and is terminated with an input line of the following form:

```
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

Here, the string `mat_name` is a user-specified name for the command block. This name is typically descriptive of the material being modeled, e.g., `aluminum_t6061`.

Within a `PROPERTY SPECIFICATION FOR MATERIAL` command block, there will be other command blocks and possibly other general material command lines that are used to describe particular material models. The general material command lines, if present, are listed first, followed by one or more material-model command blocks. The general material command lines may be used to specify the density of the material as well as the application of temperatures and thermal strains to two- or three-dimensional elements. Each material-model command block follows the naming convention of `PARAMETERS FOR MODEL model_name`, where `model_name` identifies a particular material model, such as elastic, elastic-plastic, or orthotropic crush. Each such command block contains all the parameters needed to describe a particular material model.

As noted above, more than one material-model command block can appear within a `PROPERTY SPECIFICATION FOR MATERIAL` command block. Suppose we have a `PROPERTY SPECIFICATION FOR MATERIAL` command block called `steel`. It would be possible to have two material-model command blocks within this command block. One of the material-model command blocks would provide an elastic model for `steel`; the other material-model command block would provide an elastic-plastic model for `steel`. The general form of a `PROPERTY SPECIFICATION FOR MATERIAL` command block would be as follows:

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  # {General material command lines}
  DENSITY = <real>density_value
  #
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL <string>model_name1
    {Parameters for material model model_name1}
  END PARAMETERS FOR MODEL <string>model_name1
  #
  BEGIN PARAMETERS FOR MODEL <string> model_name2
    {Parameters for material model model_name2}
  END PARAMETERS FOR MODEL <string> model_name2
  #
  {Additional model command blocks if required}
  #
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

In the above general form for a `PROPERTY SPECIFICATION FOR MATERIAL` command block, the string `model_name1` could be `ELASTIC` and the string `model_name2` could be `ORTHOTROPIC CRUSH`. Typically, however, only one material model would be desired for a given block, and the `PROPERTY SPECIFICATION FOR MATERIAL` command block would have only one `PARAMETERS FOR MODEL` command block. A particular material model may only appear once within a given `PROPERTY SPECIFICATION FOR MATERIAL` command block.

Although multiple material models can be defined for one material within a `PROPERTY SPECIFICATION FOR MATERIAL` command block, only one material model is actually used for a given element block during an analysis. The ability to define multiple constitutive models for one material is provided as a convenience to enable the user to easily switch between models. The material name and the model name are both referenced when material models are assigned to element blocks within the `FINITE ELEMENT MODEL` command block, which is described in Section 5.1.

This chapter, in general, is organized to correspond to the general form presented for the `PROPERTY SPECIFICATION FOR MATERIAL` command block. Section 4.1 discusses the `DENSITY` command line and the command lines used for thermal strains, and also explains how temperatures and thermal strains are applied. Section 4.2 describes each of the material models that are shared by Presto and Adagio. References applicable for both Presto and Adagio are listed in Section 4.3.

As indicated in the introductory material, not all the material models available are applicable to all the element types. As one example, there is a one-dimensional elastic material model that is used for a truss element but is not applicable to solid elements such as hexahedra or tetrahedra. For this

particular example, the specific material-model usage is hidden from the user. If the user specifies a linear elastic material model for a truss, the one-dimensional elastic material model is used. If the user specifies a linear elastic material model for a hexahedron, a full three-dimensional elastic material model is used. As another example, the energy-dependent material models available in Presto cannot be used for a one-dimensional element such as a truss. The energy-dependent material models can only be used for solid elements such as hexahedra and tetrahedra. (Chapter 5 indicates what material models are available for which element models.)

For each material model, the parameters needed to describe that model are listed in the section pertinent to that particular model. Solid models with elastic constants require only two elastic constants. These two constants are then used to generate all the elastic constants for the model. For example, if the user specifies Young's modulus and Poisson's ratio, then the shear modulus, bulk modulus, and lambda are calculated. If the shear modulus and lambda are specified, then Young's modulus, Poisson's ratio, and the bulk modulus are calculated.

The various nonlinear material models have state variables. See Section 8.6.2 to learn how to output the state variables for the nonlinear material models.

Note that only brief descriptions of the material models are presented in this chapter. For a detailed description of the various material models, you will need to consult a variety of references. Specific references are identified for most of the material models shared by Presto and Adagio. The references for the equation-of-state material models appear in both the Presto and Adagio user guides, even though information about the equation-of-state models appears only in the Presto user's guide.

4.1 General Material Commands

A PROPERTY SPECIFICATION FOR MATERIAL command block for a particular material may include additional command lines that are applicable to all the material models specified within the command block. These command lines related to density and to thermal strain behavior are discussed, respectively, in Section 4.1.1 and Section 4.1.2.

4.1.1 Density Command

```
DENSITY = <real>density_value
```

This command line specifies the density of the material described in a PROPERTY SPECIFICATION FOR MATERIAL command block. The units of the input parameter density_value are specified as mass per unit volume.

As previously explained, a PROPERTY SPECIFICATION FOR MATERIAL command block can contain one or more PARAMETERS FOR MODEL command blocks. The specified density_value for the material will be used with all of the models described in these PARAMETERS FOR MODEL command blocks.

4.1.2 Thermal Strain Behavior

Isotropic and orthotropic thermal strains may be defined for use by material models listed in a PROPERTY SPECIFICATION FOR MATERIAL command block. Section 4.1.2.1 describes the command lines that are used to define the thermal strain behavior. These command lines must be used in conjunction with other command blocks outside of a PROPERTY SPECIFICATION FOR MATERIAL command block for the calculations of thermal strains to be activated. Section 4.1.2.2 explains the process for activating thermal strains.

4.1.2.1 Defining Thermal Strains

```
THERMAL STRAIN FUNCTION = <string>thermal_strain_function
# or all three of the following
THERMAL STRAIN X FUNCTION =
  <string>thermal_strain_x_function
THERMAL STRAIN Y FUNCTION =
  <string>thermal_strain_y_function
THERMAL STRAIN Z FUNCTION =
  <string>thermal_strain_z_function
```

A PROPERTY SPECIFICATION FOR MATERIAL command block may include command lines that define thermal strain behavior. It is possible to specify either an isotropic thermal-strain field

using the command line `THERMAL STRAIN FUNCTION` or an orthotropic thermal-strain field using the command lines `THERMAL STRAIN X FUNCTION`, `THERMAL STRAIN Y FUNCTION`, and `THERMAL STRAIN Z FUNCTION`. For any of these command lines, the user supplies a thermal strain function (via a `DEFINITION FOR FUNCTION` command block), which defines the thermal strain as a function of temperature. The computed thermal strain is then subtracted from the strain passed to the material model.

A thermal strain can be applied to any two-dimensional or three-dimensional element, regardless of material type. For a three-dimensional element such as a hexahedron or tetrahedron, the thermal strains are applied to the strain in the global XYZ coordinate system. For the isotropic case, the thermal strains are the same in the X-direction, the Y-direction, and the Z-direction. For the anisotropic case, the thermal strains can be different in each of the three global directions—X, Y, and Z. For a two-dimensional element, shell or membrane, the thermal strain corresponding to the `THERMAL STRAIN X FUNCTION` command line is applied to the strain in the shell (or membrane) r-direction. (Reference Section 5.2.2 for a discussion of the shell rst coordinate system.) The thermal strain corresponding to the `THERMAL STRAIN Y FUNCTION` command line is applied to the strain in the shell (or membrane) s-direction. For two-dimensional elements, the current implementation of orthotropic thermal strains is limited, for practical purposes, to special cases—flat sheets of uniform shell elements lying in one of the global planes, e.g., XY, YZ, or ZX. The current orthotropic thermal-strain capability has limited use for shells and membranes in the current release of the code. Tying the orthotropic thermal-strain functionality to the shell orientation functionality (Section 5.2.2) in the future will provide much more useful orthotropic thermal-strain functionality for two-dimensional elements.

If an isotropic thermal-strain field is to be applied, the `THERMAL STRAIN FUNCTION` command line is placed in the `PROPERTY SPECIFICATION FOR MATERIAL` command block, outside of the specifications of any material models in the block. Such placement is necessary because the isotropic thermal strain is a general material property, not a property that is specific to any particular constitutive model, such as `ELASTIC` or `ELASTIC-PLASTIC`. The input value of `thermal_strain_function` is the name of the function that defines thermal strain as a function of temperature for the material model described in this particular `PROPERTY SPECIFICATION FOR MATERIAL` command block. The function is defined within the domain scope using a `DEFINITION FOR FUNCTION` command block. For more information on how to set the input to compute thermal strains and how to apply temperatures, see Section 4.1.2.2.

The specification of an orthotropic thermal-strain field requires that all three of the `THERMAL STRAIN X FUNCTION`, `THERMAL STRAIN Y FUNCTION`, and `THERMAL STRAIN Z FUNCTION` command lines be placed in the `PROPERTY SPECIFICATION FOR MATERIAL` command block. All three command lines must be provided, even when there is no thermal strain in one or more directions. The values of `thermal_strain_x_function`, `thermal_strain_y_function`, and `thermal_strain_z_function` are the names of the functions for thermal strains in the X-direction, the Y-direction, and the Z-direction, respectively. These functions are defined within the domain scope using `DEFINITION FOR FUNCTION` command blocks. To specify that there should be no thermal strain in a given direction, use a function that always evaluates to zero for that direction.

The `THERMAL STRAIN FUNCTION` command line and the `THERMAL STRAIN X FUNCTION`, `THERMAL STRAIN Y FUNCTION`, and `THERMAL STRAIN Z FUNCTION` command lines are not used for several of the material models, as discussed in Section 4.1.2.2. Note that specification of a thermal strain is identified in the descriptions of the material models in Section 4.2 by the notation " {`thermal strain option`}".

4.1.2.2 Activating Thermal Strains

Adagio has the capability to compute thermal strains on three-dimensional continuum and two-dimensional (shell, membrane) elements. Three things are required to activate thermal strains:

- First, one or more thermal strain functions (strain as a function of temperature) must be defined. Each thermal strain function is defined with a `DEFINITION FOR FUNCTION` command block. (This function is the standard function definition that appears in the domain scope.) The thermal strain function gives the total thermal strain associated with a given temperature. It is the change in thermal strain with the change in temperature that gives rise to thermal stresses in a body.

- Second, the material models used by blocks that experience thermal strain must have their thermal strain behavior defined. The command lines for defining isotropic and orthotropic thermal strain are described in Section 4.1.2.1. Materials with isotropic thermal strain use the `THERMAL STRAIN FUNCTION` command line, while those with orthotropic thermal strain must define thermal strain in all three directions using the `THERMAL STRAIN X FUNCTION`, `THERMAL STRAIN Y FUNCTION`, and `THERMAL STRAIN Z FUNCTION` command lines. These inputs can be used with all material models with the exception of the following: elastic three-dimensional orthotropic, elastic laminate, Mooney-Rivlin, NLVE three-dimensional orthotropic, Swanson, and viscoelastic Swanson. These models require their own model-specific inputs to define thermal strain and must not use these standard commands. Information for defining thermal strains is provided in the individual descriptions of these models in Section 4.2.

- Third, a temperature field must be applied to the affected blocks. The command block to specify the application of temperatures is `PRESCRIBED TEMPERATURE`, which is implemented as a standard boundary condition. A description of the `PRESCRIBED TEMPERATURE` command block is given in Section 6.7.

Whenever a temperature field is applied, the temperature is prescribed at the nodes, but thermal strain is computed based on element temperature. Element temperatures are obtained by averaging the temperatures of the nodes connected to a given element. Thermal strains are applied in rate form, so the thermal strain in an element is relative to the thermal strain at the initial temperature. Thus, the initial temperature is the stress-free temperature. If desired, a different stress-free temperature can be used by prescribing the initial temperature with the `INITIAL CONDITION` command block as described in Section 6.2.

4.2 Model Specifications

This section contains descriptions of the material models that are shared by Presto and Adagio.

4.2.1 Elastic Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
  END [PARAMETERS FOR MODEL ELASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

An elastic material model is used to describe simple linear elastic behavior of materials. This model is generally valid for small deformations.

For an elastic material, an elastic command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ELASTIC
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ELASTIC]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.

- Lambda is defined with the `LAMBDA` command line.

For information about the elastic model, consult Reference 1.

4.2.2 Elastic Fracture Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC_FRACTURE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    MAX STRESS = <real>max_stress
    CRITICAL STRAIN = <real>critical_strain
  END [PARAMETERS FOR MODEL ELASTIC_FRACTURE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

An elastic fracture material is a simple failure model that is based on linear elastic behavior. The model uses a maximum-principal-stress failure criterion. The stress decays isotropically based on the component of strain parallel to the maximum principal stress. The value of the component of strain over which the stress is decayed to zero is a user-defined parameter for the model. This strain parameter can be adjusted so that failure is mesh independent.

For an elastic fracture material, an elastic fracture command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ELASTIC_FRACTURE
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ELASTIC_FRACTURE]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.

- Poisson's ratio is defined with the `POISSONS RATIO` command line.
- The bulk modulus is defined with the `BULK MODULUS` command line.
- The shear modulus is defined with the `SHEAR MODULUS` command line.
- Lambda is defined with the `LAMBDA` command line.

- The maximum principal stress at which failure occurs is defined with the `MAX STRESS` command line.

- The component of strain over which the stress decays to zero is defined with the `CRITICAL STRAIN` command line. This component of strain is aligned with the maximum-principal-stress direction at failure.

4.2.3 Elastic-Plastic Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC_PLASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING MODULUS = <real>hardening_modulus
    BETA = <real>beta_parameter(1.0)
  END [PARAMETERS FOR MODEL ELASTIC_PLASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The elastic-plastic linear hardening models are used to model materials, typically metals, that undergoing plastic deformation at finite strains. Linear hardening generally refers to the shape of a uniaxial stress-strain curve where the stress increases linearly with the plastic, or permanent, strain. In a three-dimensional framework, hardening is the law that governs how the yield surface grows in stress space. If the yield surface grows uniformly in stress space, the hardening is referred to as isotropic hardening. When `BETA` is 1.0, we have only isotropic hardening.

Because the linear hardening model is relatively simple to integrate, the model also has the ability to define a yield surface that not only grows, or hardens, but also moves in stress space. This ability is known as kinematic hardening. When `BETA` is 0.0, we have only kinematic hardening. The elastic-plastic linear hardening model allows for isotropic hardening, kinematic hardening, or a combination of the two.

For an elastic-plastic material, an elastic-plastic command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ELASTIC_PLASTIC
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ELASTIC_PLASTIC]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The yield stress is defined with the `YIELD STRESS` command line.
- The hardening modulus is defined with the `HARDENING MODULUS` command line.
- The beta parameter is defined with the `BETA command` line.

For information about the elastic-plastic model, consult Reference 1.

4.2.4 Elastic-Plastic Power-Law Hardening Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL EP_POWER_HARD
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING CONSTANT = <real>hardening_constant
    HARDENING EXPONENT = <real>hardening_exponent
    LUDERS STRAIN = <real>luders_strain
  END [PARAMETERS FOR MODEL EP_POWER_HARD]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

A power-law hardening model for elastic-plastic materials is used for modeling metal plasticity up to finite strains. The power-law hardening model, as opposed to the linear hardening model, has a power law fit for the uniaxial stress-strain curve that has the stress increase as the plastic strain raised to some power. The power-law hardening model also has the ability to model materials that exhibit Luder's strains after yield. Due to the more complicated yield behavior, the power-law hardening model can only be used with isotropic hardening.

For an elastic-plastic power-law hardening material, an elastic-plastic power-law hardening command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL EP_POWER_HARD
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL EP_POWER_HARD]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1

and Section 4.1.2.2 for further information on specifying and applying thermal strains and temperatures.

- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The yield stress is defined with the `YIELD STRESS` command line.
- The hardening constant is defined with the `HARDENING CONSTANT` command line.
- The hardening exponent is defined with the `HARDENING EXPONENT` command line.
- The Luder's strain is defined with the `LUDERS STRAIN` command line.

For information about the elastic-plastic power-law hardening model, consult Reference 1.

4.2.5 Ductile Fracture Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL DUCTILE_FRACTURE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING CONSTANT = <real>hardening_constant
    HARDENING EXPONENT = <real>hardening_exponent
    LUDERS STRAIN <real>luders_strain
    CRITICAL TEARING PARAMETER = <real>crit_tearing
    CRITICAL CRACK OPENING STRAIN = <real>crit_crack
  END [PARAMETERS FOR MODEL DUCTILE_FRACTURE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

This model is identical to the elastic-plastic power-law hardening model with the addition of a failure criterion and a postfailure isotropic decay of the stress to zero within the constitutive model. The point at which failure occurs is defined by a critical tearing parameter. The critical tearing parameter t_p is related to the plastic strain at failure ε_f by the evolution integral

$$t_p = \int_0^{\varepsilon_f} \langle \frac{2\sigma_{\max}}{3\left(\sigma_{\max} - \sigma_m\right)} \rangle^4 \, d\varepsilon_p \,. \tag{4.1}$$

In Equation (4.1), $\sigma_{\max}$ is the maximum principal stress, and σ_m is the mean stress. The quantity in the angle brackets, the expression

$$\frac{2\sigma_{\max}}{3\left(\sigma_{\max} - \sigma_m\right)} \,, \tag{4.2}$$

is nonzero only if it evaluates to a positive value. This quantity is set to zero if it has a negative value.

The stress decays isotropically based on the component of strain parallel to the maximum principal stress. The value of the component of strain over which the stress is decayed to zero is a user-

defined parameter for the model. This strain parameter can be adjusted so that failure is mesh independent.

For an elastic-plastic power-law hardening material with failure, the command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL DUCTILE_FRACTURE
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL DUCTILE_FRACTURE]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains and temperatures.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The yield stress is defined with the `YIELD STRESS` command line.
- The hardening constant is defined with the `HARDENING CONSTANT` command line.
- The hardening exponent is defined with the `HARDENING EXPONENT` command line.
- The Luder's strain is defined with the `LUDERS STRAIN` command line.
- The critical tearing parameter is defined with the `CRITICAL TEARING PARAMETER` command line.
- The component of strain over which the stress decays to zero is defined with the `CRITICAL CRACK OPENING STRAIN` command line. This component of strain is aligned with the maximum-principal-stress direction at failure.

For information about the ductile fracture material model, consult Reference 1.

4.2.6 Multilinear Elastic-Plastic Hardening Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL MULTILINEAR_EP
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    BETA = <real>beta_parameter(1.0)
    HARDENING FUNCTION = <real>hardening_function_name
    YOUNGS MODULUS FUNCTION = <real>ym_function_name
    POISSONS RATIO FUNCTION = <real>pr_function_name
    YIELD STRESS FUNCTION = <real>yield_stress_function_name
  END [PARAMETERS FOR MODEL MULTILINEAR_EP]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

This model is similar to the power-law hardening model except that the hardening behavior is described with a piecewise-linear curve as opposed to a power law.

For a multilinear elastic-plastic hardening material, the command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL MULTILINEAR_EP
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL MULTILINEAR_EP]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:

  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.

- The yield stress is defined with the `YIELD STRESS` command line.

- The beta parameter is defined with the `BETA` command line.

- The `HARDENING FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the hardening behavior of the material as a stress versus equivalent plastic strain. This curve is expressed as the additional increment of stress over the yield stress versus equivalent plastic strain, thus the first point on the curve should be (0.0, 0.0).

- The `YOUNGS MODULUS FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on Young's modulus as a function of temperature.

- The `POISSONS RATIO FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on Poisson's ratio as a function of temperature.

- The `YIELD STRESS FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on the yield stress as a function of temperature.

4.2.7 Multilinear Elastic-Plastic Hardening Model with Failure

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ML_EP_FAIL
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    BETA = <real>beta_parameter(1.0)
    HARDENING FUNCTION = <real>hardening_function_name
    YOUNGS MODULUS FUNCTION = <real>ym_function_name
    POISSONS RATIO FUNCTION = <real>pr_function_name
    YIELD STRESS FUNCTION = <real>yield_stress_function_name
    CRITICAL TEARING PARAMETER = <real>crit_tearing
    CRITICAL CRACK OPENING STRAIN = <real>crit_crack
  END [PARAMETERS FOR MODEL ML_EP_FAIL]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

This model is similar to the power-law hardening model except that the hardening behavior is described with a piecewise-linear curve as opposed to a power law. This model incorporates a failure criterion and a postfailure isotropic decay of the stress to zero within the constitutive model. The point at which failure occurs is defined by a critical tearing parameter. The critical tearing parameter t_p is related to the plastic strain at failure ε_f by the evolution integral:

$$t_p = \int_0^{\varepsilon_f} \langle \frac{2\sigma_{\max}}{3\,(\sigma_{\max} - \sigma_m)} \rangle^4 \, d\varepsilon_p \,. \tag{4.3}$$

In Equation (4.3), $\sigma_{\max}$ is the maximum principal stress, and σ_m is the mean stress. The quantity in the angle brackets, the expression

$$\frac{2\sigma_{\max}}{3\,(\sigma_{\max} - \sigma_m)} \,, \tag{4.4}$$

is nonzero only if it evaluates to a positive value. This quantity is set to zero if it has a negative value.

The stress decays isotropically based on the component of strain parallel to the maximum principal stress. The value of the component of strain over which the stress is decayed to zero is a user-defined parameter for the model. This strain parameter can be adjusted so that failure is mesh independent.

For a multilinear elastic-plastic hardening material with failure, the command block starts with the input line

```
BEGIN PARAMETERS FOR MODEL ML_EP_FAIL
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ML_EP_FAIL]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The yield stress is defined with the `YIELD STRESS` command line.
- The beta parameter is defined with the `BETA` command line.
- The `HARDENING FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the hardening behavior of the material as a stress versus equivalent plastic strain. This curve is expressed as the additional increment of stress over the yield stress versus equivalent plastic strain, thus the first point on the curve should be (0.0, 0.0).
- The `YOUNGS MODULUS FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on Young's modulus as a function of temperature.
- The `POISSONS RATIO FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on Poisson's ratio as a function of temperature.
- The `YIELD STRESS FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes a scale factor on the yield stress as a function of temperature.

- The critical tearing parameter is defined with the `CRITICAL TEARING PARAMETER` command line.
- The component of strain over which the stress decays to zero is defined with the `CRITICAL CRACK OPENING STRAIN` command line. This component of strain is aligned with the maximum-principal-stress direction at failure.

4.2.8 Johnson-Cook Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL JOHNSON_COOK
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING CONSTANT = <real>hardening_constant
    HARDENING EXPONENT = <real>hardening_exponent
    RHOCV = <real>rho_cv
    RATE CONSTANT = <real>rate_constant
    THERMAL EXPONENT = <real>thermal_exponent
    REFERENCE TEMPERATURE = <real>reference_temperature
    MELT TEMPERATURE = <real>melt_temperature
  END [PARAMETERS FOR MODEL JOHNSON_COOK]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The Johnson-Cook model is used to model materials, typically metals, that undergoing plastic deformation at finite strains.

```
BEGIN PARAMETERS FOR MODEL JOHNSON_COOK
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL JOHNSON_COOK]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:

  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.

- The yield stress is defined with the `YIELD STRESS` command line.
- The hardening constant is defined with the `HARDENING CONSTANT` command line.
- The hardening exponent is defined with the `HARDENING EXPONENT` command line.
- The rhocv is defined with the `RHOCV` command line.
- The thermal exponent is defined with the `THERMAL EXPONENT` command line.
- The reference temperature is defined with the `REFERENCE TEMPERATURE` command line.
- The melt temperature is defined with the `MELT TEMPERATURE` command line.

For information about the Johnson-Cook material model, consult Reference 17.

4.2.9 BCJ Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL BCJ
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    C1 = <real>c1
    C2 = <real>c2
    C3 = <real>c3
    C4 = <real>c4
    C5 = <real>c5
    C6 = <real>c6
    C7 = <real>c7
    C8 = <real>c8
    C9 = <real>c9
    C10 = <real>c10
    C11 = <real>c11
    C12 = <real>c12
    C13 = <real>c13
    C14 = <real>c14
    C15 = <real>c15
    C16 = <real>c16
    C17 = <real>c17
    C18 = <real>c18
    C19 = <real>c19
    C20 = <real>c20
    DAMAGE EXPONENT = <real>damage_exponent
    INITIAL ALPHA_XX = <real>alpha_xx
    INITIAL ALPHA_YY = <real>alpha_yy
    INITIAL ALPHA_ZZ = <real>alpha_zz
    INITIAL ALPHA_XY = <real>alpha_xy
    INITIAL ALPHA_YZ = <real>alpha_yz
```

```
      INITIAL ALPHA_XZ = <real>alpha_xz
      INITIAL KAPPA = <real>initial_kappa
      INITIAL DAMAGE = <real>initial_damage
      YOUNGS MODULUS FUNCTION = <string>ym_function_name
      POISSONS RATIO FUNCTION = <string>pr_function_name
      SPECIFIC HEAT = <real>specific_heat
      THETA OPT = <integer>theta_opt
      FACTOR = <real>factor
      RHO = <real>rho
      TEMP0 = <real>temp0
    END [PARAMETERS FOR MODEL BCJ]
  END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The BCJ plasticity model is a state-variable model for describing the finite deformation behavior of metals. It uses a multiplicative decomposition of the deformation gradient into elastic, volumetric plastic, and deviatoric parts. The model considers the natural configuration defined by this decomposition and its associated thermodynamics. The model incorporates strain rate and temperature sensitivity, as well as damage, through a yield-surface approach in which state variables follow a hardening-minus-recovery format.

Because the BCJ model has such an extensive list of parameters, we will not present the usual synopsis of parameter names with command lines. As with most other material models, the {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains. In addition, only two of the five elastic constants are required. The user should consult References 2, 3, and 4 for a description of the various parameters. Note that the parameters for the `SPECIFIC HEAT`, `THETA OPT`, `FACTOR`, `RHO`, and `TEMP0` command lines are used to accommodate changes to the model for heat generation due to plastic dissipation. For coupled solid/thermal calculations, the plastic dissipation rate is stored as a state variable and passed to a thermal code as a heat source term. For uncoupled calculations, temperature is stored as a state variable, and temperature increases due to plastic dissipation are calculated within the material model.

If temperature is provided from an external source, `theta_opt` is set to 0. If the temperature is calculated by the BCJ model, `theta_opt` is set to 1.

4.2.10 Soil and Crushable Foam Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL SOIL_FOAM
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    A0 = <real>const_coeff_yieldsurf
    A1 = <real>lin_coeff_yieldsurf
    A2 = <real>quad_coeff_yieldsurf
    PRESSURE CUTOFF = <real>pressure_cutoff
    PRESSURE FUNCTION = <string>function_press_volstrain
  END [PARAMETERS FOR MODEL SOIL_FOAM]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The soil and crushable foam model is a plasticity model that can be used for modeling soil or crushable foam. Given the right input, the model is a Drucker-Prager model.

For the soil and crushable foam model, the yield surface is a surface of revolution about the hydrostat in principal stress space. A planar end cap is assumed for the yield surface so that the yield surface is closed. The yield stress σ_{yd} is specified as a polynomial in pressure p. The yield stress is given as:

$$\sigma_{yd} = a_0 + a_1 p + a_2 p^2 , \tag{4.5}$$

where p is positive in compression. The determination of the yield stress from Equation (4.5) places severe restrictions on the admissible values of a_0, a_1, and a_2. There are three valid cases for the yield surface. In the first case, there is an elastic–perfectly plastic deviatoric response, and the yield surface is a cylinder oriented along the hydrostat in principal stress space. In this case, a_0 is positive, and a_1 and a_2 are zero. In the second case, the yield surface is conical. A conical yield surface is obtained by setting a_2 to zero and using appropriate values for a_0 and a_1. In the third case, the yield surface has a parabolic shape. For the parabolic yield surface, all three coefficients

in Equation (4.5) are nonzero. The coefficients are checked to determine that a valid negative tensile-failure pressure can be derived based on the specified coefficients.

For the case of the cylindrical yield surface (e.g., $a_0 > 0$ and $a_1 = a_2 = 0$), there is no tensile-failure pressure. For the other two cases, the computed tensile-failure pressure may be too low. To handle the situations where there is no tensile-failure pressure or the tensile-failure pressure is too low, a pressure cutoff can be defined. If a pressure cutoff is defined, the tensile-failure pressure is the larger of the computed tensile-failure pressure and the defined cutoff pressure.

The plasticity theories for the volumetric and deviatoric parts of the material response are completely uncoupled. The volumetric response is computed first. The mean pressure p is assumed to be positive in compression, and a yield function ϕ_p is written for the volumetric response as:

$$\phi_p = p - f_p(\varepsilon_V) \,, \tag{4.6}$$

where $f_p(\varepsilon_V)$ defines the volumetric stress-strain curve for the pressure. The yield function ϕ_p determines the motion of the end cap along the hydrostat.

For a soil and crushable foam material, a soil and crushable foam command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL SOIL_FOAM
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL SOIL_FOAM]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The constant in the equation for the yield surface is defined with the `A0` command line.
- The coefficient for the linear term in the equation for the yield surface is defined with the `A1` command line.
- The coefficient for the quadratic term in the equation for the yield surface is defined with the `A2` command line.

- The user-defined tensile-failure pressure is defined with the `PRESSURE CUTOFF` command line.
- The pressure as a function of volumetric strain is defined with the function named on the `PRESSURE FUNCTION` command line.

For information about the soil and crushable foam model, consult with the Pronto3d document listed as Reference 5. The soil and crushable foam model is the same as the soil and crushable foam model in Pronto3d. The Pronto3d model is based on a material model developed by Krieg [6]. The Krieg version of the soil and crushable foam model was later modified by Swenson and Taylor [7]. The soil and crushable foam model developed by Swenson and Taylor is the model in Pronto3d and is also the shared model for Presto and Adagio.

4.2.11 Foam Plasticity Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL FOAM_PLASTICITY
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    PHI = <real>phi
    SHEAR STRENGTH  = <real>shear_strength
    SHEAR HARDENING = <real>shear_hardening
    SHEAR EXPONENT  = <real>shear_exponent
    HYDRO STRENGTH  = <real>hydro_strength
    HYDRO HARDENING = <real>hydro_hardening
    HYDRO EXPONENT  = <real>hydro_exponent
    BETA = <real>beta
  END [PARAMETERS FOR MODEL FOAM_PLASTICITY]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The foam plasticity model was developed to describe the response of porous elastic-plastic materials like closed-cell polyurethane foam to large deformation. Like solid metals, these foams can exhibit significant plastic deviatoric strains (permanent shape changes). Unlike metals, these foams can also exhibit significant plastic volume strains (permanent volume changes). The foam plasticity model is characterized by an initial yield surface that is an ellipsoid about the hydrostat.

When foams are compressed, they typically exhibit an initial elastic regime followed by a plateau regime in which the stress needed to compress the foam remains nearly constant. At some point in the compression process, the densification regime is reached, and the stress needed to compress the foam further begins to rapidly increase.

The foam plasticity model can be used to describe the response of metal foams and many closed-cell polymeric foams (including polyurethane, polystyrene bead, etc.) subjected to large deformation. This model is not appropriate for flexible foams that return to their undeformed shape after loads are removed.

For a foam plasticity material, a foam plasticity command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL FOAM_PLASTICITY
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL FOAM_PLASTICITY]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The initial volume fraction of solid material in the foam, φ, is defined with the `PHI` command line. For example, solid polyurethane weighs 75 pounds per cubic foot (pcf); uncompressed 10 pcf polyurethane foam would have a φ of $0.133 = 10/75$.
- The shear (deviatoric) strength of uncompressed foam is defined with the `SHEAR STRENGTH` command line.
- The shear hardening modulus for the foam is defined with the `SHEAR HARDENING` command line.
- The shear hardening exponent is defined with the `SHEAR EXPONENT` command line. The deviatoric strength is given by `(SHEAR STRENGTH)` + `(SHEAR HARDENING) * PHI**(SHEAR EXPONENT)`.
- The hydrostatic (volumetric) strength of the uncompressed foam is defined with the `HYDRO STRENGTH` command line.
- The hydrodynamic hardening modulus is defined with the `HYDRO HARDENING` command line.
- The hydrodynamic hardening exponent is defined with the `HYDRO EXPONENT` command line. The hydrostatic strength is given by `(HYDRO STRENGTH)` + `(HYDRO HARDENING) * PHI**(HYDRO EXPONENT)`.
- The prescription for nonassociated flow, β, is defined with the `BETA` command line. When $\beta = 0.0$, the flow direction is given by the normal to the yield surface (associated flow). When $\beta = 1.0$, the flow direction is given by the stress tensor. Values between 0.0 and 0.95 are recommended.

4.2.12 Elastic Three-Dimensional Orthotropic Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  BEGIN PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC
    YOUNGS MODULUS AA = <real>Eaa_value
    YOUNGS MODULUS BB = <real>Ebb_value
    YOUNGS MODULUS CC = <real>Ecc_value
    POISSONS RATIO AB = <real>NUab_value
    POISSONS RATIO BC = <real>NUbc_value
    POISSONS RATIO CA = <real>NUca_value
    SHEAR MODULUS AB = <real>Gab_value
    SHEAR MODULUS BC = <real>Gbc_value
    SHEAR MODULUS CA = <real>Gca_value
    COORDINATE SYSTEM = <string>coordinate_system_name
    DIRECTION FOR ROTATION = <real>1|2|3
    ALPHA = <real>alpha_in_degrees
    SECOND DIRECTION FOR ROTATION = <real>1|2|3
    SECOND ALPHA = <real>second_alpha_in_degrees
    THERMAL STRAIN AA FUNCTION = <string>ethaa_function_name
    THERMAL STRAIN BB FUNCTION = <string>ethbb_function_name
    THERMAL STRAIN CC FUNCTION = <string>ethcc_function_name
  END [PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The elastic three-dimensional orthotropic model describes the linear elastic response of an orthotropic material where the orientation of the principal material directions can be arbitrary. These principal axes are here denoted as A, B, and C. Thermal strains are also given along the principal material axes. The specification of these material axes is accomplished by selecting a user-defined coordinate system that can then be rotated twice about one of its current axes to give the final desired directions.

For an elastic three-dimensional orthotropic model, the command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The Youngs moduli corresponding to the principal material axes A, B, and C are given by the `YOUNGS MODULUS AA`, `YOUNGS MODULUS BB`, and `YOUNGS MODULUS CC` command lines.
- The Poisson's ratio defining the BB normal strain when the material is subjected only to AA normal stress is given by the `POISSONS RATIO AB` command line.

- The Poisson's ratio defining the CC normal strain when the material is subjected only to BB normal stress is given by the `POISSONS RATIO BC` command line.
- The Poisson's ratio defining the AA normal strain when the material is subjected only to CC normal stress is given by the `POISSONS RATIO CA` command line.
- The shear moduli for shear in the AB, BC, and CA planes are given by the `SHEAR MODULUS AB`, `SHEAR MODULUS BC`, and `SHEAR MODULUS CA` command lines, respectively.
- The specification of the principal material directions begins with the selection of a user-specified coordinate system given by the `COORDINATE SYSTEM` command line. This initial coordinate system can then be rotated twice to give the final material directions.
- The rotation of the initial coordinate system is defined using the `DIRECTION FOR ROTATION` and `ALPHA` command lines. The axis for rotation of the initial coordinate system is specified by the `DIRECTION FOR ROTATION` command line, while the angle of rotation is given by the `ALPHA` command line. This gives an intermediate specification of the material directions.
- The rotation of the intermediate coordinate system is defined using the `SECOND DIRECTION FOR ROTATION` and `SECOND ALPHA` command lines. The axis for rotation of the intermediate coordinate system is specified by the `SECOND DIRECTION FOR ROTATION` command line, while the angle of rotation is given by the `SECOND ALPHA` command line. The resulting coordinate system gives the final specification of the material directions.
- The thermal strain functions for normal thermal strains along the principal material directions are given by the `THERMAL STRAIN AA FUNCTION`, `THERMAL STRAIN BB FUNCTION`, and `THERMAL STRAIN CC FUNCTION` command lines.

See Reference 8 for more information about the elastic three-dimensional orthotropic model.

4.2.13 Orthotropic Crush Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    EX  = <real>modulus_x
    EY  = <real>modulus_y
    EZ  = <real>modulus_z
    GXY = <real>shear_modulus_xy
    GYZ = <real>shear_modulus_yz
    GZX = <real>shear_modulus_zx
    VMIN = <real>min_crush_volume
    CRUSH XX = <string>stress_volume_xx_function_name
    CRUSH YY = <string>stress_volume_yy_function_name
    CRUSH ZZ = <string>stress_volume_zz_function_name
    CRUSH XY = <string>shear_stress_volume_xy_function_name
    CRUSH YZ = <string>shear_stress_volume_yz_function_name
    CRUSH ZX = <string>shear_stress_volume_zx_function_name
  END [PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The orthotropic crush model is an empirically based constitutive relation that is useful for modeling materials like metallic honeycomb and wood. This particular implementation follows the formulation of the metallic honeycomb model in DYNA3D [9]. The orthotropic crush model divides material behavior into three phases:

- orthotropic elastic,
- volumetric crush (partially compacted), and
- elastic–perfectly plastic (fully compacted).

For an orthotropic crush material, an orthotropic crush command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH]
```

In the above command blocks:

- The uncompacted density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required:
  - Young's modulus for the fully compacted state is defined with the `YOUNGS MODULUS` command line. This is the elastic–perfectly plastic value of Young's modulus.
  - Poisson's ratio for the fully compacted state is defined with the `POISSONS RATIO` command line. This is the elastic–perfectly plastic value of Poisson's ratio.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The yield stress for the fully compacted state is defined with the `YIELD STRESS` command line. This is the elastic–perfectly plastic value of the yield stress.
- The initial directional modulus E_{xx} is defined with the `EX` command line.
- The initial directional modulus E_{yy} is defined with the `EY` command line.
- The initial directional modulus E_{zz} is defined with the `EZ` command line.
- The initial directional shear modulus G_{xy} is defined with the `GXY` command line.
- The initial directional shear modulus G_{yz} is defined with the `GYZ` command line.
- The initial directional shear modulus G_{zx} is defined with the `GZX` command line.
- The minimum crush volume as a fraction of the original volume is defined with the `VMIN` command line.
- The directional stress σ_{xx} as a function of the volume crush is defined by the function referenced in the `CRUSH XX` command line.
- The directional stress σ_{yy} as a function of the volume crush is defined by the function referenced in the CRUSH `YY` command line.
- The directional stress σ_{zz} as a function of the volume crush is defined by the function referenced in the `CRUSH ZZ` command line.

- The directional stress σ_{xy} as a function of the volume crush is defined by the function referenced in the `CRUSH XY` command line.
- The directional stress σ_{yz} as a function of the volume crush is defined by the function referenced in the `CRUSH YZ` command line.
- The directional stress σ_{zx} as a function of the volume crush is defined by the function referenced in the `CRUSH ZX` command line.

Note that several of the command lines in this command block (those beginning with `CRUSH`) reference functions. These functions must be defined in the domain scope. For information about the orthotropic crush model, consult Reference 9.

4.2.14 Orthotropic Rate Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_RATE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    MODULUS TTTT = <real>modulus_tttt
    MODULUS TTLL = <real>modulus_ttll
    MODULUS TTWW = <real>modulus_ttww
    MODULUS LLLL = <real>modulus_llll
    MODULUS LLWW = <real>modulus_llww
    MODULUS WWWW = <real>modulus_wwww
    MODULUS TLTL = <real>modulus_tltl
    MODULUS LWLW = <real>modulus_lwlw
    MODULUS WTWT = <real>modulus_wtwt
    TX = <real>tx
    TY = <real>ty
    TZ = <real>tz
    LX = <real>lx
    LY = <real>ly
    LZ = <real>lz
    MODULUS FUNCTION = <string>modulus_function_name
    RATE FUNCTION = <string>rate_function_name
    T FUNCTION = <string>t_function_name
    L FUNCTION = <string>l_function_name
    W FUNCTION = <string>w_function_name
    TL FUNCTION = <string>tl_function_name
    LW FUNCTION = <string>lw_function_name
    WT FUNCTION = <string>wt_function_name
  END [PARAMETERS FOR MODEL ORTHOTROPIC_RATE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The orthotropic rate model extends the functionality of the orthotropic crush constitutive model described in Section 4.2.13. The orthotropic rate model has been developed to describe the behavior of an aluminum honeycomb subjected to large deformation. The orthotropic rate model, like the original orthotropic crush model, has six independent yield functions that evolve with volume strain. Unlike the orthotropic crush model, the orthotropic rate model has yield functions that also depend on strain rate. The orthotropic rate model also uses an orthotropic elasticity tensor with nine elastic moduli in place of the orthotropic elasticity tensor with six elastic moduli used in the orthotropic crush model. A honeycomb orientation capability is included with the orthotropic rate model that allows users to prescribe initial honeycomb orientations that are not aligned with the original global coordinate system.

For an orthotropic rate material, an orthotropic rate command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_RATE
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ORTHOTROPIC_RATE]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- In the following list of elastic constants, only the elastic modulus (Young's modulus) is required for this model. If two elastic constants are supplied, the elastic constants will be completed. However, only the elastic modulus is used in this model.
  - Young's modulus for the fully compacted honeycomb is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio for the fully compacted state is defined with the `POISSONS RATIO` command line.
  - The bulk modulus for the fully compacted state is defined with the `BULK MODULUS` command line.
  - The shear modulus for the fully compacted state is defined with the `SHEAR MODULUS` command line.
  - Lambda for the fully compacted state is defined with the `LAMBDA` command line.
- The yield stress for the fully compacted honeycomb is defined with the `YIELD STRESS` command line.
- The nine elastic moduli for the orthotropic uncompacted honeycomb are defined with the `MODULUS TTT`, `MODULUS TTLL`, `MODULUS TTWW`, `MODULUS LLLL`, `MODULUS LLWW`, `MODULUS WWWW`, `MODULUS TLTL`, `MODULUS LWLW`, and `MODULUS WTWT` command lines. The T-direction is usually associated with the generator axis for the honeycomb. The L-direction is in the ribbon plane (plane defined by flat sheets used in reinforced honeycomb) and orthogonal to the generator axis. The W-direction is perpendicular to the ribbon plane.

- The components of a vector defining the T-direction of the honeycomb are defined by the `TX`, `TY`, and `TZ` command lines. The values of `tx`, `ty`, and `tz` are components of a vector in the global coordinate system that define the orientation of the honeycomb's T-direction (generator axis).

- The components of a vector defining the L-direction of the honeycomb are defined by the `LX`, `LY`, and `LZ` command lines. The values of `lx`, `ly`, and `lz` are components of a vector in the global coordinate system that define the orientation of the honeycomb's L-direction. *Caution*: The vectors T and L must be orthogonal.

- The function describing the variation in moduli with compaction is given by the `MODULUS FUNCTION` command line. The moduli vary continuously from their initial orthotropic values to isotropic values when full compaction is obtained.

- The function describing the change in strength with strain rate is given by the `RATE FUNCTION` command line. Note that all strengths are scaled with the multiplier obtained from this function.

- The function describing the T-normal strength of the honeycomb as a function of compaction is given by the `T FUNCTION` command line.

- The function describing the L-normal strength of the honeycomb as a function of compaction is given by the `L FUNCTION` command line.

- The function describing the W-normal strength of the honeycomb as a function of compaction is given by the `W FUNCTION` command line.

- The function describing the TL-normal strength of the honeycomb as a function of compaction is given by the `TL FUNCTION` command line.

- The function describing the LW-normal strength of the honeycomb as a function of compaction is given by the `LW FUNCTION` command line.

- The function describing the WT-normal strength of the honeycomb as a function of compaction is given by the `WT FUNCTION` command line.

Note that several of the command lines in this command block reference functions. These functions must be defined in the domain scope.

4.2.15 Elastic Laminate Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC_LAMINATE
    A11 = <real>a11_value
    A12 = <real>a12_value
    A16 = <real>a16_value
    A22 = <real>a22_value
    A26 = <real>a26_value
    A66 = <real>a66_value
    A44 = <real>a44_value
    A45 = <real>a45_value
    A55 = <real>a55_value
    B11 = <real>b11_value
    B12 = <real>b12_value
    B16 = <real>b16_value
    B22 = <real>b22_value
    B26 = <real>b26_value
    B66 = <real>b66_value
    D11 = <real>d11_value
    D12 = <real>d12_value
    D16 = <real>d16_value
    D22 = <real>d22_value
    D26 = <real>d26_value
    D66 = <real>d66_value
    COORDINATE SYSTEM = <string>coord_sys_name
    DIRECTION FOR ROTATION = 1|2|3
    ALPHA = <real>alpha_value_in_degrees
    THETA = <real>theta_value_in_degrees
    NTH11 FUNCTION = <string>nth11_function_name
    NTH22 FUNCTION = <string>nth22_function_name
    NTH12 FUNCTION = <string>nth12_function_name
    MTH11 FUNCTION = <string>mth11_function_name
    MTH22 FUNCTION = <string>mth22_function_name
    MTH12 FUNCTION = <string>mth12_function_name
  END [PARAMETERS FOR MODEL ELASTIC_LAMINATE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The elastic laminate model can be used to describe the overall linear elastic response of layered shells. The response of each layer is pre-integrated through the thickness under an assumed variation of strain through the thickness. That is, the user inputs laminate stiffness matrices directly, and the overall response is calculated appropriately. This model allows the user to input laminate stiffness matrices that are consistent with a state of generalized plane stress for each layer. Each layer can be orthotropic with a unique orientation. This model is primarily intended for capturing the response of fiber-reinforced laminated composites. The user inputs the laminate stiffness

matrices calculated with respect to a chosen coordinate system and then specifies this coordinate system's definition relative to the global coordinate system. Thermal stresses are handled via the input of thermal-force and thermal-force-couple resultants for the laminate as a whole. At present, the user cannot get layer stresses out from this material model. However, the overall section-force and force-couple resultants can be computed from available output. The details of this model are described in References 10 and 11.

For elastic laminate materials, the elastic laminate command block begins with the input line:

```
BEGIN PARAMETERS FOR MODEL ELASTIC_LAMINATE
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL ELASTIC_LAMINATE]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The extensional stiffnesses are defined with the $\mathtt{A}_{ij}$ command lines, where the values of ij are 11, 12, 16, 22, 26, 66, 44, 45, and 55.
- The coupling stiffnesses are defined with the $\mathtt{B}_{ij}$ command lines, where the values of ij are 11, 12, 16, 22, 26, and 66.
- The bending stiffnesses are defined with the $\mathtt{D}_{ij}$ command lines, where the values of ij are 11, 12, 16, 22, 26, and 66.
- The initial laminate coordinate system is defined with the `COORDINATE SYSTEM` command line.
- The rotation of the initial laminate coordinate system is defined with the `DIRECTION FOR ROTATION` and `ALPHA` command lines. The axis of initial laminate coordinate system is specified by the `DIRECTION FOR ROTATION` command line, while the angle of rotation is given by the `ALPHA` command line. This produces an intermediate laminate coordinate system that is then projected onto the surface of each shell element.
- The projected intermediate laminate coordinate system is rotated about the element normal by angle theta, which is specified by the `THETA` command line.
- The thermal-force resultants are defined by functions that are referenced on the `NTH11 FUNCTION`, `NTH22 FUNCTION`, and `NTH12 FUNCTION` command lines.
- The thermal-force-couple resultants are defined by functions that are referenced on the `MTH11 FUNCTION`, `MTH22 FUNCTION`, and `MTH12 FUNCTION` command lines.

4.2.16 Fiber Membrane Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL FIBER_MEMBRANE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    CORD DENSITY = <real>cord_density
    CORD DIAMETER = <real>cord_diameter
    MATRIX DENSITY = <real>matrix_density
    TENSILE TEST FUNCTION = <string>test_function_name
    PERCENT CONTINUUM = <real>percent_continuum
    EPL = <real>epl
    AXIS X = <real>axis_x
    AXIS Y = <real>axis_y
    AXIS Z = <real>axis_z
    MODEL = <string>RECTANGULAR
    STIFFNESS SCALE = <real>stiffness_scale
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL FIBER_MEMBRANE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The fiber membrane model is used for modeling membranes that are reinforced with unidirectional fibers. Through the use of a non-zero `PERCENT CONTINUUM`, a background isotropic material response can also be incorporated and is added in a manner such that the response in the fiber direction is unchanged. The fiber membrane model can be used in both Presto and Adagio. When the fiber membrane model is used in Adagio, the model can be used with or without the control-stiffness option in Adagio's multilevel solver. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. If the control-stiffness option is activated in Adagio, the response in the fiber direction is softened by lowering the fiber response. In all cases, the final material behavior that is used for equilibrium corresponds to the real material response. When the fiber membrane model is used in Presto, the fiber scaling, which is controlled by the `STIFFNESS SCALE` command line, is ignored.

For a fiber membrane material, a fiber membrane command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL FIBER_MEMBRANE
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL FIBER_MEMBRANE]
```

In the above command blocks, the following definitions are applicable. Usage requirements are identified both in this list of definitions and in the discussion that follows the list.

- The density of the material is defined with the `DENSITY` command line. This command line should be included, but its value will be recomputed (and hence replaced) if the `CORD DENSITY`, `CORD DIAMETER`, and `MATRIX DENSITY` command lines are specified.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required. These are used to compute values for the elastic preconditioner only.
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The density of the fibers is defined by the `CORD DENSITY` command line. This command line is optional. See the usage discussion below.
- The diameter of the fibers is defined by the `CORD DIAMETER` command line. This command line is optional. See the usage discussion below.
- The density of the matrix is defined by the `MATRIX DENSITY` command line. This command line is optional. See the usage discussion below.
- The `TENSILE TEST FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the fiber force versus strain data. This command line must be included.
- The fractional fiber stiffness to use in defining the background isotropic response is given by the `PERCENT CONTINUUM` command line. This command line must be included.
- The number of fibers per unit length is defined by the `EPL` command line. This command line must be included.
- The components of the vector defining the initial fiber direction is given by the `AXIS X`, `AXIS Y`, and `AXIS Z` command lines. These command lines must be included. See the usage discussion below.

- The coordinate system for specifying the fiber orientation is given by the `MODEL` command line. Only the option `RECTANGULAR` is available in this release. This command line must be included. See the usage discussion below.

- The fiber scaling is specified by the `STIFFNESS SCALE` command line. If the control-stiffness option is used in Adagio, this command line must be included. When the fiber membrane model is used in Presto, this command line is ignored.

- The reference strain is defined with the `REFERENCE STRAIN` command line. This command line is optional for Adagio and is not used in Presto. If the control-stiffness option is used in Adagio, this command line may be included. See the usage discussion below.

Certain command lines in the `PARAMETERS FOR MODEL FIBER_MEMBRANE` command block also have interdependencies or other factors that may impact their usage in Presto and Adagio, as discussed below.

The `CORD DENSITY`, `CORD DIAMETER`, and `MATRIX DENSITY` command lines are optional. When included, these three command lines are used for computation of the correct density corresponding to the fibers, the number of fibers per unit length, and the chosen matrix. When these three command lines are not included, the density is taken as that specified by the `DENSITY` command line.

The `AXIS X`, `AXIS Y`, and `AXIS Z` command lines must be specified if the value for the `MODEL` command line is `RECTANGULAR`. Currently, these axis-related command lines must be specified.

Specifying a reference strain (via the `REFERENCE STRAIN` command line) implies the use of strains for measuring part of the control-stiffness material constraint violation in Adagio. If this command line is not present, the material constraint violation is determined by comparing the change in the scaled fiber force over the current model problem.

4.2.17 Incompressible Solid Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    K SCALING = <real>k_scaling
    2G SCALING = <real>2g_scaling
    TARGET E = <real>target_e
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
    SCALING FUNCTION = <string>scaling_function_name
  END [PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The incompressible solid model is a variation of the elastic model and can be used in both Presto and Adagio. In Adagio, the incompressible solid model is used with the control-stiffness option in the multilevel solver. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. The model is used to model nearly incompressible materials where Poisson's ratio, ν, ≈ 0.5. In the course of solving a series of model problems in Adagio, the material response from this model incorporates scaling the bulk and/or shear behaviors to yield a material response that is more amenable to solution using Adagio's conjugate gradient solver. The final material behavior that is calculated corresponds to the actual moduli that are specified. When this model is used in Presto, the material scalings are ignored, and the model behaves like a linear elastic model.

For an incompressible solid material, an incompressible solid command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID]
```

In the above command blocks, the following definitions are applicable. Usage requirements are identified both in this list of definitions and in the discussion that follows the list.

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.
- Only two of the following elastic constants are required to define the unscaled material response:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The following material-scaling command lines are used only in Adagio:
  - The nominal bulk scaling is defined with the `K SCALING` command line. This command line is optional. See the usage discussion below.
  - The nominal shear scaling is defined with the `2G SCALING` command line. This command line is optional. See the usage discussion below.
  - The target Young's modulus is defined with the `TARGET E` command line. This command line is optional. See the usage discussion below.
  - The maximum Poisson's ratio is defined with the `MAX POISSONS RATIO` command line. This command line is optional. See the usage discussion below.
  - The reference strain is defined with the `REFERENCE STRAIN` command line. This command line is optional. See the usage discussion below.
  - The `SCALING FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the time dependent scaling to be applied. This command line is optional. See the usage discussion below.

As noted previously, only two of the elastic constants are required to define the unscaled material response. This requirement applies to use of the incompressible solid model in Presto and in Adagio. Further, all the material-scaling command lines are only used in Adagio.

Several options exist for defining the bulk and/or shear scalings that can be used with the multilevel solver in Adagio.

- Option 1: You can provide the scalings directly by including both of the `K SCALING` and `2G SCALING` command lines or either of them. When both command lines are input, the user-specified values for their parameters will be used. If only the `K SCALING` command line is input, the bulk scaling is as specified in the `k_scaling` parameter, and the value of the shear scaling parameter, `2g_scaling`, is set to 1.0. On the other hand, if only the `2G SCALING` command line is input, then the shear scaling is as specified in the `2g_scaling` parameter, but the value of the bulk-scaling parameter, `k_scaling`, is not set to 1.0. Instead, the bulk scaling is determined by computing a scaled bulk modulus from the scaled shear modulus and a (scaled) Poisson's ratio of 0.3. Then, the bulk scaling is determined simply as the ratio of the scaled bulk modulus to the actual bulk modulus.

- Option 2: You can specify either or both of the `TARGET E` and `MAX POISSONS RATIO` command lines to define the scalings. If only the `TARGET E` command line is included, the bulk and shear scalings are computed by first finding scaled moduli using the value of the `target_e` parameter along with a (scaled) Poisson's ratio of 0.3. The bulk and shear scalings are then determined as the ratio of the appropriate scaled to unscaled modulus. If only the `MAX POISSONS RATIO` command line is included, the shear scaling is set to 1.0, and the bulk scaling is computed by first calculating a scaled bulk modulus from the actual shear modulus and the value of the `max_poissons_ratio` parameter. The bulk scaling is then calculated simply as the ratio of the scaled bulk modulus to the actual bulk modulus. If both the `TARGET E` and `MAX POISSONS RATIO` command lines are included, the bulk scaling (and shear scaling) is determined from the ratio of the bulk scaled modulus (and shear scaled modulus) computed using the values of the `target_e` and `max_poissons_ratio` parameters to the unscaled bulk (and shear) modulus.

- Option 3: You can choose not to include any of the `K SCALING`, `2G SCALING`, `TARGET E`, and `MAX POISSONS RATIO` command lines. In such case, the shear scaling is set to 1.0, and the bulk scaling is computed as the ratio of the scaled bulk modulus coming from the real shear modulus and a (scaled) Poisson's ratio of 0.3 to the actual bulk modulus.

The function referenced by the value of the parameter `scaling_function_name` in the `SCALING FUNCTION` command line can be used to modify the bulk and shear scalings in solution time. The actual scalings used are computed by taking the scalings specified by the parameter values in the `K SCALING`, `2G SCALING`, `TARGET E`, and `MAX POISSONS RATIO` command lines and simply multiplying them by the function value at the specified solution time. If the `SCALING FUNCTION` command line is not included, the bulk and shear scalings are fixed in time.

The `REFERENCE STRAIN` command line supplies a value for the reference strain that is used to create a normalized material constraint violation based on strains. Specifying a reference strain implies the use of strains for measuring the material constraint violation (or part of the control-stiffness error in Adagio). Otherwise, the material constraint violation is determined by using the change in the scaled stress response over the current model problem.

4.2.18 Mooney-Rivlin Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL MOONEY_RIVLIN
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    C10 = <real>c10
    C01 = <real>c01
    C10 FUNCTION = <string>c10_function_name
    C01 FUNCTION = <string>c01_function_name
    BULK FUNCTION = <string>bulk_function_name
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL MOONEY_RIVLIN]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

Mooney-Rivlin is a hyperelastic model that is used to model rubber. The Mooney-Rivlin model incorporates temperature-dependent material moduli and can be used in both Presto and Adagio. When the model is used in Adagio, it can be used with or without the control-stiffness option in Adagio's multilevel solver. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. The model is used to model nearly incompressible materials where Poisson's ratio, ν, ≈ 0.5. In the course of solving a series of model problems in Adagio, the material response from this model incorporates scaling the bulk and/or shear behaviors to yield a material response that is more amenable to solution using Adagio's conjugate gradient solver. The final material behavior that is calculated corresponds to the actual moduli that are specified. When this model is used in Presto, the material scalings are ignored.

For a Mooney-Rivlin material, a Mooney-Rivlin command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL MOONEY_RIVLIN
```

and terminates an input line of the following form:

```
END [PARAMETERS FOR MODEL MOONEY_RIVLIN]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- Only two of the following elastic constants are required to define the unscaled bulk behavior:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.

- Poisson's ratio is defined with the `POISSONS RATIO` command line.
- The bulk modulus is defined with the `BULK MODULUS` command line.
- The shear modulus is defined with the `SHEAR MODULUS` command line.
- Lambda is defined with the `LAMBDA` command line.

- The nominal value for C10 is defined with the `C10` command line. This command line is required. See the usage discussion below.

- The nominal value for C01 is defined with the `C01` command line. This command line is required. See the usage discussion below.

- The `C10 FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the temperature dependence of the C10 material parameter. This command line is optional. See the usage discussion below.

- The `C01 FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the temperature dependence of the C01 material parameter. This command line is optional. See the usage discussion below.

- The `BULK FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the temperature dependence of the bulk modulus. This command line is optional. See the usage discussion below.

- The `THERMAL EXPANSION FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the linear thermal expansion as function of temperature. This command line is optional. See the usage discussion below.

- The following material-scaling command lines are used only in Adagio:

  - The target Young's modulus is defined with the `TARGET E` command line. This command line is optional. See the usage discussion below.
  - The `TARGET E FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the time variation of the target Young's modulus. This command line is optional. See the usage discussion below.
  - The maximum Poisson's ratio is defined with the `MAX POISSONS RATIO` command line. This command line is optional. See the usage discussion below.
  - The reference strain is defined with the `REFERENCE STRAIN` command line. This command line is optional. See the usage discussion below.

As noted previously, only two of the elastic constants are required to define the unscaled bulk behavior. Together, the values for C10 and C01 determine the shear behavior, and thus the `C10` and `C01` command lines must be included in this model.

The command lines for functions that specify the temperature dependence of C10, C01, and bulk modulus are optional, e.g., the `C10 FUNCTION`, `C01 FUNCTION` and `BULK FUNCTION` command lines. If these command lines are not included, their corresponding material parameters are taken to be independent of temperature. Mooney-Rivlin, like other material models, allows for the specification of thermal strain behavior within the material model itself, via the `THERMAL EXPANSION FUNCTION` command line. This command line, like the other "function-type" command lines in this model requires that a function associated with the name be defined in the domain scope.

The bulk and shear scalings that can be used with the multilevel solver in Adagio are specified via a combination of the `TARGET E`, `TARGET E FUNCTION`, and `MAX POISSONS RATIO` command lines. If the `TARGET E` command line is not included (and the `MAX POISSONS RATIO` command line is included), the shear scaling is set to 1.0, and the bulk scaling is determined from the ratio of the scaled bulk modulus to its unscaled value, where the scaled bulk modulus is computed using the value of the `max_poissons_ratio` parameter along with the unscaled initial shear modulus that is determined from the value of the parameters specified in the `C10` and `C01` command lines. On the other hand, if both the `TARGET E` command line and the `MAX POISSONS RATIO` command line are included, bulk and shear scaling values are computed using scaled moduli that are calculated from the `target_e` and `max_poissons_ratio` parameter values.

Including the `TARGET E FUNCTION` command line allows time-dependent bulk and shear scaling to be used. If this command line is not specified, the bulk and shear scalings remain constant in solution time. If the command line is specified, the target Young's modulus that is used for computing the scaled moduli is multiplied by the function value.

The `REFERENCE STRAIN` command line supplies a value for the reference strain used to create a normalized material constraint violation that is based on strains. Specifying a reference strain implies the use of strains for measuring the material constraint violation (or part of the control-stiffness error in Adagio). Otherwise, the material constraint violation is determined using the change in the scaled stress response over the current model problem.

Brief documentation on the theoretical basis for the Mooney-Rivlin model is given in Reference 12.

4.2.19 NLVE 3D Orthotropic Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL NLVE_3D_ORTHOTROPIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    COORDINATE SYSTEM = <string>coordinate_system_name
    DIRECTION FOR ROTATION = <real>1|2|3
    ALPHA = <real>alpha_in_degrees
    SECOND DIRECTION FOR ROTATION = <real>1|2|3
    SECOND ALPHA = <real>second_alpha_in_degrees
    FICTITIOUS LOGA FUNCTION = <string>fict_loga_function_name
    FICTITIOUS LOGA SCALE FACTOR = <real>fict_loga_scale_factor
    # In each of the five ``PRONY'' command lines and in
    # the RELAX TIME command line, the value of i can be from
    # 1 through 30
    1PSI PRONY <integer>i = <real>psi1_i
    2PSI PRONY <integer>i = <real>psi2_i
    3PSI PRONY <integer>i = <real>psi3_i
    4PSI PRONY <integer>i = <real>psi4_i
    5PSI PRONY <integer>i = <real>psi5_i
    RELAX TIME <integer>i = <real>tau_i
    REFERENCE TEMP = <real>tref
    REFERENCE DENSITY = <real>rhoref
    WLF C1 = <real>wlf_c1
    WLF C2 = <real>wlf_c2
    B SHIFT CONSTANT = <real>b_shift
    SHIFT REF VALUE = <real>shift_ref
    WWBETA 1PSI = <real>wwb_1psi
    WWTAU 1PSI = <real>wwt_1psi
    WWBETA 2PSI = <real>wwb_2psi
    WWTAU 2PSI = <real>wwt_2psi
    WWBETA 3PSI = <real>wwb_3psi
    WWTAU 3PSI = <real>wwt_3psi
    WWBETA 4PSI = <real>wwb_4psi
    WWTAU 4PSI = <real>wwt_4psi
    WWBETA 5PSI = <real>wwb_5psi
    WWTAU 5PSI = <real>wwt_5psi
    DOUBLE INTEG FACTOR = <real>dble_int_fac
    REF RUBBERY HCAPACITY = <real>hcapr
    REF GLASSY HCAPACITY = <real>hcapg
    GLASS TRANSITION TEM = <real>tg
```

```
REF GLASSY C11 = <real>c11g
REF RUBBERY C11 = <real>c11r
REF GLASSY C22 = <real>c22g
REF RUBBERY C22 = <real>c22r
REF GLASSY C33 = <real>c33g
REF RUBBERY C33 = <real>c33r
REF GLASSY C12 = <real>c12g
REF RUBBERY C12 = <real>c12r
REF GLASSY C13 = <real>c13g
REF RUBBERY C13 = <real>c13r
REF GLASSY C23 = <real>c23g
REF RUBBERY C23 = <real>c23r
REF GLASSY C44 = <real>c44g
REF RUBBERY C44 = <real>c44r
REF GLASSY C55 = <real>c55g
REF RUBBERY C55 = <real>c55r
REF GLASSY C66 = <real>c66g
REF RUBBERY C66 = <real>c66r
REF GLASSY CTE1 = <real>cte1g
REF RUBBERY CTE1 = <real>cte1r
REF GLASSY CTE2 = <real>cte2g
REF RUBBERY CTE2 = <real>cte2r
REF GLASSY CTE3 = <real>cte3g
REF RUBBERY CTE3 = <real>cte3r
LINEAR VISCO TEST = <real>lvt
T DERIV GLASSY C11 = <real>dc11gdT
T DERIV RUBBERY C11 = <real>dc11rdT
T DERIV GLASSY C22 = <real>dc22gdT
T DERIV RUBBERY C22 = <real>dc22rdT
T DERIV GLASSY C33 = <real>dc33gdT
T DERIV RUBBERY C33 = <real>dc33rdT
T DERIV GLASSY C12 = <real>dc12gdT
T DERIV RUBBERY C12 = <real>dc12rdT
T DERIV GLASSY C13 = <real>dc13gdT
T DERIV RUBBERY C13 = <real>dc13rdT
T DERIV GLASSY C23 = <real>dc23gdT
T DERIV RUBBERY C23 = <real>dc23rdT
T DERIV GLASSY C44 = <real>dc44gdT
T DERIV RUBBERY C44 = <real>dc44rdT
T DERIV GLASSY C55 = <real>dc55gdT
T DERIV RUBBERY C55 = <real>dc55rdT
T DERIV GLASSY C66 = <real>dc66gdT
T DERIV RUBBERY C66 = <real>dc66rdT
T DERIV GLASSY CTE1 = <real>dcte1gdT
T DERIV RUBBERY CTE1 = <real>dcte1rdT
T DERIV GLASSY CTE2 = <real>dcte2gdT
T DERIV RUBBERY CTE2 = <real>dcte2rdT
```

```
T DERIV GLASSY CTE3 = <real>dcte3gdT
T DERIV RUBBERY CTE3 = <real>dcte3rdT
T DERIV GLASSY HCAPACITY = <real>dhcapgdT
T DERIV RUBBERY HCAPACITY = <real>dhcaprdT
REF PSIC = <real>psic_ref
T DERIV PSIC = <real>dpsicdT
T 2DERIV PSIC = <real>d2psicdT2
PSI EQ 2T = <real>psitt
PSI EQ 3T = <real>psittt
PSI EQ 4T = <real>psitttt
PSI EQ XX 11 = <real>psiXX11
PSI EQ XX 22 = <real>psiXX22
PSI EQ XX 33 = <real>psiXX33
PSI EQ XX 12 = <real>psiXX12
PSI EQ XX 13 = <real>psiXX13
PSI EQ XX 23 = <real>psiXX23
PSI EQ XX 44 = <real>psiXX44
PSI EQ XX 55 = <real>psiXX55
PSI EQ XX 66 = <real>psiXX66
PSI EQ XXT 11 = <real>psiXXT11
PSI EQ XXT 22 = <real>psiXXT22
PSI EQ XXT 33 = <real>psiXXT33
PSI EQ XXT 12 = <real>psiXXT12
PSI EQ XXT 13 = <real>psiXXT13
PSI EQ XXT 23 = <real>psiXXT23
PSI EQ XXT 44 = <real>psiXXT44
PSI EQ XXT 55 = <real>psiXXT55
PSI EQ XXT 66 = <real>psiXXT66
PSI EQ XT 1 = <real>psiXT1
PSI EQ XT 2 = <real>psiXT2
PSI EQ XT 3 = <real>psiXT3
PSI EQ XTT 1 = <real>psiXTT1
PSI EQ XTT 2 = <real>psiXTT2
PSI EQ XTT 3 = <real>psiXTT3
REF PSIA 11 = <real>psiA11
REF PSIA 22 = <real>psiA22
REF PSIA 33 = <real>psiA33
REF PSIA 12 = <real>psiA12
REF PSIA 13 = <real>psiA13
REF PSIA 23 = <real>psiA23
REF PSIA 44 = <real>psiA44
REF PSIA 55 = <real>psiA55
REF PSIA 66 = <real>psiA66
T DERIV PSIA 11 = <real>dpsiA11dT
T DERIV PSIA 22 = <real>dpsiA22dT
T DERIV PSIA 33 = <real>dpsiA33dT
T DERIV PSIA 12 = <real>dpsiA12dT
```

```
      T DERIV PSIA 13 = <real>dpsiA13dT
      T DERIV PSIA 23 = <real>dpsiA23dT
      T DERIV PSIA 44 = <real>dpsiA44dT
      T DERIV PSIA 55 = <real>dpsiA55dT
      T DERIV PSIA 66 = <real>dpsiA66dT
      REF PSIB 1 = <real>psiB1
      REF PSIB 2 = <real>psiB2
      REF PSIB 3 = <real>psiB3
      T DERIV PSIB 1 = <real>dpsiB1dT
      T DERIV PSIB 2 = <real>dpsiB2dT
      T DERIV PSIB 3 = <real>dpsiB3dT
      PSI POT TT = <real>psipotTT
      PSI POT TTT = <real>psipotTTT
      PSI POT TTTT = <real>psipotTTTT
      PSI POT XT 1 = <real>psipotXT1
      PSI POT XT 2 = <real>psipotXT2
      PSI POT XT 3 = <real>psipotXT3
      PSI POT XTT 1 = <real>psipotXTT1
      PSI POT XTT 2 = <real>psipotXTT2
      PSI POT XTT 3 = <real>psipotXTT3
      PSI POT XXT 11 = <real>psipotXXT11
      PSI POT XXT 22 = <real>psipotXXT22
      PSI POT XXT 33 = <real>psipotXXT33
      PSI POT XXT 12 = <real>psipotXXT12
      PSI POT XXT 13 = <real>psipotXXT13
      PSI POT XXT 23 = <real>psipotXXT23
      PSI POT XXT 44 = <real>psipotXXT44
      PSI POT XXT 55 = <real>psipotXXT55
      PSI POT XXT 66 = <real>psipotXXT66
    END [PARAMETERS FOR MODEL NLVE_3D_ORTHOTROPIC]
  END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The NLVE three-dimensional orthotropic model is a nonlinear viscoelastic orthotropic continuum model that describes the behavior of fiber-reinforced polymer-matrix composites. In addition to being able to model the linear elastic and linear viscoelastic behaviors of such composites, it also can capture both “weak” and “strong” nonlinear viscoelastic effects such as stress dependence of the creep compliance and viscoelastic yielding. This model can be used in both Presto and Adagio.

Because the NLVE model is still under active development and also because it has an extensive list of command lines, we have not followed the typical approach in documenting this model.

4.2.20 Stiff Elastic

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL STIFF_ELASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    SCALE FACTOR = <real>scale_factor
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL STIFF_ELASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The stiff elastic model is a variation of the isotropic elastic model. The stiff elastic model can be used in both Presto and Adagio. When the model is used in Adagio, it is typically used with the control-stiffness option in Adagio's multilevel solver. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. The stiff elastic model is used to lower the stiffness of the bulk and shear behaviors of relatively stiff materials to yield a material response more amenable to solution using Adagio's conjugate gradient solver. The final material behavior that is calculated corresponds to the actual moduli that are specified. When this model is used in Presto, the material scalings are ignored.

For a stiff elastic material, a stiff elastic command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL STIFF_ELASTIC
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL STIFF_ELASTIC]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- The {`thermal strain option`} is used to define thermal strains. See Section 4.1.2.1 and Section 4.1.2.2 for further information on defining and activating thermal strains.

- Only two of the following elastic constants are required to define the unscaled material response:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The following command lines are used only in Adagio:
  - The material scaling is defined with the `SCALE FACTOR` command line.
  - The reference strain is defined with the `REFERENCE STRAIN` command line.

As noted previously, only two of the elastic constants are required to define the unscaled material response.

The scaled bulk and shear moduli are computed using a Young's modulus scaled by the value given by the `SCALE FACTOR` line command.

The `REFERENCE STRAIN` command line supplies a value for the reference strain used to create a normalized material constraint violation that is based on strains. Specifying a reference strain implies the use of strains for measuring the material constraint violation (or part of the control-stiffness error in Adagio). Otherwise, the material constraint violation is determined using the change in the scaled stress response over the current model problem.

4.2.21 Swanson Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL SWANSON
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    A1 = <real>a1
    P1 = <real>p1
    B1 = <real>b1
    Q1 = <real>q1
    C1 = <real>c1
    R1 = <real>r1
    CUT OFF STRAIN = <real>ecut
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL SWANSON]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The Swanson model is a hyperelastic model that is used to model rubber. The Swanson model can be used in both Presto and Adagio. When the model is used in Adagio, it can be used with or without the control-stiffness option in Adagio's multilevel solver for nearly incompressible materials where Poisson's ratio, ν, ≈ 0.5. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. In the course of solving a series of model problems in Adagio, the material response from this model incorporates scaling the bulk and/or shear behaviors to yield a material response that is more amenable to solution using Adagio's conjugate gradient solver. The final material behavior that is calculated corresponds to the actual moduli that are specified. When this model is used in Presto, the material scalings are ignored.

For a Swanson material, a Swanson command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL SWANSON
```

and terminates an input line of the following form:

```
END [PARAMETERS FOR MODEL SWANSON]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- Only two of the following elastic constants are required to define the unscaled bulk behavior:

  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.

- The following command lines are required:

  - The material constant A1 is defined with the `A1` command line.
  - The material constant P1 is defined with the `P1` command line.
  - The material constant B1 is defined with the `B1` command line.
  - The material constant Q1 is defined with the `Q1` command line.
  - The material constant C1 is defined with the `C1` command line.
  - The material constant R1 is defined with the `R1` command line.
  - The small-strain value used for computing the initial shear modulus is defined with the `CUT OFF STRAIN` command line.

- The `THERMAL EXPANSION FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the linear thermal expansion as function of temperature. This command line is optional. See the usage discussion below.

- The following material-scaling command lines are used only in Adagio:

  - The target Young's modulus is defined with the `TARGET E` command line. This command line is optional. See the usage discussion below.
  - The `TARGET E FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the time variation of the target Young's modulus. This command line is optional. See the usage discussion below.
  - The maximum Poisson's ratio is defined with the `MAX POISSONS RATIO` command line. This command line is optional. See the usage discussion below.
  - The reference strain is defined with the `REFERENCE STRAIN` command line. This command line is optional. See the usage discussion below.

As noted previously, only two of the elastic constants are required to define the unscaled bulk behavior. Together, the values for parameters in the `A1`, `P1`, `B1`, `Q1`, `C1`, and `R1` command lines define the unscaled shear behavior, so these command lines must be present. The initial unscaled shear modulus is determined from those parameter values along with the value of the parameter in the `CUT OFF STRAIN` command line, so this command line must also be present.

The Swanson model, like a few of the material models, allows for the specification of thermal strain behavior within the material model itself, via the `THERMAL EXPANSION FUNCTION` command line. This command line, like the other "function-type" command lines in this model, requires that a function associated with the name be defined in the domain scope.

The bulk and shear scalings that can be used with the multilevel solver in Adagio are specified via a combination of the `TARGET E`, `TARGET E FUNCTION`, and `MAX POISSONS RATIO` command lines. If the `TARGET E` command line is not included (and the `MAX POISSONS RATIO` command line is included), the shear scaling is set to 1.0, and the bulk scaling is determined from the ratio of the scaled bulk modulus to its unscaled value, where the scaled bulk modulus is computed using the value of the `max_poissons_ratio` parameter along with the unscaled shear modulus. On the other hand, if both the `TARGET E` command line and the `MAX POISSONS RATIO` are included, bulk and shear scaling values are computed using scaled moduli that are calculated from the `target_e` and `max_poissons_ratio` parameter values.

Including the `TARGET E FUNCTION` command line allows time-dependent bulk and shear scaling to be used. If this command line is not specified, the bulk and shear scalings remain constant in solution time. If the command line is specified, the target Young's modulus that is used for computing the scaled moduli is multiplied by the function value.

The `REFERENCE STRAIN` command line supplies a value for the reference strain used to create a normalized material constraint violation that is based on strains. Specifying a reference strain implies the use of strains for measuring the material constraint violation (or part of the control-stiffness error in Adagio). Otherwise, the material constraint violation is determined using the change in the scaled stress response over the current model problem.

Brief documentation on the theoretical basis for the Swanson model is given in Reference 12.

4.2.22 Viscoelastic Swanson Model

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL VISCOELASTIC_SWANSON
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    A1 = <real>a1
    P1 = <real>p1
    B1 = <real>b1
    Q1 = <real>q1
    C1 = <real>c1
    R1 = <real>r1
    CUT OFF STRAIN = <real>ecut
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    PRONY SHEAR INFINITY = <real>ginf
    PRONY SHEAR 1 = <real>g1
    PRONY SHEAR 2 = <real>g2
    PRONY SHEAR 3 = <real>g3
    PRONY SHEAR 4 = <real>g4
    PRONY SHEAR 5 = <real>g5
    PRONY SHEAR 6 = <real>g6
    PRONY SHEAR 7 = <real>g7
    PRONY SHEAR 8 = <real>g8
    PRONY SHEAR 9 = <real>g9
    PRONY SHEAR 10 = <real>g10
    SHEAR RELAX TIME 1 = <real>tau1
    SHEAR RELAX TIME 2 = <real>tau2
    SHEAR RELAX TIME 3 = <real>tau3
    SHEAR RELAX TIME 4 = <real>tau4
    SHEAR RELAX TIME 5 = <real>tau5
    SHEAR RELAX TIME 6 = <real>tau6
    SHEAR RELAX TIME 7 = <real>tau7
    SHEAR RELAX TIME 8 = <real>tau8
    SHEAR RELAX TIME 9 = <real>tau9
    SHEAR RELAX TIME 10 = <real>tau10
    WLF COEF C1 = <real>wlf_c1
    WLF COEF C2 = <real>wlf_c2
    WLF TREF = <real>wlf_tref
    NUMERICAL SHIFT FUNCTION = <string>ns_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
```

```
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL VISCOELASTIC_SWANSON]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]
```

The viscoelastic Swanson model is a finite strain viscoelastic model that has an initial elastic response that matches the Swanson material model. The bulk response is elastic, while the shear response is viscoelastic. This model is commonly employed in simulating the response of rubber materials. The viscoelastic Swanson model can be used in both Presto and Adagio. When the model is used in Adagio, it can be used with or without the control-stiffness option in Adagio's multilevel solver for nearly incompressible materials where Poisson's ratio, ν, ≈ 0.5. The control-stiffness option is implemented via the `CONTROL STIFFNESS` command block and is discussed in Chapter 3. In the course of solving a series of model problems in Adagio, the material response from this model incorporates scaling the bulk and/or shear behaviors to yield a material response that is more amenable to solution using Adagio's conjugate gradient solver. The final material behavior that is calculated corresponds to the actual moduli that are specified. When this model is used in Presto, the material scalings are ignored.

For a viscoelastic Swanson material, a viscoelastic Swanson command block starts with the input line:

```
BEGIN PARAMETERS FOR MODEL VISCOELASTIC_SWANSON
```

and terminates with an input line of the following form:

```
END [PARAMETERS FOR MODEL VISCOELASTIC_SWANSON]
```

In the above command blocks:

- The density of the material is defined with the `DENSITY` command line.
- Only two of the following elastic constants are required to define the unscaled bulk behavior:
  - Young's modulus is defined with the `YOUNGS MODULUS` command line.
  - Poisson's ratio is defined with the `POISSONS RATIO` command line.
  - The bulk modulus is defined with the `BULK MODULUS` command line.
  - The shear modulus is defined with the `SHEAR MODULUS` command line.
  - Lambda is defined with the `LAMBDA` command line.
- The following command lines are required:
  - The material constant A1 is defined with the `A1` command line.
  - The material constant P1 is defined with the `P1` command line.
  - The material constant B1 is defined with the `B1` command line.
  - The material constant Q1 is defined with the `Q1` command line.
  - The material constant C1 is defined with the `C1` command line.

  - The material constant R1 is defined with the `R1` command line.
  - The small-strain value used for computing the glassy shear modulus is defined with the `CUT OFF STRAIN` command line.

- The `THERMAL EXPANSION FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the linear thermal expansion as function of temperature. See the usage discussion below.

- `PRONY SHEAR INFINITY` command line. This command line is required.

- The normalized relaxation spectra coefficients are specified with the `PRONY SHEAR I` command lines, where the value of `I` varies sequentially from 1 to 10. These command lines are optional.

- The normalized relaxation spectra time constants are specified with the `SHEAR RELAX TIME I` command lines, where the value of `I` varies sequentially from 1 to 10. These command lines are optional.

- `WLF COEF C1` command line. This command line is required.

- `WLF COEF C2` command line. This command line is required.

- `WLF TREF` command line. This command line is required.

- `NUMERICAL SHIFT FUNCTION` command line. This command line is optional.

- The following material-scaling command lines are used only in Adagio:

  - The target Young's modulus is defined with the `TARGET E` command line. This command line is required. See the usage discussion below.
  - The `TARGET E FUNCTION` command line references the name of a function defined in a `DEFINITION FOR FUNCTION` command line in the domain scope that describes the time variation of the target Young's modulus. This command line is required. See the usage discussion below.
  - The maximum Poisson's ratio is defined with the `MAX POISSONS RATIO` command line. This command line is required. See the usage discussion below.
  - The reference strain is defined with the `REFERENCE STRAIN` command line. This command line is required. See the usage discussion below.

As noted previously, only two of the elastic constants are required to define the unscaled bulk behavior. Together, the values for parameters in the `A1`, `P1`, `B1`, `Q1`, `C1`, and `R1` command lines define the unscaled glassy shear behavior, so these command lines must be present. The unscaled glassy shear modulus is determined from those parameter values along with the value of the parameter in the `CUT OFF STRAIN` command line, so this command line must also be present.

The viscoelastic Swanson model, like a few of the material models, allows for the specification of thermal strain behavior within the material model itself, via the `THERMAL EXPANSION`

FUNCTION command line. This command line, like the other "function-type" command lines in this model requires that a function associated with the name be defined in the domain scope.

The bulk and shear scalings that can be used with the multilevel solver in Adagio are specified via a combination of the TARGET E, TARGET E FUNCTION, and MAX POISSONS RATIO command lines. If the TARGET E command line is not included (and the MAX POISSONS RATIO command line is included), the shear scaling is set to 1.0, and the bulk scaling is determined from the ratio of the scaled bulk modulus to its unscaled value, where the scaled bulk modulus is computed using the value of the max_poissons_ratio parameter along with the unscaled shear modulus. On the other hand, if both the TARGET E command line and the MAX POISSONS RATIO command line are included, bulk and shear scaling values are computed using scaled moduli that are calculated from the target_e and max_poissons_ratio parameter values.

Including the TARGET E FUNCTION command line allows time-dependent bulk and shear scaling to be used. If this command line is not specified, the bulk and shear scalings remain constant in solution time. If the command line is specified, the target Young's modulus that is used for computing the scaled moduli is multiplied by the function value.

The REFERENCE STRAIN command line supplies a value for the reference strain used to create a normalized material constraint violation that is based on strains. Specifying a reference strain implies the use of strains for measuring the material constraint violation (or part of the control-stiffness error in Adagio). Otherwise, the material constraint violation is determined using the change in the scaled stress response over the current model problem.

Brief documentation on the theoretical basis for the viscoelastic Swanson model is given in References 12, 13, 14, and 15.

4.3 References

1. Stone, C. M. *SANTOS – A Two-Dimensional Finite Element Program for the Quasistatic, Large Deformation, Inelastic Response of Solids*, SAND90-0543. Albuquerque, NM: Sandia National Laboratories, 1996.

2. Bammann, D. J., M. L. Chiesa, and G. C. Johnson. "Modelling Large Deformation and Failure in Manufacturing Processes." In *Proceedings of the 19th International Congress of Theoretical and Applied Mechanics*, edited by T. Tatsumi, E. Watanabe, and T. Kambe, 359–376. Amsterdam: Elsevier Science Publishers, 1997.

3. Bammann, D. J., M. L. Chiesa, M. F. Horstemeyer, and L. E. Weingarten. "Failure in Ductile Materials Using Finite Element Methods." In *Structural Crashworthiness and Failure*, edited by N. Jones and T. Wierzbicki, 1–53. London: Elsevier Applied Science, 1993.

4. Bammann, D. J. "Modeling Temperature and Strain Dependent Large Deformations in Metals." *Applied Mechanics Reviews* 43, no. 5 (1990): S312–319.

5. Taylor, L. M., and D. P. Flanagan. *Pronto3D: A Three-Dimensional Transient Solid Dynamics Program*, SAND87-1912. Albuquerque, NM: Sandia National Laboratories, March 1989.

6. Krieg, R. D. *A Simple Constitutive Description for Cellular Concrete*, SAND SC-DR-72-0883. Albuquerque, NM: Sandia National Laboratories, 1978.

7. Swenson, D. V., and L. M. Taylor. "A Finite Element Model for the Analysis of Tailored Pulse Stimulation of Boreholes." *International Journal for Numerical and Analytical Methods in Geomechanics* 7 (1983): 469–484.

8. Green, A. E., and W. Zerna. *Theoretical Elasticity, 2nd Edition*. Oxford: Clarendon Press, 1968.

9. Whirley, R. G., B. E. Engelmann, and J. O. Halquist. *DYNA3D Users Manual*. Livermore, CA: Lawrence Livermore Laboratory, 1991.

10. Hammerand, D. C. *Laminated Composites Modeling in ADAGIO/PRESTO*, SAND2004-2143. Albuquerque, NM: Sandia National Laboratories, 2004.

11. Hammerand, D. C. *Critical Time Step for a Bilinear Laminated Composite Mindlin Shell Element*, SAND2004-2487. Albuquerque, NM: Sandia National Laboratories, 2004.

12. Scherzinger, W. M., and D. C. Hammerand. *Constitutive Models in LAME*, SAND2007-5873. Albuquerque, NM: Sandia National Laboratories, September 2007.

13. HKS. *ABAQUS Version 6.6, Theory Manual*. Providence, RI: Hibbitt, Karlsson and Sorensen, 2006.

14. Hammerand, D. C. "ABAQUS Style Finite Strain Viscoelasticity in Adagio." Memo. Albuquerque, NM: Sandia National Laboratories, March 2003.

15. Hammerand, D. C. "Finite Strain Viscoelasticity in Adagio and ABAQUS." Memo. Albuquerque, NM: Sandia National Laboratories, July 2003.

16. Swegle, J. W. *SIERRA: PRESTO Theory Documentation: Energy Dependent Materials Version 1.0*. Albuquerque, NM: Sandia National Laboratories, October 2001.

17. Johnson, G. R., and Cook, W. H. "A constitutive model and data for metals subjected to large strains, high strain rates and high temperatures" *Proc. 7th. Int. Symp. on Ballistics, The Hague, The Netherlands* (1983): 541–547.

Chapter 5

Elements

This chapter explains how material, geometric, and other properties are associated with the various element blocks in a mesh file. A mesh file contains, for the most part, only topological information about elements. For example, there may be a group of elements in the mesh file that consists of four nodes defining a planar facet in three-dimensional space. Whether or not these elements are used as shells or membranes in our actual model of an object is determined by command lines in the input file. The specifics of a material type associated with these four node facets are also set in the input file.

Most elements can be used in either Presto or Adagio. If an element is available in one code but not the other, this information will be noted for the element. There is a special element implementation in Presto referred to as smoothed particle hydrodynamics(SPH). There is a section for SPH in the Presto manual but not in the Adagio manual. This chapter also includes descriptions of the commands for mass property calculations. An “element-like" capability is discussed —rigid bodies. Although rigid bodies exhibit element-like behavior, they are really implemented as boundary conditions. From a user viewpoint, it is best to discuss the rigid-body capabilities with elements.

Highlights of chapter contents follow. Section 5.1 discusses the `FINITE ELEMENT MODEL` command block, which provides the description of a mesh that will be associated with the elements. Section 5.2 presents the section command blocks that are used to define the different element sections. Section 5.3.1 explains the use of rigid bodies, which is an element like functionality. In Section 5.4, the `MASS PROPERTIES` command block is described, which lets the user compute the total mass of the model or the mass of subparts of the model once the element blocks are completely defined in terms of geometry and material.

Most of the command blocks and command lines described next appear within the domain scope. There are some exceptions, and these exceptions are noted.

5.1 Finite Element Model

```
BEGIN FINITE ELEMENT MODEL <string>mesh_descriptor
  DATABASE NAME = <string>mesh_file_name
```

```
    DATABASE TYPE = <string>database_type(exodusII)
    ALIAS <string>mesh_identifier AS <string>user_name
    OMIT BLOCK <string>block_list
    COMPONENT SEPARATOR CHARACTER = <string>separator
    BEGIN PARAMETERS FOR BLOCK <string list>block_names
      #
      # Command lines that define attributes for
      # a particular element block appear in this
      # command block.
      #
    END [PARAMETERS FOR BLOCK <string list>block_names]
  END [FINITE ELEMENT MODEL <string>mesh_descriptor]
```

The input file must point to a mesh file that is to be used for an analysis. The name of the mesh file appears within a `FINITE ELEMENT MODEL` command block, which appears in the domain scope. In this command block, you will identify the particular mesh file that describes your model. Also within this command block, there will be one or more `PARAMETERS FOR BLOCK` command blocks. (All the `PARAMETERS FOR BLOCK` command blocks are embedded in the `FINITE ELEMENT MODEL` command block.) Within the `PARAMETERS FOR BLOCK` command block, you will set a material type and model, a section, and various other parameters for the element block. The concept of "section" is explained in Section 5.1.2.

The current element library is as follows:

- Eight-node, uniform-gradient hexahedron: Both a midpoint-increment formulation [1] and a strongly objective formulation are implemented [2]. These elements can be used with any of the material models described in Chapter 4, including the equation of state (EOS) models.

- Eight-node, selective-deviatoric hexahedron: Only a strongly objective formulation is provided. This element can be used with any of the material models described in Chapter 4 except the EOS models.

- Four-node tetrahedron: There is now the regular element formulation for the four-node tetrahedron and a node-based formulation for the four-node tetrahedron. For the regular element formulation, only a strongly objective formulation is implemented. The concept of a node-based four-node tetrahedron is described in Reference 3. The regular four-node tetrahedron can be used with any of the material models described in Chapter 4 except the EOS models. The node-based tetrahedron can be used with any of the material models described in Chapter 4, including the EOS models.

- Eight-node tetrahedron: This tetrahedral element has nodes at the four vertices and nodes on the four faces. The eight-node tetrahedron has only a strongly objective formulation [4]. The eight-node tetrahedron uses a mean quadrature formulation even though it has the additional nodes. This element can be used with any of the material models described in Chapter 4, including the EOS models.

- Ten-node tetrahedron: Only a strongly objective formulation is implemented. This element can be used with any of the material models described in Chapter 4, including the EOS models.

- Four-node, quadrilateral, uniform-gradient membrane: Both a midpoint-increment formulation and a strongly objective formulation are implemented. This element is derived from the Key-Hoff shell formulation [5]. The strongly objective formulation has not been extensively tested, and it is recommended that the midpoint-increment formulation, which is the default, be used for this element type. These elements can be used with any of the following material models described in Chapter 4:

  – Elastic
  – Elastic-plastic
  – Elastic-plastic power-law hardening
  – Multilinear elastic-plastic hardening (no failure)

- Four-node, quadrilateral shell: This shell uses the Key-Hoff formulation [5]. Both a midpoint-increment formulation and a strongly objective formulation are implemented. The strongly objective formulation has not been extensively tested, and it is recommended that the midpoint-increment formulation, which is the default, be used for this element type. These elements can be used with any of the following material models described in Chapter 4:

  – Elastic
  – Elastic-plastic
  – Elastic-plastic power-law hardening
  – Multilinear elastic-plastic hardening without failure
  – Multilinear elastic-plastic hardening with failure

- Four-node, quadrilateral, selective-deviatoric membrane: Only a midpoint-increment formulation is implemented. These elements can be used with any of the following material models described in Chapter 4:

  – Elastic
  – Elastic-plastic
  – Elastic-plastic power-law hardening
  – Multilinear elastic-plastic hardening (no failure)

- (ONLY PRESTO) Two-node beam: The beam element is a uniform result model. Strains and stresses are computed only at the midpoint of the element. These midpoint values determine the forces and moments for the beam. There are five different sections currently implemented for the beam: rod, tube, bar, box, and I. This element can be used with any of the following material models described in Chapter 4:

  – Elastic

  - Elastic-plastic

- Two-node truss: The two-node truss element carries only a uniform axial stress. Currently, there is a linear-elastic material model for the truss element.

- Two-node spring: The two-node spring element computes a uniaxial resistance force based on a non-linear force-engineering strain function. This element can handle preloads, mass per unit length, resetting of the initial length after preload and any arbitrary loading function.

- Two-node damper: (Code Usage: Presto only) The two-node damping element computes a damping force based on the relative velocity of the two nodes along the axis of the element. This element uses only a damping parameter for a material property.

- Point mass: (Code Usage: Presto only) The point mass element allows the user to put a specified mass (and a mass only) at a node. This element requires input for density and an elastic material, but does not make use of the elastic material properties.

The command block to describe a mesh file begins with

```
BEGIN FINITE ELEMENT MODEL <string>mesh_descriptor
```

and is terminated with:

```
END [FINITE ELEMENT MODEL <string>mesh_descriptor]
```

where `mesh_descriptor` is a user-selected name for the mesh. In this section, we will first discuss the command lines within the scope of the `FINITE ELEMENT MODEL` command block but outside the scope of the `PARAMETERS FOR BLOCK` command block. We will then discuss the `PARAMETERS FOR BLOCK` command block and the associated command lines for this particular block.

5.1.1 Identification of Mesh File

Nested within the `FINITE ELEMENT MODEL` command block are two command lines (`DATABASE NAME` and `DATABASE TYPE`) that give the mesh name and define the type for the mesh file, respectively. The command line

```
DATABASE NAME = <string>mesh_file_name
```

gives the name of the mesh file with the string `mesh_file_name`. If the current mesh file is in the default directory and is named `job.g`, then this command line would appear as:

```
DATABASE NAME = job.g
```

If the mesh file is in some other directory, the command line would have to show the path to that directory. For parallel runs, the string `mesh_file_name` is the base name for the spread of parallel mesh files. For example, for a four-processor run, the actual mesh files associated with a base name of `job.g` would be `job.g.4.0`, `job.g.4.1`, `job.g.4.2`, and `job.g.4.3`. The database name on the command line would be `job.g`.

If the mesh file does not use the Exodus II format, you must specify the format for the mesh file using the command line:

```
DATABASE TYPE = <string>database_type(exodusII)
```

Currently, only the Exodus II database format is supported by Presto and Adagio for mesh input. Other options may be added in the future.

5.1.1.1 Alias

It is possible to associate a user-defined name with some mesh entity. The mesh entity names for Exodus II entities are typically the concatenation of the entity type (for example, "block", "nodeset", or "surface"), an underscore ("_"), and the entity id. This generated name can be aliased to a more descriptive name by using the `ALIAS command line`:

```
ALIAS <string>mesh_identifier AS <string>user_name
```

This alias can then be used in other locations in the input file in place of the Exodus II name.

Examples of this association are as follows:

```
Alias block_1   as Case
Alias block_10  as Fin
Alias block_12  as Nose
Alias surface_1 as Nose_Case_Interface
Alias surface_2 as OuterBoundary
```

The above examples use the Exodus II naming convention described in Section 1.5.

5.1.1.2 Omit Block

If the finite element mesh contains element blocks that should be omitted from the finite element analysis, the `OMIT BLOCK` line command is used.

```
OMIT BLOCK <string>block_list
```

The element blocks listed in the command are removed from the model. Any nodesets or surfaces only existing on nodes or elements in the omitted element blocks are also omitted. Note that if this command is used in a parallel analysis, it is possible for the resulting model to become unbalanced if, for example, the omitted element blocks make up a large portion of the elements on one or more processors.

Examples of omitting element blocks are:

```
Omit Block block_1 block_2
Omit Block block_10
```

5.1.1.3 Component Separator Character

A variable defined on the mesh database can be used as a prescribed energy deposition, an initial condition, or a prescribed temperature with the `READ VARIABLE` command. If the variable is a vector or a tensor, then the base name of the variable will be separated from the suffixes with a separator character. The default separator character is an underscore, but it can be changed with the `COMPONENT SEPARATOR CHARACTER` command.

```
COMPONENT SEPARATOR CHARACTER = <string>character|NONE
```

For example, the variable `displacement` can have the suffixes `x`, `y`, etc. By default, the base name is separated from the suffixes with an underscore character so that we have `displacement_x`, `displacement_y`, etc. in the mesh file. The underscore can be replaced as the default separator by using the above command line. If the data used the period as the separator, then the command would be

```
COMPONENT SEPARATOR CHARACTER = .
```

For the displacement example the components would then appear in the mesh file as `displacement.x`, `displacement.y`, etc.

The separator can be eliminated with an empty string or `NONE`.

5.1.2 Descriptors of Element Blocks

```
BEGIN PARAMETERS FOR BLOCK <string list>block_names
  MATERIAL <string>material_name
  SOLID MECHANICS USE MODEL <string>model_name
  SECTION = <string>section_id
  LINEAR BULK VISCOSITY =
    <real>linear_bulk_viscosity_value(0.06)
  QUADRATIC BULK VISCOSITY =
    <real>quad_bulk_viscosity_value(1.20)
  HOURGLASS STIFFNESS =
    <real>hour_glass_stiff_value(solid = 0.05,
      shell/membrane = 0.0)
  HOURGLASS VISCOSITY =
    <real>hour_glass_visc_value(solid = 0.0,
      shell/membrane = 0.0)
  EFFECTIVE MODULI MODEL = <string>PRESTO|PRONTO|CURRENT|
      ELASTIC(PRONTO)
  ELEMENT NUMERICAL FORMULATION = <string>OLD|NEW(OLD)
  ACTIVE FOR PROCEDURE <string>proc_name DURING PERIODS
    <string list>period_names
END [PARAMETERS FOR BLOCK <string list>block_names]
```

The finite element model consists of one or more element blocks. Associated with an element block or group of element blocks will be a `PARAMETERS FOR BLOCK` command block, which is

also referred to in this document as an *element-block command block*. The basic information about the element blocks (number of elements, topology, connectivity, etc.) is contained in a mesh file. Specific attributes for an element block must be specified in the input file. If for example, a block of eight-node hexahedra is to use the selective-deviatoric versus mean-quadrature formulation, then the selective-deviatoric formulation must be specified in the input file. The element library is listed at the beginning of Section 5.1.

The element-block command block begins with the input line

```
BEGIN PARAMETERS FOR BLOCK <string list>block_names
```

and is terminated with the input line:

```
END [PARAMETERS FOR BLOCK <string list>block_names]
```

Here `block_names` is the list of element blocks assigned to the element-block command block. If the format for the mesh file is Exodus II, the typical form of a `block_name` is `block_integerid`, where `integerid` is the integer identifier for the block. If the element block is 280, the value of `block_name` would be `block_280`. It is also possible to generate an alias identifier for the element block and use this for the `block_name`. If `block_280` is aliased to `AL6061`, then `block_name` becomes `AL6061`.

All the element blocks listed on the `PARAMETERS FOR BLOCK` command line will have the same mechanics properties. The mechanics properties are set by use of the various command lines. One of the key command lines, i.e., `MATERIAL`, will let you associate a material with the elements in the block. Another key command line is the `SECTION` command line. This command line lets you differentiate between elements with the same topology but different formulations. For example, assume that the topology of the elements in a block is a four-node quadrilateral. With the `SECTION` command line you can specify whether the element block will be used as a membrane or a shell. The `SECTION` command line also lets you assign a variety of parameters to an element, depending on the element formulation.

It is important to state here that the `SECTION` command line only specifies an identifier that maps to a section command block that is defined by the user. There are currently several kinds of section command blocks for the different elements: `SOLID SECTION`, `SHELL SECTION`, `MEMBRANE SECTION`, `BEAM SECTION`, `TRUSS SECTION`, `SPRING SECTION`, `DAMPER SECTION`, `POINT MASS SECTION`, and `SPH SECTION`. It is within a section command block that the formulation-specific entities related to a particular element are specified. If no `SECTION` command line is present in an element-block command block, the code assumes the element block is a block of eight-node hexahedra using mean quadrature and the midpoint-increment formulation.

In addition to the material- and section-related command lines in an element-block command block, there are a number of other command lines. There are, for example, two command lines, `HOURGLASS STIFFNESS`, and `HOURGLASS VISCOSITY`, that will let you specify hourglass control parameters for the elements in the block (if these elements use hourglass control). These two command lines will overwrite the default hourglass control parameters for all elements in the block.

All the command lines that can be used for the element-block command block are described in Section 5.1.2.1 through Section 5.1.2.7. The various section command blocks are described in

Section 5.2. The section command blocks and their related command lines are much easier to understand once the element-block command lines are described.

5.1.2.1 Material Property

```
MATERIAL <string>material_name
SOLID MECHANICS USE MODEL <string>model_name
```

The material property specification for an element block is done by using the above two command lines. The property specification references both a `PROPERTY SPECIFICATION FOR MATERIAL` command block and a material-model command block, which has the general form `PARAMETERS FOR MODEL model_name`. These command blocks are described in Chapter 4. The `PROPERTY SPECIFICATION FOR MATERIAL` command block contains all the parameters needed to define a material, and is associated with an element block (`PARAMETERS FOR BLOCK` command block) by use of the `MATERIAL` command line. Some of the material parameters inside the property specification are grouped on the basis of material models. A material-model command block is associated with an element block by use of the `SOLID MECHANICS USE MODEL` command line.

Consider the following example. Suppose there is a `PROPERTY SPECIFICATION FOR MATERIAL` command block with a `material_name` of steel. Embedded within this command block for steel is a material-model command block for an elastic model of steel and an elastic-plastic model of steel. Suppose that for the current element block we would like to use the material steel with the elastic model. Then the element-block command block would contain the input lines:

```
MATERIAL steel
SOLID MECHANICS USE MODEL elastic
```

If, on the other hand, we would like to use the material steel with the elastic-plastic model, the element-block command block would contain the input lines:

```
MATERIAL steel
SOLID MECHANICS USE MODEL elastic_plastic
```

The user should remember that not all material types can be used with all element types.

5.1.2.2 Section

```
SECTION = <string>section_id
```

The section specification for an element-block command block is done by using the above command line. The `section_id` is a string associated with a section command block. The various section command blocks are described in Section 5.2.

Suppose you wanted the current element-block command block to use the membrane formulation. You would define a `MEMBRANE SECTION` command block with some name, such as `membrane_rubber`. Inside the current element-block command block you would have the command line:

```
SECTION = membrane_rubber
```

The thickness of the membrane would be described in the `MEMBRANE SECTION` command block and then associated with the current element-block command block.

There can be only one `SECTION` command line in an element-block command block. Each element-block command block within the model description can reference a unique section command block, or several element-block command blocks can reference the same section command block. For example, in Figure 5.1, the section named `membrane_rubber` appears in two different `PARAMETERS FOR MODEL` command blocks, but there is only one specification for their associated `MEMBRANE SECTION` command block. When several element-block command blocks reference the same section, the input file is less verbose, and it is easier to maintain the input file.



Figure 5.1: Association between `SECTION` command lines and a section command block.

5.1.2.3 Linear and Quadratic Bulk Viscosity

```
LINEAR BULK VISCOSITY =
  <real>linear_bulk_viscosity_value(0.06)
QUADRATIC BULK VISCOSITY =
  <real>quad_bulk_viscosity_value(1.20)
```

The linear and quadratic bulk viscosity are set with these two command lines. Consult the documentation for the elements [6] for a description of the bulk viscosity parameters.

5.1.2.4 Hourglass Control

```
HOURGLASS STIFFNESS = <real>hour_glass_stiff_value(solid
  = 0.05, shell/membrane = 0.0)
HOURGLASS VISCOSITY = <real>hour_glass_visc_value(solid
  = 0.0, shell/membrane = 0.0)
```

These two command lines set the hourglass control parameters for elements that use hourglass control. Currently, the included elements are the eight-node, uniform-gradient hexahedral elements; the eight-node and ten-node tetrahedral elements; and the four-node membrane and shell elements. Consult the element documentation [6] for a description of the hourglass parameters.

The hourglass stiffness parameter defaults to 0.05 for solids using hourglass control; it defaults to 0.0 for shell and membrane elements. A reasonable user defined hourglass stiffness (if needed) for shells and membranes is 0.005 (approximately an order of magnitude lower than for solid elements). The hourglass viscosity parameter defaults to 0.0 for all elements currently using hourglass control.

The hourglass stiffness is the same as the dilatational hourglass parameter, and the hourglass viscosity is the same as the deviatoric hourglass parameter.

The computation of the hourglass parameters can be strongly affected by the method that computes the effective moduli. The command line in Section 5.1.2.5 selects the method for computing the effective moduli.

5.1.2.5 Effective Moduli Model

```
EFFECTIVE MODULI MODEL =
  <string>PRESTO|PRONTO|CURRENT|ELASTIC(PRONTO)
```

The hourglass force computations require a measure of the material moduli to ensure appropriate scaling of the hourglass forces. For elastic, isotropic material models, the moduli are constant throughout the analysis. However, for nonlinear materials, the moduli are typically computed numerically from the stresses. For models with softening regimes or that approach perfect plasticity, the moduli may be difficult to define, and the way in which they are computed may adversely affect the analysis. Through the `EFFECTIVE MODULI MODEL` command line, Presto provides several methods for the computation of these effective moduli:

- `PRESTO`: This method includes a number of techniques for returning reasonable moduli for softening and perfectly plastic materials. The effective moduli that this approach produces are stiffer than those computed by the `PRONTO` approach.

- PRONTO: This method is the default and is identical to the method of computing effective moduli present in the Pronto3D code. It is similar to the PRESTO approach but generally produces moduli that are softer than the PRESTO approach.
- CURRENT: This method computes the effective moduli without any extra handling of negative or near-zero moduli cases. It generally provides the softest response but is also less stable.
- ELASTIC: This method simply uses the initial elastic moduli for the entire analysis. It is the most robust but also the most stiff, and may produce an overly stiff global response.

The EFFECTIVE MODULI MODEL command line should be used with caution because it can strongly affect the analysis results.

5.1.2.6 Element Numerical Formulation

```
ELEMENT NUMERICAL FORMULATION = <string>OLD|NEW(OLD)
```

For calculation of the critical time step, it is necessary to determine a characteristic length for each element. In one dimension, the correct characteristic element length is obviously the distance between the two nodes of the element. In higher dimensions, this length is usually taken to be the minimum distance between any of the nodes in the element. However, some finite element codes, primarily those based on Pronto3D [1], use as a characteristic length an eigenvalue estimate based on work by Flanagan and Belytschko [7]. That characteristic length provides a stable time step, but in many cases is far more conservative than the minimum distance between nodes. For a cubic element with side length equal to 1, and thus also surface area of each face and volume equal to 1, the minimum distance between nodes is 1. However, the eigenvalue estimate is $1/\sqrt{3}$, which is only 58% of the minimum distance. As the length of the element is increased in one direction while keeping surfaces in the lateral direction squares of area 1, the eigenvalue estimate asymptotes to $1/\sqrt{2}$ for very long elements. If the length is decreased, the eigenvalue estimate asymptotes to the minimum distance between nodes for very thin elements. In this case, the eigenvalue estimate is always more conservative than the minimum distance between nodes. However, consider an element whose cross section in one direction is not a square but a trapezoid with one side length much greater than the other. Assume the large side length is 1 and the other side length is arbitrarily small, ε. In this case, the minimum distance between nodes becomes ε, creating a very small and inefficient time step. However, the eigenvalue estimate is related to the length across the middle of the trapezoid, which for the conditions stated is $1/2$. Since both distances provide stable time steps, and one or the other can be much larger in various circumstances, the most efficient calculation is obtained by using the maximum of the two lengths, either the eigenvalue estimate or the minimum distance between nodes, to determine the time step.

By using the maximum of the lengths, the computed critical time step should be at the edge of instability, and the TIME STEP SCALE FACTOR command line should be used to provide a margin of safety. In this case the scale factor for the time step should not be greater than 0.9, and in some cases it may have to be reduced further. Thus, although the maximum of the lengths provides a

time step that is closer to the critical value and provides better accuracy and efficiency, you may need to specify a smaller-than-expected scale factor for stability. For this reason, the choice of which approach to use is left to the user and is determined by the command line:

```
ELEMENT NUMERICAL FORMULATION = <string>OLD|NEW(OLD)
```

If the input parameter is `OLD`, only the eigenvalue estimate is used; `NEW` means that the maximum of the two lengths is used. The default is `OLD` so that users will have to specifically choose the new approach and be aware of the scale factor for the time step.

The `ELEMENT NUMERICAL FORMULATION` command line is applicable to both the energy-dependent and purely mechanical material models. If this command line is applied to blocks using energy-dependent materials, only the determination of the characteristic length is affected. If this command line is applied to an element block with a purely mechanical model and the `OLD` option is used, the Pronto3D-based artificial viscosity, time step, and eigenvalue estimate will be used in the element calculations. If, however, the `NEW` option is used, the artificial viscosity and time step will be computed from equations associated with the energy-dependent models. You should consult Reference 8 for further details about the critical time-step calculations and the use of this command line.

5.1.2.7 Activation/Deactivation of Element Blocks by Time

```
ACTIVE FOR PROCEDURE <string>proc_name DURING PERIODS
  <string list>period_names
```

This command line permits the activation and deactivation of element blocks by time period. The time periods are defined in the `TIME STEPPING BLOCK` command block (Section 3.10.1) within a specific procedure named in an `ADAGIO PROCEDURE` command block (Section 2.2.1). In the `ACTIVE FOR PROCEDURE` command line, the element block is active for all periods listed for the named procedure. The element block is deactivated for all time periods that are absent from the list. If this command line is not used, then by default the block is active during all time periods.

Known Issue: Deactivation of element blocks does not currently work in conjunction with the full tangent preconditioner (see Section 3.2) in Adagio. To use this capability, one of the nodal preconditioners must be used.

5.2 Element Sections

Element sections are defined by section command blocks. There are currently nine different types of section command blocks. The section command blocks appear in the domain scope, at the same level as the `FINITE ELEMENT MODEL` command block. In general, a section command block has the following form:

```
BEGIN section_type SECTION <string>section_name
  command lines dependent on section type
END [section_type SECTION <string>section_name]
```

Currently, `section_type` can be `SOLID`, `SHELL`, `MEMBRANE`, `BEAM`, `TRUSS`, `SPRING`, `DAMPER`, `POINT MASS`, or `SPH`. These various section types are identified as individual section command blocks and are described below. The corresponding `section_name` parameter in each of these command blocks, e.g., `truss_section_name` in the `TRUSS SECTION` command block, is selected by the user. The method used to associate these names with individual `SECTION` command lines in `PARAMETERS FOR BLOCK` command blocks is discussed in Section 5.1.2.2.

5.2.1 Solid Section

```
BEGIN SOLID SECTION <string>solid_section_name
  FORMULATION = <string>MEAN_QUADRATURE|
    SELECTIVE_DEVIATORIC(MEAN_QUADRATURE)
  DEVIATORIC PARAMETER = <real>deviatoric_param
  STRAIN INCREMENTATION = <string>MIDPOINT_INCREMENT|
    STRONGLY_OBJECTIVE|NODE_BASED(MIDPOINT_INCREMENT)
  NODE BASED ALPHA FACTOR = <real>bulk_stress_weight(0.01)
  NODE BASED BETA FACTOR = <real>shear stress_weight(0.35)
  RIGID BODY = <string>rigid_body_name
  USE LAME
END [SOLID SECTION <string>solid_section_name]
```

The `SOLID SECTION` command block is used to specify the properties for solid elements (hexahedra and tetrahedra). This command block is to be referenced by an element block made up of solid elements. The two types of solid-element topologies currently supported are hexahedra and tetrahedra. The parameter `solid_section_name` is user-defined and is referenced by a `SECTION` command line in a `PARAMETERS FOR BLOCK` command block.

The `FORMULATION` command line specifies whether the element will use a single-point integration rule (mean quadrature) or a selective-deviatoric rule. The selective-deviatoric integration rule is a higher-order integration scheme, which is discussed below.

If the user wishes to use the selective-deviatoric rule, the `DEVIATORIC PARAMETER` command line must also appear in the `SOLID SECTION` command block. The selective-deviatoric parameter, `deviatoric_param`, which is valid from 0.0 to 1.0, indicates how much of the deviatoric

response should be taken from a uniform-gradient integration and how much should be taken from a full integration of the element. A value of 0.0 will give a pure uniform-gradient response with no hourglass control. Thus, this value is of little practical use. A value of 1.0 will give a fully integrated deviatoric response. Although any value between 0.0 and 1.0 is perfectly valid, lower values are generally preferred.

The selective-deviatoric elements, when used with a value greater than 0.0, provide hourglass control without artificial hourglass parameters.

Some of the solid elements support different strain-incrementation formulations. See the element summary at the beginning of Section 5.1 to determine what strain-incrementation formulations are available for the various elements. The `STRAIN INCREMENTATION` command line, lets you specify a midpoint-increment strain formulation (`MIDPOINT_INCREMENT`), a strongly objective strain formulation (`STRONGLY_OBJECTIVE`), or a node-based formulation (`NODE_BASED`) for some of the elements. Consult the element documentation [2, 6] for a description of these strain formulations.

The node-based formulation can only be used with four-node tetrahedral elements. If your element-block command block (i.e., a `PARAMETERS FOR BLOCK` command block) has a `SECTION` command line that references a `SOLID SECTION` command block that uses:

```
STRAIN INCREMENTATION = NODE_BASED
```

then the element block must be a block of four-node tetrahedral elements.

The node-based formulation lets you calculate a solution that is some mixture of an element-based formulation (information from the center of an element) and a node-based formulation (information at a node that is based on all elements attached to the node). The node-based tetrahedron allows the user to model with four-node tetrahedral elements and avoid the main problems with regular tetrahedral elements. Regular tetrahedral elements are much too stiff and can produce very inaccurate results.

You can adjust the mixture of node-based versus element-based information incorporated into your solution with the `NODE BASED ALPHA FACTOR` and `NODE BASED BETA FACTOR` command lines. These two lines apply only if you have selected the `NODE BASED` option on the `STRAIN INCREMENTATION` command line. The value for `bulk_stress_weight` on the `NODE BASED ALPHA FACTOR` command line sets the element bulk stress weighting factor, while the value for `shear_stress_weight` on the `NODE BASED BETA FACTOR` command line sets the element shear stress weighting factor. You should consult Reference 3 to better understand the use of these weighting factors. If both of these factors are set to 0.0, you will be using a strictly node-based formulation. If both of these factors are set to 1.0, you will be using a strictly element-based formulation.

You can indicate that elements using this section should be rigid by including the `RIGID BODY` command line. The `RIGID BODY` command line specifies an identifier that maps to a rigid body command block. Consult with Section 5.3.1 for a full discussion of how to create rigid bodies.

You can request that the material model that will be used with this solid section come from the LAME material model library [9] with the `USE LAME` line command.

5.2.2 Shell Section

```
BEGIN SHELL SECTION <string>shell_section_name
  THICKNESS = <real>shell_thickness
  THICKNESS MESH VARIABLE =
    <string>THICKNESS|<string>var_name
  THICKNESS TIME STEP = <real>time_value
  THICKNESS SCALE FACTOR = <real>thick_scale_factor(1.0)
  INTEGRATION RULE = TRAPEZOID|GAUSS|LOBATTO|SIMPSONS|
    USER(TRAPEZOID)
  NUMBER OF INTEGRATION POINTS = <integer>num_int_points(5)
  BEGIN USER INTEGRATION RULE
    <real>location_1 <real>weight_1
    <real>location_2 <real>weight_2
    .
    .
    <real>location_n <real>weight_n
  END [USER INTEGRATION RULE]
  LOFTING FACTOR = <real>lofting_factor(0.5)
  ORIENTATION = <string>orientation_name
  RIGID BODY = <string>rigid_body_name
END [SHELL SECTION <string>shell_section_name]
```

The `SHELL SECTION` command block is used to specify the properties for a shell element. If this command block is referenced in an element block of three-dimensional, four-node elements, the elements in the block will be treated as shell elements. The parameter, `shell_section_name`, is user-defined and is referenced by a `SECTION` command line in a `PARAMETERS FOR BLOCK` command block.

Either a `THICKNESS` command line or a `THICKNESS MESH VARIABLE` command line must appear in the `SHELL SECTION` command block.

If a shell element block references a `SHELL SECTION` command block with the command line:

```
THICKNESS = <real>shell_thickness
```

then all the membrane elements in the block will have their thickness initialized to the value `shell_thickness`.

Adagio can also initialize the thickness using an attribute defined on elements in the mesh file. Meshing programs such as PATRAN and CUBIT typically set the element thickness as an attribute on the elements. If the elements have one and only one attribute defined on the mesh, the `THICKNESS MESH VARIABLE` command line should be specified as:

```
THICKNESS MESH VARIABLE = THICKNESS
```

which causes the thickness of the element to be initialized to the value of the attribute for that element. If there are zero attributes or more than one attribute, the thickness variable will not be automatically defined, and the command will fail.

The thickness may also be initialized by any other field present on the input mesh. To specify a field other than the single-element attribute, use this form of the THICKNESS MESH VARIABLE command line:

```
THICKNESS MESH VARIABLE = <string>var_name
```

Here, the string var_name is the name of the initializing field.

The input mesh may have values defined at more than one point in time. To choose the point in time in the mesh file that the variable should be read, use the command line:

```
THICKNESS TIME STEP = <real>time_value
```

The default time point in the mesh file at which the variable is read is 0.0.

Once the thickness of a shell element is initialized by using either the THICKNESS command line or the THICKNESS MESH VARIABLE command line, this initial thickness value can then be scaled using the scale-factor command line:

```
THICKNESS SCALE FACTOR = <real>thick_scale_factor
```

If the initial thickness of the shell is 0.15 inch, and the value for thick_scale_factor is 0.5, then the scaled thickness of the membrane will be 0.075.

The thickness mesh variable specification may be coupled with the THICKNESS SCALE FACTOR command line. In this case, the thickness mesh variable is scaled by the specified factor.

For shell elements, the user can select from a number of integration rules, including a user-defined integration option. The integration rule is selected with the command line:

```
INTEGRATION RULE = <string>TRAPEZOID|GAUSS|LOBATTO|SIMPSONS|
     USER(TRAPEZOID)
```

Consult the element documentation [6] for a description of different integration schemes for shell elements.

The default integration scheme is TRAPEZOID with five integration points through the thickness. The number of integration points for TRAPEZOID can be set to any number greater than one by using the following command line:

```
NUMBER OF INTEGRATION POINTS = <integer>num_int_points(5)
```

The SIMPSONS, GAUSS, and LOBATTO integration schemes in the INTEGRATION RULE command line all default to five integration points. The number of integration points for these three schemes can be reset by using the NUMBER OF INTEGRATION POINTS command line. There are limitations on the number of integration points for some of these integration rules. The SIMPSONS rule can be set to any number greater than one, the GAUSS scheme can be set to one through seven integration points, and the LOBATTO integration scheme can be set to two through seven integration points.

In addition to these standard integration schemes, you may also define an integration scheme by using the USER INTEGRATION RULE command block.

```
BEGIN USER INTEGRATION RULE
  <real>location_1 <real>weight_1
```

```
    <real>location_2 <real>weight_2
    .
    .
    <real>location_n <real>weight_n
  END [USER INTEGRATION RULE]
```

You may NOT specify both a standard integration scheme and a user scheme. If the `USER` option is specified in the `INTEGRATION RULE` command line, a set of integration locations with associated weight factors must be specified. This is done with tabular input command lines inside the `USER INTEGRATION RULE` command block. The number of command lines inside this command block should match the number of integration points specified in the `NUMBER OF INTEGRATION POINTS` command line. For example, suppose we wish to use a user-defined scheme with three integration points. The `NUMBER OF INTEGRATION POINTS` command line should specify three (3) integration points and the number of command lines inside the `USER INTEGRATION RULE` command block should be three (to give three locations and three weight factors).

For the user-defined rule, the integration point locations should fall between –1 and +1, and the weights should sum to 1.0.

The command line

```
LOFTING FACTOR = <real>lofting_factor(0.5)
```

allows the user to shift the location of the midsurface of a shell element relative to the geometric location of the shell element. By default, the geometric location of a shell element in a mesh represents the midsurface of the shell. If a shell has a thickness of 0.2 inch, the top surface of the shell is 0.1 inch above the geometric surface defined by the shell element, and the bottom surface of the shell is 0.1 inch below the geometric surface defined by the shell element. (The top surface of the shell is the surface with a positive element normal; the bottom surface of the shell is the surface with a negative element normal.)

Figure 5.2 shows an edge-on view of shell elements with a thickness of t and the location of the geometric plane in relation to the shell surfaces for three different values of the lofting factor—0.0, 0.5, and 1.0. If you want to have the geometric surface defined by the shell correspond to the top surface of the shell element, set the lofting factor to 1.0. If you want to have the geometric surface defined by the shell correspond to the bottom surface of the shell element, set the lofting factor to 0.0. The geometric surface is midway between the top and bottom surfaces for a lofting factor of 0.5. Note that the default for this factor is 0.5.

Suppose that the lofting factor is set to 1.0 and the thickness of the shell is 0.2 inch. Let us measure distances to the shell surfaces (top and bottom) by measuring along the positive element normal. The top surface of the shell will be located at a distance of 0.0 inch from the geometric shell surface, and the bottom surface of the shell will be located at a distance of –0.2 inch from the geometric shell surface.

Both the shell mechanics and contact use shell lofting. See Section 7.3 for a discussion of lofting surfaces for shells and contact.

The `ORIENTATION` command line lets you select a coordinate system for output of stresses. The `ORIENTATION` option makes use of an embedded coordinate system *rst* associated with each shell



Figure 5.2: Location of geometric plane of shell for various lofting factors.

element. The *rst* coordinate system for a shell element is shown in Figure 5.3. The *r*-axis extends from the center of the shell to the midpoint of the side of the shell defined by nodes 1 and 2. The *t*-axis is located at the center of the shell and is normal to the surface of the shell at the center point. The *s*-axis is the cross-product of the *t*-axis and the *r*-axis. The *rst*-axes form a local coordinate system at the center of the shell; this local coordinate system moves with the shell element as the element deforms.



Figure 5.3: Local *rst* coordinate system for a shell element.

The `ORIENTATION` command line in the `SHELL SECTION` command block references an `ORIENTATION` command block that appears in the domain scope. As described in Chapter 2 of this document, the `ORIENTATION` command block can be used to define a local coordinate system $X''Y''Z''$ at the center of a shell element. In the original shell configuration (time 0), one of the axes—X'', Y'', or Z''—is projected onto the plane of the shell element. The angle between this projected axis of the

$X''Y''Z''$ coordinate system and the r-axis is used to establish the transformation for the stresses. We will illustrate this with an example.

Suppose that in our `ORIENTATION` command block we have specified a rotation of 30 degrees about the 1-axis (X'-axis). The command line for this rotation in the `ORIENTATION` command block would be:

```
ROTATION ABOUT 1 = 30
```

For this case, we project the Y''-axis onto the plane of the shell (Figure 5.4). The angle between this projection and the r-axis establishes a transformation for the in-plane stresses of the shell (the stresses in the center of the shell lying in the plane of the shell). What will be output as the in-plane stress σ_{xx}^{ip} will be in the Y''-direction; what will be output as the in-plane stress σ_{yy}^{ip} will be in the Z''-direction. The in-plane stress σ_{xy}^{ip} is a shear stress in the $Y''Z''$-plane. The $X''Y''Z''$ coordinate system maintains the same relative position in regard to the *rst* coordinate system. This means that the $X''Y''Z''$ coordinate system is a local coordinate system that moves with the shell element as the element deforms.



Figure 5.4: Rotation of 30 degrees about the 1-axis (X'-axis).

The following permutations for output of the in-plane stresses occur depending on the axis (1, 2, or 3) specified in the `ROTATION ABOUT` command line:

- Rotation about the 1-axis (X'-axis): The in-plane stress σ_{xx}^{ip} will be in the Y''-direction; the in-plane stress σ_{yy}^{ip} will be in the Z''-direction. The in-plane stress σ_{xy}^{ip} is a shear stress in the $Y''Z''$-plane.

- Rotation about the 2-axis (Y'-axis): The in-plane stress σ_{xx}^{ip} will be in the Z''-direction; the in-plane stress σ_{yy}^{ip} will be in the X''-direction. The in-plane stress σ_{xy}^{ip} is a shear stress in the $Z''X''$-plane.

- Rotation about the 3-axis (Z'-axis): The in-plane stress σ_{xx}^{ip} will be in the X''-direction; the in-plane stress σ_{yy}^{ip} will be in the Y''-direction. The in-plane stress σ_{xy}^{ip} is a shear stress in the $X''Y''$-plane.

You can indicate that elements using this section should be rigid by including the `RIGID BODY` command line. The `RIGID BODY` command line specifies an indenter that maps to a rigid body command block. Consult with Section 5.3.1 for a full discussion of how to create rigid bodies.

5.2.3 Membrane Section

```
BEGIN MEMBRANE SECTION <string>membrane_section_name
  THICKNESS = <real>mem_thickness
  THICKNESS MESH VARIABLE =
    <string>THICKNESS|<string>var_name
  THICKNESS TIME STEP = <real>time_value
  THICKNESS SCALE FACTOR = <real>thick_scale_factor(1.0)
  FORMULATION = <string>MEAN_QUADRATURE|
    SELECTIVE_DEVIATORIC(MEAN_QUADRATURE)
  DEVIATORIC PARAMETER = <real>deviatoric_param
  LOFTING FACTOR = <real>lofting_factor(0.5)
  RIGID BODY = <string>rigid_body_name
END [MEMBRANE SECTION <string>membrane_section_name]
```

The `MEMBRANE SECTION` command block is used to specify the properties for a membrane element. If a section defined by this command block is referenced in the parameters for a block of four-noded elements, the elements in that block will be treated as membranes. The parameter `membrane_section_name` is user-defined and is referenced by a `SECTION` command line in a `PARAMETERS FOR BLOCK` command block.

Either a `THICKNESS` command line or a `THICKNESS MESH VARIABLE` command line must appear in the `MEMBRANE SECTION` command block.

If a membrane element block references a `MEMBRANE SECTION` command block with the command line:

```
THICKNESS = <real>mem_thickness
```

then all the membrane elements in the block will have their thickness initialized to the value `mem_thickness`.

Adagio can also initialize the thickness using an attribute defined on elements in the mesh file. Meshing programs such as PATRAN and CUBIT typically set the element thickness as an attribute on the elements. If the elements have one and only one attribute defined on the mesh, the `THICKNESS MESH VARIABLE` command line should be specified as:

```
THICKNESS MESH VARIABLE = THICKNESS
```

which causes the thickness of the element to be initialized to the value of the attribute for that element. If there are zero attributes or more than one attribute, the thickness variable will not be

automatically defined, and the command will fail.

The thickness may also be initialized by any other field present on the input mesh. To specify a field other than the single-element attribute, use this form of the THICKNESS MESH VARIABLE command line:

```
THICKNESS MESH VARIABLE = <string>var_name
```

where the string var_name is the name of the initializing field.

The input mesh may have values defined at more than one point in time. To choose the point in time in the mesh file that the variable should be read, use the command line:

```
THICKNESS TIME STEP = <real>time_value
```

The default time point in the mesh file at which the variable is read is 0.0.

Once the thickness of a membrane element is initialized by using either the THICKNESS command line or the THICKNESS MESH VARIABLE command line, this initial thickness value can then be scaled by using the scale-factor command line:

```
THICKNESS SCALE FACTOR = <real>thick{_}scale_factor
```

If the initial thickness of the membrane is 0.15 inch, and the value for thick_scale_factor is 0.5, then the scaled thickness of the membrane will be 0.075.

The FORMULATION command line specifies whether the element will use a single-point integration rule (mean quadrature) or a selective-deviatoric integration rule:

```
FORMULATION = <string>MEAN_QUADRATURE|SELECTIVE_DEVIATORIC
  (MEAN_QUADRATURE)
```

The selective-deviatoric rule is a higher-order integration scheme, which is discussed below.

If the user wishes to use the selective-deviatoric rule, the DEVIATORIC PARAMETER command line must also appear in the MEMBRANE SECTION command block:

```
DEVIATORIC PARAMETER = <real>deviatoric_param
```

The selective-deviatoric parameter, deviatoric_param, which is valid from 0.0 to 1.0, indicates how much of the deviatoric response should be taken from a uniform-gradient integration and how much should be taken from a full integration of the element. A value of 0.0 will give a pure uniform-gradient response with no hourglass control. Thus, this value is of little practical use. A value of 1.0 will give a fully integrated deviatoric response. Although any value between 0.0 and 1.0 is perfectly valid, lower values are generally preferred.

The selective-deviatoric elements, when used with a parameter greater than 0.0, provide hourglass control without artificial hourglass parameters.

The command line

```
LOFTING FACTOR = <real>lofting_factor(0.5)
```

allows the user to shift the location of the midsurface of a membrane element relative to the geometric location of the membrane element. By default, the geometric location of a membrane

element in a mesh represents the midsurface of the membrane. If a membrane has a thickness of 0.2 inch, the top surface of the membrane is 0.1 inch above the geometric surface defined by the membrane element, and the bottom surface of the membrane is 0.1 inch below the geometric surface defined by the membrane element. (The top surface of the membrane is the surface with a positive element normal; the bottom surface of the membrane is the surface with a negative element normal.)

Figure 5.2, which shows lofting for shells, is also applicable to membranes. For membranes, Figure 5.2 represents an edge-on view of membrane elements with a thickness of t and the location of the geometric plane in relation to the membrane surfaces for three different values of the lofting factor—0.0, 0.5, and 1.0. If you want to have the geometric surface defined by the membrane correspond to the top surface of the membrane element, set the lofting factor to 1.0. If you want to have the geometric surface defined by the membrane correspond to the bottom surface of the membrane element, set the lofting factor to 0.0. The geometric surface is midway between the top and bottom surfaces for a lofting factor of 0.5. Note that the default for this factor is 0.5.

Suppose that the lofting factor is set to 1.0 and the thickness of the membrane is 0.2 inch. Let us measure distances to the membrane surfaces (top and bottom) by measuring along the positive element normal. The top surface of the membrane will be located at a distance of 0.0 inch from the geometric membrane surface, and the bottom surface of the membrane will be located at a distance of –0.2 inch from the geometric membrane surface.

Both the membrane mechanics and contact use membrane lofting. See Section 7.3 for a discussion of lofting surfaces for membranes and contact.

You can indicate that elements using this section should be rigid by including the `RIGID BODY` command line. The `RIGID BODY` command line specifies an indenter that maps to a rigid body command block. Consult with Section 5.3.1 for a full discussion of how to create rigid bodies.

5.2.4 Truss Section

```
BEGIN TRUSS SECTION <string>truss_section_name
  AREA = <real>cross_sectional_area
  INITIAL LOAD = <real>initial_load
  PERIOD = <real>period
  RIGID BODY = <string>rigid_body_name
END [TRUSS SECTION <string>truss_section_name]
```

The `TRUSS SECTION` command block is used to specify the properties for a truss element. If this command block is referenced in an element block of three-dimensional, two-node elements, the elements in the block will be treated as truss elements. The parameter, `truss_section_name`, is user-defined and is referenced by a `SECTION` command line in a `PARAMETERS FOR BLOCK` command block.

The cross-sectional area for truss elements is specified by the `AREA` command line. The value `cross_sectional_area` is the cross-sectional area of the truss members in the element block.

The truss can be given some initial load over some given time period. The magnitude of the load is specified by the `INITIAL LOAD` command line. If the load is compressive, the sign on the value `initial_load` should be negative; if the load is tensile, the sign on the value `initial{_}value` should be positive. The period is specified by the `PERIOD` command line.

The initial load is applied over some period by specifying the axial strain rate in the truss, $\dot{\varepsilon}$, over some period p. At some given time t, the strain rate is

$$\dot{\varepsilon} = \frac{ap}{2}\left[1 - \cos\left(\pi t/p\right)\right], \tag{5.1}$$

where

$$a = \frac{2F_i}{EAp}. \tag{5.2}$$

In Equation (5.2), F_i is the initial load, E is the modulus of elasticity for the truss, and A is the area of the truss. Over the period p, the total strain increment generates the desired initial load in the truss.

During the initial load period, the time increments should be reasonably small so that the integration of $\dot{\varepsilon}$ over the period is accurate. The period should be set long enough so that if the model was held in a steady state after time p, there would only be a small amount of oscillation in the load in the truss.

When doing an analysis, you may not want to activate certain boundary conditions until after the prestressing is done. During the prestressing, time-independent boundary conditions such as fixed displacement will most likely be turned on. Time-dependent boundary conditions such as prescribed acceleration or prescribed force will most likely be activated after the prestressing is complete.

You can indicate that elements using this section should be rigid by including the `RIGID BODY` command line. The `RIGID BODY` command line specifies an indenter that maps to a rigid body command block. Consult with Section 5.3.1 for a full discussion of how to create rigid bodies.

5.2.5 Point Mass Section

```
BEGIN POINT MASS SECTION <string>pointmass_section_name
  VOLUME = <real>volume
  RIGID BODY = <string>rigid_body_name
END [POINT MASS SECTION <string>pointmass_section_name]
```

A point mass element is simply a mass at a node, which can be a convenient modeling tool in certain instances. The user can create an element block with one or more point masses. Each point mass must be associated with an existing node. A point mass will have its mass added to the mass at the node. (Other mass at the node will be derived from mass due to elements attached to the node.) The mass at a node due to a point mass is treated like any other mass at a node derived from

an element. The mass due to point mass will be included in body force calculations and kinetic energy calculations, for example.

Point masses are a convenient modeling tool to be used in conjunction with rigid bodies. An element block including one or more point masses can be included like any other element block in a collection of element blocks used to define a rigid body. The element block of point masses can be used to adjust the total mass and inertia properties for the rigid body. (The point mass element does not have to be used only in conjunction with rigid bodies. One can place a point mass at a node associated with solid or structural elements.)

If you have an element block in which the connectivity for each element is only one node, then you may use this element block as a collection of point masses. This command block would have the following form:

```
BEGIN PARAMETERS FOR BLOCK <string>block_id
  MATERIAL = <string>material_name
  SOLID MECHANICS USE MODEL <string> material_model_name
  SECTION = <string>point_mass_section_name
END PARAMETERS FOR BLOCK <string>block_id
```

The element block associated with our point mass must reference a material command block just like any other element block. The product of the density specified in the material block and the volume specified in the section block (for the point mass) will be taken as the mass of each point mass in the element block. Suppose, for example, you have the following `PARAMETERS FOR BLOCK` command block for an element block with point masses:

```
BEGIN PARAMETERS FOR BLOCK block_105
  MATERIAL = mass_for_pointmass
  SOLID MECHANICS USE MODEL elastic
  SECTION = pmass_1
END PARAMETERS FOR BLOCK block_105
```

The above element block for the point mass elements references the material `mass_for_pointmass`. Let the density associated with this material be 0.0153. Let the value of the volume parameter associated with the section block `pmass_1` be 4.0. Each point mass in the element block will have a mass of $4.0 \times 0.0153 = 0.0612$.

If you have access to the SEACAS codes from Sandia National Laboratories, you may use the codes in this library to generate element blocks with point mass elements. See Reference 11 for an overview of the SEACAS codes. By using various SEACAS codes, you can easily generate an element block with one or more point masses. For each point mass in the element block, you should create an eight-node hexahedral element that is centered at the point where you want the point mass located. The hexahedron can have arbitrary dimensions, but it is best to work with a unit cube. Suppose you wanted a point mass at (13.5, 27.0, 3.1415). You could create a unit hexahedron (1 by 1 by 1) centered on (13.5, 27.0, 3.1415). The SEACAS program SPHGEN3D will convert the hexahedron to a zero-dimensional element in three-dimensional space located at the center of the hexahedron. For our specific example, the program SPHGEN3D would create a zero-dimensional element, basically an element consisting of a single node, at (13.5, 27.0, 3.1415).

5.3 Element-like Functionality

This section describes the rigid body functionality in Adagio. The rigid body functionality resembles the previously described elements to some extent, but it is not implemented using the element structure in Adagio. The rigid body functionality described in this section is specified through command blocks that appear in the domain scope.

5.3.1 Rigid Body

```
BEGIN RIGID BODY <string>rb_name
  MASS = <real>mass
  MASS LOCATION = <real>CGx <real>CGy <real>CGz
  INERTIA = <real>Ixx <real>Iyy <real>Izz <real>Ixy
    <real>Iyz <real>Izx
  POINT INERTIA = <real>Ixx <real>Iyy <real>Izz <real>Ixy
    <real>Iyz <real>Izx
  MAGNITUDE = <real>magnitude_of_velocity
  DIRECTION = <string>direction_definition
  ANGULAR VELOCITY = <real>omega
  CYLINDRICAL AXIS = <string>axis_definition
END [RIGID BODY <string>rb_name]
```

A rigid body can consist of any combination of elements—solid elements, structural elements, and point masses. All nodes associated with a rigid body maintain their same relative position to each other as determined at time 0 when there is no deformation of the body. This means that the elements associated with the rigid body do not deform over time. These elements are free to move (rotate and translate) through space, but they cannot deform. Element blocks that are part of a rigid body can adjoin deformable element blocks. For any rigid body consisting of several element blocks, the element blocks defining the rigid body do not have to be contiguous. You may have more than one rigid body in a model.

Adagio creates a new node for each rigid body in the analysis. The new nodes are true nodes in that they are associated with solution fields such as displacement, velocity, and rotational velocity. These nodes will appear in a results file along with other nodes. The global node number given to the new nodes is simply the total number of nodes in the mesh plus one, repeated for each new rigid body node.

To construct the rigid body, you will need to use the above command block, which appears in the domain scope, plus the `RIGID BODY` command line that appears in the various `SECTION` command blocks described in this chapter. Suppose, for example, `rigidbody_1` consists of element blocks 100, 110, and 280. The `PARAMETERS FOR BLOCK` command blocks for element blocks 100, 110, and 280 must all contain a `SECTION` command line. In each case, the Section referred to must contain a line such as:

```
RIGID BODY = rigidbody_1
```

Once you have declared an element block or some collection of element blocks to be a rigid body and created a rigid body name (through the Section chosen), that rigid body name must appear as the name in a RIGID BODY command block. In our example, we must have a RIGID BODY command block with the value for rb_name set to rigidbody_1. Therefore, at a minimum, you must have a command block in the domain with the form

```
BEGIN RIGID BODY rigidbody_1
   END RIGID BODY rigidbody_1
```

for our example.

The RIGID BODY command block has several different command lines, composing essentially three groups of commands. One group consists of the MASS, MASS LOCATION, POINT INERTIA, and INERTIA command lines, a second group consists of the paired MAGNITUDE and DIRECTION command lines, and a third group consists of the paired ANGULAR VELOCITY and CYLINDRICAL AXIS command lines. Each of the three groups is optional. You can combine any of these groups in the command block, or you could have a command block that contains none of the command lines, whereupon you would only supply the value for rb_name in the block.

Input to the MASS command line consists of a single real number that defines the total mass of the rigid body. If this line command is not present, the mass of the rigid body will be computed using the elements in the rigid body and their densities.

The MASS LOCATION command line requires three real numbers. Using this line command will specify the center of mass for the rigid body. If this line command is not present, the center of mass will be calculated.

Input to the INERTIA command line also consists of six real numbers. If present, this command line will set the inertia for the rigid body. If it is not present, moments and products of inertia are computed for the rigid body based on the location of the center of mass of the rigid body and the element masses for all the elements associated with the rigid body.

Input to the POINT INERTIA command line consists of six real numbers that define moments (Ixx, Iyy, Izz) and products (Ixy, Iyx, Izx) of inertia to be added to the inertia tensor of the rigid body. This modified inertia tensor (rather than the inertia tensor based solely on element mass) is then used to calculate the motion of the rigid body.

If the rigid body has an initial velocity in some direction, this should be specified with the MAGNITUDE and DIRECTION command lines. The MAGNITUDE command line gives the magnitude of the initial velocity applied to the center of mass of the rigid body, and the DIRECTION command line gives a defined direction for the initial velocity for the center of mass. All blocks associated with the rigid body should be given the same initial velocity by using an INITIAL VELOCITY command block. (The information in the RIGID BODY command block is only applied to the center of mass of the rigid body.)

If the rigid body has an initial rotation about some axis, this should be specified with the ANGULAR VELOCITY and CYLINDRICAL AXIS command lines. The ANGULAR VELOCITY command line gives the initial velocity of the center of mass of the rigid body due to an angular velocity about some defined axis given on the CYLINDRICAL AXIS command line. All blocks associated with the rigid body should be given the same initial angular velocity by using an INITIAL VELOCITY

command block. (The information in the `RIGID BODY` command block is only applied to the center of mass of the rigid body.)

Adagio automatically outputs quantities such as displacement for the center of mass of the rigid body. The name assigned to a rigid body will be used to construct registered variable names that give the quantities. This lets you identify the output associated with a rigid body based on the name you assigned for the rigid body.

In summary, if you use a rigid body in an analysis, you will do one or more of the following steps:

- Create a rigid body using one or more element blocks (except SPH element blocks). A `RIGID BODY` command line must appear in the `SECTION` command block used in the `PARAMETERS FOR BLOCK` command block for any element block associated with a rigid body.
- Include point mass element blocks with the rigid body if appropriate. To include point mass element blocks in a rigid body, a `RIGID BODY` command line must appear in the `SECTION` command block used in the `PARAMETERS FOR BLOCK` command block for those point mass element blocks.
- Include a `RIGID BODY` command block in the domain.
- Associate an initial velocity or initial rotation about an axis with the rigid body, if appropriate. If any of the blocks associated with a rigid body have been given an initial velocity or initial rotation, the rigid body must have the same specification for the initial velocity or initial rotation.
- Output center-of-mass information for the rigid body.

The above steps involve a number of different command blocks. To demonstrate how to fully implement a rigid body, we will provide a specific example that exercises the various options available to a user.

Let us assume that we want to create a rigid body named `part_a` consisting of three element blocks. Two of the element blocks, element block 100 and element block 535, are eight-node hexahedra; one of the element blocks, element block 600, consists of only point masses. The `RIGID BODY` command block, `SECTION` command block, and the element blocks we want to associate with the rigid body will be as follows:

```
begin solid section hex_section
  rigid body = part_a
end
begin point mass section pm_section
  rigid body = part_a
  volume = 0.1
end

begin parameters for block block_100
  material steel
```

```
    solid mechanics model use elastic
    section = hex_section
  end
  begin parameters for block block_535
    material = aluminum
    solid mechanics model use elastic
    section = hex_section
  end
  begin parameters for block block_600
    material = mass_for_pointmass
    solid mechanics model use elastic
    section = pm_section
  end
```

To adjust the moments and products of inertia computed by Presto for the rigid body `part_a`, we included the `POINT INERTIA` command line in the above section command block for the rigid body.

Now that we have defined the rigid body, we will examine how to specify an initial angular velocity about an axis for the rigid body and how to output information at the center of mass for the rigid body. The center of mass of the rigid body is some computed point associated with the body. It may or may not be at or near any node in the body.

Suppose we want to have the rigid body spin at 600 radians/sec about an axis parallel to the x-axis and passing through a point at (0, 10, 20). We would define this axis using the following set of `DEFINE` command lines:

```
define direction parallel_to_x with vector 2.0 0.0 0.0
define point off_axis with coordinates 0.0 10.0 20.0
define axis body_axis with point off_axis
direction parallel to x
```

The blocks in the rigid body will be given an initial angular velocity of 600 radians/sec about the above axis if we use the following command block for initial angular velocity:

```
begin initial velocity
  block = block_100 block_535 block_600
  cylindrical axis = body_axis
  angular velocity = 600
end initial velocity
```

The `RIGID BODY` command block must be given the same specification for an initial angular velocity. The angular velocity specification in the `RIGID BODY` command block is applied to the center of mass of the rigid body to make sure its initial motion is consistent with the initial motion of all the nodes in the rigid body as defined by the `INITIAL VELOCITY` command block. Our `RIGID BODY` command block (in the region) will appear as follows:

```
begin rigid body part_a
  cylindrical axis = body_axis
  angular velocity = 600
end rigid body part_a
```

Adagio automatically generates and outputs global data associated with the rigid body (e.g. displacement and quaternion). The displacement of the rigid body named `part_a` will be written to the results file with the name `DISPLX_PART_A`.

If you have more than one rigid body in your model, you will be able to keep track of the center-of-mass information based on the rigid body name you give to each rigid body.

5.4 Mass Property Calculations

```
BEGIN MASS PROPERTIES
  # {block set commands}
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE BLOCK = <string list>block_names
  #
  # structure command
  STRUCTURE NAME = <string>structure_name
END [MASS PROPERTIES]
```

Adagio automatically gives mass property information for the total model, which consists of all the element blocks. (The mass for the total model, for example, is the total mass of all the element blocks.) Adagio also automatically gives mass property information for each element block.

In addition to the mass property information that is generated, Adagio gives you the option of defining a structure that represents some combination of element blocks and then of calculating the mass properties for this particular structure. If you wish to define a structure that is a combination of some group of element blocks, you must use the `MASS PROPERTIES` command block. This command block appears in the region scope.

For the total model, each element block, and any user-defined structure, Adagio reports the mass and the center of mass in the global coordinate system. It also reports the moments and products of inertia, as computed in the global coordinate system about the center of mass.

The `MASS PROPERTIES` command block contains two groups of commands—block set and structure. Each of these groups is basically independent of the other. Following are descriptions of the two command groups.

5.4.1 Block Set Commands

The {`block set commands`} portion of the `MASS PROPERTIES` command block defines a set of blocks for which mass properties are being requested, and can include some combination of the following command lines:

```
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of blocks. See Section 6.1.1 for more information about the use of these command lines for creating a set of blocks used by the command block. There must be at least one `BLOCK` or `INCLUDE ALL BLOCKS` command line in the command block.

The `REMOVE BLOCK` command line allows you to delete blocks from the set specified in the `BLOCK` and/or `INCLUDE ALL BLOCKS` command line(s) through the string list `block_names`. Typically,

you will use the `REMOVE BLOCK` command line with the `INCLUDE ALL BLOCKS` command line. If you want to include all but a few of the element blocks, a combination of the `REMOVE BLOCK` command line and `INCLUDE ALL BLOCKS` should minimize input information.

Suppose that only one element block, `block_300`, is specified on the `BLOCK` command line. Then only the mass properties for that block will be calculated. If several element blocks are specified on the `BLOCK` command line, then that collection of blocks will be treated as one entity, and the mass properties for that single entity will be calculated. Thus, for example, if two element blocks, say, `block_150` and `block_210`, are specified on the `BLOCK` command line, the total mass for the two element blocks will be reported as the total mass property.

5.4.2 Structure Command

The output for the mass properties will be identified by the command line:

```
STRUCTURE NAME = <string>structure_name
```

where the string `structure_name` is a user-defined name for the structure.

5.5 References

1. Taylor, L. M., and D. P. Flanagan. *Pronto3D: A Three-Dimensional Transient Solid Dynamics Program*, SAND87-1912. Albuquerque, NM: Sandia National Laboratories, March 1989.

2. Rashid, M. M. "Incremental Kinematics for Finite Element Applications." *International Journal for Numerical Methods in Engineering* 36 (1993): 3937–3956.

3. Dohrman, C. R., M. W. Heinstein, J. Jung, S. W. Key, and W. R. Witkowski. "Node-Based Uniform Strain Elements for Three-Node Triangular and Four-Node Tetrahedral Meshes." *International Journal for Numerical Methods in Engineering* 47 (2000): 1549–1568.

4. Key, S. W., M. W. Heinstein, C. M. Stone, F. J. Mello, M. L. Blanford, and K. G. Budge. "A Suitable Low-Order, Tetrahedral Finite Element for Solids." *International Journal for Numerical Methods in Engineering* 44 (1999) 1785–1805.

5. Key, S. W., and C. C. Hoff. "An Improved Constant Membrane and Bending Stress Shell Element for Explicit Transient Dynamics." *Computer Methods in Applied Mechanics and Engineering* 124, no. 1–2 (1995): 33–47.

6. Laursen, T. A., S. W. Attaway, and R. I. Zadoks. *SEACAS Theory Manuals: Part III. Finite Element Analysis in Nonlinear Solid Mechanics*, SAND98-1760/3. Albuquerque, NM: Sandia National Laboratories, 1999.

7. Flanagan, D. P., and T. Belytschko. "A Uniform Strain Hexahedron and Quadrilateral with Orthogonal Hourglass Control." *International Journal for Numerical Methods in Engineering* 17 (1981): 679–706.

8. Swegle, J. W. *SIERRA: PRESTO Theory Documentation: Energy Dependent Materials Version 1.0*. Albuquerque, NM: Sandia National Laboratories, October 2001.

9. Scherzinger, W. M., and D. C. Hammerand. *Constitutive Models in LAME*, SAND2007-5873. Albuquerque, NM: Sandia National Laboratories, September 2007.

10. Swegle, J. W., S. W. Attaway, M. W. Heinstein, F. J. Mello, and D. L. Hicks. *An Analysis of Smoothed Particle Hydrodynamics*, SAND93-2513. Albuquerque, NM: Sandia National Laboratories, March 1994.

11. Sjaardema, G. D. *Overview of the Sandia National Laboratories Engineering Analysis Code Access System*, SAND92-2292. Albuquerque, NM: Sandia National Laboratories, January 1993. http://jal.sandia.gov/SEACAS/Documentation/SEACAS_Overview.pdf.

12. Brown, K. H., R. M. Summers, M. W. Glass, A. S. Gullerud, M. W. Heinstein, and R. E. Jones. *ACME: Algorithms for Contact in a Multiphysics Environment*, API Version, 2.2, SAND2004-5486. Albuquerque, NM: Sandia National Laboratories, October 2001.

13. Sandia National Laboratories. "Zoltan: Data-Management Services for Parallel Applications." http://www.cs.sandia.gov/zoltan/ (accessed March 17, 2008).

Chapter 6

Boundary Conditions and Initial Conditions

Adagio offers a variety of options for defining boundary and initial conditions. Typically, boundary and initial conditions are defined on some subset of mesh entities (node, element face, element) defining a model. Adagio offers a flexible means to define subsets of mesh entities. Section 6.1.1 describes commands that will let you define some subset of a mesh entity using a collection of commands that constitute a set of Boolean operators.

The remaining parts of this chapter discuss the following functionality:

- Section 6.2 presents methods for setting the initial values of registered variables in Adagio. Adagio has the flexibility to set a complex initial state for some variable such as nodal velocity or element stress.

- Kinematic boundary conditions typical of those you would expect in a quasistatic code (fixed displacement, prescribed velocity, etc.) are options in Adagio and described in Section 6.3. Most of these boundary conditions let you specify a time history using some SIERRA function or a more complex time-varying and spatially varying history with a user subroutine.

- Section 6.4 documents a number of initial velocity options available in Adagio.

- Force boundary conditions typical of those you would expect in a quasistatic code (prescribed force, traction, etc.) are options in Adagio and described in Section 6.5. Most of these force boundary conditions let you specify a time history using some SIERRA function or a more complex time-varying and spatially varying history with a user subroutine.

- Section 6.6 discusses the gravity load option. A gravity load is a body force boundary condition.

- Section 6.7 details a number of options available for describing a temperature field in Adagio.

6.1 General Boundary Condition Concepts

There are general principles that apply to all of the available types of boundary conditions. To apply a boundary condition, a set of mesh entities and the magnitude and/or direction in which it is to be applied must be specified. Adagio provides several methods for both specifying the set of mesh entities and for prescribing how the boundary condition is to be applied. The general concepts on how this is done are applicable to all of the boundary condition types, and are described in the following sections.

6.1.1 Mesh-Entity Assignment Commands

A number of standard command lines exist to define a set of mesh entities (node, element face, element) associated with some type of mechanics. (Mechanics can be a boundary condition, an initial condition, or a gravity load.) All these command lines exist within the command blocks for the various mechanics, which in turn exist within the region scope. These command lines, taken collectively, constitute a set of boolean operators for constructing sets of mesh entities.

The first set of command lines we will consider is as follows:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
```

In the above command lines, the string list `nodelist_names` is used to represent one or more node sets as discussed in Section 1.5. A node set is referenced as `nodelist_id`, where id is some integer. For example, suppose you have three node lists in your model: 10, 23, and 105. If you want to combine all these node lists so that they form one set of nodes for, say, your boundary condition or initial condition, then you would use the command line:

```
NODE SET = nodelist_10 nodelist_23 nodelist_105
```

This convention applies as well to any surface-related command line that uses the string list `surface_names` or any block-related command line that uses the string list `block_names`.

The `NODE SET` command line associates a set of nodes with a mechanics. A mechanics may be applied to multiple node sets by putting multiple node set names on the command line or by repeating the command line multiple times.

The `SURFACE` command line associates a set of element faces with a mechanics. A mechanics may be applied to multiple surfaces by putting multiple surface names on the command line or by repeating the command line multiple times. The `SURFACE` command line can also be used to associate a set of nodes with a mechanics. For example, suppose we wish to use the fixed displacement kinematic boundary condition. Although this is a nodal boundary condition (the condition is applied to individual nodes), a `SURFACE` command line can be used to establish the set of nodes. If the command line

```
SURFACE = surface_101
```

appears in a fixed displacement boundary condition, then all the nodes associated with surface 101 will be associated with the boundary condition.

The `BLOCK` command line associates a set of elements with a mechanics. A mechanics may be applied to multiple blocks by putting multiple block names on the command line or by repeating the command line multiple times. The `BLOCK` command line can also be used to associate a set of nodes with a mechanics. For example, suppose we wish to use the fixed displacement kinematic boundary condition as in the previous example. If the command line

```
BLOCK = block_50
```

appears in a fixed displacement kinematic boundary condition, then all the nodes associated with block 50 will be associated with the boundary condition.

The `INCLUDE ALL BLOCKS` command line associates all blocks with a mechanics. This will apply the mechanics to all nodes and elements in the model.

The block-related command lines associated with contact will generate surfaces. The block command lines associated with boundary conditions, initial conditions, and gravity will NOT generate surfaces.

Any combination of the above command lines can be used to create a union of mesh entities. Suppose, for example, that the command lines

```
NODE SET = nodelist_2
   SURFACE = surface_3
```

appear in a `FIXED DISPLACEMENT` command block for a kinematic boundary condition. The set of nodes associated with the boundary condition will be the union of the set of nodes associated with surface 3 and the set of nodes associated with node set 2.

When a union of mesh entities is created by using two or more of the above command lines, a mesh entity may appear in more than one topological entity—node set, surface, block. However, the mechanics is applied to the mesh entity only once. For example, node 67 may be a part of nodelist 2 and surface 3. Including both nodelist 2 and surface 3 into a mechanics will only apply the mechanics to node 67 once.

The set of mesh entities associated with a mechanics can be edited (mesh entities can be deleted from the set) by using the following command lines:

```
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

The `REMOVE NODE SET` command line deletes a set of nodes from the node set associated with a mechanics.

The `REMOVE SURFACE` command line deletes a set of element faces from the set of element faces associated with a mechanics. It will remove a set of nodes associated with the surface from the set of nodes associated with the mechanics.

The `REMOVE BLOCK` command line deletes a set of elements from the set of elements associated with a mechanics. It will remove a set of nodes associated with the block from the node set associated with the mechanics.

6.1.2 Methods for Specifying Boundary Conditions

There are three main methods which can be used to prescribe most types of boundary conditions available in Adagio.

- The boundary condition can be prescribed using commands in the input file. These commands are categorized as "specification commands" in this document. Depending on the type of the boundary condition, it is be necessary to prescribe its direction and/or magnitude. Boundary conditions can be specified this way when a set of mesh entities is to experience a similar condition with a time variation that can be expressed by a function. One of the following commands is used to specify the direction of the boundary condition: `COMPONENT`, `DIRECTION`, `CYLINDRICAL AXIS`, or `RADIAL AXIS`. The magnitude is defined using one of `MAGNITUDE`, `FUNCTION` or `ANGULAR VELOCITY`. These commands are used in various combinations depending on the type of the boundary condition. The details of how to use them are provided in the descriptions of the various boundary condition types.

- If the nature of the boundary condition is such its variation in time and space can not be described easily by the combination of a function and a direction, it may be necessary to use a user-defined subroutine. User subroutines provide a very general capability to define how kinematic or force boundary conditions are applied. The use of user-defined subroutines does increase the complexity of defining the model, however. The user must write and debug the subroutine and compile and link it in with Adagio. Because of the added complexity, user subroutines should only be used if the needed capability is not provided by the other methods of prescribing boundary conditions.

- For some types of boundary conditions, the values of the field to be prescribed can be read in from an existing output database. This is often used as a method to transfer results from one analysis code to another. One of the common uses for this capability is to compute temperatures using a thermal code, and then transfer the temperature fields to Adagio to study combined mechanical and thermal effects. This capability can be used either to read in initial values or to read in a series of values that vary over time.

In the following sections describing specific types of boundary conditions, the commands are grouped according to these three categories.

6.2 Initial Variable Assignment

```
BEGIN INITIAL CONDITION
  # {mesh-entity set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # variable identification commands
  INITIALIZE VARIABLE NAME = <string>var_name
  VARIABLE TYPE = [NODE|EDGE|FACE|ELEMENT|GLOBAL]
  #
  # specification command
  MAGNITUDE = <real list>initial_values
  #
  # input mesh commands
  READ VARIABLE = <string>mesh_var_name
  TIME = <real>time
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name |
    SURFACE SUBROUTINE = <string>subroutine_name |
    ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional command
  SCALE FACTOR = <real>scale_factor(1.0)
END [INITIAL CONDITION]
```

Adagio supports a general initialization procedure for setting the value of any variable. This procedure can be used to set material state variables, shell thickness, initial stress, etc. There is minimal checking in Adagio, however, to ensure that the changes made yield a consistent system. There is also no guarantee that the changes will not be overwritten or misinterpreted by some other internal routine depending on what variable is being changed. Thus, caution is advised when using this capability.

The `INITIAL CONDITION` command block, which appears in the region scope, is used to select a method and set values for initializing a variable. The command block specifies the initial value of a global variable or a variable associated with a set of mesh entities, i.e., nodes, edges, faces, or elements. The user has three options for setting initial values: with a constant magnitude, with an input mesh variable, or by a user subroutine. Only one of these three options can be specified in the command block.

The command block contains five groups of commands—mesh-entity set, variable identification, magnitude, input mesh variable, and user subroutine. In addition to the command lines in the five groups, there is one additional command line: `SCALE FACTOR`. Following are descriptions of the different command groups and the `SCALE FACTOR` command line.

6.2.1 Mesh-Entity Set Commands

The `{mesh-entity set commands}` portion of the `INITIAL CONDITION` command block specifies the nodes, element faces, or elements associated with the variable to be initialized. This portion of the command block can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes, element faces, or elements. See Section 6.1.1 for more information about the use of these command lines for mesh entities. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.2.2 Variable Identification Commands

Any variable used in the `INITIAL CONDITION` command block must exist in Adagio. The variable can be any currently registered variable in Adagio or any user-defined variable created with the `USER VARIABLE` command block (see Section 9.2.4).

There are two command lines that identify the variable:

```
INITIALIZE VARIABLE NAME = <string>var_name
   VARIABLE TYPE = [NODE|EDGE|FACE|ELEMENT|GLOBAL]
```

The `INITIALIZE VARIABLE NAME` command line gives the name of the variable for which initial values are being assigned. As mentioned, the string `var_name` must be some variable known to Adagio; it cannot be an arbitrary user-selected name.

The VARIABLE TYPE command line provides additional information about the variable being initialized. The options NODE, EDGE, FACE, ELEMENT, and GLOBAL on the command line indicate whether the variable is, respectively, a nodal, edge, face, element, or global quantity. One of these options must appear in the VARIABLE TYPE command line.

Both of these command lines are required regardless of the option selected to set values for the variable.

6.2.3 Specification Command

If the constant magnitude command is used, one or more initial values are specified directly in the command block. This is done using the following command line:

```
MAGNITUDE = <real list>initial_values
```

The initial_values specified on the MAGNITUDE command line will set the values for the variable given by var_name in the INITIALIZE VARIABLE NAME command line. The number of values is dependent on the type of the variable specified in the INITIALIZE VARIABLE NAME command line. For example, if the user wanted to initialize the velocity at a set of nodes, three quantities would have to be specified since the velocity at a node is a vector quantity. If the user wanted to initialize the stress tensor for a set of uniform-gradient, eight-node hexahedral elements, six quantities would have to be specified since the stress tensor for this element type is described with six values.

6.2.4 Input Mesh Command

If the input mesh option is used, the initial values will be read from a variable that exists in a mesh file. As an example, suppose the mesh file contains a set of element temperatures. These temperature values (which can vary for each element) can be used to initialize a temperature value associated with each element.

Following are the command lines related to the input mesh option:

```
READ VARIABLE = <string>mesh_var_name
   TIME = <real>temp_time
```

The string mesh_var_name must match the name of the variable in the mesh file. The number of values associated with the variable in the mesh file must be the same number associated with the variable name specified in the INITIALIZE VARIABLE NAME command line. For example, if the variable specified by the INITIALIZE VARIABLE NAME has a single value, then the variable specified in the mesh file must also have a single value. You may select the variable at a specific time by using the TIME command line. If the specified time on the TIME command line does not correspond exactly to a time on the mesh file, the data on the mesh file will be interpolated as needed to obtain the initial values.

The variable name used on the mesh file can be arbitrary. The name can be identical to or different from the registered variable name specified on the INITIALIZE VARIABLE NAME command line.

6.2.5 User Subroutine Commands

If the user subroutine option is used, the initial values will be calculated by a subroutine that is written by the user explicitly for this purpose. The subroutine will be called by Adagio at the appropriate time to perform the calculations.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name |
  SURFACE SUBROUTINE = <string>subroutine_name |
  ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

Only one of the first three command lines listed above can be specified in the command block. The particular command line selected depends on the mesh-entity type of the variable being initialized. For example, variables associated with nodes would be initialized if you are using the `NODE SET SUBROUTINE` command line, variables associated with faces if you are using the `SURFACE SUBROUTINE` command line, and variables associated with elements if you are using the `ELEMENT BLOCK SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the selected subroutine command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The application of user subroutines for variable initialization is essentially the same as the application of user subroutines in general. See Section 6.3.7 and Chapter 9 for more details on implementing the user subroutine option.

When the user subroutine option is used for variable initialization, the user subroutine is called only once. Also, when a user subroutine is being used, the returned value is the new (initial) variable value at each mesh entity, and the flags array is ignored.

6.2.6 Additional Command

This command line provides an additional option for the `INITIAL CONDITION` command block:

```
SCALE FACTOR = <real>scale\string (1.0)
```

Any initial value can be scaled by use of the `SCALE FACTOR` command line. An initial value generated by any one of the three initial-value-setting options in this command block (i.e., constant magnitude, input mesh, or user subroutine) will be scaled by the real value `scale_factor`.

6.3 Kinematic Boundary Conditions

The various kinematic boundary conditions available in Adagio are described in this section. The kinematic boundary conditions are nested inside the region scope.

6.3.1 Fixed Displacement Components

```
BEGIN FIXED DISPLACEMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  COMPONENT = <string>X/Y/Z | COMPONENTS = <string>X/Y/Z
  #
  # additional command
  ACTIVE PERIODS = <string list>period_names
END [FIXED DISPLACEMENT]
```

The `FIXED DISPLACEMENT` command block fixes displacement components (X, Y, Z, or some combination thereof) for a set of nodes. This command block contains two groups of commands—node set and component. Each of these command groups is basically independent of the other. In addition to the command lines in the two command groups, there is an additional command line: `ACTIVE PERIODS`. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups and the `ACTIVE PERIODS` command line.

6.3.1.1 Node Set Commands

The `{node set commands}` portion of the `FIXED DISPLACEMENT` command block specifies the nodes associated with the boundary condition. This portion of the command block can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.3.1.2 Specification Commands

There are two component specification commands available in the `FIXED DISPLACEMENT` command block:

```
COMPONENT = X/Y/Z | COMPONENTS = X/Y/Z
```

The displacement components that are to be fixed can be specified with either the `COMPONENT` command line or the `COMPONENTS` command line. There can be only one `COMPONENT` command line or one `COMPONENTS` command line in the command block. The user can specify any combination of the components to be fixed, as in `X`, `Z`, `X Z`, `Y X`, etc.

6.3.1.3 Additional Command

The `ACTIVE PERIODS` command line can optionally appear in the `FIXED DISPLACEMENT` command block:

```
ACTIVE PERIODS = <string list>period_names
```

This command line determines when the boundary condition is active. See Section 2.4 for more information about this optional command line.

6.3.2 Prescribed Displacement

```
BEGIN PRESCRIBED DISPLACEMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z |
    CYLINDRICAL AXIS = <string>defined_axis |
    RADIAL AXIS = <string>defined_axis
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED DISPLACEMENT]
```

The `PRESCRIBED DISPLACEMENT` command block prescribes a displacement field for a given set of nodes. The displacement field associates a vector giving the magnitude and direction of the displacement with each node in the node set. The displacement field may vary over time and space. If the displacement field has only a time-varying magnitude and uses one of four methods for setting direction, the specification commands in the above command block can be used to specify the displacement field. If the displacement field is more complex, a user subroutine is used to specify the displacement field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED DISPLACEMENT` command block contains three groups of commands—node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can

be used in conjunction with either the specification commands or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups and the `SCALE FACTOR` and `ACTIVE PERIODS` command lines.

6.3.2.1 Node Set Commands

The `{node set commands}` portion of the `PRESCRIBED DISPLACEMENT` command block defines a set of nodes associated with the prescribed displacement field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.3.2.2 Specification Commands

If the specification commands are used, the displacement vector at any given time is the same for all nodes in the node set associated with the particular `PRESCRIBED DISPLACEMENT` command block.

Following are the command lines used to specify the prescribed displacement with a direction and a function:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z |
     CYLINDRICAL AXIS = <string>defined_axis |
     RADIAL AXIS = <string>defined_axis
   FUNCTION = <string>function_name
```

The displacement can be specified along an arbitrary user-defined direction, along a component direction (X, Y, or Z), along the azimuthal direction in a cylindrical coordinate system (defined in reference to an axis), or along a radial direction (defined in reference to an axis). Only one of these options (i.e., command lines) is allowed. The displacement is prescribed only in the specified direction. A prescribed displacement boundary condition does not influence the motion in directions orthogonal to the prescribed direction.

- The `DIRECTION` command line is used to prescribe displacement in an arbitrary user-defined direction. The name in the string `defined_direction` is a reference to a direction, which is defined using the `DEFINE DIRECTION` command block within the domain scope.

- The `COMPONENT` command line is used to specify that the prescribed displacement vector lies along one of the component directions. The `COMPONENT` command line is a shortcut to an internally defined direction vector; for example, component `x` corresponds to using direction vector (1, 0, 0).

- The `CYLINDRICAL AXIS` command line is used to specify that the prescribed displacement is to be applied in the azimuthal direction of a cylindrical coordinate system. The string `defined_axis` refers to the name of the axis of the cylindrical coordinate system, and which is defined via a `DEFINE AXIS` command block in the domain scope. The displacement is prescribed as a rotation in radians about the axis. Nodes with this type of boundary condition are free to move in the radial and height directions in the cylindrical coordinate system. Restraints can be placed on the nodeset in those directions if desired by applying separate kinematic boundary conditions that contain `RADIAL AXIS` or `DIRECTION` commands that refer to the same axis. Note that this type of boundary condition is not a rotational boundary condition; it only affects translational degrees of freedom.

- The `RADIAL AXIS` command line requires an axis definition that appears in the domain scope. The string `defined_axis` uses an `axis_name` that is defined in the domain scope (via a `DEFINE AXIS` command line). For this option, a radial line is drawn from a node to the radial axis. The prescribed displacement vector lies along this radial line from the node to the radial axis.

The magnitude of the displacement is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope using a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the displacement vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.3.2.4.

6.3.2.3 User Subroutine Commands

If the user subroutine option is used, the displacement vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED DISPLACEMENT` command block. The user subroutine option allows for a more complex description of the displacement field than do the specification commands, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a displacement direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the displacement field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
```

```
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.3.2.4.

See Section 6.3.7 and Chapter 9 for more details on implementing the user subroutine option.

6.3.2.4 Additional Commands

These command lines in the `PRESCRIBED DISPLACEMENT` command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the displacement in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the displacement from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.3.3 Prescribed Velocity

```
BEGIN PRESCRIBED VELOCITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z |
    CYLINDRICAL AXIS = <string>defined_axis |
    RADIAL AXIS = <string>defined_axis
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED VELOCITY]
```

The `PRESCRIBED VELOCITY` command block prescribes a velocity field for a given set of nodes. The velocity field associates a vector giving the magnitude and direction of the velocity with each node in the node set. The velocity field may vary over time and space. If the velocity field has only a time-varying magnitude and uses one of four methods for setting direction, the specification commands in the above command block can be used to specify the velocity field. If the velocity field is more complex, a user subroutine is used to specify the velocity field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED VELOCITY` command block contains three groups of commands— node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with either the specification commands or the user subroutine commands.

The ACTIVE PERIODS command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups and the SCALE FACTOR and ACTIVE PERIODS command lines.

6.3.3.1 Node Set Commands

The {node set commands} portion of the PRESCRIBED VELOCITY command block defines a set of nodes associated with the prescribed velocity field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one NODE SET, SURFACE, BLOCK, or INCLUDE ALL BLOCKS command line in the command block.

6.3.3.2 Specification Commands

If the specification commands are used, the velocity vector at any given time is the same for all nodes in the node set associated with the particular PRESCRIBED VELOCITY command block.

Following are the command lines used to specify the prescribed velocity with a direction and a function:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z |
     CYLINDRICAL AXIS = <string>defined_axis |
     RADIAL AXIS = <string>defined_axis
   FUNCTION = <string>function_name |
```

The velocity can be specified along an arbitrary user-defined direction, along a component direction (X, Y, or Z), along the azimuthal direction in a cylindrical coordinate system (defined in reference to an axis), or along a radial direction (defined in reference to an axis). Only one of these options (i.e., command lines) is allowed. The velocity is prescribed only in the specified direction. A prescribed velocity boundary condition does not influence the motion in directions orthogonal to the prescribed direction.

- The DIRECTION command line is used to prescribe velocity in an arbitrary user-defined direction. The name in the string defined_direction is a reference to a direction, which is defined using the DEFINE DIRECTION command block within the domain scope.

- The `COMPONENT` command line is used to specify that the prescribed velocity vector lies along one of the component directions. The `COMPONENT` command line is a shortcut to an internally defined direction vector; for example, component `x` corresponds to using direction vector (1, 0, 0).

- The `CYLINDRICAL AXIS` command line is used to specify that the prescribed velocity is to be applied in the azimuthal direction of a cylindrical coordinate system. The string `defined_axis` refers to the name of the axis of the cylindrical coordinate system, and which is defined via a `DEFINE AXIS` command block in the domain scope. The velocity is prescribed as a rotation in radians about the axis. Nodes with this type of boundary condition are free to move in the radial and height directions in the cylindrical coordinate system. Restraints can be placed on the nodeset in those directions if desired by applying separate kinematic boundary conditions that contain `RADIAL AXIS` or `DIRECTION` commands that refer to the same axis. Note that this type of boundary condition is not a rotational boundary condition; it only affects translational degrees of freedom.

- The `RADIAL AXIS` command line requires an axis definition that appears in the domain scope. The string `defined_axis` uses an `axis_name` that is defined in the domain scope (via a `DEFINE AXIS` command line). For this option, a radial line is drawn from a node to the radial axis. The velocity vector lies along this radial line from the node to the radial axis.

The magnitude of the velocity is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope using a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the velocity vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.3.3.4.

6.3.3.3 User Subroutine Commands

If the user subroutine option is used, the velocity vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED VELOCITY` command block. The user subroutine option allows for a more complex description of the velocity field than do the specification commands, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a velocity direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the velocity field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.3.3.4.

6.3.3.4 Additional Commands

These command lines in the `PRESCRIBED VELOCITY` command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the velocity in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the velocity from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.3.4 Prescribed Acceleration

```
BEGIN PRESCRIBED ACCELERATION
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED ACCELERATION]
```

The `PRESCRIBED ACCELERATION` command block prescribes an acceleration field for a given set of nodes. The acceleration field associates a vector giving the magnitude and direction of the acceleration with each node in the node set. The acceleration field may vary over time and space. If the acceleration field has only a time-varying component, the specification commands in the above command block can be used to specify the acceleration field. If the acceleration field has both time-varying and spatially varying components, a user subroutine is used to specify the acceleration field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED ACCELERATION` command block contains three groups of commands—node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with either the specification commands or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary

condition for certain time periods. Following are descriptions of the different command groups and the `SCALE FACTOR` and `ACTIVE PERIODS` command lines.

6.3.4.1 Node Set Commands

The `{node set commands}` portion of the `PRESCRIBED ACCELERATION` command block defines a set of nodes associated with the prescribed acceleration field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.3.4.2 Specification Commands

If the specification commands are used, the acceleration vector at any given time is the same for all nodes in the node set associated with the particular `PRESCRIBED ACCELERATION` command block. The direction of the acceleration vector is constant for all time; the magnitude of the acceleration vector may vary with time, however.

Following are the command lines used to specify the prescribed acceleration with a direction and a function:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z
   FUNCTION = <string>function_name
```

The acceleration can be specified either along an arbitrary user-defined direction or along a component direction (X, Y, or Z), but not both. The acceleration is prescribed only in the specified direction. A prescribed acceleration boundary condition does not influence the motion in directions orthogonal to the prescribed direction.

- The `DIRECTION` command line is used to prescribe acceleration in an arbitrary user-defined direction. The name in the string `defined_direction` is a reference to a direction, which is defined using the `DEFINE DIRECTION` command block within the domain scope.

- The COMPONENT command line is used to specify that the prescribed acceleration vector lies along one of the component directions. The COMPONENT command line is a shortcut to an internally defined direction vector; for example, component x corresponds to using direction vector (1, 0, 0).

The magnitude of the acceleration is specified by the FUNCTION command line. This references a function_name (defined in the domain scope using a DEFINITION FOR FUNCTION command block) that specifies the magnitude of the acceleration vector as a function of time. The magnitude can be scaled by use of the SCALE FACTOR command line described in Section 6.3.4.4.

6.3.4.3 User Subroutine Commands

If the user subroutine option is used, the acceleration vector may vary spatially at any given time for each of the nodes in the node set associated with the particular PRESCRIBED ACCELERATION command block. The user subroutine option allows for a more complex description of the acceleration field than do the specification commands, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define an acceleration direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the acceleration field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the NODE SET SUBROUTINE command line. The string subroutine_name is the name of a FORTRAN subroutine that is written by the user.

Following the NODE SET SUBROUTINE command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of SUBROUTINE DEBUGGING OFF, SUBROUTINE DEBUGGING ON, SUBROUTINE REAL PARAMETER, SUBROUTINE INTEGER PARAMETER, and SUBROUTINE STRING PARAMETER. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the SCALE FACTOR command line, as described in Section 6.3.4.4.

See Section 6.3.7 and Chapter 9 for more details on implementing the user subroutine option.

6.3.4.4 Additional Commands

These command lines in the PRESCRIBED ACCELERATION command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The SCALE FACTOR command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the acceleration in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the acceleration from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The ACTIVE PERIODS command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.3.5 Fixed Rotation

```
BEGIN FIXED ROTATION
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  COMPONENT = <string>X/Y/Z | COMPONENTS = <string>X/Y/Z
  #
  # additional command
  ACTIVE PERIODS = <string list>periods_names
END [FIXED ROTATION]
```

The `FIXED ROTATION` command block fixes rotation about direction components (X, Y, Z, or some combination thereof) for a set of nodes. This command block contains two groups of commands—node set and component. Each of these command groups is basically independent of the other. In addition to the command lines in the two command groups, there is an additional command line: `ACTIVE PERIODS`. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups and the `ACTIVE PERIODS` command line.

6.3.5.1 Node Set Commands

The `{node set commands}` portion of the command block specifies the nodes associated with the boundary condition. This portion of the command block can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.3.5.2 Specification Commands

There are two component specification commands available in the `FIXED ROTATION` command block:

```
COMPONENT = X/Y/Z | COMPONENTS = X/Y/Z
```

The rotation components that are to be fixed can be specified with either the `COMPONENT` command line or the `COMPONENTS` command line. There can be only one `COMPONENT` command line or one `COMPONENTS` command line in the command block. The user can specify any combination of the components to be fixed, as in `X`, `Z`, `X Z`, `Y X`, etc.

6.3.5.3 Additional Command

The `ACTIVE PERIODS` command line can optionally appear in the `FIXED ROTATION` command block:

```
ACTIVE PERIODS = <string list>period_names
```

This command line determines when the boundary condition is active. See Section 2.4 for more information about this optional command line.

6.3.6 Prescribed Rotation

```
BEGIN PRESCRIBED ROTATION
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
   COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED ROTATION]
```

The `PRESCRIBED ROTATION` command block prescribes the rotation about an axis for a given set of nodes. The rotation field associates a vector giving the magnitude and direction of the rotation with each node in the node set. The rotation field may vary over time and space. If the rotation field has only a time-varying component, the specification commands in the above command block can be used to specify the rotation field. If the rotation field has both time-varying and spatially varying components, a user subroutine is used to specify the rotation field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED ROTATION` command block contains three groups of commands—node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with either the specification commands or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups

and the SCALE FACTOR and ACTIVE PERIODS command lines.

6.3.6.1 Node Set Commands

The {node set commands} portion of the PRESCRIBED ROTATION command block defines a set of nodes associated with the prescribed rotation field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one NODE SET, SURFACE, BLOCK, or INCLUDE ALL BLOCKS command line in the command block.

6.3.6.2 Specification Commands

If the specification commands are used, the rotation vector at any given time is the same for all nodes in the node set associated with the particular PRESCRIBED ROTATION command block. The direction of the rotation vector is constant for all time; the magnitude of the rotation vector may vary with time, however.

Following are the command lines used to specify the prescribed rotation with a direction and a function:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z
   FUNCTION = <string>function_name
```

The rotation can be specified either along an arbitrary user-defined direction or along a component direction (X, Y, or Z), but not both. The rotation is prescribed only in the specified direction. A prescribed rotation boundary condition does not influence the rotation in directions orthogonal to the prescribed direction.

- The DIRECTION command line is used to prescribe rotation in an arbitrary user-defined direction. The name in the string defined_direction is a reference to a direction, which is defined using the DEFINE DIRECTION command block within the domain scope.

- The COMPONENT command line is used to specify that the prescribed rotation vector lies along one of the component directions. The COMPONENT command line is a shortcut to an

internally defined direction vector; for example, component `x` corresponds to using direction vector (1, 0, 0).

The magnitude of the rotation is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope in a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the rotation vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.3.6.4.

The magnitude of the rotation, as specified by the product of the function and the scale factor, has units of radians per second.

6.3.6.3 User Subroutine Commands

If the user subroutine option is used, the rotation vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED ROTATION` command block. The user subroutine option allows for a more complex description of the rotation field than do the specification commands, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a rotation direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the rotation field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.3.6.4.

See Section 6.3.7 and Chapter 9 for more details on implementing the user subroutine option.

6.3.6.4 Additional Commands

These command lines in the `PRESCRIBED ROTATION` command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the rotation in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the rotation from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.3.7 Subroutine Usage for Kinematic Boundary Conditions

The prescribed kinematic boundary conditions may be defined by a user subroutine. All these conditions use a node set subroutine. See Chapter 9 for an in-depth discussion of user subroutines. The kinematic boundary conditions will be applied to nodes. The subroutine that you write will have to return six output values per node and one output flag per node. The usage of the output values depends on the returned flag value for a node, as follows:

- If the flag value is negative, no constraint will be applied to the node.
- If the flag value is equal to zero, the constraint will be absolute. All components of the boundary condition will be specified. For example, suppose you have written a user subroutine to be called from a prescribed displacement subroutine. The prescribed displacements are to be passed through an array `output_values`. For a given node `inode`, the `output_values` array would have the following values:

```
output_values(1,inode) = displacement in x at inode
output_values(2,inode) = displacement in y at inode
output_values(3,inode) = displacement in z at inode
output_values(4,inode) = not used
output_values(5,inode) = not used
output_values(6,inode) = not used
```

- If the flag value is equal to one, the constraint will be a specified amount in a given direction. For example, suppose you have written a user subroutine to be called from a prescribed displacement subroutine. The prescribed displacements are to be passed through an array `output_values`. For a given node `inode`, the `output_values` array would have the following values:

```
output_values(1,inode) = magnitude of displacement
output(values(2,inode) = not used
output_values(3,inode) = not used
output_values(4,inode) = x component of direction vector
output_values(5,inode) = y component of direction vector
output_values(6,inode) = z component of direction vector
```

The direction in which the constraint will act is given by `output_values` 4 through 6 for `inode`. The magnitude of the displacement in the specified direction is given by `output_values` 1 at `inode`. To compute the constraint, Adagio first normalizes the direction vector. Next, Adagio multiplies the normalized direction vector by the magnitude of the displacement and applies the resultant constraint vector.

Displacements or velocities orthogonal to the prescribed direction will not be constrained. (This is true regardless of whether or not one uses a user subroutine for the prescribed kinematic boundary conditions.) Take the case of a prescribed displacement condition. The displacement orthogonal to a prescribed direction of motion depends on the internal and external forces orthogonal to the prescribed direction. Displacement orthogonal to the prescribed direction may or may not be zero.

6.4 Initial Velocity Conditions

```
BEGIN INITIAL VELOCITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # direction specification commands
  COMPONENT = <string>X|Y|Z |
    DIRECTION = <string>defined_direction
  MAGNITUDE = <real>magnitude_of_velocity
  #
  # angular velocity specification commands
  CYLINDRICAL AXIS = <string>defined_axis
  ANGULAR VELOCITY = <real>angular_velocity
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
END [INITIAL VELOCITY]
```

The `INITIAL VELOCITY` command block specifies an initial velocity field for a set of nodes. There are two simple options for specifying the initial velocity field: by direction and by angular velocity. The user subroutine option available is also available to specify an initial velocity. You may use only one of the available options—direction specification, angular velocity specification, or user subroutine.

The `INITIAL VELOCITY` command block contains four groups of commands—node set, direction specification, angular velocity specification, and user subroutine. Command lines associated with the node set commands must appear. As mentioned, command lines associated with one of the options must also appear. Following are descriptions of the different command groups.

6.4.1 Node Set Commands

The `{node set commands}` portion of the `INITIAL VELOCITY` command block defines a set of nodes associated with the initial velocity field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.4.2 Direction Specification Commands

If the direction specification commands are used, the initial velocity is applied along a defined direction with a specific magnitude. Following are the command lines for the direction option:

```
COMPONENT = <string>X|Y|Z |
     DIRECTION = <string>defined_direction
   MAGNITUDE = <real>magnitude_of_velocity
```

The initial velocity can be specified either along an arbitrary user-defined direction or along a component direction (X, Y, or Z), but not both. The velocity is prescribed only in the specified direction. A prescribed velocity boundary condition does not influence the movement in directions orthogonal to the prescribed direction.

- The `DIRECTION` command line is used to prescribe initial velocity in an arbitrary user-defined direction. The name in the string `defined_direction` is a reference to a direction, which is defined using the `DEFINE DIRECTION` command block within the domain scope.
- The `COMPONENT` command line is used to specify that the initial velocity vector lies along one of the component directions. The `COMPONENT` command line is a shortcut to an internally defined direction vector; for example, component `x` corresponds to using direction vector (1, 0, 0).

The magnitude of the initial velocity is given by the `MAGNITUDE` command line with the real value `magnitude_of_velocity`.

Either the `COMPONENT` command line or the `DIRECTION` command line must be specified with the `MAGNITUDE` command line if you use the direction specification commands.

6.4.3 Angular Velocity Specification Commands

If the angular velocity specification commands are used, the initial velocity is applied as an initial angular velocity about some axis. Following are the command lines for angular velocity specification:

```
CYLINDRICAL AXIS = <string>defined_axis
   ANGULAR VELOCITY = <real>angular_velocity
```

The axis about which the body is initially rotating is given by the `CYLINDRICAL AXIS` command line. The string `defined_axis` uses an `axis_name` that is defined in the domain scope (via a `DEFINE AXIS` command line).

The magnitude of the angular velocity about this axis is specified by the `ANGULAR VELOCITY` command line with the real value `angular_velocity`. This value is specified in units of radians per unit of time. Typically, the value for the angular velocity will be radians per second.

Both the `CYLINDRICAL AXIS` command line and the `ANGULAR VELOCITY` command line are required if you use the angular velocity specification commands.

6.4.4 User Subroutine Commands

If the user subroutine option is used, the initial velocity vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `INITIAL CONDITION` command block. The user subroutine option allows for a more complex description of the initial velocity field than do the direction and angular-velocity options, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a velocity direction and a magnitude for every node to which the initial velocity field will be applied. The subroutine will be called by Adagio at the appropriate time to generate the initial velocity field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL`

`PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

See Section 6.3.7 and Chapter 9 for more details on implementing the user subroutine option.

6.5 Force Boundary Conditions

A variety of force boundary conditions are available in Adagio. This section describes these boundary conditions.

6.5.1 Pressure

```
BEGIN PRESSURE
  # {surface set commands}
  SURFACE = <string list>surface_names
  REMOVE SURFACE = <string list>surface_names
  #
  # specification command
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  SURFACE SUBROUTINE = <string>subroutine_name |
    NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # external pressure sources
  READ VARIABLE = <string>variable_name
  OBJECT TYPE = <string>NODE|FACE(NODE)
  TIME = <real>time
  FIELD VARIABLE = <string>field_variable
  #
  # output external forces from pressure
  EXTERNAL FORCE CONTRIBUTION OUTPUT NAME =
    <string>variable_name
  #
  # additional commands
  USE DEATH = <string>death_name
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESSURE]
```

The `PRESSURE` command block applies a pressure to each face in the associated surfaces. The pressure field can either be constant over the faces and vary in time, or it can be determined by a user subroutine. If the pressure field is constant over the faces and has only a time-varying component, the function command in the above command block can be used to specify the pressure

field. If the pressure field has both time-varying and spatially varying components, user subroutine commands are used to specify the pressure field. The pressure field may also be obtained from a mesh file or from another SIERRA code through a transfer operator. You can use only one of these four options—function, user subroutine, mesh file, transfer from another code—to specify the pressure field.

Currently, the `PRESSURE` command block can be used for surfaces that have faces derived from solid elements (eight-node hexahedra, four-node tetrahedra, eight-node tetrahedra, etc.), membranes, and shells.

A pressure boundary condition generates nodal forces that are summed into the external force vector that is used to calculate the motion of a body. The external force vector contains the contribution from all forces acting on the body. There is an option in the `PRESSURE` command block to save information about the contribution to the external force vector due only to pressure loads. This option does not change the magnitude or time history of the pressure load (regardless of how they are defined), but merely stores information in a user-accessible variable.

The `PRESSURE` command block contains five groups of commands—surface set, function, user subroutine, external pressure, and output external forces. Each of these command groups is basically independent of the others. In addition to the command lines in the five command groups, there are three additional command lines: `USE DEATH`, `SCALE FACTOR` and `ACTIVE PERIODS`. The `USE DEATH` command line links the pressure boundary condition to an element death definition so that the underlying surface geometry is updated as elements are killed. The `SCALE FACTOR` command line can be used in conjunction with either the function command or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this force boundary condition for certain time periods. Following are descriptions of the different command groups and the `USE DEATH`, `SCALE FACTOR`, and `ACTIVE PERIODS` command lines.

6.5.1.1 Surface Set Commands

The `{surface set commands}` portion of the `PRESSURE` command block defines a set of surfaces associated with the pressure field and can include some combination of the following command lines:

```
SURFACE = <string list>surface_names
   REMOVE SURFACE = <string list>surface_names
```

In the `SURFACE` command line, you can list a series of surfaces through the string list `surface_names`. There must be at least one `SURFACE` command line in the command block. The `REMOVE SURFACE` command line allows you to delete surfaces from the set specified in the `SURFACE` command line(s) through the string list `surface_names`. See Section 6.1.1 for more information about the use of these command lines for creating a set of surfaces used by the boundary condition.

6.5.1.2 Specification Commands

If the function command is used, the pressure vector at any given time is the same for all surfaces associated with the particular `PRESSURE` command block. The direction of the pressure vector is

constant for all time; the magnitude of the pressure vector may vary with time, however.

Following is the command line used to specify the pressure with a function:

```
FUNCTION = <string>function_name
```

The pressure is applied in the opposite direction to the outward normals of the faces that define the surfaces. The magnitude of the pressure is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope in a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the pressure vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.5.1.6.

6.5.1.3 User Subroutine Commands

If the user subroutine option is used, the pressure may vary spatially at any given time for each of the surfaces associated with the particular `PRESSURE` command block. The user subroutine option allows for a more complex description of the pressure field than does the function command, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a pressure for every face to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the pressure field.

Following are the command lines related to the user subroutine option:

```
SURFACE SUBROUTINE = <string>subroutine_name |
   NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `SURFACE SUBROUTINE` command line or the `NODE SET` subroutine command line. The string `subroutine_name` in both command lines is the name of a FORTRAN subroutine that is written by the user. The particular command line selected depends on the mesh-entity type for which the pressure field is being calculated. Associating pressure values with faces would require the use of a `SURFACE SUBROUTINE` command line. Associating pressure values with nodes would require the use of a `NODE SET SUBROUTINE` command line.

Following the selected subroutine command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.5.1.6.

Usage requirements. Following are the usage requirements for the two types of subroutines:

- The surface subroutine operates on a group of faces. The subroutine that you write will return one output value per face. Suppose you write a user subroutine that returns the pressure information through an array `output_value`. The value `output_value(1,iface)` corresponds to the average pressure on face `iface`. The values of the flags array are not used.
- The node set subroutine that you write will return one value per node. Suppose you write a user subroutine that returns the pressure information through an array `output_value`. The return value `output_value(1,inode)` is the pressure at the node `inode`. The total pressure on the each face is found by integrating the pressures at the nodes. The values of the flags array are not used.

See Chapter 9 for more details on implementing the user subroutine option.

6.5.1.4 External Pressure Sources

Pressure may be obtained from two different external sources. The first option for obtaining pressure from an external source uses a mesh file. The commands for obtaining pressure information from a mesh file are as follows:

```
READ VARIABLE = <string>variable_name
OBJECT TYPE = <string>NODE|FACE(NODE)
TIME = <real>time
```

The `READ VARIABLE` command line specifies the name of the variable on the mesh file, `variable_name`, that is used to prescribe the pressure field. The `OBJECT TYPE` command line specifies whether the pressure field on the mesh file is specified for nodes (the mesh object type is `NODE`) or for faces (the mesh object type is `FACE`). If the `OBJECT TYPE` command line is not present, it is assumed that the variable is for nodes. If the `TIME` command line is present, only the pressure field information at a given time, as set by the `time` parameter, is read from the mesh file. If the `TIME` command line is not present, the pressure field information for all times is read. Pressure field information will then be interpolated as necessary during an analysis.

The second option for obtaining pressure from and external sources relies on the transfer of information from another SIERRA code. The command for obtaining pressure information by transfer from another code is:

```
FIELD VARIABLE = <string>variable_name
```

Here `variable_name` is the name of the registered variable where pressure information is to be stored. The pressure information will be transferred into this registered variable from another SIERRA code via a transfer operator.

6.5.1.5 Output Command

This command line lets the user create a variable that stores information about the contribution to the external force vector at a node arising solely from a pressure:

```
EXTERNAL FORCE CONTRIBUTION OUTPUT NAME =
     <string>variable_name
```

If the above command line appears in a `PRESSURE` command block, then there will be a variable created with whatever name the user specifies for `variable_name`. The variable defines a three-dimensional vector at each node associated with this particular command block. The three-dimensional vector at each node represents the external force due solely to the pressure on the elements attached to that node. For example, if one of the nodes associated with this particular command block has four elements attached to it and each element has a pressure load, then the external force contribution at the node would be summed from the pressure load for all four elements.

Once this variable for the external force contribution from a pressure load is specified, it may be used like any other registered nodal variable. The user can, for example, specify the variable as a nodal variable to be output in a `RESULTS OUTPUT` command block. Or the user can reference the variable in a user subroutine.

6.5.1.6 Additional Commands

These command lines in the `PRESSURE` command block provide additional options for the boundary condition:

```
USE DEATH = <string>death_name
   SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The `USE DEATH` command line links the pressure boundary condition to an element death definition. The string `death_name` must match a name used in an `ELEMENT DEATH` command block. When elements are killed by the named element death definition, the pressure boundary condition will be applied to the newly exposed faces.

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the function command or the user subroutine. For example, if the magnitude of the pressure in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the pressure from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.5.2 Traction

```
BEGIN TRACTION
  # {surface set commands}
  SURFACE = <string list>surface_names
  REMOVE SURFACE = <string list>surface_names
  #
  # specification commands
  DIRECTION = <string>direction_name
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
  #
END [TRACTION]
```

The `TRACTION` command block applies a traction to each face in the associated surfaces. The traction has units of force per unit area. (A traction, unlike a pressure, may not necessarily be in the direction of the normal to the face to which it is applied.) The given traction is integrated over the surface area of a face.

The traction field can be determined by a SIERRA function or a user subroutine. If the traction field is constant over the faces and has only a time-varying component, the specification commands in the above command block can be used to specify the traction field. If the traction field has both time-varying and spatially varying components, a user subroutine is used to specify the traction field.

The traction field can only be controlled by one method. Accordingly, a `TRACTION` command block can only contain one of the options: function or user subroutine.

Currently, the `TRACTION` command block can be used for surfaces that have faces derived from solid elements (eight-node hexahedra, four-node tetrahedra, eight-node tetrahedra, etc.), membranes, and shells.

The `TRACTION` command block contains three groups of commands—surface set and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the four command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with the

specification commands or the user subroutine option. The ACTIVE PERIODS command line is used to activate or deactivate this force boundary condition for certain time periods. Following are descriptions of the different command groups and the SCALE FACTOR and ACTIVE PERIODS command lines.

6.5.2.1 Surface Set Commands

The {surface set commands} portion of the TRACTION command block defines a set of surfaces associated with the traction field and can include some combination of the following command lines:

```
SURFACE = <string list>surface_names
   REMOVE SURFACE = <string list>surface_names
```

In the SURFACE command line, you can list a series of surfaces through the string list surface_names. There must be at least one SURFACE command line in the command block. The REMOVE SURFACE command line allows you to delete surfaces from the set specified in the SURFACE command line(s) through the string list surface_names. See Section 6.1.1 for more information about the use of these command lines for creating a set of surfaces used by the boundary condition.

6.5.2.2 Specification Commands

If the specification commands are used, the traction vector at any given time is the same for all surfaces associated with the particular TRACTION command block. The direction of the traction vector is constant for all time; the magnitude of the traction vector may vary with time, however.

Following are the command lines used to specify the traction with a direction and a function:

```
DIRECTION = <string>defined_direction
   FUNCTION = <string>function_name
```

The traction is specified in an arbitrary user-defined direction, and is defined using the DIRECTION command line. The name in the string defined_direction is a reference to a direction, which is defined using the DEFINE DIRECTION command block within the domain scope.

The magnitude of the traction is specified by the FUNCTION command line. This references a function_name (defined in the domain scope in a DEFINITION FOR FUNCTION command block) that specifies the magnitude of the traction vector as a function of time. The magnitude can be scaled by use of the SCALE FACTOR command line described in Section 6.5.2.4.

6.5.2.3 User Subroutine Commands

If the user subroutine option is used, the traction vector may vary spatially at any given time for each of the surfaces associated with the particular TRACTION command block. The user subroutine option allows for a more complex description of the traction field than does the function option, but the user subroutine option also requires that you write a user subroutine to implement this

capability. The user subroutine will be used to define a traction for every face to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the traction field.

Following is the command line related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET` subroutine command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user. Associating traction values with nodes requires the use of a `NODE SET SUBROUTINE` command line.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.5.2.4.

Usage requirements for the node set subroutine. The node set subroutine that you write will return six values per node. Suppose you have written a user subroutine that passes the output values through an array `output_values`. For a given node inode, the `output_values` array would have the following values:

```
output_values(1,inode) = magnitude of traction
output(values(2,inode) = not used
output_values(3,inode) = not used
output_values(4,inode) = x component of direction vector
output_values(5,inode) = y component of direction vector
output_values(6,inode) = z component of direction vector
```

The direction in which the traction will act is given by components 4 through 6 of `output_values` for `inode`. The magnitude of the traction in the specified direction is given by component 1 of `output_values` at `inode`. The total force on each node is found by integrating the local nodal tractions using the associated directions, which are normalized by Adagioover the face areas. The values of the flags array are not used.

See Chapter 9 for more details on implementing the user subroutine option.

6.5.2.4 Additional Commands

These command lines in the TRACTION command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The SCALE FACTOR command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the traction in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the traction from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The ACTIVE PERIODS command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.5.3 Prescribed Force

```
BEGIN PRESCRIBED FORCE
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED FORCE]
```

The `PRESCRIBED FORCE` command block prescribes a force field for a given set of nodes. The force field associates a vector giving the magnitude and direction of the force with each node in the node set. The force field may vary over time and space. If the force field has only a time-varying component, the specification commands in the above command block can be used to specify the force field. If the force field has both time-varying and spatially varying components, a user subroutine is used to specify the force field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED FORCE` command block contains three groups of commands—node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with either the specification commands or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this force boundary condition for certain time periods. Following are descriptions of the different command groups and the

SCALE FACTOR and ACTIVE PERIODS command lines.

6.5.3.1 Node Set Commands

The {node set commands} portion of the PRESCRIBED FORCE command block defines a set of nodes associated with the prescribed force field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one NODE SET, SURFACE, BLOCK, or INCLUDE ALL BLOCKS command line in the command block.

6.5.3.2 Specification Commands

If the specification commands are used, the force vector at any given time is the same for all nodes in the node set associated with the particular PRESCRIBED FORCE command block. The direction of the force vector is constant for all time; the magnitude of the force vector may vary with time, however.

Following are the command lines used to specify the prescribe force with a direction and a function:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z
   FUNCTION = <string>function_name
```

The force can be specified either along an arbitrary user-defined direction or along a component direction (X, Y, or Z), but not both.

- The DIRECTION command line is used to prescribe force in an arbitrary user-defined direction. The name in the string defined_direction is a reference to a direction, which is defined using the DEFINE DIRECTION command block within the domain scope.

- The COMPONENT command line is used to specify that the force vector lies along one of the component directions. The COMPONENT command line is a shortcut to an internally defined direction vector; for example, component x corresponds to using direction vector (1, 0, 0).

The magnitude of the force is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope in a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the force vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.5.3.4.

The force is applied only in the prescribed direction, and is not applied in any direction orthogonal to that direction.

6.5.3.3 User Subroutine Commands

If the user subroutine option is used, the force vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED FORCE` command block. The user subroutine option allows for a more complex description of the force field than does the function option, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a force direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the force field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.5.3.4.

Usage requirements for the node set subroutine. The subroutine that you write will return three output values per node. Suppose you write a user subroutine that passes the output values through an array `output_values`. For a given node `inode`, the `output_values` array would have the following values:

```
output_values(1,inode) = x component of force at inode
```

```
output_values(2,inode) = y component of force at inode
output_values(3,inode) = z component of force at inode
```

The three components of the force vector are given in `output_values` 1 through 3. The values of the flags array are ignored.

See Chapter 9 for more details on implementing the user subroutine option.

6.5.3.4 Additional Commands

These command lines in the `PRESCRIBED FORCE` command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
```

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the force in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the force from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.5.4 Prescribed Moment

```
BEGIN PRESCRIBED MOMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # specification commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED MOMENT]
```

The `PRESCRIBED MOMENT` command block prescribes a moment field for a given set of nodes. Moments can only be defined for nodes attached to beam or shell elements. The moment field associates a vector giving the magnitude and direction of the moment with each node in the node set. If the moment field has only a time-varying component, the specification commands in the above command block can be used to specify the moment field. If the moment field has both time-varying and spatially varying components, a user subroutine option is used to specify the moment field. You cannot use both the specification commands and the user subroutine commands in the same command block.

The `PRESCRIBED MOMENT` command block contains three groups of commands—node set, function, and user subroutine. Each of these command groups is basically independent of the others. In addition to the command lines in the three command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with either the specification commands or the user subroutine commands. The `ACTIVE PERIODS` command line is used to activate or deactivate this force boundary condi-

tion for certain time periods. Following are descriptions of the different command groups and the `SCALE FACTOR` and `ACTIVE PERIODS` command lines.

6.5.4.1 Node Set Commands

The `{node set commands}` portion of the `PRESCRIBED MOMENT` command block defines a set of nodes associated with the prescribed moment field and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

6.5.4.2 Specification Commands

If the specification commands are used, the moment vector at any given time is the same for all nodes in the node set associated with the particular `PRESCRIBED MOMENT` command block. The direction of the moment vector is constant for all time; the magnitude of the moment vector may vary with time, however.

Following are the command lines used to specify the prescribed moment with a function and a direction:

```
DIRECTION = <string>defined_direction |
     COMPONENT = <string>X|Y|Z
   FUNCTION = <string>function_name
```

The moment can be specified either along an arbitrary user-defined direction or along a component direction (X, Y, or Z), but not both.

- The `DIRECTION` command line is used to prescribe the moment in an arbitrary user-defined direction. The name in the string `defined_direction` is a reference to a direction, which is defined using the `DEFINE DIRECTION` command block within the domain scope.
- The `COMPONENT` command line is used to specify that the moment vector lies along one of the component directions. The `COMPONENT` command line is a shortcut to an internally defined direction vector; for example, component `x` corresponds to using direction vector (1, 0, 0).

The magnitude of the moment is specified by the `FUNCTION` command line. This references a `function_name` (defined in the domain scope in a `DEFINITION FOR FUNCTION` command block) that specifies the magnitude of the moment vector as a function of time. The magnitude can be scaled by use of the `SCALE FACTOR` command line described in Section 6.5.4.4.

The moment is applied only in the prescribed direction, and is not applied in any direction orthogonal to that direction.

6.5.4.3 User Subroutine Commands

If the user subroutine option is used, the moment vector may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED MOMENT` command block. The user subroutine option allows for a more complex description of the moment field than do specification commands, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a moment direction and a magnitude for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the moment field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The magnitude set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.5.4.4.

Usage requirements for the node set subroutine. The subroutine that you write will return three output values per node. Suppose you write a user subroutine that passes the output values through an array `output_values`. For a given node `inode`, the `output_values` array would have the following values:

```
output_values(1,inode) = moment about x-direction at inode
```

```
output_values(2,inode) = moment about y-direction at inode
output_values(3,inode) = moment about z-direction at inode
```

The three components of the moment vector are given in `output_values` 1 through 3. The values of the flags array are ignored.

See Chapter 9 for more details on implementing the user subroutine option.

6.5.4.4 Additional Commands

These command lines in the `PRESCRIBED MOMENT` command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The `SCALE FACTOR` command line is used to apply an additional scaling factor, which is constant in both time and space, to all vector magnitude values of the field defined by the specification commands or the user subroutine. For example, if the magnitude of the moment in a time history function is given as 1.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the magnitude of the moment from time 1.0 to 2.0 is 0.75. The default value for the scale factor is 1.0.

The `ACTIVE PERIODS` command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.6 Gravity

```
BEGIN GRAVITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  DIRECTION = <string>defined_direction
  FUNCTION = <string>function_name
  GRAVITATIONAL CONSTANT = <real>g_constant
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [GRAVITY]
```

A gravity load is generally referred to as a body force boundary condition. A gravity load generates a force at a node that is proportional to the mass of the node. This section describes how to apply a gravity load to a body.

The GRAVITY command block is used to specify a gravity load that is applied to all nodes selected within a command block. The gravity load boundary condition uses the function and scale (gravitational constant and scale factor) information to generate a body force at a node based on the mass of the node. Multiple GRAVITY command blocks can be defined on different sets of nodes. If two different GRAVITY command blocks reference the same node, the node will have gravity loads applied by both of the command blocks. Care must be taken to make sure you do not apply multiple gravity loads to one block if you only want one gravity load condition applied.

The {node set commands} portion of the GRAVITY command block defines a set of nodes associated with the gravity load and can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list>surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one NODE SET, SURFACE, BLOCK, or INCLUDE ALL BLOCKS command line in the command block.

The gravity load is specified along an arbitrary user-defined direction, and is defined using the DIRECTION command line. The name in the string defined_direction is a reference to a direction, which is defined using the DEFINE DIRECTION command block within the domain scope.

The strength of the gravitational field can be varied with time by using the FUNCTION command line. This command line references a function_name defined in the domain scope in a DEFINITION FOR FUNCTION command block.

A gravitational constant is specified by the GRAVITATIONAL CONSTANT command line in the real value g_constant. For example, the gravitational constant in units of inches and seconds would be 386.4 inches per second squared. You must set this quantity based on the actual units for your model.

The dependent variables in the function can be scaled by the real value scale_factor in the SCALE FACTOR command line. At any given time, the strength of the gravitational field is a product of the gravitational constant, the value of the function at that time, and the scale factor.

The ACTIVE PERIODS command line provides an additional option for the gravity load condition. This command line can activate or deactivate the gravity load for certain time periods. See Section 2.4 for more information about this command line.

6.7 Prescribed Temperature

```
 BEGIN PRESCRIBED TEMPERATURE
   # {block set commands}
   BLOCK = <string list>block_names
   INCLUDE ALL BLOCKS
   REMOVE BLOCK = <string list>block_names
   #
   # specification command
   FUNCTION = <string>function_name
   #
   # user subroutine commands
   NODE SET SUBROUTINE = <string>subroutine_name
   SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
   SUBROUTINE REAL PARAMETER: <string>param_name
     = <real>param_value
   SUBROUTINE INTEGER PARAMETER: <string>param_name
     = <integer>param_value
   SUBROUTINE STRING PARAMETER: <string>param_name
     = <string>param_value
   #
   # read variable commands
   READ VARIABLE = <string>variable_name
   TIME = <real>time
   #
   # additional commands
   SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED ACCELERATION]
```

The `PRESCRIBED TEMPERATURE` command block prescribes a temperature field for a given set of nodes. The prescribed temperature is for each node in the node set. The temperature field may vary over time and space. If the temperature field has only a time-varying component, the function command in the above command block can be used to specify the temperature field. If the temperature field has both time-varying and spatially varying components, a user subroutine option can be used to specify the temperature field. Finally, you may also read the temperature as a variable from the mesh file. You can select only one of these options—function, user subroutine, or read variable—in a command block.

Temperature is applied to nodes, but it is frequently used at the element level, such as in the case for thermal strains. If the temperatures are used at the element level, the nodal values are averaged (depending on element) connectivity to produce an element temperature. The temperatures must be defined for all the nodes defining the connectivity for any given element. For this reason, we use block commands to derive a set of nodes at which to define temperatures. If the temperatures are used on an element basis, then the temperature at all the necessary nodes will be defined.

The `PRESCRIBED TEMPERATURE` command block contains four groups of commands—block set,

function, user subroutine, and read variable. Each of these command groups is basically independent of the others. In addition to the command lines in the four command groups, there are two additional command lines: `SCALE FACTOR` and `ACTIVE PERIODS`. The `SCALE FACTOR` command line can be used in conjunction with the function command, the user subroutine option, or the read variable option. The `ACTIVE PERIODS` command line is used to activate or deactivate this kinematic boundary condition for certain time periods. Following are descriptions of the different command groups and the `SCALE FACTOR` and `ACTIVE PERIODS` command lines.

6.7.1 Block Set Commands

The `{block set commands}` portion of the `PRESCRIBED TEMPERATURE` command block defines a set of nodes associated with the prescribed temperature field and can include some combination of the following command lines:

```
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes derived from some combination of element blocks. See Section 6.1.1 for more information about the use of these command lines for creating a set of nodes used by the boundary condition. There must be at least one `BLOCK` or `INCLUDE ALL BLOCKS` command line in the command block.

6.7.2 Specification Command

If the function command is used, the temperature at any given time is the same for all nodes in the node set associated with the particular `PRESCRIBED TEMPERATURE` command block. The command line

```
FUNCTION = <string>function_name
```

references a `function_name` (defined in the domain scope using a `DEFINITION FOR FUNCTION` command block) that specifies the temperature as a function of time. The temperature can be scaled by use of the `SCALE FACTOR` command line described in Section 6.7.5.

6.7.3 User Subroutine Commands

If the user subroutine option is used, the temperature field may vary spatially at any given time for each of the nodes in the node set associated with the particular `PRESCRIBED TEMPERATURE` command block. The user subroutine option allows for a more complex description of the temperature field than does the function command, but the user subroutine option also requires that you write a user subroutine to implement this capability. The user subroutine will be used to define a

temperature for every node to which the boundary condition will be applied. The subroutine will be called by Adagio at the appropriate time to generate the temperature field.

Following are the command lines related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the `NODE SET SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the `NODE SET SUBROUTINE` command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

The temperature set in the user subroutine can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.7.5.

See Chapter 9 for more details on implementing the user subroutine option.

6.7.4 Read Variable Commands

If the read variable option is used, the temperature field will be read from a variable defined in the mesh file. The following command lines are used for the read variable option:

```
READ VARIABLE = <string>mesh_var_name
   TIME = <real>temp_time
```

The string `mesh_var_name` must correspond to the variable name for the temperature field present in the mesh file. The temperature field may be specified at several different times on the mesh file. You may select the temperature field at a specific time by using the `TIME` command line. If the specified time on the `TIME` command line does not correspond exactly to a time on the mesh file, the data on the mesh file will be interpolated as needed to obtain the nodal temperatures.

The temperature set by the read variable option can be scaled by use of the `SCALE FACTOR` command line, as described in Section 6.7.5.

6.7.5 Additional Commands

These command lines in the PRESCRIBED TEMPERATURE command block provide additional options for the boundary condition:

```
SCALE FACTOR = <real>scale_factor(1.0)
   ACTIVE PERIODS = <string list>period_names
```

The SCALE FACTOR command line is used to apply an additional scaling factor, which is constant in both time and space, to all temperature values of the field defined by the function command, the user subroutine, or the read variable option. For example, if the temperature in a time history function is given as 100.5 from time 1.0 to time 2.0 and the scale factor is 0.5, then the temperature from time 1.0 to 2.0 is 50.25. The default value for the scale factor is 1.0.

The ACTIVE PERIODS command line determines when the boundary condition is active. See Section 2.4 for more information about this command line.

6.8 References

1. Brown, K. H., J. R. Koteras, D. B. Longcope, and T. L. Warren. *CavityExpansion: A Library for Cavity Expansion Algorithms, Version 1.0*, in review. Albuquerque, NM: Sandia National Laboratories, 2003.

2. Lysmer, J., and R. L. Kuhlmeyer. "Finite Dynamic Model for Infinite Media." *Journal of the Engineering Mechanics Division, Proceedings of the American Society of Civil Engineers* (August 1979): 859–877.

3. Cook, R. D., Malkus, D. S., and Plesha, M. E. *Concepts and Applications of Finite Element Analysis, Third Edition.* New York: John Wiley and Sons, 1989.

Chapter 7

Contact

This chapter describes the input syntax for defining interactions of contact surfaces in a Adagio analysis. For more information on contact and its computational details, consult References 1 and 2.

Contact refers to the interaction of one or more bodies when they physically touch. This can include the interaction of one part of a surface against another part of the same surface, the surface of one body against the surface of another body, and so forth. The contact algorithms within Adagio are designed to ensure that surfaces do not inter-penetrate in a nonphysical way, and that the interface behavior is computed correctly (e.g., energy dissipation from a friction model). Adagio uses a kinematic approach rather than a penalty approach to eliminate the interpenetration of surfaces. In the kinematic approach, a series of constraint equations are satisfied that remove interpenetration. A penalty approach can be thought of as introducing "stiff" springs between contact surfaces as a means of preventing interpenetration.

In the current version of Adagio contact between surfaces is computed as node-face interactions. To establish some key definitions for node-face contact and node-face interactions, we consider the simple two-dimensional contact problem shown in Figure 7.1. There are two blocks, a and b. Block a is enclosed by surface a, and block b is enclosed by surface b. In finite element models, a surface is defined by a collection of finite element faces. The surface of a block of hexahedral elements, for example, is defined by a collection of quadrilateral faces on the surface of the block. For our two-dimensional example, the faces are a straight line between two nodes. We only show the faces on the portions of the surfaces that will come into contact.

Figure 7.1 shows the two blocks at time step n. Figure 7.2 shows the two blocks at time step $n+1$. The blocks have moved and deformed under the influence of external forces. Contact has not been taken into account, and we now observe interpenetration of the two blocks. We remove this interpenetration by applying our contact algorithm.

For interpenetration to occur as shown in Figure 7.2, any node on surface a that interpenetrates surface b must pass through some face on surface b. Likewise, each node on surface b that interpenetrates surface a must pass through some face on surface a. We could push all the nodes on surface a so that they lie on surface b, where surface b has the configuration shown in Figure 7.2. Or we could push all the nodes on surface b so that they lie on surface a, where surface a has the



Figure 7.1: Two blocks at time step *n* before contact.

configuration shown in Figure 7.2. The interface surface is shown as a straight line, but it would really be a curved line in all but the most unusual cases for a two-dimensional problem like the one shown. For three-dimensional problems, the interface surface will be a complex surface in three-dimensional space.

The simple two-dimensional example we have just discussed is analogous to much of the contact that is encountered when contact in Adagio is used in an analysis. Surfaces are generated that consist of a collection of faces, each face being defined by a nodal connectivity. Node-face interactions from these surfaces are used to move nodes to account for any interpenetration of the surfaces. Interpenetration means we have a node on a surface that has moved through a face on an opposing surface.

Contact in Adagio will handle the node-face contact just presented. It will also handle variations of the node-face contact we have just discussed. Some of these variations are as follows:

- In some cases, you may want one surface of a surface pair to determine the interface surface. One surface will be designated as the master surface. The opposing surface will be designated as the slave surface. The nodes on the slave surface will be moved to the master surface. The master surface sets the interface surface.

- A special case of contact called "tied contact" allows you to tie two surfaces on different objects together. The two surfaces that are tied together share a coincident surface or are in very close proximity at time 0.0. The initial point of contact between a tied node and an opposing face at time 0.0 is maintained for all times. At each time step, the node is moved so that it as the same point on the face regardless of where the faces move or how the face deforms.

- Instead of having two surfaces in contact, you can have a set of nodes not associated with



Figure 7.2: Two blocks at time step $n + 1$, after penetration.

faces that contacts a surface. We refer to this set of nodes as a "contact node set." The nodes in the contact node set cannot penetrate the surface.

There are some special considerations for contact with structural elements (i.e. shells) with the current implementation of contact. A shell element has both a top face and a bottom face that are defined by the same geometric entity.

Shell elements are handled by the contact algorithm, but they are much more difficult to handle than solid elements. Determining whether a node has penetrated a shell element is more difficult than determining whether a node has penetrated a solid. For a solid element with an external face, there is only one normal for the face. For a shell element, there are two faces—one on each side of the geometric entity that defines the shell. Each face has a normal, and the two normals for the shell element point in opposite directions. For shell elements, two faces are constructed for the element within the contact algorithm. The faces, each with a unique outward normal, can be coincident, or they can be separated by the thickness of the shell. Separating the two shell faces that are originally coincident at the geometric plane of the shell by the thickness of the shell is referred to as "lofting." To implement lofting, we need information about the thickness of the shell. This information is specified in the `SHELL SECTION` command block described in Section 5.2.2. For more information on lofting, see Section 7.5.

Contact for shell elements is only considered on shell faces; shell edges are currently not considered. The contact of a shell edge with another shell edge is not detected, and the contact of a shell edge with a continuum element edge is not detected. A shell element can coincide with the face of a continuum element. The contact algorithm will properly account for this situation. Two shell elements can also overlay each other, i.e., share the same set of nodes. The contact algorithm will also properly account for this situation. For a block of shell elements, two surfaces are created in contact.

Contact in Adagio is implemented in two distinct phases: a search algorithm and an enforcement algorithm. The search algorithm identifies nodes that have penetrated a face, while the enforcement algorithm computes the forces to remove penetration and the forces that observe the user-specified surface physics. The contact search within Adagio focuses on large-scale global contact in a massively parallel environment. The search algorithm relies on normal and tangential tolerances to describe a region around each face within which any nodes found are identified as potential interactions. The size of these tolerances is problem dependent.

The enforcement algorithm is based on a kinematic approach as opposed to a penalty approach. A kinematic approach is more accurate than the penalty approach.

Contact within a Adagio analysis is defined within a `CONTACT DEFINITION` command block. Within the contact definition scope, there are command lines and command blocks that define the specifics for the interaction of surfaces via the contact algorithm. Some of the command lines and command blocks within the contact scope set up default parameters that affect all contact calculations. Some of the command blocks in the contact scope affect only the interaction between a pair of surfaces.

There are three approaches that can be used to define a contact problem:

1. Accept all the Adagio default parameters for a problem.
2. Accept the Adagio default parameters for some of the contact surfaces. For the rest of the contact surfaces, the user can change some of the Adagio default settings.
3. Define all surface-pair interactions separately.

The general pattern of syntax for describing contact is as follows:

- Identify all surfaces that need to be considered for contact. This is done with command lines (or command blocks) within the contact scope.
- Specify values for interactions between specific contact surfaces. This is done within an `INTERACTION` command block. Values specified in this command block override the defaults for the particular pair of surface interactions.

7.1 Contact Definition Block

All commands for contact occur within a `CONTACT DEFINITION` command block. A summary of these commands follows.

```
BEGIN CONTACT DEFINITION <string>name
  #
  # enforcement options
  ENFORCEMENT = <string>TIED|FRICTIONLESS|FRICTIONAL
  #
  # contact surface and node set definition
  CONTACT SURFACE <string>name
    CONTAINS <string list>surface_names
  #
  BEGIN CONTACT SURFACE <string>name
    BLOCK = <string list>block_names
    SURFACE = <string list>surface_names
    NODE SET = <string list>node_set_names
    REMOVE BLOCK = <string list>block_names
    REMOVE SURFACE = <string list>surface_names
    REMOVE NODE SET = <string list>nodelist_names
  END [CONTACT SURFACE <string>name]
  #
  CONTACT NODE SET <string>surface_name
    CONTAINS <string>nodelist_names
  #
  BEGIN SURFACE NORMAL SMOOTHING
    ANGLE = <real>angle
    DISTANCE = <real>distance
    RESOLUTION = <string>NODE|EDGE
  END SURFACE NORMAL SMOOTHING
  #
  BEGIN INTERACTION [<string>name]
    MASTER = <string>surface
    SLAVE = <string>surface
    CAPTURE TOLERANCE = <real>cap_tol
    NORMAL TOLERANCE = <real>norm_tol
    TANGENTIAL TOLERANCE = <real>tang_tol
    TENSION RELEASE = <real>ten_release
    TENSION RELEASE FUNCTION = <string>ten_release_func
    FRICTION COEFFICIENT = <real>coeff
    FRICTION COEFFICIENT FUNCTION = <string>coeff_func
  END [INTERACTION <string>name]

  #

  # end enforcement
```

```
    #
  END [CONTACT DEFINITION <string>name]
```

The command block begins with the input line:

```
BEGIN CONTACT DEFINITION <string>name
```

and is terminated with the input line:

```
END [CONTACT DEFINITION <string>name]
```

where `name` is a name for this contact definition. The name should be unique among all the contact definitions in an analysis. All other contact commands are encapsulated within this command block, as shown in the summary of the block presented previously. These other contact commands are described in Section 7.1through Section 7.6. Section 7.8 explains how to implement contact for several example problems.

A typical analysis will have only one `CONTACT DEFINITION` command block. However, more than one contact definition can be used. As each `CONTACT DEFINITION` command block creates its own contact entity, fewer of these command blocks provide more efficient contact processing.

7.2 Enforcement

```
ENFORCEMENT = <string>TIED|FRICTIONLESS|FRICTIONAL
```

The `ENFORCEMENT` command line indicates which of three types of contact enforcement available in Adagio should be used in this `CONTACT DEFINITION` block. The first of these, `TIED`, will match slave nodes to master surfaces during initialization. Thereafter, the slave nodes will not be allowed to move relative to their master surfaces.

The `FRICTIONLESS` option allows slave nodes to slide along master surfaces but prevents penetration.

The `FRICTIONAL` option also allows slave nodes to slide along master surfaces. However, the sliding motion is affected by a frictional law. No penetration is allowed.

7.3 Descriptions of Contact Surfaces

In general, contact determines whether one surface has inter-penetrated another surface. As indicated previously, a surface is defined by an analytic representation or a collection of finite element faces. This section describes how to define a surface composed of finite element faces. It also describes how to define a set of nodes (zero-dimensional entities) not associated with faces that can contact a surface.

Generally, a surface is defined as a collection of finite element faces. Both continuum elements and shell elements have faces. For a continuum element, any face that is not shared with another element can be considered for contact. For a shell element, one element can have both a top face and a bottom face. These top and bottom surfaces are automatically created for the contact algorithm and may be lofted by a user-specified thickness. Shell contact is done by computing the contact forces on the top and bottom surfaces of the shells and then moving the resulting forces back to the original shell nodes.

At this point, it is important to introduce the concept of "skinning" a block of elements. We can generate a surface (a collection of faces) from a block of continuum elements by skinning the block of elements. All exterior faces (any face not shared by two elements) will be associated with the surface for that block when the block is skinned. If we have two blocks of continuum elements that are connected (some of the element faces in one block are shared by the element faces in the other block) and we skin both of these blocks, then the skinned surface for each block will consist of faces that are exterior to both blocks. For this case, we will have generated two surfaces. The set of external faces from skinning the first block will have a unique surface name, and the set of external faces generated by skinning the second block will have a unique surface name. Any face shared by the two blocks will not be in the surfaces derived by skinning the two blocks. If we have a single block of shell elements and we skin the block, then all the top faces of all the shell elements will be one surface and the bottom faces of all the shell elements will be another surface. (In Adagio we do not have to be concerned with naming two distinct surfaces for shell elements. This is handled internally by the code.) Suppose we have two blocks of shell elements in which none of the elements in one block overlap the elements in another block; the two blocks are joined only at the shell edges. In this case, we will get a unique surface identifier that references both the top and bottom faces of all the shell elements in the first block, and we will get a unique surface identifier that references both the top and bottom faces of all the shell elements in the second block.

Skinning becomes more complicated when we have a shell surface that overlays the surface of a block of continuum elements. If a shell surface overlays the surface of a block of continuum elements, we can have shell elements that are coincident with the external faces of the continuum elements. Coincident in this case means that a shell element has the same nodal connectivity as the nodal connectivity defining an external face of a continuum element. Skinning also becomes more complicated when we have two shell blocks with coincident elements. Coincident in this case means we have two shell elements in different blocks that have the same nodal connectivity. See Section 7.5 for more information about skinning with shells.

A face can only be associated with a single contact surface. However, in the process of defining contact surfaces, you might create a situation where one face appears on more than one contact surface. If a face appears on more than one contact surface, an ambiguous situation arises. The

following example should help to explain this ambiguous situation.

First, let us establish a situation where there is a face that appears on two contact surfaces. One contact surface is defined by skinning an element block of hexahedral elements. The name of this surface obtained by skinning a block is `block_1024`. One of the faces in surface `block_1024` is defined by the node connectivity {100, 101, 1002, 1001}. A surface on the same element block is defined by specifying a side set definition. The name of this surface obtained by using a side set definition is `surface_1000`. One of the faces in surface `surface_1000` is defined by the node connectivity {100, 101, 1002, 1001}. In this example, we have the same face, {100, 101, 1002, 1001}, defined on two different surfaces, `block_1024` and `surface_1000`. The definition of the surface with the side set includes one of the faces in the surface obtained by skinning the block.

Now let us show how an ambiguous situation can arise. Suppose, in our example, that the friction model specified for surface `block_1024` is different from the friction model specified for surface `surface_1000`. Furthermore, suppose that the tolerances specified for surface `block_1024` are different from the tolerances specified for surface `surface_1000`. For contact, only one friction model and only one set of tolerances can be applied to face {100, 101, 1002, 1001}. The question arises as to which friction model and which set of tolerances should be applied to the face. Any face, in general, can have only one type of a given contact property—friction model, tolerances, etc.,—applied to the face.

To handle the case of a face defined in more than one contact surface, any face defined in more than one contact surface will be assigned to the first contact surface defined in the `CONTACT DEFINITION` command block that includes the face. For example, if contact surface `block_1024` is defined before contact surface `surface_1000` in the `CONTACT DEFINITION` command block, then face {100, 101, 1002, 1001} will be assigned to contact surface `block_1024`. Face {100, 101, 1002, 1001} will not be assigned to contact surface `surface_1000`. In general, then, any face appearing on multiple contact surfaces will be assigned to the first contact surface defined in the `CONTACT DEFINITION` command block that includes the face. (The ordering of the contact surface definitions in the `CONTACT DEFINITION` command block will determine how faces defined on multiple contact surfaces are assigned to a contact surface.) If a face is defined on multiple contact surfaces, a warning is generated.

For the case where unassociated nodes are contacting a surface, you will need to define some collection of unassociated nodes and a surface that can be contacted by these nodes. The contact of one-dimensional elements (springs, trusses, beams) with a surface can also be modeled as unassociated nodes contacting a surface, although, as in the case of shells, there are some limitations. The contact algorithm cannot detect a one-dimensional element cutting through the edge of a shell element, the edge of a continuum element, or through another one-dimensional element.

To describe surfaces defined by finite element faces that can be considered for contact, you can use the `CONTACT SURFACE` command line or the `CONTACT SURFACE` command block. To describe unassociated nodes that can come into contact with surfaces, you should use the `CONTACT NODE SET` command line or the `CONTACT SURFACE` command block. A `CONTACT DEFINITION` command block can contain any combination of these command lines and command blocks provided that no two of these commands have the same name. The `CONTACT DEFINITION` command block MUST include some type of surface definition. Any element faces or unassociated nodes that you want to use for contact interaction must be identified as contact faces or contact nodes, respectively.

Section 7.3.1 through Section 7.3.3 describe the command lines and command blocks for defining contact surfaces composed of finite element faces and node sets that can contact surfaces.

7.3.1 Contact Surface Command Line

```
CONTACT SURFACE <string>name
  CONTAINS <string list>surface_names
```

This command line identifies a set of surfaces (specified as side sets) and element blocks that will be considered as a single contact surface; the string `name` is the unique name for this contact surface. The list denoted by `surfaces_names` is a list of strings identifying surfaces that are to be associated with this contact surface `name`. The surfaces can be side sets, element blocks, or any combination of the two as defined in the exodus file. These are not names of analytic surfaces. Any specified element blocks are "skinned," i.e., a surface is created from the exterior of the element block. See the previous discussion on skinning. Blocks of shell elements will be skinned, and the shell surfaces generated from a `CONTACT SURFACE` command line will be lofted for contact if the lofting algorithm is `ON` in the `SHELL LOFTING` command block.

If a block of one-dimensional elements (springs, trusses, beams) is included in the list of `surface_names`, the element block will be ignored. Thus, to include the one-dimensional elements for contact, a `CONTACT NODE SET` command line should be used. See Section 7.3.3.

The `name` you create for a surface can be referenced in command blocks that specify how that surface will interact with another contact surface or with itself. See Section 7.6.1.

The surfaces can contain a heterogeneous set of face types as well as any number of side sets and element blocks.

If a face appears in a side set and also in a set of faces generated by the skinning of an element block, that face will produce an error. As indicated previously, any given face may not appear in more than one contact surface.

7.3.2 Contact Surface Command Block

```
BEGIN CONTACT SURFACE <string>name
  BLOCK = <string list>block_names
  SURFACE = <string list>surface_names
  NODE SET = <string list>node_set_names
  REMOVE BLOCK = <string list>block_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE NODE SET = <string list>node_set_names
END [CONTACT SURFACE <string>name]
```

The `CONTACT SURFACE` command block can be used to define a contact surface consisting of a collection of finite element faces or a set of unassociated nodes that will be a contact node set. We can use some combinations of the above command lines as a set of Boolean operations to define

our collection of faces or collection of unassociated nodes. The result of this command block must be either a set of faces or a set of nodes.

If you want to define a surface named `name` that is a set of faces, you can use some combination of the command lines `BLOCK`, `SURFACE`, `REMOVE BLOCK`, and `REMOVE SURFACE`. For this case, however, the `BLOCK` and `REMOVE BLOCK` command lines must refer to element blocks that are continuum or shell elements. If the element block referred to is a block of continuum elements, the block is skinned. If the element block referred to is a block of shell elements, the top and bottom faces of the shell elements will form the contact faces.

Suppose you specify a `BLOCK` command line that references several continuum blocks. The set of faces defining the surface will consist of the exterior faces for all the element blocks. If you want to preserve the list of element blocks on the `BLOCK` command line while removing the exterior faces associated with one or more of the blocks, you could simply add a `REMOVE BLOCK` command line listing only those blocks whose associated faces are to be removed from the contact surface.

Suppose you specify a `BLOCK` command line that references a block of continuum elements and a `SURFACE` command line that references a side set. Then the contact surface produced by the command block will be the union of the faces defined by the skinning of the block of continuum elements and the faces defined in the side set.

Suppose you specify a `BLOCK` command line that references a block of continuum elements and a `REMOVE SURFACE` command line that references a side set. Furthermore, suppose that the side set is a set of faces that is a subset of the set of faces obtained from skinning the continuum block. Then the contact surface produced by the command block will be the set of faces obtained by skinning the continuum block minus the faces in the side set.

As can be seen from the above examples, we can use the command lines `BLOCK`, `SURFACE`, `REMOVE BLOCK`, and `REMOVE SURFACE` as Boolean operators to construct a set of finite element faces defining a surface. The `BLOCK` and `REMOVE BLOCK` command lines should produce (or remove) faces, however, so that we are performing the Boolean operations on like topological entities. See Section 7.3.3 for further information about using a node set that contacts a surface.

There must be at least one `BLOCK`, `SURFACE`, or `NODE SET` command line in the command block.

7.3.3 Contact Node Set

```
CONTACT NODE SET <string>surface_name
  CONTAINS <string list>nodelist_names
```

As indicated previously, contact interactions may also be defined between a surface and a set of nodes. The `CONTACT NODE SET` command line names a set of nodes (the parameter `surface_name` in the above command line) as a collection of nodes in various node sets specified by the string list `nodelist_names`. All the nodes in the node set can then interact with a contact surface. If a node in the node set defined as `surface_name` attempts to penetrate a contact surface, the node will be moved to the surface through the contact calculations.

The node defined by the `CONTACT NODE SET` command line will be paired with a mesh surface

when contact interactions are defined. The easiest way to define the correct relation between the nodes in the node set and the faces in the actual surface is to pair the surface with the `MASTER` command line and the node set with the `SLAVE` command line. Suppose the set of nodes is named `beam_nodes` on the `CONTACT NODE SET` command line and the surface these nodes are paired with is named `plate`. Then the `INTERACTION` command block for the interaction of the node set and surface would contain the command lines below.

```
MASTER = plate
   SLAVE = beam_nodes
```

The `CONTACT NODE SET` command line also presents a simple approach for contact between one-dimensional elements (beams, trusses) and other contact surfaces—faces on solid elements, shell/membrane faces, and analytic surfaces. In this case, contact processing will seek to remove interpenetration of the nodes of the one-dimensional elements into the other contact surfaces. The contact capabilities in Adagio will not currently handle any contact between two one-dimensional elements.

7.4 Surface Normal Smoothing

```
BEGIN SURFACE NORMAL SMOOTHING
  ANGLE = <real>angle(60.0)
  DISTANCE = <real>distance(0.01)
  RESOLUTION = <string>NODE|EDGE(NODE)
END SURFACE NORMAL SMOOTHING
```

Finite element discretization often results in models with faceted edges, while the true geometry of the part is actually smoothly curved. If the faces of adjacent finite elements on a surface have differing normals, the discontinuities at the edges between those faces can cause problems with contact. These discontinuities in the face normals are particularly troublesome with an implicit code such as Adagio, which uses an iterative solver to obtain a converged solution at every step. If a node is in contact near an edge with a normal discontinuity, the node may slide back and forth between the two neighboring faces during the iterations. Because the normal directions of the two faces differ, this can make it difficult to converge on a solution to this discontinuous contact problem.

Surface normal smoothing is a technique that creates a smooth variation in the normal near edges. The normal varies linearly from the value on one face to the value on the other face over a distance that spans the edge. A smoothly varying normal at the edge makes it much easier for an iterative solver to obtain a converged solution in the case where a node has penetrated near the edge of a face.

Presto does not use an iterative solver and thus does not encounter the difficulties associated with face normal discontinuities. Consequently, the `SURFACE NORMAL SMOOTHING` command block is not typically useful for Presto models. It is provided in both Presto and Adagio, however, to provide a consistent transition between the two codes if they are used together in a coupled analysis.

If the `SURFACE NORMAL SMOOTHING` command block is present, this feature is activated. There are three optional commands that can be used within this block to control the behavior of normal smoothing.

- The `ANGLE` command is used to control whether smoothing should occur between neighboring faces. If the angle between two faces is less than the specified angle (given in degrees), smoothing is activated between them. Otherwise, the discontinuity is considered to be a feature of the model rather than an artifact of meshing, and they are not smoothed. The default value for `angle` is 60.

- The `DISTANCE` command specifies the distance as a fraction of the face size over which smoothing should occur. The specified value can vary from 0 to 1. The default value for `distance` is 0.01.

- The `RESOLUTION` command specifies the method used to determine the smoothed normal direction. The default `NODE` option uses a node-based algorithm to fit a smooth curve, while the `EDGE` option uses an edge-based algorithm.

7.5 Shell Lofting

```
BEGIN SHELL LOFTING
  LOFTING ALGORITHM = <string>ON|OFF(ON)
  COINCIDENT SHELL TREATMENT = <string>DISALLOW|IGNORE|
    SIMPLE(DISALLOW)
  COINCIDENT SHELL HEX TREATMENT = <string>DISALLOW|
    IGNORE|TAPERED|EMBEDDED(DISALLOW)
END [SHELL LOFTING]
```

Adagio can also assess contact on shell elements. Shell elements can interact with other shell elements, faces of solid elements, and contact node sets. Contact on shell elements can occur on either the meshed shell geometry, i.e., ignoring any shell thickness, or on the "lofted" geometry, i.e., a geometry that includes the thickness of the shell. Currently, contact appears to be more robust on the non-lofted geometry; however, for simulations in which the thickness is important, the lofted geometry can provide more-reasonable results. Also critical to shell contact is how shells that are fully coincident with other elements (i.e., share all their nodes with another element) are treated. These options are controlled by the user in the `SHELL LOFTING` command block.

The `LOFTING ALGORITHM` command line determines whether contact on a shell should be done on the lofted geometry or on the original shell geometry. If the value of the `LOFTING ALGORITHM` command line is set to `ON`, shell contact uses the lofted geometry; if it set to `OFF`, shell contact uses the original shell geometry.

The `COINCIDENT SHELL TREATMENT` command line identifies how shells that share the same nodes should be treated. If the `DISALLOW` option is selected, (the default), then any time that shells in contact are detected to share all the same nodes, the code will abort with an error message indicating which elements were found to be coincident. The `DISALLOW` option should be used if you do not want any coincident shells to be considered in the analysis. The option operates essentially as a check on the mesh. If the `IGNORE` option is selected, any contact faces attached to coincident shells are ignored for contact. This option is only provided as a backup approach if undiagnosed code problems arise from coincident shells. If such a case occurs, the `IGNORE` option may permit the user to continue with an analysis while the code team diagnoses the problem. The `SIMPLE` option enables coincident shells to be processed correctly. If lofting has been enabled and the `SIMPLE` option is selected, the thickness of the lofted coincident shell is taken as the largest thickness of all the coincident shells. If lofting is off and the `SIMPLE` option is selected, the coincident shell is treated as if only one of the shells is present.

The `COINCIDENT SHELL HEX TREATMENT` command line has a function similar to that of the `COINCIDENT SHELL TREATMENT` command line. The `COINCIDENT SHELL HEX TREATMENT` command line, however, identifies how shells that are fully coincident with the hex elements are treated. If the `DISALLOW` option is selected (the default), then any time that a shell in contact is detected to share all the same nodes with the face of a continuum element, the code will abort with an error message indicating which elements were found to be coincident. The `DISALLOW` option should be used if you do not want any shells coincident with hexes to be considered in the analysis. The option operates essentially as a check on the mesh. If the `IGNORE` option is selected, any contact faces attached to shells that are coincident with faces of continuum elements

are ignored for contact. This option is only provided as a backup approach if undiagnosed code problems arise from coincident shells and continuum elements. If such a case occurs, the `IGNORE` option may permit the user to continue with an analysis while the code team diagnoses the problem. The `TAPERED` and `EMBEDDED` options permit shells that are coincident with faces of continuum elements to be processed in contact. The `TAPERED` option does two things: it includes for contact any faces that are on the free surface and ignores faces sandwiched between the shell and the continuum element, and it automatically adjusts the lofting of the surfaces to provide a smooth transition between shells that are not coincident with the faces of the continuum elements and those that are coincident with the faces of the continuum elements. The `EMBEDDED` option includes for contact both free surface faces and those that are between the coincident shells and faces of the continuum elements; the option does not adjust thicknesses to make smooth transitions between shells that are not coincident with faces of continuum elements and those that are coincident with faces of continuum elements. In general, the `TAPERED` option is preferred; only use the `EMBEDDED` option if the `TAPERED` option causes a code problem.

7.6 Values for Interactions

```
BEGIN INTERACTION [<string>name]
  SURFACES = <string>surface1 <string>surface2
  MASTER = <string>surface
  SLAVE = <string>surface
  CAPTURE TOLERANCE = <real>cap_tol
  NORMAL TOLERANCE = <real>norm_tol
  TANGENTIAL TOLERANCE = <real>tang_tol
  TENSION RELEASE = <real>ten_release
  TENSION RELEASE FUNCTION = <string>ten_release_func
  FRICTION COEFFICIENT = <real>coeff
  FRICTION COEFFICIENT FUNCTION = <string>coeff_func
END [INTERACTION <string>name]
```

The Adagio contact input also permits the setting of values for specific interactions using the `INTERACTION` command block.

The `INTERACTION` command block begins with:

```
BEGIN INTERACTION [<string>name]
```

and ends with:

```
END [INTERACTION <string>name]
```

where `name` is a name for the interaction. Note that this name is currently not used or required.

The valid commands within an `INTERACTION` command block are described in Section 7.6.1 through Section 7.6.6.

7.6.1 Surface Identification

```
SURFACES = <string>surface1 <string>surface2

MASTER = <string>surface
SLAVE = <string>surface
```

There are two methods to identify the surfaces described by a specific interaction. The standard method is to identify both surfaces in a single line with the `SURFACES` command line, where `surface1` and `surface2` are the names of the two contact surfaces to which the interaction refers. In this syntax, the first surface is the master, and the second is the slave.

It is also possible to use the `MASTER` and `SLAVE` command lines, where `surface` is the name of a contact surface defined in the `CONTACT DEFINITION` command block (see Section 7.3). In this case, all interaction values specified in this command block are applied only to nodes of the slave surface interacting with faces of the master surface. You cannot specify two master-slave interactions in which the contact surfaces are switched.

In the INTERACTION command block, either the SURFACES syntax (SURFACES command line only) or the MASTER/SLAVE syntax (MASTER and SLAVE command lines) should be used, but not both.

7.6.2 Tolerances

```
CAPTURE TOLERANCE = <real>cap_tol
NORMAL TOLERANCE = <real>norm_tol
TANGENTIAL TOLERANCE = <real>tang_tol
```

You can set tolerances for the interaction for a specific contact surface pair by using the above tolerance-related command lines in an INTERACTION command block.

As indicated previously, the contact functionality in Adagio uses a box defined around each face to locate nodes that may potentially contact the face. This box is defined by a tolerance normal to the face and another tolerance tangential to the face (see Figure 7.3). The code adds to these tolerances the maximum motion over a time step when identifying interactions. In the above command lines, the parameter norm_tol is the normal tolerance (defined on the NORMAL TOLERANCE command line) for the search box and the parameter tang_tol is the tangential tolerance (defined on the TANGENTIAL TOLERANCE command line) for the search box.



Figure 7.3: Illustration of normal and tangential tolerances.

The CAPTURE TOLERANCE, which should be no larger than the NORMAL TOLERANCE, is used to determine which slave nodes near a master surface should be pulled to the master surface and considered for contact. (This applies to slave nodes which have not penetrated the master surface. Slave nodes that have penetrated the master surface will be pushed to the surface regardless of the CAPTURE TOLERANCE.) If later checks determine that a slave node that was pulled to the surface (because it was nearer the surface than the CAPTURE TOLERANCE value) is in fact in tension and should be released, that slave node will not be considered as a potential contact node again during the load step as long as the node remains within the NORMAL TOLERANCE.

7.6.3 Tension Release

```
TENSION RELEASE = <real>ten_release
```

The command line `TENSION RELEASE` can be used to set a traction threshold below which slave nodes that have come into contact with master faces will not be released. When this value is set and a slave node is in tension, it will only be allowed to pull away from the master surface if the slave node's traction is greater than the `TENSION RELEASE` tolerance.

7.6.4 Tension Release Function

```
TENSION RELEASE FUNCTION = <real>ten_release_func
```

The command line `TENSION RELEASE FUNCTION` provides a way for the tension release threshold to be set using a function from the input file. If the `TENSION RELEASE` line command is also present, the threshold used by the code will be the `TENSION RELEASE` value multiplied by the value obtained from the function.

7.6.5 Friction Coefficient

```
FRICTION COEFFICIENT = <real>coeff
```

You can set the coefficient of friction for the interaction for a specific contact surface pair by using the above command line in an `INTERACTION` command block.

7.6.6 Friction Coefficient Function

```
FRICTION COEFFICIENT FUNCTION = <real>coeff_func
```

The command line `FRICTION COEFFICIENT FUNCTION` provides a way for the friction coefficient to be set using a function from the input file. If the `FRICTION COEFFICIENT` line command is also present, the friction coefficient used by the code will be the `FRICTION COEFFICIENT` value multiplied by the value obtained by the function.

7.7 Legacy Contact

This section describes the use of the contact library written for JAS3D. This library is referred to as the Legacy Contact Library or LCLib.

Adagio has two contact search and enforcement options. The first option, the default, is to use ACME for the contact search and Adagio's own enforcement library. The second option is to use JAS3D's contact library for both the search and the enforcement. While the capabilities of the two options are nominally the same, one may perform better than the other for certain problems.

To invoke the use of LCLib, include the line command

```
JAS MODE
```

in the region.

When using LCLib, only one `CONTACT DEFINITION` block is allowed in the region. The `ENFORCEMENT` line command must invoke the `FRICTIONAL` type. If frictionless contact is desired for an interaction, set the `FRICTION COEFFICIENT` to zero. If tied contact is desired for an interaction, set the `FRICTION COEFFICIENT` to -1.

7.8 Examples

This section has several example problems. We present the geometric configuration for the problems and the appropriate command lines to describe contact for the problems.

7.8.1 Example 1

Our first example problem has two blocks that come into contact due to initial velocity conditions. Block 1 has an initial velocity equal to $v1$, and block 2 has an initial velocity equal to $v2$. The geometric configuration for this problem is shown in Figure 7.4.



Figure 7.4: Problem with two blocks coming into contact.

The simplest input for this problem will be named `EXAMPLE1` and is shown as follows:

```
BEGIN CONTACT DEFINITION EXAMPLE1

  # enforcement option
  ENFORCEMENT = FRICTIONLESS

  # contact surfaces
  CONTACT SURFACE B1 CONTAINS BLOCK_1
  CONTACT SURFACE B2 CONTAINS BLOCK_2

  # set interactions
  BEGIN INTERACTION EX1
    MASTER = B1
    SLAVE = B2
    CAPTURE TOLERANCE = 1.0E-3
    NORMAL TOLERANCE = 1.0E-3
    TANGENTIAL TOLERANCE = 1.0E-3
  END INTERACTION EX1
END
```

In this example, we define frictionless contact.

Now, let us consider the same problem (two blocks coming into contact) with frictional contact. The input for this variation of our two-block problem will be named `EXAMPLE1A` and is shown as follows:

```
BEGIN CONTACT DEFINITION EXAMPLE1A

  # enforcement option
  ENFORCEMENT = FRICTIONAL

  # contact surfaces
  CONTACT SURFACE B1 CONTAINS BLOCK_1
  CONTACT SURFACE B2 CONTAINS BLOCK_2

  # set interactions
  BEGIN INTERACTION EX1A
    MASTER = B1
    SLAVE = B2
    FRICTION COEFFICIENT = 0.5
    CAPTURE TOLERANCE = 1.0E-3
    NORMAL TOLERANCE = 1.0E-3
    TANGENTIAL TOLERANCE = 1.0E-3
  END INTERACTION EX1A
END
```

For `EXAMPLE1A`, we want to have frictional contact between the two blocks. For the frictional contact, we specify the coefficient of friction as `0.5`.

7.8.2 Example 2

Our second example problem has three blocks that come into contact due to initial velocity conditions. Block 1 has an initial velocity equal to $v1$, and block 3 has an initial velocity equal to $v3$. The geometric configuration for this problem is shown in Figure 7.5.

The input for this three-block problem will be named `EXAMPLE2` and is shown as follows:

```
BEGIN CONTACT DEFINITION EXAMPLE2

  # enforcement
  ENFORCEMENT = FRICTIONLESS

  # define contact surfaces
  CONTACT SURFACE surface_1 CONTAINS block_1
  CONTACT SURFACE surface_2 CONTAINS block_2
  CONTACT SURFACE surf_3 CONTAINS surface_3
```



Figure 7.5: Problem with three blocks coming into contact.

```
  # set interaction
  BEGIN INTERACTION S1TOS2
    MASTER = surface_2
    SLAVE = surface_1
    NORMAL TOLERANCE = 1.0E-3
    TANGENTIAL TOLERANCE = 1.0E-3
  END INTERACTION S2TOS3

  # set interaction
  BEGIN INTERACTION S2TOS3
    MASTER = surface_2
    SLAVE = surf_3
    NORMAL TOLERANCE = 0.5E-3
    TANGENTIAL TOLERANCE = 0.5E-3
  END INTERACTION S2TOS3
END
```

For the `EXAMPLE2` command block, we have defined three surfaces. The first surface, `surface_1`, is obtained by skinning `block_1`. The second surface, `surface_2` is obtained by skinning `block_2`. The third surface, `surf_3`, is the user-defined surface `surface_3`. The user-defined surface, `surface_3`, can contain a subset of the external element faces that define `block_3` or all the external element faces that define `block_3`.

7.9 References

1. Brown, K. H., R. M. Summers, M. W. Glass, A. S. Gullerud, M. W. Heinstein, and R. E. Jones. *ACME: Algorithms for Contact in a Multiphysics Environment*, API Version, 2.2, SAND2004-5486. Albuquerque, NM: Sandia National Laboratories, October 2001.

2. Heinstein, M. W., and T. E. Voth. *Contact Enforcement for Explicit Transient Dynamics*, Draft SAND report. Albuquerque, NM: Sandia National Laboratories, 2005.

Chapter 8

Output

Adagio produces a variety of output. This chapter discusses how to control the four major types of output: results output, history output, heartbeat output, and restart output. Results output lets the user select some set of variables (registered, user-defined, or some combination thereof). If the user selects a nodal variable such as displacement for results output, the displacements for all the nodes in a model will be output to a results file. If the user selects an element variable such as rotated stress for results output, the rotated stress for all elements in the model that calculate this quantity (rotated stress) will be output. The history output option lets the user select a very specific set of information for output. For example, if you know that the displacement at a particular node is critical, then you can select only the displacement at that particular node as history output. The heartbeat output is similar to the history output except that the output is written to a text file instead of to a binary (exodusII [1]) file. The restart output is written so that any calculation can be halted at some arbitrary analysis time and then restarted at this time. The user has no control over what is written to the restart file. When a restart file is written, it must be a complete state description of the calculations at some given time. A restart file contains a great deal of information and is typically much larger than a results file. You need to carefully limit how often a restart file is written.

Section 8.1 describes the results output. Included in the results output is a description of commands for user-defined output (Section 8.1.2). User-defined output lets the user postprocess analysis results as the code is running to produce a reduced set of output information. Section 8.2 describes the history output, Section 8.3 describes the heartbeat output, and Section 8.4 describes the restart output. All four types of output (results, history, heartbeat, and restart) can be synchronized for analyses with multiple regions. This scheduling functionality is discussed in Section 8.5. In Section 8.6, there is a list of key registered variables.

Unless otherwise noted, the command blocks and command lines discussed in Chapter 8 appear in the region scope.

8.1 Results Output

The results output capability lets you select some set of variables that will be written to a file at various intervals. As previously indicated, all the values for each selected variable will be written to the results file. (The interval at which information is written can be changed throughout the analysis time.) The name of the results file is set in the `RESULTS OUTPUT` command block.

8.1.1 Exodus Results Output File

```
BEGIN RESULTS OUTPUT <string>results_name
  DATABASE NAME = <string>results_file_name
  DATABASE TYPE = <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
    (ON|TRUE|YES)
  TITLE <string>user_title
  NODE VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | NODAL VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name] ...
        <string>variable_name [AS
        <string>dbase_variable_name]
  NODESET VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | NODESET VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name]
        INCLUDE|ON|EXCLUDE <string list>nodelist_names
        ... <string>variable_name
        [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
        <string list>nodelist_names
  FACE VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | FACE VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name]
        INCLUDE|ON|EXCLUDE <string list>surface_names
        ...  <string>variable_name
        [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
        <string list>surface_names
  ELEMENT VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | ELEMENT VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name]
        INCLUDE|ON|EXCLUDE <string list>block_names
        ... <string>variable_name
        [AS dbase_variable_name] INCLUDE|ON|EXCLUDE
        <string list>block_names
  OUTPUT MESH = EXPOSED_SURFACE|BLOCK_SURFACE
```

```
    COMPONENT SEPARATOR CHARACTER = <string>character|NONE
    GLOBAL VARIABLES = <string>variable_name
      [AS <string>dbase_variable_name] ...
      <string>variable_name [AS
      <string>dbase_variable_name]
    START TIME = <real>output_start_time
    TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
    AT TIME <real>time_begin INCREMENT =
      <real>time_increment_dt
    ADDITIONAL TIMES = <real>output_time1
      <real>output_time2 ...
    AT STEP <integer>step_begin INCREMENT =
      <integer>step_increment
    ADDITIONAL STEPS = <integer>output_step1
      <integer>output_step2 ...
    TERMINATION TIME = <real>termination_time_value
    USE OUTPUT SCHEDULER <string>scheduler name
    OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
      SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
      SIGKILL|SIGILL|SIGSEGV
  END [RESULTS OUTPUT <string>results_name]
```

You can specify a results file, the results to be included in this file, and the frequency at which results are written by using a `RESULTS OUTPUT` command block. The command block appears inside the region scope.

More than one results file can be specified for an analysis. Thus for each results file, there will be one `RESULTS OUTPUT` command block. The command block begins with:

```
BEGIN RESULTS OUTPUT <string>results_name
```

and is terminated with:

```
END [RESULTS OUTPUT <string>results_name]
```

where `results_name` is a user-selected name for the command block. Nested within the `RESULTS OUTPUT` command block are a set of command lines, as shown in the block summary given above. The first two command lines listed (`DATABASE NAME` and `DATABASE TYPE`) give pertinent information about the results file. The command line

```
DATABASE NAME = <string>results_file_name
```

gives the name of the results file with the string `results_file_name`. If the results file is to appear in the current directory and is named `job.e`, this command line would appear as:

```
DATABASE NAME = job.e
```

If the results file is to be created in some other directory, the command line would have to show the path to that directory.

If the results file does not use the Exodus II format [1], you must specify the format for the results file using the command line:

```
DATABASE TYPE = <string>database_type(exodusII)
```

Currently, both the Exodus II database and the XDMF database [2] are supported in Presto and Adagio. Exodus II is more commonly used than XDMF. Other options may be added in the future.

The `OVERWRITE` command line can be used to prevent the overwriting of existing results files.

```
OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
     (ON|TRUE|YES)
```

The `OVERWRITE` command line allows only a single value. If you set the value to `FALSE`, `NO`, or `OFF`, the code will terminate before existing results files can be overwritten. If you set the value to `TRUE`, `YES`, or `ON`, then existing results files can be overwritten (the default status). Suppose, for example, that we have an existing results file named `job21.e`. Suppose also that we have an input file with a `RESULTS OUTPUT` command block that contains the `OVERWRITE` command line set to `ON` and the `DATABASE NAME` command line set to:

```
DATABASE NAME = job21.e
```

If you run the code under these conditions, the existing results file `job21.e` will be overwritten.

Whether or not results files are overwritten is also impacted by the use of the automatic read and write option for restart files described in Section 8.4.1.1. If you use the automatic read and write option for restart files, the results files, like the restart files, are automatically managed. The automatic read and write option in restart adds extensions to file names and prevents the overwriting of any existing restart or results files. For the case of a user-controlled read and write of restart files (Section 8.4.1.2) or of no restart, however, the `OVERWRITE` command line is useful for preventing the overwriting of results files.

You may add a title to the results file by using the `TITLE` command line. Whatever you specify for the `user_title` will be written to the results file. Some of the programs that process the results file (such as various SEACAS programs [3]) can read and display this information.

The other command lines that appear in the `RESULTS OUTPUT` command block determine the type and frequency of information that is output. Descriptions of these command lines follow in Section 8.1.1.1 through Section 8.1.1.16.

8.1.1.1 Output Nodal Variables

```
NODE VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
  | NODAL VARIABLES = <string>variable_name
      [AS <string>dbase_variable_name] ...
      <string>variable_name [AS
      <string>dbase_variable_name]
```

Any nodal variable in Adagio can be selected for output in the results file by using a command line in one of the two forms shown above. The only difference between the two forms is the use

of NODE or NODAL. The string variable_name is the name of the nodal variable to output. The string variable_name can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4).

For the above two command lines, any nodal variable requested for output is output for all nodes.

It is possible to specify an alias for any of the nodal variables by using the AS specification. Suppose, for example, you wanted to output the external forces in Adagio, which are registered as force_external, with the alias f_ext. You would then enter the command line:

```
NODE VARIABLES = force_external AS f_ext
```

In this example, the external force is a vector quantity. For a vector quantity at a node, suffixes are appended to the variable name (or alias name) to denote each vector component. The results database would have three variable names associated with the external force: f_ext_x, f_ext_y, and f_ext_z. Consult with Table 8.4 for a list of component identifiers for vectors. You can change the component separator, an underscore in this example, by using the COMPONENT SEPARATOR CHARACTER command line (see Section 8.1.1.6).

The NODE VARIABLES command line can be used an arbitrary number of times within a RESULTS OUTPUT command block. It is also possible to specify more than one nodal variable for output on a command line, as indicated by the ellipsis in the command line format. In the following example, two nodal variables are specified for output. Note that the internal forces are registered as force_internal.

```
NODE VARIABLES = force_external force_internal
```

Aliases can be specified for each of the variables in a single command line. Thus, If you wanted to output the alias f_ext for external forces and also wanted to output the alias f_int for internal forces, you would enter the command line:

```
NODE VARIABLES = force_external AS f_ext
     force_internal AS f_int
```

The specification of an alias is always optional.

8.1.1.2 Output Node Set Variables

```
NODESET VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
  | NODESET VARIABLES = <string>variable_name
      [AS <string>dbase_variable_name]
      INCLUDE|ON|EXCLUDE <string list>nodelist_names
      ... <string>variable_name
      [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
      <string list>nodelist_names
```

A nodal variable may be registered only on a subset of the total set of nodes defining a model. A nodal variable that is registered only on some subset of nodes is referred to as a node set variable. The NODESET VARIABLES command line lets you specify a node set variable for output to the results file.

There are two forms of the NODESET VARIABLES command line. Either form will let you output a node set variable.

The first form of the command line is as follows:

```
NODESET VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
```

Here, the string variable_name is a node set variable associated with one or more node sets. In this form, the node set variable is output for all node sets associated with that node set variable.

It is possible to specify an alias in the results file for any of the node set variables by using the AS specification. Suppose, for example, you wanted to output a node set variable registered as force_nsetype with the alias fnsetype. You would then enter the command line:

```
NODESET VARIABLES = force_nsetype AS fnsetype
```

The NODESET VARIABLES command line can be used an arbitrary number of times within a RESULTS OUTPUT command block. It is also possible to specify more than one node set variable for output on a command line, as indicated by the ellipsis in the command line format. In the following example, two node set variables are specified for output. Here, the second node set variable is registered as force_nsetype2.

```
NODESET VARIABLES = force_nsetype force_nsetype2
```

Aliases can be specified for each of the variables in a single command line. Thus, If you wanted to output the alias fnsetype for node set variable force_nsetype and also wanted to output the alias fnsetype2 for node set variable force_nsetype2, you would enter the command line:

```
NODESET VARIABLES = force_nsetype AS fnsetype
     force_nsetype2 AS fnsetype2
```

The specification of an alias is always optional.

The second form of the command line is as follows:

```
NODESET VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name]
  INCLUDE|ON|EXCLUDE <string list>nodelist_names
  ... <string>variable_name
  [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
  <string list>nodelist_names
```

This form of the NODESET VARIABLES command line is similar to the first, except that the user can control which node sets are used for output. The user can include a specific list of node sets

for output by using the INCLUDE option or the ON option. (The key word INCLUDE is synonymous with the key word ON.) Alternatively, the user can exclude a specific list of node sets for output by using the EXCLUDE option.

Suppose that the node set variable force_nsetype from the above example has been registered for nodelist_10, nodelist_11, nodelist_20, and nodelist_21. If we only want to output the node set variable for node sets nodelist_10, nodelist_11, and nodelist_21, then we could specify the NODESET VARIABLES command line as follows:

```
NODESET VARIABLES = force_nsetype AS fnsetype
     INCLUDE nodelist_10, nodelist_11,
     nodelist_21
```

(In the above command line, the keyword ON could be substituted for INCLUDE.) Alternatively, we could use the command line:

```
NODESET VARIABLES = force_nsetype AS fnsetype
     EXCLUDE nodelist_20
```

In the above command lines, an alias for a node set can be substituted for a node set identifier. For example, if center_case is an alias for nodelist_10, then the string center_case could be substituted for nodelist_10 in the above command lines. Because a node set identifier is a mesh entity, the alias for the node set identifier would be defined via an ALIAS command line in a FINITE ELEMENT MODEL command block.

Note that the list of identifiers uses a comma to separate one node set identifier from the next node set identifier.

8.1.1.3 Output Face Variables

```
FACE VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
  | FACE VARIABLES = <string>variable_name
      [AS <string>dbase_variable_name]
      INCLUDE|ON|EXCLUDE <string list>surface_names
      ...  <string>variable_name
      [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
      <string list>surface_names
```

A variable may be registered on some set of faces that constitute a surface. A variable registered on a set of faces is referred to as a face variable. The FACE VARIABLES command line lets you specify a face variable for output to the results file.

There are two forms of the FACE VARIABLE command line. Either form will let you output a face variable.

The first form of the command line is as follows:

```
FACE VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
```

Here, the string `variable_name` is a face variable associated with one or more surfaces. In this form, the face variable is output for all surfaces associated with that face variable.

It is possible to specify an alias in the results file for any face variable by using the `AS` specification. Suppose, for example, you wanted to output a face variable registered as `pressure_face` with the alias `pressuref`. You would then enter the command line:

```
FACE VARIABLES = pressure_face AS pressuref
```

The `FACE VARIABLES` command line can be used an arbitrary number of times within a `RESULTS OUTPUT` command block. It is also possible to specify more than one face variable for output on a command line, as indicated by the ellipsis in the command line format. In the following example, two face variables are specified for output. Here, the second face variable is registered as `scalar_face2`.

```
FACE VARIABLES = pressure_face scalar_face2
```

Aliases can be specified for each of the variables in a single command line. Thus, If you wanted to output the alias `pressuref` for face variable `pressure_face` and also wanted to output the alias `scalarf2` for face variable `scalar_face2`, you would enter the command line:

```
FACE VARIABLES = pressure_face AS pressuref
     scalar_face2 AS scalarf2
```

The specification of an alias is always optional.

The second form of the command line is as follows:

```
FACE VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name]
  INCLUDE|ON|EXCLUDE <string list>surface_names
  ...  <string>variable_name
  [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
  <string list>surface_names
```

This form of the `FACE VARIABLES` command line is similar to the first, except that the user can control which surfaces are used for output. The user can include a specific list of surfaces for output by using the `INCLUDE` option or the `ON` option. (The key word `INCLUDE` is synonymous with the key word `ON`.) Alternatively, the user can exclude a specific list of surfaces for output by using the `EXCLUDE` option.

Suppose that the face variable `pressure_face` from the above example has been registered for `surface_10`, `surface_11`, `surface_20`, and `surface_21`. If we only want to output the face variable for `surface_10`, `surface_11`, and `surface_21`, then we could specify the `FACE VARIABLES` command line as follows:

```
FACE VARIABLES = pressure_face AS pressuref
     INCLUDE surface_10, surface_11,
     surface_21
```

(In the above command line, the keyword `ON` could be substituted for `INCLUDE`.) Alternatively, we could use the command line:

```
FACE VARIABLES = pressure_face AS pressuref
     EXCLUDE surface_20
```

In the above command lines, an alias for a surface can be substituted for a surface identifier. For example, if `center_case` is an alias for `surface_10`, then the string `center_case` could be substituted for `surface_10` in the above command lines. Because a surface identifier is a mesh entity, the alias for the surface identifier would be defined via an `ALIAS` command line in a `FINITE ELEMENT MODEL` command block.

Note that the list of identifiers uses a comma to separate one surface identifier from the next surface identifier.

8.1.1.4 Output Element Variables

```
ELEMENT VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
  | ELEMENT VARIABLES = <string>variable_name
      [AS <string>dbase_variable_name]
      INCLUDE|ON|EXCLUDE <string list>block_names
      ... <string>variable_name
      [AS dbase_variable_name] INCLUDE|ON|EXCLUDE
      <string list>block_names
```

Any element variable in Adagio can be selected for output in the results file by using the `ELEMENT VARIABLES` command line.

There are two forms of the `ELEMENT VARIABLES` command line. Either form will let you output an element variable.

The first form of the command line is as follows:

```
ELEMENT VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name] ...
  <string>variable_name [AS
  <string>dbase_variable_name]
```

Here, the string `variable_name` is the name of the element variable to output. The string `variable_name` can be a registered variable listed in Section 8.6, a user-defined variable (see

Section 8.1.2 and Section 9.2.4), or a derived output quantity. The derived output option is discussed in detail in the latter portion of this discussion of the `ELEMENT VARIABLES` command line.

In the first form of the `ELEMENT VARIABLES` command line, the element variable is output for all element blocks that have the element variable as a registered variable. For example, all the solid elements have `rotated_stress` as a registered variable. If you had a mesh consisting of hexahedral and tetrahedral elements and requested output of the element variable `rotated_stress`, then `rotated_stress` would be output for all element blocks consisting of hexahedral and tetrahedral elements.

It is possible to specify an alias for any of the element variables by using the `AS` specification. Suppose, for example, you wanted to output the stress in Adagio, which is registered as `rotated_stress`, with the alias `stress`. You would then enter the command line:

```
ELEMENT VARIABLES = rotated_stress AS stress
```

In this example, stress is a symmetric tensor quantity. For a symmetric tensor quantity, suffixes are appended to the variable name (or alias name) to denote each symmetric tensor component. The results database would have six variable names associated with the stress: `stress_xx`, `stress_yy`, `stress_zz`, `stress_xy`, `stress_xz`, and `stress_yz`. Consult with Table 8.4 for a list of component identifiers for symmetric and full tensors. You can change the tensor component separator, an underscore in this example, by using the `COMPONENT SEPARATOR CHARACTER` command line (see Section 8.1.1.6).

The `ELEMENT VARIABLES` command line can be used an arbitrary number of times within a `RESULTS OUTPUT` command block. It is also possible to specify more than one element variable for output on a command line, as indicated by the ellipsis in the command line format. In the following example, two element variables are specified for output. Here, the second element variable is registered as `stretch`.

```
ELEMENT VARIABLES = rotated_stress stretch
```

Aliases can be specified for each of the variables in a single command line. Thus, If you wanted to output the alias `stress` for element variable `rotated_stress` and also wanted to output the alias `strch` for face variable `stretch`, you would enter the command line:

```
ELEMENT VARIABLES = rotated_stress AS stress
     stretch AS strch
```

The specification of an alias is always optional.

The second form of the command line is as follows:

```
ELEMENT VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name]
  INCLUDE|ON|EXCLUDE <string list>block_names
  ... <string>variable_name
  [AS dbase_variable_name] INCLUDE|ON|EXCLUDE
  <string list>block_names
```

This form of the ELEMENT VARIABLES command line is similar to the first, except that the user can control which element blocks are used for output. The user can include a specific list of element blocks for output by using the INCLUDE option or the ON option. (The key word INCLUDE is synonymous with the key word ON.) Alternatively, the user can exclude a specific list of element blocks for output by using the EXCLUDE option.

Suppose that the element variable rotated_stress from the above example exists for element blocks block_10, block_11, block_20, and block_21. If we only want to output the element variable for block_10, block_11, and block_21, then we could specify the ELEMENT VARIABLES command line as follows:

```
ELEMENT VARIABLES = rotated_stress AS stress
     INCLUDE block_10, block_11,
     block_21
```

(In the above command line, the keyword ON could be substituted for INCLUDE.) Alternatively, we could use the command line:

```
ELEMENT VARIABLES = rotated_stress AS stress
     EXCLUDE block_20
```

In the above command lines, an alias for an element block can be substituted for an element block identifier. For example, if center_case is an alias for block_10, then the string center_case could be substituted for block_10 in the above command lines. Because an element block identifier is a mesh entity, the alias for the element block identifier would be defined via an ALIAS command line in a FINITE ELEMENT MODEL command block.

Note that the list of identifiers uses a comma to separate one element block identifier from the next element block identifier.

As mentioned previously, you can use the ELEMENT VARIABLES command line for the output of a derived quantity. Derived quantities are calculated for solid elements and for shell elements. A derived quantity is identified by supplying one of the available options listed in Table 8.1, Table 8.2, or Table 8.3 for the string variable_name. For example, you would use the following command to compute and output von Mises stress on all solid elements:

```
ELEMENT VARIABLES = von_mises
```

Note that the AS specification can be included in the command line when you output derived quantities. The above command line could be written as:

```
ELEMENT VARIABLES = von_mises AS vm
```

Table 8.1 gives the complete set of derived stresses for solid elements and for shell elements. For the shell elements, the derived quantities from the stress tensor are given at each of the integration points. For the shell elements, the derived quantities from the stress are given at each of the integration points. A suffix ranging from 1 to the number of integration points is attached to the derived quantity to indicate the corresponding integration point. The suffix is padded with leading zeros. If the number of integration points is less than 10, the suffix has the form _*i*, where *i* ranges from 1 to the number of integration points. If the number of integration points is greater than or equal to 10 and less than 100, the sequence of suffixes takes the form _01, _02, _03,

and so forth. Finally, if the number of integration points is greater than or equal to 100, the sequence of suffixes takes the form `_001`, `_002`, `_003`, and so forth. As an example, if the von Mises stress is requested for a shell element with 15 integration points, then the derived quantities `von_mises_01`, `von_mises_02`, ..., `von_mises_15` are output for the shell element.

Table 8.1: Derived Stress Output for Elements

Option	**Option Description**
`von_mises`	Von Mises stress norm.
`hydrostatic_stress`	One-third the trace of the stress sensor.
`stress_invariant_1`	Trace of the stress tensor.
`stress_invariant_2`	Second invariant of the stress tensor.
`stress_invariant_3`	Third invariant of the stress tensor.
`max_principal_stress`	Largest eigenvalue of the stress tensor.
`intermediate_principal_stress`	Middle eigenvalue of the stress tensor.
`min_principal_stress`	Smallest eigenvalue of the stress tensor
`max_shear_stress`	Maximum shear stress from Mohr's circle.
`octahedral_shear_stress`	Octahedral shear norm of the stress tensor.

Most solid elements use only one integration point. For solid elements with multiple integration points, the conventions used for multiple integration points in shells are also used for multiple integration points in solids.

In the above discussion concerning the format for output at multiple integration points, the underscore character preceding the integration point number can be replaced by another delimiter or the underscore character can be eliminated by use of the `COMPONENT SEPARATOR CHARACTER` command line (see Section 8.1.1.6).

Table 8.2 gives the complete set of quantities derived from the log strain for solid elements. (Solid elements generate log strain information, while shell elements generate integrated strain information.)

Table 8.2: Derived Log Strain Output for Solid Elements

Option	**Option Description**
`effective_log_strain`	Effective log strain.
`log_strain_invariant_1`	Trace of the log strain tensor.
`log_strain_invariant_2`	Second invariant of the log strain tensor.
`log_strain_invariant_3`	Third invariant of the log strain tensor.
`max_principal_log_strain`	Largest eigenvalue of the log strain tensor.
`intermediate_principal_log_strain`	Middle eigenvalue of the log strain tensor.
`min_principal_log_strain`	Smallest eigenvalue of the log strain tensor.
`max_shear_log_strain`	Maximum shear log strain from Mohr's circle.
`octahedral_shear_log_strain`	Octahedral strain norm of the log strain tensor.

Most solid elements use only one integration point. For solid elements with multiple integration points, the conventions used for multiple integration points in shells are also used for multiple integration points in solids.

Table 8.3 gives the complete set of quantities derived from the integrated strain for shell elements. (Solid elements generate log strain information, while shell elements generate integrated strain information.) For the shell elements, the derived quantities from the integrated strain are given at each of the integration points. A suffix ranging from 1 to the number of integration points is attached to the derived quantity to indicate the corresponding integration point. The suffix is padded with leading zeros. If the number of integration points is less than 10, the suffix has the form *_i*, where *i* ranges from 1 to the number of integration points. If the number of integration points is greater than or equal to 10 and less than 100, the sequence of suffixes takes the form `_01`, `_02`, `_03`, and so forth. Finally, if the number of integration points is greater than or equal to 100, the sequence of suffixes takes the form `_001`, `_002`, `_003`, and so forth. As an example, if the effective strain is requested for a shell element with 15 integration points, then the derived quantities `effective_strain_01`, `effective_strain_02`, ..., `effective_strain_15` are output for the shell element.

In the above discussion concerning the output format for multiple integration points for shells, the underscore character preceding the integration point number can be replaced by another delimiter, or the underscore character can be eliminated by use of the `COMPONENT SEPARATOR CHARACTER` command line (see Section 8.1.1.6).

Table 8.3: Derived Strain Output for Shell Elements

Option	Option Description
effective_strain	Effective strain.
strain_invariant_1	Trace of the strain tensor.
strain_invariant_2	Second invariant of the strain tensor.
strain_invariant_3	Third invariant of the strain tensor.
max_principal_strain	Largest eigenvalue of the strain tensor.
intermediate_principal_strain	Middle eigenvalue of the strain tensor.
min_principal_strain	Smallest eigenvalue of the strain tensor.
max_shear_strain	Maximum shear strain from Mohr's circle.
octahedral_shear_strain	Octahedral strain norm of the strain tensor.

8.1.1.5 Output Mesh Selection

```
OUTPUT MESH = EXPOSED_SURFACE|BLOCK_SURFACE
```

The OUTPUT MESH command provides a way to reduce the amount of data that is written to the results database. There are two options that can be selected:

EXPOSED_SURFACE Only output the element faces that make up the "skin" of the finite element model; no internal nodes or elements will be written to the results database. The element results variables will be applied to the skin faces. If the mesh is visualized without any cutting planes, the display should look the same as if the original full mesh were visualized; however, the amount of data written to the output file can be much less than is needed if the full mesh were output.

BLOCK_SURFACE This option is similar to the EXPOSED_SURFACE option except that the skinning process is done an element block at a time instead of for the full model. In this option, faces shared between element blocks will appear in the output model.

8.1.1.6 Component Separator Character

```
COMPONENT SEPARATOR CHARACTER = <string>character|NONE
```

The component separator character is used to separate an output-variable base name from any suffixes. For example, the variable stress can have the suffixes xx, yy, etc. By default, the base name is separated from the suffixes with an underscore character so that we have stress_xx, stress_yy, etc. in the results output file.

You can replace the underscore as the default separator by using the above command line. If you wanted to use the period as the separator, then you would use the following command line:

```
COMPONENT SEPARATOR CHARACTER = .
```

For our example with stress, the stress components would then appear in the results output file as `stress.xx`, `stress.yy`, etc. If the stress is for a shell element, there is also an integration point suffix preceded, by default, with an underscore. The above command line also resets the underscore character that precedes the integration point suffix. For our example with the `stress` base name and the underscore replaced by the period, the results file would have `stress.xx.01`, `stress.xx.02`, etc., for the shell elements.

You can eliminate the separator with an empty string or `NONE`.

8.1.1.7 Output Global Variables

```
GLOBAL VARIABLES = <string>variable_name
  [AS <string>dbase_variable_name
  <string>variable_name AS <string>dbase_variable_name ...]
```

Any global variable in Adagio can be selected for output in the results file by using the `GLOBAL VARIABLES` command line. The string `variable_name` is the name of the global variable. The string `variable_name` can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4).

With the `AS` specification, you can specify the variable and select an alias for this variable in the results file. Suppose, for example, you wanted to output the time steps in Adagio, which are identified as `timestep`, with the alias `tstep`. You would then enter the command line:

```
GLOBAL VARIABLES = timestep AS tstep
```

The `GLOBAL VARIABLES` command line can be used an arbitrary number of times within a `RESULTS OUTPUT` command block. It is also possible to specify more than one global variable for output on a command line. If you also wanted to output the total number of iterations , which is registered as `total_iter`, with the alias `ti`, you would enter the command line:

```
GLOBAL VARIABLES = timestep as tstep
     total_iter as ti
```

The specification of an alias is always optional.

8.1.1.8 Set Begin Time for Results Output

```
START TIME = <real>output_start_time
```

Using the `START TIME` command line, you can write output to the results file beginning at time `output_start_time`. No results will be written before this time. If other commands set times for results (`AT TIME`, `ADDITIONAL TIMES`) that are less than `output_start_time`, those times will be ignored, and results will not be written at those times.

8.1.1.9 Adjust Interval for Time Steps

```
TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
```

This command line is used to specify that the output will be at exactly the times specified. To hit the output times exactly in an explicit, transient dynamics code, it is necessary to adjust the time step as the time approaches an output time. The integer value `steps` in the `TIMESTEP ADJUSTMENT INTERVAL` command line specifies the number of time steps to look ahead in order to adjust the time step.

If this command line does not appear, results are output at times closest to the specified output times.

8.1.1.10 Output Interval Specified by Time Increment

```
AT TIME <real>time_begin INCREMENT = <real>time_increment_dt
```

At the time specified by `time_begin`, results will be output every time increment given by the real value `time_increment_dt`.

8.1.1.11 Additional Times for Output

```
ADDITIONAL TIMES = <real>output_time1 <real>output_time2 ...
```

In addition to any times specified by the command line in Section 8.1.1.10, you can use the `ADDITIONAL TIMES` command line to specify an arbitrary number of additional output times.

8.1.1.12 Output Interval Specified by Step Increment

```
AT STEP <integer>step_begin INCREMENT =
  <integer>step_increment
```

At the step specified by `step_begin`, results will be output every step increment given by the integer value `step_increment`.

8.1.1.13 Additional Steps for Output

```
ADDITIONAL STEPS = <integer>output_step1
  <integer>output_step2 ...
```

In addition to any steps specified by the command line in Section 8.1.1.12, you can use the `ADDITIONAL STEPS` command line to specify an arbitrary number of additional output steps.

8.1.1.14 Set End Time for Results Output

```
TERMINATION TIME = <real>termination_time_value
```

Results will not be written to the results file after time `termination_time_value`. If other commands set times for results (`AT TIME`, `ADDITIONAL TIMES`) that are greater than `termination_time_value`, those times will be ignored, and results will not be written at those times.

8.1.1.15 Use Output Scheduler

```
USE OUTPUT SCHEDULER <string>scheduler_name
```

In an analysis with multiple regions, it can be difficult to synchronize output such as results files. To help synchronize output for analyses with multiple regions, you can define an `OUTPUT SCHEDULER` command block at the domain level. The scheduler can then be referenced in the `RESULTS OUTPUT` command block via the `USE OUTPUT SCHEDULER` command line. The string `scheduler_name` must match a name used in an `OUTPUT SCHEDULER` command block. See Section 8.5 for a description of using this command block and the `USE OUTPUT SCHEDULER` command line.

8.1.1.16 Write Results If System Error Encountered

```
OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
  SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
  SIGKILL|SIGILL|SIGSEGV
```

The `OUTPUT ON SIGNAL` command line is used to initiate the writing of a results file when the system encounters a type of system error. Only one error type in the list of error types should be entered for this command line. Generally, these system errors cause the code to terminate before the code can add any current results output (results output past the last results output time step) to the results output file. If the code encounters the specified type of error during execution, a results file will be written before execution is terminated.

This command line can also be used to force the writing of a results file at some point during execution of the code. Suppose the command line

```
OUTPUT ON SIGNAL = SIGUSR2
```

is included in the input file. While the code is running, a user can execute (from the keyboard) the system command line

`kill -s SIGUSR2` *pid*

to terminate execution and force the writing of a results file. In the above system command line, *pid* is the process identifier, which is an integer.

Note that the `OUTPUT ON SIGNAL` command line is primarily a debugging tool for code developers.

8.1.2 User-Defined Output

```
BEGIN USER OUTPUT
  # mesh-entity set commands
  NODE SET = <string_list>nodeset_names
  SURFACE = <string_list>surface_names
  BLOCK = <string_list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list> surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # compute global result command
  COMPUTE GLOBAL <string>results_var_name AS
    <string>SUM|AVERAGE|MAX|MIN OF <string>NODAL|ELEMENT
    <string>value_var_name [(<integer>component_num)]
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name |
    SURFACE SUBROUTINE = <string>subroutine_name |
    ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # copy command
  COPY ELEMENT VARIABLE <string>ev_name TO NODAL VARIABLE
    <string>nv_name

  #
  # additional command
  ACTIVE PERIODS = <string list>period_names
END [USER OUTPUT]
```

The `USER OUTPUT` command block lets the user generate specialized output information derived from analysis results such as element stresses, displacements, and velocities. For example, the `USER OUTPUT` command block could be used to sum the contact forces in a particular direction in the global axes and on a certain surface to give a net resultant contact force on that surface. In this example, we essentially postprocess contact information and reduce it to a single value for a surface (or set of surfaces). This, then, is one of the purposes of the `USER OUTPUT` command block—to postprocess analysis results as the code is running and produce a reduced set of specialized output information. The `USER OUTPUT` command block offers an alternative to writing out large quantities of data and then postprocessing them with some external code in order to produce

specialized output results.

There are three options for calculating user-defined quantities. In the first option, a single command line in the command block is used to compute reductions of registered variables on subsets of the mesh. This option makes use of the `COMPUTE GLOBAL` command line. The above example of the contact force represents an instance where we can accomplish the desired result simply by using the `COMPUTE GLOBAL` command line. In the second option, the command block specifies a user subroutine to run immediately preceding output to calculate any desired variable. This option makes use of a `NODE SET`, `SURFACE`, or `ELEMENT BLOCK SUBROUTINE` command line. Finally, there is an option to copy an element variable for an element to the nodes associated with the element, via the `COPY ELEMENT VARIABLE` command line. This copy option is a specialized option that has been made available primarily for creating results files for some of the postprocessing tools used with Adagio. You can use only one of the three options—compute global result, user subroutine, or copy—in a given command block.

For the compute global result option, a user-defined variable is automatically generated. This user-defined variable is given whatever name the user selects for `results_var_name` in the above specification for the `COMPUTE GLOBAL` command line. If the user subroutine or copy option is used, the user will need to define some type of user variable with the `USER VARIABLE` command block described in Section 9.2.4.

User-defined variables, whether they are generated via the compute global result option or the `USER VARIABLE` command block, are not automatically written to a results or history file. If the user wants to output any user-defined variables, these variables must be referenced in a results or history output specification (see Section 8.1.1 and Section 8.2, which describe the output of variables to results files and history files, respectively).

The `USER OUTPUT` command block contains four groups of commands—mesh-entity set, compute global result, user subroutine, and copy. Each of these command groups is basically independent of the others. In addition to the command lines in the four command groups, there is an additional command line: `ACTIVE PERIODS`. The following sections provide descriptions of the different command groups and the `ACTIVE PERIODS` command line.

8.1.2.1 Mesh-Entity Set Commands

The {`mesh-entity set commands`} portion of the `USER OUTPUT` command block specifies the nodes, element faces, or elements associated with the variable to be output. This portion of the command block can include some combination of the following command lines:

```
NODE SET = <string_list>nodeset_names
SURFACE = <string_list>surface_names
BLOCK = <string_list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list> surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes, element faces, or elements. See Section 6.1.1 for more information about the use of these command lines for mesh entities. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

8.1.2.2 Compute Global Result Command

If the compute global result option is selected, Adagio returns a single global value or a set of global values by examining the current values for a named registered nodal or element variable and then calculating the output according to a user-specified operation. A single global value, for example, might be the maximum value of one of the stress components of all the elements in our specified set; a set of global values would be the maximum value of each stress component of all elements in our specified set. Importantly, this option can only be used with a variable that is registered in Adagio, not a variable that is created by the user via the `USER VARIABLE` command block.

The following command line is related to the compute global result option.

```
COMPUTE GLOBAL <string>results_var_name AS
  <string>SUM|AVERAGE|MAX|MIN OF <string>NODAL|ELEMENT
  <string>value_var_name [(<integer>component_num)]
```

In the above command line, the following definitions apply:

- The string `results_var_name` is the name of a new global variable in which to store the reduced results. To output this variable in a results file, a heartbeat file, or a history file, you will simply use whatever you have selected for `results_var_name` as the variable name in a `GLOBAL VARIABLES` command line.
- Four different methods (or reduction types) are available for specifying the operation that will be performed on the values retrieved from the registered variable: `SUM`, `AVERAGE`, `MAX`, and `MIN`. Only one of these methods can be selected in a `GLOBAL COMPUTE` command line, however. `SUM` adds the variable value of all included mesh entities. `AVERAGE` takes the average value of the variable over all included mesh entities. `MAX` finds the maximum value over all included mesh entities. `MIN` finds the minimum value over all included mesh entities.
- The registered variable used to compute the global variable must be either a nodal quantity or an element quantity, as specified by the `NODAL` or `ELEMENT` option.
- The string `value_var_name` is the name of the registered variable (see Section 8.6 for a listing of the registered variables).
- There is an optional input, `component_num` (meaning component number), on the command line that allows the user to specify a particular (and single) value that will be returned for the new global variable. If `component_num` is not included in the command line, the global variable will have as many components as the registered variable. For example, if

component_num was not specified and the registered variable was a displacement (which has three components—x, y, and z), the global variable that is returned would have three values. Each component of the registered variable will be reduced independently and placed in the corresponding position of the returned global variable. In the output file, the returned values will begin with the name of the global variable and be appended with the identification of the kind of component. For example, if myresults was specified for results_var_name and the registered variable was a displacement, the output values would be displayed as myresults_x, myresults_y, and myresults_z.

Usage of component_num, which must be enclosed in parentheses, requires that you enter an integer number that corresponds to the position of the desired value in the set of possible values for the named registered variable. In other words, this number does not indicate how many components are stored for the variable. See the section below titled "Determining the Component Number" for further information on obtaining the required value for component_num.

The following is an example of using the GLOBAL COMPUTE command line to compute the net x-direction reaction force:

```
COMPUTE GLOBAL wall_x_reaction AS SUM OF NODAL reactions(1)
```

Determining the Component Number: If you want to specify that a specific value is returned for the global variable, the one named results_var_name, select an integer that corresponds to the position of that value in Table 8.4. Thus, for example, if you only wanted the ZZ component of a registered variable that was a symmetric tensor, the value for component_num would be specified as "(3)" in the command line.

8.1.2.3 User Subroutine Commands

If the user subroutine option is used, the user-defined output quantities will be calculated by a subroutine that is written by the user explicitly for this purpose. The subroutine will be called by Adagio at the appropriate time to perform the calculations. User subroutines allow for more generality in computing user-defined results than the COMPUTE GLOBAL command line. Suppose, for example, you had an analytic solution for a problem and wanted to compute the difference between some analytic value and a corresponding computed value throughout an analysis. The user subroutine option would allow you to make this comparison. The full details for user subroutines are given in Chapter 9.

The following command lines are related to the user subroutine option:

```
NODE SET SUBROUTINE = <string>subroutine_name |
  SURFACE SUBROUTINE = <string>subroutine_name |
  ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
```

Table 8.4: Selection of Component Number

Variable Type	**component_num and Description**	**Notes**
Vector	1 X component 2 Y component 3 Z component	A vector has three components. Displacements, for example, are handled as vectors.
Symmetric Tensor	1 XX component 2 YY component 3 ZZ component 4 XY component 5 YZ component 6 ZX component	Symmetric tensors have six components. Stresses for most solid elements are symmetric tensors.
Full Tensor	1 XX component 2 YY component 3 ZZ component 4 XY component 5 YZ component 6 ZX component 7 YX component 8 ZY component 9 XZ component	Full tensors are used occasionally by Adagio. Examples include velocity gradients and material rotations.

```
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

The user subroutine option is invoked by using the NODE SET SUBROUTINE command line, the SURFACE SUBROUTINE command line, or the ELEMENT BLOCK SUBROUTINE command line. The particular command line selected depends on the mesh-entity type of the variable for which the result quantities are being calculated. For example, variables associated with nodes would be calculated by using a NODE SET SUBROUTINE command line, variables associated with faces by using a SURFACE SUBROUTINE command line, and variables associated with elements by using the ELEMENT BLOCK SUBROUTINE command line. The string subroutine_name is the name of a FORTRAN subroutine that is written by the user. A user subroutine in the USER OUTPUT command block returns no values. Instead, it performs its operations directly with commands such as aupst_put_nodal_var, aupst_put_elem_var, and aupst_put_global_var. Consult with Chapter 9 for further discussion of these various put commands.

Following the selected command line (NODE SET SUBROUTINE, SURFACE SUBROUTINE, or ELEMENT BLOCK SUBROUTINE) are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of SUBROUTINE DEBUGGING OFF, SUBROUTINE DEBUGGING ON, SUBROUTINE REAL PARAMETER, SUBROUTINE INTEGER PARAMETER, and SUBROUTINE STRING PARAMETER. Examples of using these command lines are provided in Chapter 9.

Importantly, to implement the user subroutine option and output the calculated information, you would also need to do the following:

1. Create the user-defined variable with a USER VARIABLE command block.
2. Calculate the results for the user-defined variable in the user subroutine.
3. Write the results for the user-defined variable to an output file by referencing it in a RESULTS OUTPUT command block and/or a HISTORY OUTPUT command block and/or a HEARTBEAT OUTPUT command block. In the RESULTS OUTPUT command block, you would use a NODAL VARIABLES command line, an ELEMENT VARIABLES command line, or a GLOBAL VARIABLES command line, depending on how you defined the variable in the USER VARIABLE command block. Similarly, in the HISTORY OUTPUT or HEARTBEAT OUTPUT command block, you would use the applicable form of the VARIABLE command line, depending on how you defined the variable in the USER VARIABLE command block.

8.1.2.4 Copy Command

```
COPY ELEMENT VARIABLE <string>ev_name TO NODAL VARIABLE
  <string>nv_name
```

The COPY ELEMENT VARIABLE command line copies the value of an element variable to a node associated with the element. The element variable to be copied is specified by ev_name; the name

of the nodal variable to which the value is being transferred is `nv_name`. The nodal variable must be specified as a user-defined variable.

8.1.2.5 Compute at Every Step Command

```
COMPUTE AT EVERY TIME STEP
```

If this command line appears in the `USER OUTPUT` command block, a user-defined variable in the command block will be written at every time step. (Section 9.2.4 discusses user-defined variables.)

8.1.2.6 Additional Command

The `ACTIVE PERIODS` command line can appear as an option in the `USER OUTPUT` command block:

```
ACTIVE PERIODS = <string list>period_names
```

This command line determines when the boundary condition is active. See Section 2.4 for more information about this optional command line.

8.2 History Output

```
BEGIN HISTORY OUTPUT <string>history_name
  DATABASE NAME = <string>history_file_name
  DATABASE TYPE = <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
    (ON|TRUE|YES)
  TITLE <string>user_title
  #
  # for global variables
  VARIABLE = GLOBAL
    <string>variable_name
    [AS <string>history_variable_name]
  #
  # for mesh entity - node, edge, face,
  # element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
    [AS <string>history_variable_name]
  #
  # for nearest point output of mesh entity - node,
  # edge, face, element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    NEAREST LOCATION <real>global_x,
      <real>global_y>, <real>global_z
    [AS <string>history_variable_name]
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
    SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
END [HISTORY OUTPUT <string>history_name]
```

A history file gives nodal variable results (displacements, forces, etc.) for specific nodes, edge variable results for specific edges, face variable results for specific faces, element results (stress,

strain, etc.) for specific elements, and global results at specified times. You can specify a history file, the results to be included in this file, and the frequency at which results are written by using a HISTORY OUTPUT command block. The command block appears inside the region scope. For history output, you will typically work with node and element variables, and, on some occasions, face variables.

More than one history file can be specified for an analysis. For each history file, there will be one HISTORY OUTPUT command block. The command block for a history file description begins with:

```
BEGIN HISTORY OUTPUT <string>history_name
```

and is terminated with:

```
END [HISTORY OUTPUT <string>history_name]
```

where history_name is a user-selected name for the command block. Nested within the HISTORY OUTPUT command block are a set of command lines, as shown in the block summary given above. The first two command lines listed (DATABASE NAME and DATABASE TYPE) give pertinent information about the history file. The command line

```
DATABASE NAME = <string>history_file_name
```

gives the name of the history file with the string history_file_name. If the history file is to appear in the current directory and is named job.h, this command line would appear as:

```
DATABASE NAME = job.h
```

If the history file is to be created in some other directory, the command line would have to show the path to that directory.

If the history file does not use the Exodus II format [1], you must specify the format for the history file using the command line:

```
DATABASE TYPE = <string>database_type(exodusII)
```

Currently, both the Exodus II database and the XDMF database [2] are supported in Presto and Adagio. Exodus II is more commonly used than XDMF. Other options may be added in the future.

The OVERWRITE command line can be used to prevent the overwriting of existing history files.

```
OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
     (ON|TRUE|YES)
```

The OVERWRITE command line allows only a single value. If you set the value to FALSE, NO, or OFF, the code will terminate before existing history files can be overwritten. If you set the value to TRUE, YES, or ON, then existing history files can be overwritten (the default status). Suppose, for example, that we have an existing history file named job21.h. Suppose also that we have an input file with a HISTORY OUTPUT command block that contains the OVERWRITE command line set to ON and the DATABASE NAME command line set to:

```
DATABASE NAME = job21.h
```

If you run the code under these conditions, the existing history file job21.h will be overwritten.

Whether or not history files are overwritten is also impacted by the use of the automatic read and write option for restart files described in Section 8.4.1.1. If you use the automatic read and write option for restart files, the history files, like the restart files, are automatically managed. The automatic read and write option in restart adds extensions to file names and prevents the overwriting of any existing restart or history files. For the case of a user-controlled read and write of restart files (Section 8.4.1.2) or of no restart, however, the `OVERWRITE` command line is useful for preventing the overwriting of history files.

You may add a title to the history file by using the `TITLE` command line. Whatever you specify for the `user_title` will be written to the history file. Some of the programs that process the history file (such as various SEACAS programs [3]) can read and display this information.

The other command lines that appear in the `HISTORY OUTPUT` command block determine the type and frequency of information that is output. Descriptions of these command lines follow in Section 8.2.1 through Section 8.2.11. Note that the command lines for controlling the frequency of history output (in Section 8.2.1 through Section 8.2.11) are the same as those for controlling the frequency of results output. These frequency-related command lines are repeated here for convenience.

8.2.1 Output Variables

The `VARIABLE` command line is used to select variables for output in the history file. One of several types of variables—`GLOBAL`, `NODE` (or `NODAL`), `EDGE`, `FACE`, or `ELEMENT`—can be selected for output. The form of the command line varies depending on the type of variable that is selected for output.

8.2.1.1 Global Output Variables

```
VARIABLE = GLOBAL
  <string>variable_name
  [AS <string>history_variable_name]
```

This form of the `VARIABLE` command line lets you select any global variable for output in the history file. The variable is selected with the string `variable_name`. The string `variable_name` is the name of the global variable and can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4).

You can also specify an arbitrary name, `history_variable_name`, for the selected entity following the `AS` key word. For example, suppose you want to output the total number of iterations (total_iter) as ti. The command line to obtain the total number of iterationsin the history file would be

```
VARIABLE = GLOBAL total_iter AS ti
```

The specification of an alias is always optional.

8.2.1.2 Mesh Entity Output Variables

```
VARIABLE =
  NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
  AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
  [AS <string>history_variable_name]
```

This form of the VARIABLE command line lets you select any nodal, edge, face, or element variable for a specific mesh entity for output in the history file. For example, this form of the VARIABLE command line will let you pick the displacement at a specific node and output the displacement to the history file using an alias that you have chosen.

For this form of the VARIABLE command line, the mesh entity type following the delimiter (=) is set to NODE (or NODAL), EDGE, FACE, or ELEMENT depending on the variable (set by variable_name) to be output. If the mesh entity type is set to NODE (or NODAL), EDGE, or FACE, the string variable_name can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4). If the mesh entity type is set to ELEMENT, the string variable_name can be a registered variable listed in Section 8.6, a user-defined variable (see Section 8.1.2 and Section 9.2.4), or a derived output quantity. See the latter portion of Section 8.1.1.4 for a detailed discussion of derived output. A complete list of derived output quantities is given in Tables 8.1, 8.2, and 8.3 in Section 8.1.1.4.

Selection of a specific mesh entity follows the AT key word. You select a mesh entity type (NODE [or NODAL], EDGE, FACE, or ELEMENT) followed by the specific integer identifier, entity_id, for the mesh entity. You can specify an arbitrary name, history_variable_name, for the selected entity following the AS key word. For example, suppose you want to output the accelerations at node 88. The command line to obtain the accelerations at node 88 for the history file would be:

```
VARIABLE = NODE ACCELERATION AT NODE 88 AS accel_88
```

where accel_88 is the arbitrary name that will be used for this history variable in the history file.

Note that either the key word NODE or NODAL can be used for nodal quantities. The specification of an alias is always optional.

As an example of derived output, suppose you wanted to output the von Mises stress for solid element 1024. The command line to obtain the von Mises stress for element 1024 for the history file would be:

```
VARIABLE = ELEMENT VON_MISES AT ELEMENT 1024 AS vm_1024
```

where vm_1024 is the arbitrary name that will be used for this history variable in the history file.

8.2.1.3 Nearest Point Output Variables

```
VARIABLE =
   NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
   NEAREST LOCATION <real>global_x,
     real<global_y>, real<global_z>
   [AS <string>history_variable_name]
```

This form of the VARIABLE command line lets you select any nodal, edge, face, or element variable for output in the history file using a nearest point criterion. The command line described in this subsection is an alternative to the command line described in the preceding section, Section 8.2.1.2, for obtaining history output. The command line in this section or the command line in Section 8.2.1.2 produces history files with variable information. The difference in these two command lines (Section 8.2.1.3 and Section 8.2.1.2) is simply in how the variable information is selected.

For the above form of the VARIABLE command line, the mesh entity type following the delimiter (=) is set to NODE (or NODAL), EDGE, FACE, or ELEMENT depending on the variable (set by variable_name) to be output. If the mesh entity type is set to NODE (or NODAL), EDGE, or FACE, the string variable_name can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4). If the mesh entity type is set to ELEMENT, the string variable_name can be a registered variable listed in Section 8.6, a user-defined variable (see Section 8.1.2 and Section 9.2.4), or a derived output quantity. See the latter portion of Section 8.1.1.4 for a detailed discussion of derived output. A complete list of derived output quantities is given in Tables 8.1, 8.2, and 8.3 in Section 8.1.1.4.

The specific mesh entity used for output is determined by global coordinates specified by the NEAREST LOCATION key word and its associated input parameters—global_x, global_y, global_z. The specific mesh entity chosen for output is as follows:

- If the mesh entity has been set to NODE (or NODAL), the node in the mesh selected for output is the node whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to EDGE, the edge in the mesh selected for output is the edge with a center point (the average location of the two end points of the edge) whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to FACE, the face in the mesh selected for output is the face with a centroid whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to ELEMENT, the element in the mesh selected for output is the element with a centroid whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.

Note that, in all the above cases, the original model coordinates are used when selecting the nearest entity, not the current coordinates.

You can specify an arbitrary name, history_variable_name, for the selected entity following the AS key word. As an example, suppose you want to output the accelerations at a node closest to the point with global coordinates (1012.0, 54.86, 103.3141). The command line to obtain the accelerations at the node closest to this location for the history file would be:

```
VARIABLE = NODE ACCELERATION
     NEAREST LOCATION 1012.0, 54.86, 103.3141 AS accel_near
```

where accel_near is the arbitrary name that will be used for this history variable in the history file.

Note that either the key word NODE or NODAL can be used for nodal quantities. The specification of an alias is always optional.

8.2.2 Outputting History Data on a Node Set

It is commonly desired to output history data on a single-node node set. If a mesh file is slightly modified, the node and element numbers will completely change. The node associated with a node set, however, remains the same, i.e., the node in the node set retains the same initial geometric location with the same connectivity to other elements even when its node number changes. Therefore, we might want to specify the history output for a node set with a single node rather than with the global identifier for a node. This can easily be accomplished, as follows:

```
 begin user output
   node set = nodelist_1
   compute global disp_ns_1 as average of nodal displacement
 end

begin history output
  variable = global disp_ns_1
end
```

If nodelist_1 contains only a single node, the history output variable disp_ns_1 will contain the displacement for the single node in the node set. If nodelist_1 contains multiple nodes, the average displacement of the nodes will be output.

8.2.3 Set Begin Time for History Output

```
START TIME = <real>output_start_time
```

Using the START TIME command line, you can write history variables to the history file beginning at time output_start_time. No history variables will be written before this time. If other commands set times for history output (AT TIME, ADDITIONAL TIMES) that are less than output_start_time, those times will be ignored, and history output will not be written at those times.

8.2.4 Adjust Interval for Time Steps

```
TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
```

This command line is used to specify that the output will be at exactly the times specified. To hit the output times exactly in an explicit, transient dynamics code, it is necessary to adjust the time step as the time approaches an output time. The integer value `steps` in the `TIMESTEP ADJUSTMENT INTERVAL` command line specifies the number of time steps to look ahead in order to adjust the time step.

If this command line does not appear, history variables are output at times closest to the specified output times.

8.2.5 Output Interval Specified by Time Increment

```
AT TIME <real>time_begin INCREMENT = <real>time_increment_dt
```

At the time specified by `time_begin`, history variables will be output every time increment given by the real value `time_increment_dt`.

8.2.6 Additional Times for Output

```
ADDITIONAL TIMES = <real>output_time1 <real>output_time2 ...
```

In addition to any times specified by the command line in Section 8.2.5, you can use the `ADDITIONAL TIMES` command line to specify an arbitrary number of additional output times.

8.2.7 Output Interval Specified by Step Increment

```
AT STEP <integer>step_begin INCREMENT =
  <integer>step_increment
```

At the step specified by `step_begin`, history variables will be output every step increment given by the integer value `step_increment`.

8.2.8 Additional Steps for Output

```
ADDITIONAL STEPS = <integer>output_step1
  <integer>output_step2 ...
```

In addition to any steps specified by the command line in Section 8.2.7, you can use the `ADDITIONAL STEPS` command line to specify an arbitrary number of g

8.2.9 Set End Time for History Output

```
TERMINATION TIME = <real>termination_time_value
```

History output will not be written to the history file after time `termination_time_value`. If other commands set times for history output (`AT TIME`, `ADDITIONAL TIMES`) that are greater than `termination_time_value`, those times will be ignored, and history output will not be written at those times.

8.2.10 Use Output Scheduler

```
USE OUTPUT SCHEDULER <string>scheduler_name
```

In an analysis with multiple regions, it can be difficult to synchronize output such as history files. To help synchronize output for analyses with multiple regions, you can define an `OUTPUT SCHEDULER` command block at the domain level. The scheduler can then be referenced in the `HISTORY OUTPUT` command block via the `USE OUTPUT SCHEDULER` command line. The string `scheduler_name` must match a name used in an `OUTPUT SCHEDULER` command block. See Section 8.5 for a description of using this command block and the `USE OUTPUT SCHEDULER` command line.

8.2.11 Write History If System Error Encountered

```
OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
  SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
  SIGKILL|SIGILL|SIGSEGV
```

The `OUTPUT ON SIGNAL` command line is used to initiate the writing of a history file when the system encounters a type of system error. Only one error type in the list of error types should be entered for this command line. Generally, these system errors cause the code to terminate before the code can add any current history output (history output past the last history output time step) to the history file. If the code encounters the specified type of error during execution, a history file will be written before execution is terminated.

This command line can also be used to force the writing of a history file at some point during execution of the code. Suppose the command line

```
OUTPUT ON SIGNAL = SIGUSR2
```

is included in the input file. While the code is running, a user can execute (from the keyboard) the system command line

`kill -s SIGUSR2` *pid*

to terminate execution and force the writing of a results file. In the above system command line, *pid* is the process identifier, which is an integer.

Note that the `OUTPUT ON SIGNAL` command line is primarily a debugging tool for code developers.

8.3 Heartbeat Output

```
BEGIN HEARTBEAT OUTPUT <string>heartbeat_name
  # Can also use predefined streams "cout", "stdout",
  # "cerr", "clog", "log", "output", or "outputP0"
  STREAM NAME = <string>heartbeat_file_name
  #
  # for global variables
  VARIABLE = GLOBAL
    <string>variable_name
    [AS <string>heartbeat_variable_name]
  #
  # for mesh entity - node, edge, face,
  # element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
    [AS <string>heartbeat_variable_name]
  #
  # for nearest point output of mesh entity - node,
  # edge, face, element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    NEAREST LOCATION <real>global_x,
      <real>global_y>, <real>global_z
    [AS <string>heartbeat_variable_name]
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
    SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
  PRECISION = <integer>precision
  LABELS = <string>OFF|ON
  LEGEND = <string>OFF|ON
  TIMESTAMP FORMAT <string>timestamp_format
  MONITOR = <string>RESULTS|RESTART|HISTORY
END [HEARTBEAT OUTPUT <string>heartbeat_name]
```

The heartbeat output is text output file that gives:

- nodal variable results (displacements, forces, etc.) for specific nodes,
- edge variable results for specific edges,
- face variable results for specific faces,
- element results (stress, strain, etc.) for specific elements, and
- global results

at specified times.

Known Issue: User defined variables (see Section 9.2.4) are not currently supported with heartbeat output.

The output is written as text instead of the binary history output. You can specify a heartbeat file, the results to be included in this file, the formatting of the output, and the frequency at which results are written by using a `HEARTBEAT OUTPUT` command block. The command block appears inside the region scope. For heartbeat output, you will typically work with global, node, and element variables, and, on some occasions, face variables.

More than one heartbeat file can be specified for an analysis. For each heartbeat file, there will be one `HEARTBEAT OUTPUT` command block. The command block for a heartbeat file description begins with

```
BEGIN HEARTBEAT OUTPUT <string>heartbeat_name
```

and is terminated with

```
END [HEARTBEAT OUTPUT <string>heartbeat_name]
```

where `heartbeat_name` is a user-selected name for the command block. Nested within the `HEARTBEAT OUTPUT` command block are a set of command lines, as shown in the block summary given above. The first command line listed (`STREAM NAME`) gives pertinent information about the heartbeat file. The command line

```
STREAM NAME = <string>heartbeat_file_name
```

gives the name of the heartbeat file with the string `heartbeat_file_name`. If the file already exists, it is overwritten. If the heartbeat file is to appear in the current directory and is named `job.h`, this command line would appear as

```
STREAM NAME = job.h
```

If the heartbeat file is to be created in some other directory, the command line would have to show the absolute path to that directory.

In addition to specifying a specific filename, there are several predefined streams that can be specified. The predefined streams are:

- 'cout' or 'stdout' specifies standard output;
- 'cerr', 'stderr', 'clog', or 'log' specifies standard error;
- 'output' or 'outputP0' specifies Sierra's standard output which is redirected to the file specified by the '-o' option on the command line.

The other command lines that appear in the `HEARTBEAT OUTPUT` command block determine the type, frequency, and format of information that is output. Descriptions of these command lines follow in Section 8.3.1 through Section 8.3.13. Note that the command lines for controlling the frequency of heartbeat output (in Section 8.3.3 through Section 8.3.11) are the same as those for controlling the frequency of results and history output. These frequency-related command lines are repeated here for convenience.

8.3.1 Output Variables

The `VARIABLE` command line is used to select variables for output in the heartbeat file. One of several types of variables—`GLOBAL`, `NODE` (or `NODAL`), `EDGE`, `FACE`, or `ELEMENT`—can be selected for output. The form of the command line varies depending on the type of variable that is selected for output.

8.3.1.1 Global Output Variables

```
VARIABLE = GLOBAL
  <string>variable_name
  [AS <string>heartbeat_variable_name]
```

This form of the `VARIABLE` command line lets you select any global variable for output in the heartbeat file. The variable is selected with the string `variable_name`. The string `variable_name` is the name of the global variable and can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4). The `variable_name` can also specify `time`, `timestep`, or `step` to output the current simulation time, timestep, or execution step, respectively.

You can also specify an arbitrary name, `heartbeat_variable_name`, for the selected entity following the `AS` key word. For example, suppose you want to output the total number of iterations (total_iter) as ti. The command line to obtain the total number of iterationsin the heartbeat file would be:

```
VARIABLE = GLOBAL total_iter AS ti
```

The specification of an alias is always optional.

8.3.1.2 Mesh Entity Output Variables

```
VARIABLE =
```

```
NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
[AS <string>heartbeat_variable_name]
```

This form of the VARIABLE command line lets you select any nodal, edge, face, or element variable for a specific mesh entity for output in the heartbeat file. For example, this form of the VARIABLE command line will let you pick the displacement at a specific node and output the displacement to the heartbeat file using an alias that you have chosen.

For this form of the VARIABLE command line, the mesh entity type following the delimiter (=) is set to NODE (or NODAL), EDGE, FACE, or ELEMENT depending on the variable (set by variable_name) to be output. If the mesh entity type is set to NODE (or NODAL), EDGE, or FACE, the string variable_name can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4). If the mesh entity type is set to ELEMENT, the string variable_name can be a registered variable listed in Section 8.6, a user-defined variable (see Section 8.1.2 and Section 9.2.4), or a derived output quantity. See the latter portion of Section 8.1.1.4 for a detailed discussion of derived output. A complete list of derived output quantities is given in Tables 8.1, 8.2, and 8.3 in Section 8.1.1.4.

Selection of a specific mesh entity follows the AT key word. You select a mesh entity type (NODE [or NODAL], EDGE, FACE, or ELEMENT) followed by the specific integer identifier, entity_id, for the mesh entity. You can specify an arbitrary name, heartbeat_variable_name, for the selected entity following the AS key word. For example, suppose you want to output the accelerations at node 88. The command line to obtain the accelerations at node 88 for the heartbeat file would be:

```
VARIABLE = NODE ACCELERATION AT NODE 88 AS accel_88
```

where accel_88 is the arbitrary name that will be used for this heartbeat variable in the heartbeat file.

Note that either the key word NODE or NODAL can be used for nodal quantities. The specification of an alias is always optional.

As an example of derived output, suppose you wanted to output the von Mises stress for solid element 1024. The command line to obtain the von Mises stress for element 1024 for the heartbeat file would be:

```
VARIABLE = ELEMENT VON_MISES AT ELEMENT 1024 AS vm_1024
```

where vm_1024 is the arbitrary name that will be used for this heartbeat variable in the heartbeat file.

8.3.1.3 Nearest Point Output Variables

```
VARIABLE =
   NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
   NEAREST LOCATION <real>global_x,
     real<global_y>, real<global_z>
   [AS <string>heartbeat_variable_name]
```

This form of the VARIABLE command line lets you select any nodal, edge, face, or element variable for output in the heartbeat file using a nearest point criterion. The command line described in this subsection is an alternative to the command line described in the preceding section, Section 8.3.1.2, for obtaining heartbeat output. The command line in this section or the command line in Section 8.3.1.2 produces heartbeat files with variable information. The difference in these two command lines (Section 8.3.1.3 and Section 8.3.1.2) is simply in how the variable information is selected.

For the above form of the VARIABLE command line, the mesh entity type following the delimiter (=) is set to NODE (or NODAL), EDGE, FACE, or ELEMENT depending on the variable (set by variable_name) to be output. If the mesh entity type is set to NODE (or NODAL), EDGE, or FACE, the string variable_name can be either a registered variable listed in Section 8.6 or a user-defined variable (see Section 8.1.2 and Section 9.2.4). If the mesh entity type is set to ELEMENT, the string variable_name can be a registered variable listed in Section 8.6, a user-defined variable (see Section 8.1.2 and Section 9.2.4), or a derived output quantity. See the latter portion of Section 8.1.1.4 for a detailed discussion of derived output. A complete list of derived output quantities is given in Tables 8.1, 8.2, and 8.3 in Section 8.1.1.4.

The specific mesh entity used for output is determined by global coordinates specified by the NEAREST LOCATION key word and its associated input parameters—global_x, global_y, global_z. The specific mesh entity chosen for output is as follows:

- If the mesh entity has been set to NODE (or NODAL), the node in the mesh selected for output is the node whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to EDGE, the edge in the mesh selected for output is the edge with a center point (the average location of the two end points of the edge) whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to FACE, the face in the mesh selected for output is the face with a centroid whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.
- If the mesh entity has been set to ELEMENT, the element in the mesh selected for output is the element with a centroid whose initial position is nearest the input global X, Y, and Z coordinates specified with the parameters global_x, global_y, and global_z.

Note that, in all the above cases, the original model coordinates are used when selecting the nearest entity, not the current coordinates.

You can specify an arbitrary name, heartbeat_variable_name, for the selected entity following the AS key word. As an example, suppose you want to output the accelerations at a node closest to the point with global coordinates (1012.0, 54.86, 103.3141). The command line to obtain the accelerations at the node closest to this location for the heartbeat file would be:

```
VARIABLE = NODE ACCELERATION
     NEAREST LOCATION 1012.0, 54.86, 103.3141 AS accel_near
```

where accel_near is the arbitrary name that will be used for this heartbeat variable in the heartbeat file.

Note that either the key word NODE or NODAL can be used for nodal quantities. The specification of an alias is always optional.

8.3.2 Outputting Heartbeat Data on a Node Set

It is commonly desired to output heartbeat data on a single-node node set. If a mesh file is slightly modified, the node and element numbers will completely change. The node associated with a node set, however, remains the same, i.e., the node in the node set retains the same initial geometric location with the same connectivity to other elements even when its node number changes. Therefore, we might want to specify the heartbeat output for a node set with a single node rather than with the global identifier for a node. This can easily be accomplished, as follows:

```
 begin user output
   node set = nodelist_1
   compute global disp_ns_1 as average of nodal displacement
 end

begin heartbeat output
  variable = global disp_ns_1
end
```

If nodelist_1 contains only a single node, the heartbeat output variable disp_ns_1 will contain the displacement for the single node in the node set. If nodelist_1 contains multiple nodes, the average displacement of the nodes will be output.

8.3.3 Set Begin Time for Heartbeat Output

```
START TIME = <real>output_start_time
```

Using the START TIME command line, you can write heartbeat variables to the heartbeat file beginning at time output_start_time. No heartbeat variables will be written before this time. If other commands set times for heartbeat output (AT TIME, ADDITIONAL TIMES) that are less than output_start_time, those times will be ignored, and heartbeat output will not be written at those times.

8.3.4 Adjust Interval for Time Steps

```
TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
```

This command line is used to specify that the output will be at exactly the times specified. To hit the output times exactly in an explicit, transient dynamics code, it is necessary to adjust the time step as the time approaches an output time. The integer value `steps` in the `TIMESTEP ADJUSTMENT INTERVAL` command line specifies the number of time steps to look ahead in order to adjust the time step.

If this command line does not appear, heartbeat variables are output at times closest to the specified output times.

8.3.5 Output Interval Specified by Time Increment

```
AT TIME <real>time_begin INCREMENT = <real>time_increment_dt
```

At the time specified by `time_begin`, heartbeat variables will be output every time increment given by the real value `time_increment_dt`.

8.3.6 Additional Times for Output

```
ADDITIONAL TIMES = <real>output_time1 <real>output_time2 ...
```

In addition to any times specified by the command line in Section 8.3.5, you can use the `ADDITIONAL TIMES` command line to specify an arbitrary number of additional output times.

8.3.7 Output Interval Specified by Step Increment

```
AT STEP <integer>step_begin INCREMENT =
  <integer>step_increment
```

At the step specified by `step_begin`, heartbeat variables will be output every step increment given by the integer value `step_increment`.

8.3.8 Additional Steps for Output

```
ADDITIONAL STEPS = <integer>output_step1
  <integer>output_step2 ...
```

In addition to any steps specified by the command line in Section 8.2.7, you can use the `ADDITIONAL STEPS` command line to specify an arbitrary number of g

8.3.9 Set End Time for Heartbeat Output

```
TERMINATION TIME = <real>termination_time_value
```

Heartbeat output will not be written to the heartbeat file after time `termination_time_value`. If other commands set times for heartbeat output (`AT TIME`, `ADDITIONAL TIMES`) that are greater than `termination_time_value`, those times will be ignored, and heartbeat output will not be written at those times.

8.3.10 Use Output Scheduler

```
USE OUTPUT SCHEDULER <string>scheduler_name
```

In an analysis with multiple regions, it can be difficult to synchronize output such as heartbeat files. To help synchronize output for analyses with multiple regions, you can define an `OUTPUT SCHEDULER` command block at the domain level. The scheduler can then be referenced in the `HEARTBEAT OUTPUT` command block via the `USE OUTPUT SCHEDULER` command line. The string `scheduler_name` must match a name used in an `OUTPUT SCHEDULER` command block. See Section 8.5 for a description of using this command block and the `USE OUTPUT SCHEDULER` command line.

8.3.11 Write Heartbeat On Signal

```
OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
  SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
  SIGKILL|SIGILL|SIGSEGV
```

The `OUTPUT ON SIGNAL` command line is used to initiate the writing of a heartbeat file when the system encounters the specified signal. The signal can either occur as the result of a system error, or the user can explicitly send the specified signal to the application (See the system documentation man pages for "signal" or "kill" for more information). Only one signal type in the list of signal types should be entered for this command line. Generally, these signals cause the code to terminate before the code can add any current heartbeat output (heartbeat output past the last heartbeat output time step) to the heartbeat file. If the code encounters the specified type of error during execution, a heartbeat file will be written before execution is terminated.

This command line can also be used to force the writing of a heartbeat file at some point during execution of the code. Suppose the command line

```
OUTPUT ON SIGNAL = SIGUSR2
```

is included in the input file. While the code is running, a user can execute (from the keyboard) the system command line

`kill -s SIGUSR2` *pid*

to force the writing of a results file. In the above system command line, *pid* is the process identifier, which is an integer.

Note that the `OUTPUT ON SIGNAL` command line is primarily a debugging tool for code developers.

8.3.12 Heartbeat Output Formatting Commands

There are several command lines for the heartbeat section that modify the formatting of the heartbeat text output. The default output for the heartbeat data consists of a line beginning with a timestamp showing the current wall-clock time followed by multiple columns of data, for example:

```
Begin HeartBeat Region_1_Heartbeat
  Stream Name = output
  At Step 0, Increment = 10

  precision is 5

  Variable = global step
  Variable = global timestep as dt
  Variable = global time
  Variable = global total_energy as te
End
```

```
+[12:18:51] step=240, dt=3.13933e-04, time=7.56578e-02, te=4.02795e-06
+[12:18:51] step=250, dt=3.13933e-04, time=7.87971e-02, te=1.32125e-06
+[12:18:51] step=260, dt=3.13933e-04, time=8.19365e-02, te=6.88142e-07
+[12:18:51] step=270, dt=3.13933e-04, time=8.50758e-02, te=3.93574e-06
+[12:18:52] step=280, dt=3.13933e-04, time=8.82151e-02, te=7.46609e-06
+[12:18:52] step=290, dt=3.13933e-04, time=9.13545e-02, te=1.03856e-05
+[12:18:52] step=300, dt=3.13933e-04, time=9.44938e-02, te=1.36822e-05
+[12:18:52] step=310, dt=3.13933e-04, time=9.76331e-02, te=1.64630e-05
```

The above example begins each line with a timestamp followed by five labelled data columns. The precision of the real data is 5. There is no legend in the above example. This format can be modified with the following commands.

8.3.12.1 Specify floating point precision

```
PRECISION = <integer>precision
```

By default, the real data is written with a precision of 5 which gives 5 digits following the decimal point. This can be altered with the `PRECISION` command. If the command line `PRECISION = 2` is specified, then the above data would look like:

```
Begin HeartBeat Region_1_Heartbeat
```

```
...
        precision = 2
...
      End

+[12:18:51] step=240, dt=3.14e-04, time=7.57e-02, te=4.03e-06
+[12:18:51] step=250, dt=3.14e-04, time=7.88e-02, te=1.32e-06
+[12:18:51] step=260, dt=3.14e-04, time=8.19e-02, te=6.88e-07
```

Note that the precision applies to all real data; it is not possible to specify a different precision for each variable.

8.3.12.2 Specify Labelling of Heartbeat Data

```
  LABELS = <string>OFF|ON
```

The above example shows the default output which consists of a label and the data separated by "=". The existence of the labels is controlled with the `LABELS` command. If `LABELS = OFF` is specified, then the above data would look like:

```
      Begin HeartBeat Region_1_Heartbeat
...
        labels = off
        precision = 2
...
      End

+[12:17:37] 240, 3.14e-04, 7.57e-02, 4.03e-06
+[12:17:37] 250, 3.14e-04, 7.88e-02, 1.32e-06
+[12:17:38] 260, 3.14e-04, 8.19e-02, 6.88e-07
```

8.3.12.3 Specify Existance of Legend for Heartbeat Data

```
  LEGEND = <string>OFF|ON
```

Outputting the data without labels can make it easier to work with the data in a spreadsheet program or other data manipulation program, but with no labels, it is difficult to determine what the data really represents. The `LEGEND` output will print a line at the beginning of the heartbeat output identifying the data in each column. For example:

```
      Begin HeartBeat Region_1_Heartbeat
...
legend = on
labels = off
        precision = 2
...
      End
```

```
+[12:17:37] Legend: step, dt, time, te
+[12:17:37] 240, 3.14e-04, 7.57e-02, 4.03e-06
+[12:17:37] 250, 3.14e-04, 7.88e-02, 1.32e-06
+[12:17:38] 260, 3.14e-04, 8.19e-02, 6.88e-07
```

8.3.12.4 Specify format of timestamp

```
TIMESTAMP FORMAT <string>"timestamp_format"
```

Each line of the heartbeat output is preceded by a timestamp which shows the wall-clock time at the time that the line was output. This can be useful to verify that the code is still running and producing output and to determine how fast the code is running. The default timestamp is in the format "[12:34:56]" which is specified by the format [%H:%M:%S]. If a different format is desired, it can be specified with the `TIMESTAMP FORMAT` command line. The format must be surrounded by double or single quotes and the format is defined to be the string between the first single or double quote and the last matching quote type. If you want to modify the format, see the documentation for the UNIX `strftime` command for details on how to specify the format. The example below shows a timestamp format delimited by "`{`" and "`}`". The timestamp consists of a ISO-8601 date format followed by the current time.

```
...
timestamp format "{%F %H:%M:%S}"
...
+{2008-03-17 09:26:17} 2212, 1.34244e-06, 2.96948e-03, 2.96948e-03
+{2008-03-17 09:26:17} 2213, 1.34244e-06, 2.97082e-03, 2.97082e-03
+{2008-03-17 09:26:17} 2214, 1.34244e-06, 2.97216e-03, 2.97216e-03
+{2008-03-17 09:26:17} 2215, 1.34244e-06, 2.97350e-03, 2.97350e-03
+{2008-03-17 09:26:17} 2216, 1.34244e-06, 2.97485e-03, 2.97485e-03
```

8.3.13 Monitor Output Events

```
MONITOR = <string>RESULTS|RESTART|HISTORY
```

It is sometimes a benefit to know when the code has written a new set of data to one of the other output files (restart output, history output, or results output). The hearbeat output will report this data if the `MONITOR` command line is specified. Each time output is performed to any of the monitored output types, a line will be written to the heartbeat file specifying the timestamp, the simulation time and step, and the label name of the output type. For example:

```
      begin results output my_results
        at step 0, increment = 10
...
      end results output results
```

```
begin heartbeat data hb
  stream name = stdout
  monitor = results
  labels = off
  legend = on
  timestamp format "%F %H:%M:%S "
  at step 0, increment = 2
  variable = global step
  variable = global timestep as dt
  variable = global time
  variable = element spring_engineering_strain at \#
              element 1 as sp1
 end
```

Will give the following output:

```
....
+2008-03-17 10:03:22  718, 1.34244e-06, 9.63871e-04, 9.63871e-04
-2008-03-17 10:03:22  Results data written at time = 0.00096656,
step = 720. my_results
+2008-03-17 10:03:22  720, 1.34244e-06, 9.66556e-04, 9.66556e-04
+2008-03-17 10:03:22  722, 1.34244e-06, 9.69241e-04, 9.69241e-04
+2008-03-17 10:03:22  724, 1.34244e-06, 9.71926e-04, 9.71926e-04
+2008-03-17 10:03:22  726, 1.34244e-06, 9.74611e-04, 9.74611e-04
+2008-03-17 10:03:22  728, 1.34244e-06, 9.77296e-04, 9.77296e-04
-2008-03-17 10:03:22  Results data written at time = 0.00097998,
step = 730. my_results
+2008-03-17 10:03:22  730, 1.34244e-06, 9.79981e-04, 9.79981e-04
....
```

8.4 Restart Data

```
BEGIN RESTART DATA <string>restart_name
  DATABASE NAME = <string>restart_file
  INPUT DATABASE NAME = <string>restart_input_file
  OUTPUT DATABASE NAME = <string>restart_output_file
  DATABASE TYPE = <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
    (ON|TRUE|YES)
  START TIME = <real>restart_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  OVERLAY COUNT = <integer>overlay_count
  CYCLE COUNT = <integer>cycle_count
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
    SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
END [RESTART DATA <string>restart_name]
```

You can specify restart files, either to be written to or read from, and the frequency at which restarts are written by using a `RESTART DATA` command block. The command block appears inside the region scope. To initiate a restart, the `RESTART TIME` command line (see Section 2.1.3.1) or the `RESTART` command line (see Section 2.1.3.2) must also be used. These command lines appear in the domain scope.

NOTE: In addition to the times at which you request restart information to be written, restart information is automatically written when an element inverts.

The `RESTART DATA` command block begins with the input line:

```
BEGIN RESTART DATA <string>restart_name
```

and is terminated with:

```
END [RESTART DATA <string>restart_name]
```

where `restart_name` is a user-selected name for the `RESTART DATA` command block.

Nested within the `RESTART DATA` command block are a set of command lines, as shown in the block summary given above.

We begin the discussion of the `RESTART DATA` command block with various options regarding the

use of restart in general. In Section 8.4.1, you will learn how to use the DATABASE NAME, INPUT DATABASE NAME, OUTPUT DATABASE NAME, and DATABASE TYPE command lines. Usage of the first three of these command lines is tied to the two restart-related command lines RESTART and RESTART TIME, which are found in the domain scope.

Section 8.4.2 discusses use of the OVERWRITE command line, which will prevent or allow the overwriting of existing restart files. (Note that this command line also appears in the command blocks for results output and history output.)

The other command lines that appear in the RESTART DATA command block determine the frequency at which restarts are written. Descriptions of these command lines follow in Section 8.4.3 through Section 8.4.13. Note that the command lines for controlling the frequency of restart output are the same as those for controlling the frequency of results output and history output. These frequency-related command lines are repeated here for convenience.

8.4.1 Restart Options

```
DATABASE NAME = <string>restart_file
INPUT DATABASE NAME = <string>restart_input_file
OUTPUT DATABASE NAME = <string>restart_output_file
DATABASE TYPE = <string>database_type(exodusII)
```

You can read from and create restart files in an automated fashion, the preferred method, or you can carefully control how you read from and create restart files. In our discussion of the overall options for the use of restart, we begin with the first three command lines listed above (DATABASE NAME, INPUT DATABASE NAME, and OUTPUT DATABASE NAME). All three of these command lines specify a parameter that is a file name or a directory path and file name. If the parameter begins with the "/" character, it is an absolute path; otherwise, the path to the current directory will be prepended to the parameter on the command line. Suppose, for example, that we want to work with a restart file named component.rst in the current directory. If we are using the DATABASE NAME command line, then this command line would appear as:

```
DATABASE NAME = component.rst
```

If we wanted to read or create files in some other directory, the command line would have to show the path to that directory in addition to our file name.

The DATABASE NAME command line will let you read restart information and write restart information to the same file. Section 8.4.1.1 through Section 8.4.1.4 show how this command line is used in particular instances.

You can specify a restart file to read from by using the command line:

```
INPUT DATABASE NAME = <string>restart_input_file
```

You can specify a restart file to write to by using the command line:

```
OUTPUT DATABASE NAME = <string>restart_output_file
```

Note that you must use either a DATABASE NAME command line or the INPUT DATABASE NAME

command line/`OUTPUT DATABASE NAME` command line pair, but not both, in a `RESTART DATA` command block.

If the restart file does not use the Exodus II format [1], you must specify the format for the results file using the `DATABASE TYPE` command line:

```
DATABASE TYPE = <string>database_type(exodusII)
```

Currently, the Exodus II database and the XDMF database [2] are supported in Presto and Adagio. Exodus II is more commonly used than XDMF. Other options may be added in the future.

8.4.1.1 Automatic Read and Write of Restart Files

You can use the restart option in an automated fashion by using a combination of the `RESTART` command line in the domain scope and the `DATABASE NAME` command line in the `RESTART DATA` command block. This automated use of restart can best be explained by an example. We will use a two-processor example and assume all files will be in our current directory.

The option of automated restart will not only manage the restart files to prevent overwriting, it will also manage the results files and history files to prevent overwriting. In the example we give, we will assume our run includes a `RESULTS OUTPUT` command block with the command line

```
DATABASE NAME = rslt.e
```

to generate results files with the root file name `rslt.e`. We will also assume a run includes a `HISTORY OUTPUT` command block with the command line

```
DATABASE NAME = hist.h
```

to generate history files with the root file name `hist.h`.

For the first run in our restart sequence, we will have the command line

```
RESTART = AUTOMATIC
```

in the domain scope of our input file. In a `TIME STEPPING` command block, which is embedded in a `TIME CONTROL` command block (Section 3.10.1) in the procedure scope of our input file, we will have the command line:

```
START TIME = 0.0
```

In the `TIME CONTROL` command block we will have the command line

```
TERMINATION TIME = 2.5E-3
```

to set the limits for the begin and end times of the first restart run. These time-related command lines should not be confused with the `START TIME` and `TERMINATION TIME` command lines that appear in the `RESTART DATA` command block.

Finally, for the first run in our restart sequence, the `RESTART DATA` command block in our input file will be as follows:

```
BEGIN RESTART DATA ADAGIO_RESTART
  DATABASE NAME = g.rsout
```

```
  AT TIME 0.0 INCREMENT = 0.25E-3
END RESTART DATA ADAGIO_RESTART
```

In this block, the `DATABASE NAME` command line specifies a root file name for the restart file. The `AT TIME` command line gives the time when we will start to write the restart information and the interval at which the restart information will be written (see Section 8.4.5).

For our first run, the automatic restart option will generate the following restart files:

```
# restart files
g.rsout.2.0
g.rsout.2.1
# results files
rslt.e.2.0
rslt.e.2.1
# history files
hist.h.2.0
hist.h.2.1
```

For the above files, there are extensions on the file names that indicate we have a two-processor run. The 2.0 and 2.1 extensions associate the restart files with the corresponding individual mesh files on each processor. (If our mesh file is `mesh.g`, then our mesh files on the individual processors will be `mesh.g.2.0` and `mesh.g.2.1`.) All restart information in the above files appears at time intervals of 0.25×10^{-3}, and the last restart information is written at time 2.5×10^{-3}. We have also listed the results and history files that will be generated for this run due to the file definitions in the command blocks for the results and history files.

For the second run in our sequence of restart runs, we want to start at the previous termination time, 2.5×10^{-3}, and terminate at time 5.0×10^{-3}. We leave everything in our input file (including the `START TIME = 0.0` command line in the `TIME STEPPING` command block, the `RESTART` command line, and the `RESTART DATA` command block) the same except for the `TERMINATION TIME` command line (in the `TIME CONTROL` command block). The `TERMINATION TIME` command line will now become:

```
TERMINATION TIME = 5.0E-3
```

It is important to note here that the actual start time for the second run in our analysis is now set by the last time (2.5×10^{-3}) that restart information was written. The command line `START TIME = 0.0` in the `TIME STEPPING` command block is now superseded as the actual starting time for the second run by the restart commands. Any `START TIME` command line in a `TIME STEPPING` command block is still valid in terms of defining time stepping blocks (these blocks being used to set activation periods), but the restart process sets the actual start time for our analysis. This pattern of control for setting the actual start time holds for any run in our sequence of restart runs.

For the second run in our sequence of restart runs, the restart files will be from time 2.5×10^{-3} to time 5.0×10^{-3}. The restart files in our current directory after the second run will be as follows:

```
# restart files
```

```
g.rsout.2.0
g.rsout.2.1
g.rsout-s0002.2.0
g.rsout-s0002.2.1
# results files
rslt.e.2.0
rslt.e.2.1
rslt.e-s0002.2.0
rslt.e-s0002.2.1
# history files
hist.h.2.0
hist.h.2.1
hist.h-s0002.2.0
hist.h-s0002.2.1
```

Notice that we have generated new restart files with a `-s0002` extension in addition to the extension associated with the individual processors. All restart information in the above files with the `-s0002` extension appears at time intervals of 0.25×10^{-3}, the restart information is written between time 2.5×10^{-3} and time 5.0×10^{-3}, and the final restart information is written at time 5.0×10^{-3}. The restart files for the first run in our sequence of restart runs, `g.rsout.2.0` and `g.rsout.2.1`, have been preserved. New results and history files have been created using the same extension, `-s0002`, as that used for the restart files. The original results and history files have been preserved.

Now, we want to do a third run in our sequence of restart runs. For the third run in our sequence of restart runs, we want to start at the previous termination time, 5.0×10^{-3}, and terminate at time 8.5×10^{-3}. We leave everything in our input file (including the `START TIME` command line, the `RESTART` command line, and the `RESTART DATA` command block) the same except for the `TERMINATION TIME` command line. The `TERMINATION TIME` command line (within the `TIME CONTROL` command block) will now become:

```
TERMINATION TIME = 8.5E-3
```

For the third run in our sequence of restart runs, the restart files will be from time 5.0×10^{-3} to time 8.5×10^{-3}. The restart files in our current directory after the third run will be as follows:

```
# restart files
g.rsout.2.0
g.rsout.2.1
g.rsout-s0002.2.0
g.rsout-s0002.2.1
g.rsout-s0003.2.0
g.rsout-s0003.2.1
# results files
rslt.e.2.0
rslt.e.2.1
rslt.e-s0002.2.0
rslt.e-s0002.2.1
```

```
rslt.e-s0003.2.0
rslt.e-s0003.2.1
# history files
hist.h.2.0
hist.h.2.1
hist.h-s0002.2.0
hist.h-s0002.2.1
hist.h-s0003.2.0
hist.h-s0003.2.1
```

Notice that we have generated new restart files with a `-s0003` extension in addition to the extension associated with the individual processors. All restart information in the above files with the `-s0003` extension appears at time intervals of 0.25×10^{-3}, the restart information is written between time 5.0×10^{-3} and time 8.5×10^{-3}, and the final restart information is written at time 8.5×10^{-3}. The restart files for the first and second runs in our sequence of restart runs have been preserved. New results and history files have been created using the same extension, `-s0003`, as that used for the restart files. The original results and history files have been preserved.

The process just described can be continued as long as necessary. We will continue the process of generating new restart files with extensions that indicate their place in the sequence of runs.

8.4.1.2 User-Controlled Read and Write of Restart Files

You can use the restart option and select specific restart times and specific restart files to read from and write to by using a combination of the `RESTART TIME` command line in the domain scope and the `INPUT DATABASE NAME` and `OUTPUT DATABASE NAME` command line in the `RESTART DATA` command block. This "controlled" use of restart can best be explained by an example. We will use a two-processor example and assume all files will be in our current directory. In this example, we will manage the creation of new restart files so as not to overwrite existing restart files. Unlike the automated option for restart, this controlled use of restart requires that the user manage restart file names so as to prevent overwriting previously generated restart files. The same is true for the results and history files. The user will have to manage the creation of new results and history files so as not to overwrite existing results and history files. Creating new results and history files for each run in the sequence of restart runs requires changing the `DATABASE NAME` command line in the `RESULTS OUTPUT` and `HISTORY OUTPUT` command blocks. We will not show examples for use of the `DATABASE NAME` command line in the `RESULTS OUTPUT` and `HISTORY OUTPUT` command blocks here, as the actual use of the `DATABASE NAME` command line in the results and history command blocks would closely parallel the pattern we see for management of the restart file names.

For the first run in our restart sequence, we will have only a `RESTART DATA` command block in the region; there will be no restart-related command line in the domain scope of our input file. We will, however, have a

```
START TIME = 0.0
```

command line in a `TIME STEPPING` command block (within the `TIME CONTROL` command block)

and a

```
TERMINATION TIME = 2.5E-3
```

command line within the `TIME CONTROL` command block to set the limits for the begin and end times. The `RESTART DATA` command block in our input file will be as follows:

```
BEGIN RESTART DATA ADAGIO_RESTART
  OUTPUT DATABASE NAME = RS1.rsout
  AT TIME 0.0 INCREMENT = 0.5E-3
END RESTART DATA ADAGIO_RESTART
```

For our first run, the restart option will generate the following restart files:

```
RS1.rsout.2.0
RS1.rsout.2.1
```

For the above files, the extensions on the file names indicate that we have a two-processor run. The 2.0 and 2.1 extensions associate the restart files with the corresponding individual mesh files on each processor. If our mesh file is `mesh.g`, then our mesh files on the individual processors will be `mesh.g.2.0` and `mesh.g.2.1`. All restart information in the above files appears at time intervals of 0.5×10^{-3}, and the last restart information is written at time 2.5×10^{-3}.

For the second run in our sequence of restart runs, we want to start at the previous termination time, 2.5×10^{-3}, and terminate at time 5.0×10^{-3}. To do this, we must add a

```
RESTART TIME = 2.5E-3
```

command line to the domain scope and set the termination time to 5.0×10^{-3} by using the command line

```
TERMINATION TIME = 5.0E-3 \rm
```

within the `TIME CONTROL` command block.

It is important to note here that the actual start time for the second run in our analysis is now set by the restart time set on the `RESTART TIME` command line, 2.5×10^{-3}. The command line `START TIME = 0.0` in the `TIME STEPPING` command block is now superseded as the actual starting time for the second run by the restart commands. Any `START TIME` command line in a `TIME STEPPING` command block is still valid in terms of defining time stepping blocks (these blocks being used to set activation periods), but the restart process sets the actual start time for our analysis. This pattern of control for setting the actual start time holds for any run in our sequence of restart runs.

We also must change the `RESTART DATA` command block to the following:

```
BEGIN RESTART DATA ADAGIO_RESTART
  INPUT DATABASE NAME = RS1.rsout
  OUTPUT DATABASE NAME = RS2.rsout
  AT TIME 0.0 INCREMENT = 0.5E-3
END RESTART DATA ADAGIO_RESTART
```

For this second run, we will read from the following files:

```
RS1.rsout.2.0
RS1.rsout.2.1
```

And we will write to the following files:

```
RS2.rsout.2.0
RS2.rsout.2.1
```

All restart information in the above output files, `RS2.rsout.2.0` and `RS2.rsout.2.1`, appears at time intervals of 0.5×10^{-3}, restart information is written from time 2.5×10^{-3} to time 5.0×10^{-3}, and the last restart information is written at time 5.0×10^{-3}. Notice that we have preserved the restart files from the first run from our restart sequence of runs because we have specifically given the input and output databases distinct names—`RS2.rsout` for the input file name and `RS1.rsout` for the output file name.

Now, we want to do a third run in our sequence of restart runs. For this third run, we want to start at time 4.5×10^{-3} and terminate at time 8.5×10^{-3}. We do not want to start at the termination time for the previous restart, which is 5.0×10^{-3}; rather, we want to start at time 4.5×10^{-3}. We change the `RESTART TIME` command line to

```
RESTART TIME = 4.5E-3
```

and the `TERMINATION TIME` command line within the `TIME CONTROL` command block to:

```
TERMINATION TIME = 8.5E-3
```

And we change the `RESTART DATA` command block to the following:

```
BEGIN RESTART DATA ADAGIO_RESTART
  INPUT DATABASE NAME = RS2.rsout
  OUTPUT DATABASE NAME = RS3.rsout
  AT TIME 0.0, INCREMENT = 0.5E-3
END RESTART DATA ADAGIO_RESTART
```

For this third run, we will read from the following files:

```
RS2.rsout.2.0
RS2.rsout.2.1
```

And we will write to the following files:

```
RS3.rsout.2.0
RS3.rsout.2.1
```

All restart information in the above output files, `RS3.rsout.2.0` and `RS3.rsout.2.1`, appears at time intervals of 0.5×10^{-3}, restart information is written from time 4.5×10^{-3} to time 8.5×10^{-3}, and the last restart information is written at time 8.5×10^{-3}. Notice that we have preserved all restart files from previous runs in our restart sequence of runs because we have specifically given the input and output databases distinct names for this third run.

8.4.1.3 Overwriting Restart Files

If you use the `RESTART TIME` command line in conjunction with the `DATABASE NAME` command line, you will overwrite restart information (unless you have included an `OVERWRITE` command line set to `ON`). As indicated previously, you will probably want to have a restart file (or files in the case of parallel runs) associated with each run in a sequence of restart runs. The example in this section shows how to overwrite restart files if that is an acceptable approach for a particular analysis.

For our first run, we will set a termination time of 1.0×10^{-3} with the command line

```
TERMINATION TIME = 1.0E-3
```

and set the `RESTART DATA` command block as follows:

```
BEGIN RESTART DATA
  DATABASE NAME = RS.out
  AT TIME 0.0 INTERVAL = 0.25E-3
END RESTART DATA
```

Our first run will generate the following restart files:

```
RS.out.2.0
RS.out.2.1
```

All restart information in the above output files, `RS.out.2.0` and `RS.out.2.1`, appears at time intervals of 0.25×10^{-3}, restart information is written from time 0.0 to time 1.0×10^{-3}, and the last restart information is written at time 1.0×10^{-3}.

Suppose for our second run we set the termination time to 2.0×10^{-3} with the command line

```
TERMINATION TIME = 2.0E-3
```

and add the command line

```
RESTART TIME = 1.0E-3
```

to the domain scope. We leave the `RESTART DATA` command block unchanged.

For our second run, restart information is read from the files `RS.out.2.0` and `RS.out.2.1`. These files are then overwritten with new restart information beginning at time 1.0×10^{-3}. The files `RS.out.2.0` and `RS.out.2.1` will have restart information beginning at time 1.0×10^{-3} in intervals of 0.25×10^{-3}. The restart information will terminate at time 2.0×10^{-3}.

Now we want to do a third run with a termination time of 3.0×10^{-3}. We change the termination time by using the command line:

```
TERMINATION TIME = 3.0E-3
```

And we change the `RESTART TIME` command line so that it is now:

```
RESTART TIME = 3.0E-3
```

For our third run, restart information is read from the files `RS.out.2.0` and `RS.out.2.1`. These files are then overwritten with new restart information beginning at time 2.0×10^{-3}. The files `RS.out.2.0` and `RS.out.2.1` will have restart information beginning at time 2.0×10^{-3} in intervals of 0.25×10^{-3}. The restart information will terminate at time 3.0×10^{-3}.

8.4.1.4 Recovering from a Corrupted Restart

Suppose you are using the automated option for restart and a system crash occurs when the restart file is being written. The restart file contains a corrupted entry for one of the restart times. In this case, you can continue using the automated option for restart. Restart will detect the corrupted entry and then find an entry previous to the corrupted entry that can be used for restart. This previous entry should be the entry prior to the corrupted entry unless something unusual has occurred. If the first intact restart entry is not the previous entry, restart continues to back up until an intact restart entry is found.

You could do a manual recovery. The manual recovery requires the use of a `RESTART TIME` command line to select some intact restart entry. You will have to use the `INPUT DATABASE NAME` and `OUTPUT DATABASE NAME` command lines to avoid overwriting previous restart files (see Section 8.4.1.2). You will also have to change file names in the results and history command blocks to avoid overwriting previous results and history files. Once you have done the manual recovery, you could then revert to the automatic restart option.

8.4.2 Overwrite Command in Restart

```
OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
  (ON|TRUE|YES)
```

The `OVERWRITE` command line can be used to prevent the overwriting of existing restart files. The use of the automatic read and write option for restart files as described in Section 8.4.1.1 does not require the `OVERWRITE` command line. The automatic read and write option adds extensions to file names and prevents the overwriting of any existing restart files. For the case of a user-controlled read and write of restart files (Section 8.4.1.2), however, the `OVERWRITE` command line is useful for preventing the overwriting of restart files. If the `OVERWRITE` command line is set to `OFF`, `FALSE`, or `NO`, then existing restart files will not be overwritten. Execution of the code will terminate before existing restart files are overwritten. The default option is to overwrite existing restart files. If the `OVERWRITE` command line is not included, or the command line is set to `ON`, `TRUE`, or `YES`, then existing files can be overwritten.

8.4.3 Set Begin Time for Restart Writes

```
START TIME = <real>restart_start_time
```

Using the `START TIME` command line, you can write restarts to the restart file beginning at time `restart_start_time`. No restarts will be written before this time. If other commands set times

for restarts (`AT TIME`, `ADDITIONAL TIMES`) that are less than `restart_start_time`, those times will be ignored, and restarts will not be written at those times.

8.4.4 Adjust Interval for Time Steps

```
TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
```

This command line is used to specify that the restarts will be written at exactly the times specified. To hit the restart times exactly in an explicit transient dynamics code, it is necessary to adjust the time step as the time approaches a restart time. The integer value `steps` in the `TIMESTEP ADJUSTMENT INTERVAL` command line specifies the number of time steps to look ahead in order to adjust the time step.

If this command line does not appear, then restarts are written at times closest to the specified restart times.

8.4.5 Restart Interval Specified by Time Increment

```
AT TIME <real>time_begin INCREMENT = <real>time_increment_dt
```

At the time specified by `time_begin`, restarts will be written every time increment given by the real value `time_increment_dt`.

8.4.6 Additional Times for Restart

```
ADDITIONAL TIMES = <real>output_time1 <real>output_time2 ...
```

In addition to any restart times specified by the command line in Section 8.4.5, you can use the `ADDITIONAL TIMES` command line to specify an arbitrary number of additional restart times.

8.4.7 Restart Interval Specified by Step Increment

```
AT STEP <integer>step_begin INCREMENT =
  <integer>step_increment
```

At the step specified by `step_begin`, restarts will be written every step increment given by the integer value `step_increment`.

8.4.8 Additional Steps for Restart

```
ADDITIONAL STEPS = <integer>output_step1
  <integer>output_step2 ...
```

In addition to any steps specified by the command line in Section 8.4.7, you can use the `ADDITIONAL STEPS` command line to specify an arbitrary number of additional restart steps.

8.4.9 Set End Time for Restart Writes

```
TERMINATION TIME = <real>termination_time_value
```

Restarts will not be written to the restart file after time `termination_time_value`. If other commands set times for restarts (`AT TIME`, `ADDITIONAL TIMES`) that are greater than `termination_time_value`, those times will be ignored, and restarts will not be written at those times.

8.4.10 Overlay Count

```
OVERLAY COUNT = <integer>overlay_count
```

The `OVERLAY COUNT` command line specifies the number of restart output times that will be overlaid on top of the current step before advancing to the next step. For example, suppose that we set the `overlay_count` parameter to 2, and we request that restart information be written every 0.1 second. At time 0.1 second, restart step 1 will be written to the output restart database. At time 0.2 second, restart information will be written over the step 1 information, which originally contained restart information at 0.1 second. At time 0.3 second, restart information will be written over the step 1 information, which last contained information at 0.2 second. At time 0.4 second, we will now write step 2 to the output restart database (step 1 has already been written over twice). At time 0.5 second, restart information will be written over the step 2 information, which originally contained information at 0.4 second. At time 0.6 second, restart information will be written over the step 2 information, which last contained information at 0.5 second. At time 0.7 second, restart step 3 will be written to the output restart database (step 2 has already been written over twice). This pattern continues so that we would build up a sequence of restart information at times 0.3, 0.6, 0.9, . . . second until we reach the termination time for the problem. If there was a problem during the analysis, the last step on the output restart database would be whatever had last been written to the database. If, for example, we had set our termination time to 1.0 second and a problem occurred after restart information had been written at 0.7 second but before we completed the time step at 0.8 second, then the last information on the output restart database would be at 0.7 second.

You can use the `OVERLAY COUNT` command line in conjunction with a `CYCLE COUNT` command line. For a description of the `CYCLE COUNT` command line and its use with the `OVERLAY COUNT` command line, see Section 8.4.11.

8.4.11 Cycle Count

```
CYCLE COUNT = <integer>cycle_count
```

The `CYCLE COUNT` command line specifies the number of restart steps that will be written to the output restart database before previously written steps are overwritten. For example, suppose we set the `cycle_count` parameter to 5, and we request that restart information be written every 0.1 second. The restart system will write information to the output restart database at times 0.1, 0.2, 0.3, 0.4, and 0.5 second. At time 0.6 second, the information at step 1, originally written at time 0.1 second, will be overwritten with information at time 0.6 second. At time 0.7 second, the information at step 2, originally written at time 0.2 second, will be overwritten with information at time 0.7 second. At time 0.8 second, the output restart database will contain restart information at times 0.6, 0.7, 0.8, 0.4, and 0.5 second. Time will not necessarily be monotonically increasing on a database that uses a `CYCLE COUNT` command line.

If you only want the last step available on the output restart database, set `cycle_count` equal to 1.

The `CYCLE COUNT` and `OVERLAY COUNT` command lines can be used at the same time. For this example, we will combine our example with an overlay count of 2 as given in Section 8.4.10 with our example of a cycle count of 5 as given in this section (Section 8.4.11). Information is written to the output restart database time step every 0.1 second. The output times at which information is written to the output restart database are 0.1, 0.2, 0.3, . . . second. Each of these times corresponds to an output step. Time 0.1 second corresponds to output step 1, time 0.2 second corresponds to output step 2, time 0.3 corresponds to output step 3, and so forth. An output time of $n \times 0.1$ corresponds to output step n. The overlay command will result in information at time 0.3, 0.6, 0.9, 1.2, and 1.5 seconds written as steps 1, 2, 3, 4, and 5 on the output restart database. For times greater than 1.6 seconds, the cycle command will now take effect because we have five steps written on the output restart database. Information at times 1.6, 1.7, and 1.8 seconds will now overwrite the information at step 1, which had information at time 0.3 second. Information at times 1.9, 2.0, and 2.1 seconds will now overwrite the information at step 2, which had information at time 0.6 second. For any output step n, its position, step number n_s, in the restart output database is as follows:

$$
\begin{aligned}
&if\, n_s \neq 0 \\
&\qquad n_s = int(n/(n_o+1))\%n_c \\
&else \\
&\qquad n_s = n_c \\
&end
\end{aligned}
$$

In the above equations, n_c is the cycle count, and n_o is the overlay count. The expression $int(n/(n_o+1))$ produces an integer arithmetic result. For example, if n is 4 and n_o is 2, then we have 4 divided by 3, and the integer arithmetic result is 1 (any fractional remainder is discarded). The operator % is the modulus operator; the modulus operator gives the modulus of its first operand with respect

to its second operand, i.e., it produces the remainder of dividing the first operand by the second operand. The result of 1 % 5 is 1, for example.

8.4.12 Use Output Scheduler

```
USE OUTPUT SCHEDULER <string>scheduler_name
```

In an analysis with multiple regions, it can be difficult to synchronize output such as restart files. To help synchronize output for analyses with multiple regions, you can define an `OUTPUT SCHEDULER` command block at the domain level. The scheduler can then be referenced in the `RESTART DATA` command block via the `USE OUTPUT SCHEDULER` command line. The string `scheduler_name` must match a name used in an `RESTART DATA` command block. See Section 8.5 for a description of using this command block and the `USE OUTPUT SCHEDULER` command line.

8.4.13 Write Restart If System Error Encountered

```
OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
  SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
  SIGKILL|SIGILL|SIGSEGV
```

The `OUTPUT ON SIGNAL` command line is used to initiate the writing of a restart file when the system encounters a type of system error. Only one error type in the list of error types should be entered for this command line. Generally, these system errors cause the code to terminate before the code can add any current restart output (restart output past the last restart output time step) to the restart file. If the code encounters the specified type of error during execution, a restart file will be written before execution is terminated.

This command line can also be used to force the writing of a restart file at some point during execution of the code. Suppose the command line

```
OUTPUT ON SIGNAL = SIGUSR2
```

is included in the input file. While the code is running, a user can execute (from the keyboard) the system command line

`kill -s SIGUSR2` *pid*

to terminate execution and force the writing of a results file. In the above system command line, *pid* is the process identifier, which is an integer.

The most useful application of the command line is to send a signal via a system command line to write a restart file. Note that the `OUTPUT ON SIGNAL` command line is primarily a debugging tool for code developers.

8.5 Output Scheduler

In an analysis with multiple regions, it can be difficult to synchronize output such as results files, history files, and restart files. To help synchronize output for analyses with multiple regions, you can define an `OUTPUT SCHEDULER` command block at the domain level. This scheduler can then be referenced in several places:

- The scheduler can be referenced in the `RESULTS OUTPUT` command block to control the output of results information.
- The scheduler can be referenced in the `HISTORY OUTPUT` command block to control the output of history information.
- The scheduler can be referenced in the `RESTART DATA` command block to control the writing of restart files.

In summary, the `OUTPUT SCHEDULER` command block is defined in the domain scope. The scheduler is referenced by a `USE OUTPUT SCHEDULER` command line that can appear in a `RESULTS OUTPUT`, `HISTORY OUTPUT`, and `RESTART DATA` command block. Section 8.5.1 describes the `OUTPUT SCHEDULER` command block, and Section 8.5.2 illustrates how this block is referenced with the `USE OUTPUT SCHEDULER` command line.

8.5.1 Output Scheduler Command Block

```
BEGIN OUTPUT SCHEDULER <string>scheduler_name
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
END [OUTPUT SCHEDULER <string>scheduler_name]
```

An output scheduler is defined with a command block in the domain scope. The `OUTPUT SCHEDULER` command block begins with the input line:

```
BEGIN OUTPUT SCHEDULER <string>scheduler_name
```

and is terminated with the line:

```
END OUTPUT SCHEDULER <string>scheduler_name
```

where scheduler_name is a user-defined name for the command block. All the normal scheduling command lines are valid in an OUTPUT SCHEDULER command block.

8.5.1.1 Set Begin Time for Output Scheduler

```
START TIME = <real>output_start_time
```

Using the START TIME command line, you can set the start time for a scheduler beginning at time output_start_time. The scheduler will not take effect before this time. If other commands set times for scheduling (AT TIME, ADDITIONAL TIMES) that are less than output_start_time, those times will be ignored.

8.5.1.2 Adjust Interval for Time Steps

```
TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
```

This command line is used to specify that, when the scheduler is in effect, output will be at exactly the times specified. To hit the output times exactly in an explicit, transient dynamics code, it is necessary to adjust the time step as the time approaches an output time. The integer value steps in the TIMESTEP ADJUSTMENT INTERVAL command line specifies the number of time steps to look ahead in order to adjust the time step.

If this command line does not appear, output occurs at times closest to the specified output times.

8.5.1.3 Output Interval Specified by Time Increment

```
AT TIME <real>time_begin INCREMENT = <real>time_increment_dt
```

At the time specified by time_begin, output will be scheduled at every time increment given by the real value time_increment_dt.

8.5.1.4 Additional Times for Output

```
 ADDITIONAL TIMES = <real>output_time1 <real>output_time2 ...
```

In addition to any times specified by the command line in Section 8.5.1.3, you can use the ADDITIONAL TIMES command line to specify an arbitrary number of additional output times.

8.5.1.5 Output Interval Specified by Step Increment

```
AT STEP <integer>step_begin INCREMENT =
  <integer>step_increment
```

At the step specified by `step_begin`, output will be scheduled at every step increment given by the integer value `step_increment`.

8.5.1.6 Additional Steps for Output

```
ADDITIONAL STEPS = <integer>output_step1
  <integer>output_step2 ...
```

In addition to any steps specified by the command line in Section 8.5.1.5, you can use the `ADDITIONAL STEPS` command line to specify an arbitrary number of additional output steps.

8.5.1.7 Set End Time for Output Scheduler

```
TERMINATION TIME = <real>termination_time_value
```

Using the `TERMINATION TIME` command line, you can set the termination time for a scheduler beginning at time `termination_time_value`. The scheduler will not be in effect after this time. If other commands set times for scheduling (`AT TIME`, `ADDITIONAL TIMES`) that are greater than `termination_time_value`, those times will be ignored by the scheduler.

8.5.2 Example of Using the Output Scheduler

Once an output scheduler has been defined via the `OUTPUT SCHEDULER` command block, it can be used by inserting a `USE OUTPUT SCHEDULER` command line in any of the following command blocks: `RESULTS OUTPUT`, `HISTORY OUTPUT`, and `RESTART DATA`. The following paragraph provides an example of using output schedulers.

In the domain scope, we define two output schedulers, `Timer` and `Every_Step`:

```
BEGIN OUTPUT SCHEDULER Timer
  AT TIME 0.0 INCREMENT = 10.0e-6
  TIME STEP ADJUSTMENT INTERVAL = 4
END OUTPUT SCHEDULER Timer
#
BEGIN OUTPUT SCHEDULER Every_Step
  AT STEP 0 INCREMENT = 1
END OUTPUT SCHEDULER Every_Step
```

With the `USE OUTPUT SCHEDULER` command, we reference the scheduler named `Timer` for results output:

```
BEGIN RESULTS OUTPUT Out_Region_1
  .
```

```
  USE OUTPUT SCHEDULER Timer
  .
END RESULTS OUTPUT Out_Region_1
```

With the `USE OUTPUT SCHEDULER` command, we reference the scheduler named `Every_STEP` for history output:

```
BEGIN HISTORY OUTPUT Out_Region_2
  .
  USE OUTPUT SCHEDULER Every_Step
  .
END HISTORY OUTPUT Out_Region_2
```

8.6 Registered Variables

This section lists commonly used registered variables that the user can select as output to the results file and the history file. The first part of this section lists global, nodal, and element registered variables. The second part of this section lists registered variables associated with material models.

8.6.1 Global, Nodal, and Element Registered Variables

This section lists commonly used global, nodal, and element registered variables. The registered variables are presented in tables based on use, as follows:

- Table 8.5 Variables Registered on Nodes (Variable and Type)
- Table 8.6 Element Variables Registered for All Elements
- Table 8.7 Element Variables Registered for Solid Elements
- Table 8.8 Element Variables Registered for Membranes
- Table 8.9 Nodal Variables Registered for Shells
- Table 8.10 Element Variables Registered for Shells
- Table 8.11 Element Variables Registered for Truss
- Table 8.12 Global Registered Variables

The tables provide the following information about each registered variable:

Variable Name. This is the string that will appear on the `GLOBAL VARIABLES`, `NODE VARIABLES`, or `ELEMENT VARIABLES` command line.

Type. This is the variable's type. The various types are denoted with the labels `Integer`, `Real`, `Vector_2D`, `Vector_3D`, `SymTen33`, and `FullTen36`. The type `Integer` indicates the registered variable is an integer; the type `Real` indicates the registered variable is a real. The type `Vector_2D` indicates the registered variable type is a two-dimensional vector. The type `Vector_3D` indicates the registered variable is a three-dimensional vector. For a three-dimensional vector, the variable quantities will be output with suffixes of `_x`, `_y`, and `_z`. For example, if the registered variable displacement is requested to be output as `displ`, the components of the displacement vector on the results file will be `displ_x`, `displ_y`, and `displ_z`. The type `SymTen33` indicates the registered variable is a symmetric 3×3 tensor. For a 3×3 symmetric tensor, the variable quantities will be output with suffixes of `_xx`, `_yy`, `_zz`, `_xy`, `_yz`, and `_zx`. For example, if the registered variable `rotated_stress` is requested for output as `stress`, the components of the stress tensor on the results file will be `stress_xx`, `stress_yy`, `stress_zz`, `stress_xy`, `stress_yz`, and `stress_zx`. The type `FullTen36` is a full 3×3 tensor with three diagonal terms and six off-diagonal terms.

The tables of registered variables follow.

Table 8.5: Variables Registered on Nodes (Variable and Type)

Variable Name	Type	Comments
model_coordinates	Vector_3D	Original coordinates of nodes.
coordinates	Vector_3D	Current coordinates of nodes.
displacement	Vector_3D	Total displacement.
displacement_increment	Vector_3D	Displacement increment at current time step.
velocity	Vector_3D	
acceleration	Vector_3D	
force_internal	Vector_3D	
force_external	Vector_3D	
force_hourglass	Vector_3D	
force_contact	Vector_3D	
reactions	Vector_3D	
moment_reactions	Vector_3D	
mass	Real	

Table 8.6: Element Variables Registered for All Elements

Variable Name	Type	Comments
elem_time_step	Real	Critical time step for the element. The element in the model with the smallest time step controls the analysis time step.
element_mass	Real	

Table 8.7: Element Variables Registered for Solid Elements

Variable Name	Type	Comments
stress	SymTen33	
rotated_stress	SymTen33	
stretch	SymTen33	
rotation	FullTen36	
log_strain	SymTen33	
volume	Real	
shrmod	Real	
dilmod	Real	

Table 8.8: Element Variables Registered for Membranes

Variable Name	Type	Comments
memb_stress	SymTen33	
element_area	Real	
element_thickness	Real	

Table 8.9: Nodal Variables Registered for Shells

Variable Name	Type	Comments
rotational_displacement	Vector_3D	
rotational_velocity	Vector_3D	
rotational_acceleration	Vector_3D	
moment_internal	Vector_3D	
moment_external	Vector_3D	
rotational_mass	Real	

Table 8.10: Element Variables Registered for Shells

Variable Name	Type	Comments
memb_stress	SymTen33	Stress at midplane in global X, Y, and Z coordinates.
bottom_stress	SymTen33	Stress at bottom integration point in global X, Y, and Z coordinates.
top_stress	SymTen33	Stress at top integration point in global X, Y, and Z coordinates.
strain	SymTen33	Integrated strain at midplane in local shell coordinate system.
element_area	Real	
element_thickness	Real	

Table 8.11: Element Variables Registered for Truss

Variable Name	Type	Comments
truss_init_length	Real	
truss_stretch	Real	
truss_stress	Real	
truss_strain_incr	Real	
truss_force	Real	

Table 8.12: Global Registered Variables

Variable Name	**Type**	**Comments**
`timestep`	`Real`	
`KineticEnergy`	`Real`	
`MomentumX`	`Real`	Momentum in global X-direction.
`MomentumY`	`Real`	Momentum in global Y-direction.
`MomentumZ`	`Real`	Momentum in global Z-direction.

8.6.2 Registered Variables for Material Models

It is possible to output the state variables from the material models. Most of the materials, with the exception of simple models such as the elastic model, have state variables that can be output. The method used to output state variables depends on how the model is implemented. There are currently three cases:

- The native version of most of the solid models for which state variables are accessed by index
- The native version of a few solid models for which state variables are accessed by name
- The versions of the solid models implemented in the LAME library for which state variables are accessed by name

In the future, the implementation of the solid material models in LAME will be used by default, and all state variables will be accessed by name. The following sections describe the different methods required to output material model variables.

8.6.2.1 State Variable Output by Index for Native Solid Material Models

There are two ways to output the state variables for the native material models. The simplest way outputs all of the state variables for a given material model. Use the `ELEMENT VARIABLES` command line in the `RESULTS OUTPUT` command block of the form:

```
ELEMENT VARIABLES = state_material_name
```

where `material_name` is the name of the material model, e.g. `elastic_plastic`, `power_law_hardening`, `foam_plasticity`, or `orthotropic_rate`. All of the state variables for the material will be output.

If it is desired to output a subset of the state variables for a material model, one must use a different syntax in which the variable name starts with `MAT%`. This `MAT%` syntax allows for all or part of the state variables for a material to be output. In this case, the `ELEMENT VARIABLES` command line in the `RESULTS OUTPUT` command block has the following form:

```
ELEMENT VARIABLES = MAT%material_name
```

where `material_name` is the name of the material model, e.g. `elastic_plastic`, `power_law_hardening`, `foam_plasticity`, or `orthotropic_rate`.

For example, if you wanted to get all the state variables for the elastic-plastic material model, you would use:

```
ELEMENT VARIABLES = MAT%elastic_plastic
```

or

```
ELEMENT VARIABLES = MAT%elastic_plastic(:)
```

In the preceding command line, the parentheses indicate a subset of the state variables, and the colon should be read as “through.” The notation (:) implies all the state variables; the notion (`3:7`) would imply state variables 3 through 7.

Depending on the material type, there may be several hundred material state variables. A subset of state variables may be output using a FORTRAN-like array syntax. For example, to output the equivalent plastic strain for the elastic-plastic material and rename it to something meaningful, use:

```
ELEMENT VARIABLES = MAT%elastic_plastic(1) as eqps
```

To output a six-entry symmetric tensor subset of the orthotropic rate material, use:

```
ELEMENT VARIABLES = MAT%orthotropic_rate(2:7)
```

Finally, if a scattered set of material variables is desired, the variables may be selected by using the `|` array operator, as in the command:

```
ELEMENT VARIABLES = MAT%foam_plasticity(1|4:6|9)
```

This command would output state variables 1, 4, 5, 6, and 9 of the foam plasticity model.

Section 8.6.2.4 provides tables listing the state variables for all solid material models. Models for which state variable output is requested using the method described here have indices entered in a column entitled "Index (Native Model)".

8.6.2.2 State Variable Output by Name for Native Solid Material Models

Some of the native material models are implemented in a way such that state variables are accessed directly by name rather than by index. For example, to access the `C10` variable in the Mooney-Rivlin material model, one would simply list the name `C10` to obtain that output. The state variables for the Mooney-Rivlin, Swanson, and Orthotropic Crush material models are accessed in this way. In addition, the state variables for all of the energy-dependent models (Mie-Gruneisen, Mie-Gruneisen Power-Series, JWL, and ideal gas) are accessed this way.

Section 8.6.2.4 provides tables listing the state variables for all solid material models. Models for which state variable output is requested by name have names entered in a column entitled "Name (Native Model)".

8.6.2.3 State Variable Output for LAME Solid Material Models

The state variables for material models in LAME are accessible directly by name. For instance, the equivalent plastic strain variable is accessible by the name `EQPS` for all elastic-plastic material models.

Section 8.6.2.4 provides tables listing the state variables for all solid material models. Models that are implemented in LAME have state variable names listed in the column entitled "Name (LAME Model)". If there are no entries in that column for a given material, then that material is not implemented in LAME.

8.6.2.4 State Variable Tables for Solid Material Models

As explained in the preceding sections, there are three cases to be considered for state variable output from solid material models: native models for which state output is obtained using an index with the `MAT%` syntax, native models for which state output is obtained using the variable name, and LAME models, for which state output is also obtained by variable name. Tables of state variables for commonly used material models are provided in Tables 8.13 through 8.38. These tables contain the indices or names used to access the state variables in the native version of the models, as well as the names used to access the LAME versions of the models. If there are no entries in the "Native Model" column for a model, that model is only implemented in LAME. Likewise, if there are no entries in the "LAME Model" column, there is no version of that model in LAME.

Table 8.13: State Variables for DUCTILE FRACTURE Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	`EQPS`	equivalent plastic strain
2	`TEAR`	tearing parameter
3	`CRIT_COS`	crack opening strain
4	`CD_X`	crack opening direction - x component
5	`CD_Y`	crack opening direction - y component
6	`CD_Z`	crack opening direction - z component
7	`FLAG_DEATH`	flag for element death
8	`RADIUS`	radius of yield surface

Table 8.14: State Variables for ELASTIC Model

This model has no state variables.

Table 8.15: State Variables for ELASTIC FRACTURE Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	`FLAG_DEATH`	flag for element death
2	`CRIT_COS`	critical value of opening strain
3	`CD_X`	crack opening direction - x component
4	`CD_Y`	crack opening direction - y component
5	`CD_Z`	crack opening direction - z component
6	`MAXSTRESS`	value of maximum principal stress

Table 8.16: State Variables for ELASTIC PLASTIC Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	EQPS	equivalent plastic strain
2	ALPHA_XX	back stress - xx component
3	ALPHA_YY	back stress - yy component
4	ALPHA_ZZ	back stress - zz component
5	ALPHA_XY	back stress - xy component
6	ALPHA_YZ	back stress - yz component
7	ALPHA_ZX	back stress - zx component
	RADIUS	

Table 8.17: State Variables for EP POWER HARD Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	EQPS	equivalent plastic strain
2	RADIUS	radius of yield surface

Table 8.18: State Variables for FOAM PLASTICITY Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	ITER	iterations
2	VOL_STRAIN	volumetric strain
3	PHI	phi
4	EQPS	equivalent plastic strain
5	PA	A
6	PB	B

Table 8.19: State Variables for HONEYCOMB Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	CRUSH	minimum volume ratio
2	EQDOT	effective strain rate
3	RMULT	rate multiplier
5	ITER	iterations
6	EVOL	volumetric strain

Table 8.20: State Variables for HYPERFOAM Model

This model has no state variables.

Table 8.21: State Variables for JOHNSON COOK Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	`RADIUS`	radius of yield surface
2	`EQPS`	equivalent plastic strain
3		temperature
4	`EQDOT`	equivalent strain rate
5		iterations

Table 8.22: State Variables for LOW DENSITY FOAM Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	`PAIR`	

Table 8.23: State Variables for MOONEY RIVLIN Model

Name (Native Model)	**Name (LAME Model)**	**Variable Description**
C01	C01	
C10	C10	
RK	K	
SFJth	SFJTH	
RJTH	JTH	
V_MECH	VMECH_XX	
	VMECH_YY	
	VMECH_ZZ	
	VMECH_XY	
	VMECH_YZ	
	VMECH_ZX	
	SFJTH_FLAG	

Table 8.24: State Variables for MULTILINEAR EP Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	EQPS	equivalent plastic strain
2	RADIUS	radius of yield surface
3	ALPHA_XX	back stress - xx component
4	ALPHA_YY	back stress - yy component
5	ALPHA_ZZ	back stress - zz component
6	ALPHA_XY	back stress - xy component
7	ALPHA_YZ	back stress - yz component
8	ALPHA_ZX	back stress - zx component

Table 8.25: State Variables for ML EP FAIL Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	EQPS	equivalent plastic strain
2	RADIUS	radius of yield surface
3	ALPHA_XX	back stress - xx component
4	ALPHA_YY	back stress - yy component
5	ALPHA_ZZ	back stress - zz component
6	ALPHA_XY	back stress - xy component
7	ALPHA_YZ	back stress - yz component
8	ALPHA_ZX	back stress - zx component
9		tearing parameter
10		crack opening strain
11		crack opening direction - x component
12		crack opening direction - y component
13		crack opening direction - z component
14		flag for element death

Table 8.26: State Variables for NEO HOOKEAN Model

This model has no state variables.

Table 8.27: State Variables for ORTHOTROPIC CRUSH Model

Name (Native Model)	**Name (LAME Model)**	**Variable Description**
CRUSH	CRUSH	

Table 8.28: State Variables for ORTHOTROPIC RATE Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	CRUSH	

Table 8.29: State Variables for PIEZO Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	STATE	

Table 8.30: State Variables for POWER LAW CREEP Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	ECREEP	equivalent creep strain
2	SEQDOT	equivalent stress rate

Table 8.31: State Variables for SHAPE MEMORY Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	STATE	

Table 8.32: State Variables for SOIL FOAM Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	EVOL	

Table 8.33: State Variables for SWANSON Model

Name (Native Model)	**Name (LAME Model)**	**Variable Description**
SFJTH	SFJTH	
RJTH	RJTH	
V_MECH	VMECHXX	
	VMECHYY	
	VMECHZZ	
	VMECHXY	
	VMECHYZ	
	VMECHZX	
	SFJTH_FLAG	

Table 8.34: State Variables for THERMO EP POWER Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
1	EQPS	equivalent plastic strain
2	RADIUS	radius of yield surface
3	ALPHA_XX	back stress - xx component
4	ALPHA_YY	back stress - yy component
5	ALPHA_ZZ	back stress - zz component
6	ALPHA_XY	back stress - xy component
7	ALPHA_YZ	back stress - yz component
8	ALPHA_ZX	back stress - zx component

Table 8.35: State Variables for THERMO EP POWER WELD Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	EQPS	equivalent plastic strain
	RADIUS	radius of yield surface
	ALPHA_XX	back stress - xx component
	ALPHA_YY	back stress - yy component
	ALPHA_ZZ	back stress - zz component
	ALPHA_XY	back stress - xy component
	ALPHA_YZ	back stress - yz component
	ALPHA_ZX	back stress - zx component
	WELD_FLAG	

Table 8.36: State Variables for UNIVERSAL POLYMER Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	AEND	
	IGXX1 - IGXX20	
	IGYY1 - IGYY20	
	IGZZ1 - IGZZ20	
	IGXY1 - IGXY20	
	IGYZ1 - IGYZ20	
	IGZX1 - IGZX20	
	IKI11 - IKI120	
	IKAT1 - IKAT20	
	IF1P1 - IF1P20	
	IF2J1 - IF2J20	
	EPSXX	
	EPSYY	
	EPSZZ	
	EPSXY	
	EPSYZ	
	EPSZX	
	LOGA	

Table 8.37: State Variables for VISCOELASTIC SWANSON Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	SFJTH	
	JTH	
	VMECHXX	
	VMECHYY	
	VMECHZZ	
	VMECHXY	
	VMECHYZ	
	VMECHZX	
	VSXXDEV1 - VSXXDEV10	
	VSYYDEV1 - VSYYDEV10	
	VSZZDEV1 - VSZZDEV10	
	VSXYDEV1 - VSXYDEV10	
	VSYZDEV1 - VSYZDEV10	
	VSZXDEV1 - VSZXDEV10	
	SOXXDEV	
	SOYYDEV	
	SOZZDEV	
	SOXYDEV	
	SOYZDEV	
	SOZXDEV	

Table 8.38: State Variables for VISCOPLASTIC Model

Index (Native Model)	**Name (LAME Model)**	**Variable Description**
	SVBXX	
	SVBYY	
	SVBZZ	
	SVBXY	
	SVBYZ	
	SVBZX	
	EQDOT	
	COUNT	
	SHEAR	
	BULK	
	RATE	
	EXP	
	ALPHA	
	A1	
	A2	
	A4	
	A5	

8.6.2.5 Registered Variables for Shell/Membrane Material Models

Shell and membrane material models also make their state variables available through direct naming of the variables. Tables 8.39 through 8.42 indicate the names of the state variables for the shell material models.

Table 8.39: State Variables for Elastic-Plastic Model for Shells

Variable Name	Variable Description
`eqps`	Equivalent plastic strain
`back_stress`	Back stress
`radius`	Radius of the yield surface

Table 8.40: State Variables for Elastic-Plastic Power-Law Hardening Model for Shells

Variable Name	Variable Description
`eqps`	Equivalent plastic strain
`radius`	Radius of yield surface

Table 8.41: State Variables for Multilinear Elastic-Plastic Hardening Model for Shells

Variable Name	Variable Description
`eqps`	Equivalent plastic strain
`tensile_eqps`	Equivalent plastic strain only accumulated in tension
`back_stress`	Back stress
`radius`	Radius of the yield surface

Table 8.42: State Variables for Multilinear Elastic-Plastic Hardening Model with Failure for Shells

Variable Name	**Variable Description**
`eqps`	Equivalent plastic strain
`back_stress`	Back stress
`radius`	Radius of the yield surface
`tearing_parameter`	The current value of the tearing parameter
`crack_opening_strain`	The value of the crack opening strain during the failure process
`crack_flag`	Status of the model: 0 for loading, 1 or 2 for initiation of failure, 3 during unloading

8.7 References

1. Larry A. Schoof, Victor R. Yarberry, *EXODUS II: A Finite Element Data Model*, SAND92-2137, Sandia National Laboratories, September 1994. See also new draft documentation available at
http://sourceforge.net/projects/exodusii.

2. The eXtensible Data Model and Format (XDMF) . . . .
http://www.xdmf.org (Accessed March 17, 2008).

3. Sjaardema, G. D. *Overview of the Sandia National Laboratories Engineering Analysis Code Access System*, SAND92-2292. Albuquerque, NM: Sandia National Laboratories, January 1993.
http://jal.sandia.gov/SEACAS/Documentation/SEACAS_Overview.pdf.

Chapter 9

User Subroutines

User-defines subroutines is a functionality shared by Adagio and Presto. This chapter discusses when and how to use user-defined subroutines. There are examples of user-defined subroutines in the latter part of this chapter. Some of the examples are code specific, i.e., they are applicable to Presto rather than Adagio or vice versa. All examples, regardless of their applicability, do provide important information about how to use the command options available for user-defined subroutines.

In the introductory part of Chapter 9, we first describe, in general, possible applications for the user subroutine functionality in Adagio. Then, again in general, we describe the various pieces and steps that are required by the user to implement a user subroutine. Subsequently, we focus on various aspects of implementing the user subroutine functionality. Section 9.1 describes the details of the user subroutine. Section 9.2 describes the command lines associated with user subroutines that appear in the Adagio input file. In Section 9.3, we explain how to build and use a version of Adagio that incorporates your user subroutine. Finally, Section 9.4 provides examples of actual user subroutines, and Section 9.5 lists some subroutines that are now in the standard user library.

Applications. User subroutines are primarily intended as complex function evaluators that are to be used in conjunction with existing Adagio capability (boundary conditions, , user output, etc.). For example, suppose we want to have a prescribed displacement boundary condition applied to a set of nodes, and we want the displacement at each node to vary with both time and spatial location of the node. The standard function option associated with the prescribed direction displacement boundary condition in Adagio only allows for time variation; i.e., at any given time, the direction and the magnitude of the displacement at each node, regardless of the spatial location of the node, are the same. If we wanted to have a spatial variation of the displacement field in addition to the time variation, it would be necessary to implement a user subroutine for the prescribed direction displacement boundary condition. Other examples of possible uses of user subroutines are as follows:

- The user wants to compute the total contact force acting on a given surface.
- Element stress information must be transformed to a local coordinate system so that the stress values will be meaningful.

- An aerodynamic pressure based on velocity and surface normal is applied to a specified surface.

Some capability exists for using mesh connectivity. It is possible to compute an element quantity based on values at the element nodes.

Some difficulties might occur in parallel applications. If computations for element A depend on quantities in element B and elements A and B are on different processors, then the computations for A may not have access to quantities in element B. For most computations in user subroutines, however, this should not be a problem.

Implementing completely new capabilities, particularly if these capabilities involve parallel computing, may be difficult or impossible with user subroutines.

General Pieces and Steps. A number of pieces and steps are required to make use of user subroutines. Here, we present a brief description of the pieces and steps that a user will need for user subroutines without going into detail. The details are discussed in later parts of this chapter.

1. You must first determine whether your application fits in the user subroutine format. This can be done by considering the above requirements and examining the description of commands for functionality in Adagio. For example, the basic kinematic boundary conditions and force conditions allow for the use of user subroutines. The description of these commands includes a discussion of how a user subroutine could be applied and what command line will invoke a user subroutine.

2. If you determine that your application can make use of the user subroutine functionality in Adagio, you will then need to write the subroutine. The parts of the subroutine that interface to Adagio have specified formats. The details of these interfaces are described in later sections. One part of the subroutine with a specified format is the call list. Other parts of the subroutine with a specified format are code that will do the following:

   - Read parameters from the Adagio input file
   - Access a variety of information—field variables, analysis time, etc.—from Adagio
   - Store computed quantities

   Parameters are values they may be passed from the Adagio input file to the user subroutine. Suppose that the spatial variation for some quantity in the user subroutine uses some characteristic length and the user wishes to examine results generated by using several different values of the characteristic length. By setting up the characteristic length as a parameter, the value for the parameter in the user subroutine can easily be changed by changing the value for the parameter in the input file. This lets the user change the value for a variable inside the user subroutine without having to recompile the user subroutine.

   The portion of your subroutine not built on the Adagio specifications will reflect your specific application. The code to implement your application may include a loop over nodes that prescribes a displacement based on the current time for the analysis and the spatial location of the node.

3. After you write the user subroutine, you will need to have a command line in your input file that tells Adagio you want to use the user subroutine you have written. For example, if your user subroutine is a specialized prescribed displacement boundary condition, then inside a `PRESCRIBED DISPLACEMENT` command block, you will have a command line of the form

   ```
   NODE SET SUBROUTINE = <string>subroutine_name
   ```

   that provides the name of your user subroutine.

4. Following the invocation of the user subroutine, there may be command lines for various parameters associated with the user subroutine. There may also be some additional command lines in other sections of the code required for your application. For example, you may have to add command lines in the region scope that will create an internal variable associated with a computed quantity so that the computed quantity can be written to the results file.

5. Once you have constructed the user subroutine, which is a FORTRAN file, and the Adagio input file, you can build an executable version of Adagio that will run your user subroutine. Your Adagio run will then incorporate the functionality you have created in your user subroutine.

Figure 9.1 presents a very high-level overview of the various components that work together to implement the user subroutine functionality. The two main components needed for user subroutines, which are commands in the Adagio input file and the actual user subroutine, are represented by the two columns in Figure 9.1.



Figure 9.1: Overview of components required to implement user subroutine functionality, excluding compilation and execution commands.

9.1 User Subroutines: Programming

Currently, user subroutines are only supported in FORTRAN 77. Any subroutine that can be compiled with a FORTRAN 77 compiler on the target execution machine can be used. The user should be aware that some computers support different FORTRAN language extensions than others. (In the future, other languages such as FORTRAN 90, C, and C++ may be supported.)

User subroutine variable types must interface directly with the matching variable types used in the main Adagio code. Thus, the FORTRAN 77 subroutines should use only integer, double precision, or character types for any data used in the interface or in any query function. Using the wrong data type may yield unpredictable results. The methods used to pass character types from Adagio to FORTRAN user subroutines can be machine-dependent, but generally this functionality works quite well.

The basic structure for the user subroutine is as follows:

```
subroutine sub_name(call list)
{declaration of variables}
{retrieve parameters from Adagio input file}
{query Adagio for information}
{application-specific code
    .
    .
}
{write computed values}
END
```

In general, the user will begin the subroutine with variable declarations. After the variable declarations, the user can then query the Adagio input file for parameters. Additional Adagio information such as field variables or element topology can then be retrieved from Adagio. Once the user has collected all the information for the application, the application-specific portion of the code can be written. After the application-specific code is complete, the user may store computed values.

Section 9.1.1 through Section 9.1.3 describe in detail the format for the interfaces to Adagio that will allow the user to make the subroutine call, retrieve information from Adagio, and write computed values. In these sections, mesh entities can be a node, an element face, or an element.

9.1.1 Subroutine Interface

The following interface is used for all user subroutines:

```
subroutine sub_name(int  num_objects,
            int  num_values,
            real evaluation_time,
            int  object_ids[],
            real output_values[],
            int  output_flags[],
            int  error_code)
```

The name of the user subroutine, `sub_name`, is selected by the user. Avoid names for the subroutine that are longer than 10 characters. This may cause build problems on some systems.

A detailed description of the input and output parameters is provided in Table 9.1 and Table 9.2.

Table 9.1: Subroutine Input Parameters

Input Parameter	**Data Type**	**Parameter Description**
num_objects	Integer	Number of input mesh entities. For example, if the subroutine is a node set subroutine, this would be the number of nodes on which the subroutine will operate.
num_values	Integer	Number of return values. This is the number of values per mesh entity.
evaluation_time	Real	Time at which the subroutine should be evaluated. This may vary slightly from the current analysis time.
object_ids (num_objects)	Integer	Array of mesh-entity identification numbers. The array has a length of num_objects. The input numbers are the global numbers of the input objects. The object identification numbers can be used to query information about a mesh entity.

9.1.2 Query Functions

Adagio follows a design philosophy for user subroutines that a minimal amount of information should be passed through the call list. Additional information may be queried from within the subroutine. A user subroutine may query a wide variety of information from Adagio.

Table 9.2: Subroutine Output Parameters

Output Parameter	**Data Type**	**Parameter Description**
output_values (num_values, num_objects)	Integer	Array of output values computed by the subroutine. The number of output values will be either the number of mesh entities or some multiple of the number of mesh entities. For example, if there were six nodes (num_objects equals 6) and one value was to be computed per node, the length of output_values would be 6. Similarly, if there were six nodes (num_objects equals 6) and three values were to be computed for each node (as for acceleration, which has X-, Y-, and Z-components), the length of output_values would be 18.
output_flags (num_objects)	Integer	Array of returned flags for each set of data values. When used, this array will generally have a length of num_objects. The usage of the flags depends on subroutine type; the flags are currently used only for element death and for kinematic boundary conditions. For the kinematic boundary conditions (displacement, velocity, acceleration) a flag of –1 means ignore the constraint, a flag of 0 means set the absolute constraint value, and a flag of 1 means set the constraint with direction and distance.
error_code	Integer	Error code returned by the user subroutine. A value of 0 indicates no errors. Any value other than zero is an error. If the return value is nonzero, Adagio will report the error code and terminate the analysis.

9.1.2.1 Parameter Query

A number of user subroutine parameters may be set as described in Section 9.2.2.3. These subroutine parameters can be obtained from the Adagio input file via the query functions listed below.

```
aupst_get_real_param(string var_name, real var_value,
                     int error_code)

aupst_get_integer_param(string var_name, int var_value,
                        int error_code)

aupst_get_string_param(string var_name, string var_value,
                     int error_code)
```

All three of these subroutine calls are tied to a corresponding "parameter" command line that will appear in the Adagio input file. The parameter command lines are described in Section 9.2.2.3. These command lines are named based on the type of value they store, i.e., `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`.

We will use the example of a real parameter to show how the subroutine call works in conjunction with the `SUBROUTINE REAL PARAMETER` command line. Suppose we have a real parameter radius that is set to a value of 2.75 on the `SUBROUTINE REAL PARAMETER` command line:

```
SUBROUTINE REAL PARAMETER: radius = 2.75
```

Also suppose we have a call to `aupst_get_real_parameter` in the user subroutine:

```
call aupst_get_real_parameter("radius",cyl_radius,error_code)
```

In the call to `aupst_get_real_parameter`, we have `var_name` set to `radius` and `var_value` defined as the real FORTRAN variable `cyl_radius`. The call to `aupst_get_real_parameter` will assign the value 2.75 to the FORTRAN variable `cyl_radius`. A similar pattern is followed for integer and string parameters.

The arguments for the parameter-related query functions are described in Table 9.3, Table 9.4, and Table 9.5. The function is repeated prior to each table for easy reference.

```
aupst_get_real_param(string var_name, real var_value,
                     int error_code)
```

Table 9.3: aupst_get_real_param Arguments

Parameter	**Usage**	**Data Type**	**Description**
var_name	Input	String	Name of a real-valued subroutine parameter, as defined in the Adagio input file via the `SUBROUTINE REAL PARAMETER` command line.
var_value	Output	Real	Name of a real variable to be used in the FORTRAN subroutine. The FORTRAN variable var_value will be set to the value specified by the `SUBROUTINE REAL PARAMETER` command line.
error_code	Output	Integer	Error code indicating status of retrieving the parameter value from the input file. If the retrieval is successful, error_code is set to 0. If the parameter is not found or is the wrong type, error_code is set to a value other than 0.

```
aupst_get_integer_param(string var_name, int var_value,
                        int error_code)
```

Table 9.4: aupst_get_integer_param Arguments

Parameter	**Usage**	**Data Type**	**Description**
var_name	Input	String	Name of an integer-valued subroutine parameter, as defined in the Adagio input file via the `SUBROUTINE INTEGER PARAMETER` command line.
var_value	Output	Integer	Name of an integer variable to be used in the FORTRAN subroutine. The FORTRAN variable var_value will be set to the value specified by the `SUBROUTINE INTEGER PARAMETER` command line.
error_code	Output	Integer	Error code indicating status of retrieving the parameter value from the input file. If the retrieval is successful, error_code is set to 0. If the parameter is not found or is the wrong type, error_code is set to a value other than 0.

```
aupst_get_string_param(string var_name, string var_value,
                       int error_code)
```

Table 9.5: aupst_get_string_param Arguments

Parameter	**Usage**	**Data Type**	**Description**
var_name	Input	String	Name of a string-valued subroutine parameter, as defined in the Adagio input file via the `SUBROUTINE STRING PARAMETER` command line.
var_value	Output	String	Name of a string variable to be used in the FORTRAN subroutine. The FORTRAN variable var_value will be set to the value specified by the `SUBROUTINE STRING PARAMETER` command line.
error_code	Output	Integer	Error code indicating status of retrieving the parameter value from the input file. If the retrieval is successful, error_code is set to 0. If the parameter is not found or is the wrong type, error_code is set to a value other than 0.

9.1.2.2 Function Data Query

The function data query routine listed below may be used for extracting data from a function that is defined in a `DEFINITION FOR FUNCTION` command block in the Adagio input file. This query allows the user to directly access information stored in a function defined in the Adagio input file.

```
aupst_evaluate_function(string func_name, real
input_times[], int num_times, real output_data[])
```

The arguments for this function are described in Table 9.6.

Table 9.6: aupst_evaluate_function Arguments

Parameter	Usage	Data Type	Description
func_name	Input	String	Name of the function to look up.
input_times (num_times)	Input	Real	Array of times used to extract values of the function.
num_times	Input	Integer	Length of the array input_times.
output_data (num_times)	Output	Real	Array of output values of the named function at the specified times.

9.1.2.3 Time Query

The time query function can be used to determine the current analysis time. This is the time associated with the new time step. This time may not be equivalent to the `evaluation_time` argument passed into the subroutine (see Section 9.1.1, Table 9.1) as some boundary conditions need to be evaluated at different times than others. The parameter of the time query function listed below is given in Table 9.7.

```
aupst_get_time(real time)
```

Table 9.7: aupst_get_time Argument

Parameter	Usage	Data Type	Description
time	Output	Real	Current analysis time.

9.1.2.4 Field Variables

Field variables (displacements, stresses, etc.) may be defined on groups of mesh entities. A number of queries are available for getting and putting field variables. These queries involve passing in a set of mesh-entity identification numbers to receive field values on the mesh entities. There are

query functions to check for the existence and size of a field, functions to retrieve the field values, and functions to store new variables in a field. The field query functions listed below can be used to extract any registered nodal or element variable field.

```
aupst_check_node_var(int num_nodes, int num_components,
                     int node_ids[], string var_name,
                     int error_code)

aupst_check_elem_var(int num_elems, int num_components,
                     int elem_ids[], string var_name,
                     int error_code)

aupst_get_node_var(int num_nodes, int num_components,
                   int node_ids[], real return_data[],
                   string var_name, int error_code)

aupst_get_elem_var(int num_elems, int num_components,
                   int elem_ids[], real return_data[],
                   string var_name, int error_code)

aupst_put_node_var(int num_nodes, int num_components,
                   int node_ids[], real new_data[],
                   string var_name, int error_code)

aupst_put_elem_var(int num_elems, int num_components,
                   int elem_ids[], real new_data[],
                   string var_name, int error_code)
```

The arrays where data are stored are static arrays. These arrays of a set size will be declared at the beginning of a user subroutine. The query functions to check for the existence and size of a field can be used to ensure that the size of the array of information being returned from Adagio does not exceed the size of the array allocated by the user.

The arguments to field query functions are defined in Table 9.8 through Table 9.13. The function is repeated before each table for easy reference.

```
aupst_check_node_var(int num_nodes, int num_components,
                     int node_ids[], string var_name,
                     int error_code)
```

Table 9.8: aupst_check_node_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_nodes	Input	Integer	Number of nodes used to extract field information.
num_components	Output	Integer	Number of components in the field information. A displacement field at a node has three components, for example.
node_ids (num_nodes)	Input	Integer	Array of size num_nodes listing the node identification number for each node where field information will be retrieved.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

```
aupst_check_elem_var(int num_elems, int num_components,
                     int elem_ids[], string var_name,
                     int error_code)
```

Table 9.9: aupst_check_elem_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_elems	Input	Integer	Number of elements used to extract field information.
num_components	Output	Integer	Number of components in the field information. A stress field for a an eight-node hexahedron element has six components, for example.
elem_ids (num_elems)	Input	Integer	Array of size num_elems listing the element identification number for each element where field information will be retrieved.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

```
aupst_get_node_var(int num_nodes, int num_components,
                   int node_ids[], real return_data[],
                   string var_name, int error_code)
```

Table 9.10: aupst_get_node_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_nodes	Input	Integer	Number of nodes used to extract field information.
num_components	Input	Integer	Number of components in the field information. A displacement field at a node has three components, for example.
node_ids (num_nodes)	Input	Integer	Array of size num_nodes listing the node identification number for each node where field information will be retrieved.
return_data (num_components, num_nodes)	Output	Real	Array of size num_components $\times$ num_nodes containing the field data at each node.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

```
aupst_get_elem_var(int num_elems, int num_components,
                   int elem_ids[], real return_data[],
                   string var_name, int error_code)
```

Table 9.11: aupst_get_elem_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_elems	Input	Integer	Number of elements used to extract field information.
num_components	Input	Integer	Number of components in the field information. A stress field for a an eight-node hexahedron element has six components, for example.
elem_ids (num_elems)	Input	Integer	Array of size num_elems listing the element identification number for each element where field information will be retrieved.
return_data (num_components, num_elems)	Output	Real	Array of size num_components $\times$ num_elems containing the field data for each element.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

```
aupst_put_node_var(int num_nodes, int num_components,
                   int node_ids[], real new_data[],
                   string var_name, int error_code)
```

Table 9.12: aupst_put_node_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_nodes	Input	Integer	Number of nodes for which the user will specify the field data.
num_components	Input	Integer	Number of components in the field information. A displacement field at a node has three components, for example.
node_ids (num_nodes)	Input	Integer	Array of size num_nodes listing the node identification number for each node where field information will be retrieved.
new_data (num_compon ents, num_nodes)	Input	Real	Array of size num_components $\times$ num_nodes containing the new data for the field.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

```
aupst_put_elem_var(int num_elems, int num_components,
                   int elem_ids[], real new_data[],
                   string var_name, int error_code)
```

Table 9.13: aupst_put_elem_var Arguments

Parameter	Usage	Data Type	Description
num_elems	Input	Integer	Number of elements for which the user will specify the field data.
num_components	Input	Integer	Number of components in the field information. A stress field for a an eight-node hexahedron element has six components, for example.
elem_ids (num_elems)	Input	Integer	Array of size num_elems listing the element identification number for each element where field information will be retrieved.
new_data (num_compon ents, num_elems)	Input	Real	Array of size num_components × num_elems containing the new data for the field.
var_name	Input	String	Name of the field variable. The field variable must be a registered Adagio variable.
error_code	Output	Integer	Error code indicating status of retrieving the field. If the retrieval is successful, error_code is set to 0. If a nonzero value is returned for error_code, the field variable does not exist or is not defined on one or more of the input nodes.

9.1.2.5 Global Variables

Global variables may be extracted or set from user subroutines. A global variable has a single value for a given region.

Global variables have limited support for parallel operations. There are two subroutines to perform parallel modification of global variables: `aupst_put_global_var` and `aupst_local_put_global_var`.

- The subroutine `aupst_local_put_global_var` only modifies a temporary local copy of the global variable. The local copies on the various processors are reduced to create the

true global value at the end of the time step. Global variables set with `aupst_local_put_global_var` do not have the single processor value available immediately. The true global variable will not be available through the `aupst_get_global_var` routine until the next time step.

- The subroutine `aupst_put_global_var` attempts to immediately modify and perform a parallel reduction of the value of a global variable. Care must be taken to call this routine on all processors at the same time with the same arguments. Failure to call the routine from all processors will result in the code hanging. For some types of subroutines this is not possible or reliable. For example, a boundary condition subroutine may not be called at all on a processor that contains no nodes in the set of nodes assigned to the boundary condition. It is recommended that `aupst_local_put_global_var` only be used in conjunction with a user subroutine referenced in a `USER OUTPUT` command block (Section 8.1.2).

Only user-defined global variables may be modified by the user subroutine (see Section 9.2.4). However, any global variable that exists on the region may be checked or extracted. The following subroutine calls pertain to global variables:

```
aupst_get_global_var(int num_comp, real return_data,
                     string var_name, int error_code)

aupst_put_global_var(int num_comp, real input_data,
                     string reduction_type,
                     string var_name, int error_code)

aupst_local_put_global_var(int num_comp, real input_data,
                     string var_name, string reduction_type,
                     int error_code)
```

The arguments for subroutine calls pertaining to global variables are defined in Table 9.14 through Table 9.17. The call is repeated before each table for easy reference.

```
aupst_check_global_var(int num_comp, string var_name
                       int error_code)
```

Table 9.14: aupst_check_global_var Arguments

Parameter	Usage	Data Type	Description
num_comp	Output	Integer	Number of components of the global variable.
var_name	Input	String	Name of the global variable.
error_code	Output	Integer	Error code indicating status of accessing the global variable. If there is no error in accessing this variable, error_code is set to 0. A nonzero value of error_code means the global variable does not exist or in some way cannot be accessed.

```
aupst_get_global_var(int num_comp, real return_data,
                     string var_name, int error_code)
```

Table 9.15: aupst_get_global_var Arguments

Parameter	Usage	Data Type	Description
num_comp	Input	Integer	Number of components of the global variable.
return_data	Output	Real	Value of the global variable.
var_name	Input	String	Name of the global variable.
error_code	Output	Integer	Error code indicating status of accessing the global variable. If there is no error in accessing this variable, error_code is set to 0. A nonzero value of error_code means the global variable does not exist or in some way cannot be accessed.

```
aupst_put_global_var(int num_comp, real input_data,
                     string reduction_type,
                     string var_name, int error_code)
```

Table 9.16: aupst_put_global_var Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_comp	Input	Integer	Number of components of the global variable.
input_data	Input	Real	New value of the global variable.
reduction_type	Input	String	Type of parallel reduction to perform on the variable. Options are “sum”, “min”, “max”, and “none”.
var_name	Input	String	Name of the global variable.
error_code	Output	Integer	Error code indicating status of accessing the global variable. If there is no error in accessing this variable, error_code is set to 0. A nonzero value of error_code means the global variable does not exist, in some way cannot be accessed, or may not be overwritten.

```
aupst_local_put_global_var(int num_comp, real input_data,
                           string var_name,
                           string reduction_type,
                           int error_code)
```

Table 9.17: aupst_local_put_global_var Arguments

Parameter	Usage	Data Type	Description
num_comp	Input	Integer	Number of components of the global variable.
input_data	Input	Real	New value of the global variable.
reduction_type	Input	String	Type of parallel reduction to perform on the variable. Options are "sum", "min", and "max". The operation type specified here must match the operation type given to the user-defined global variable when it is defined in the Adagio input file.
var_name	Input	String	Name of the global variable.
error_code	Output	Integer	Error code indicating status of accessing the global variable. If there is no error in accessing this variable, error_code is set to 0. A nonzero value of error_code means the global variable does not exist, in some way cannot be accessed, or may not be overwritten.

9.1.2.6 Topology Extraction

The element and surface subroutines operate on groups of elements or faces. The elements and faces may have a variety of topologies. Topology queries can be used to get topological data about elements and faces. The topology of an object is represented by an integer. The integer is formed from a function of the number of dimensions, vertices, and nodes of an object. The topology of an object is given by:

```
topology = num_node + 100 * num_vert + 10000 * num_dim
```

In a FORTRAN routine, the number of nodes can easily be extracted with the mod function:

```
num_node = mod(topo,100)
num_vert = mod(topo / 100, 100)
num_dim  = mod(topo / 10000, 100)
```

Table 9.18: Topologies Used by Adagio

Topology	Element / Face Type
00101	One-node particle
10202	Two-node beam, truss, or damper
20404	Four-node quadrilateral
20303	Three-node triangle
20304	Four-node triangle
20306	Six-node triangle
30404	Four-node tetrahedron
30408	Eight-node tetrahedron
30410	Ten-node tetrahedron
30808	Eight-node hexahedron

Table 9.18 lists the topologies currently in use by Adagio.

The following topology query functions are available in Adagio:

```
aupst_get_elem_topology(int num_elems, int elem_ids[],
                        int topology[], int error_code)

aupst_get_elem_nodes(int num_elems, int elem_ids[],
                     int elem_node_ids[], int error_code)

aupst_get_face_topology(int num_faces, int face_ids[],
                        int topology[], int error_code)

aupst_get_face_nodes(int num_faces, int face_ids[],
                     int face_node_ids[], int error_code)
```

The arguments for the topology extraction functions are defined in Table 9.19 through Table 9.22. The function is repeated before each table for easy reference.

```
aupst_get_elem_topology(int num_elems, int elem_ids[],
                        int topology[], int error_code)
```

Table 9.19: aupst_get_elem_topology Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_elems	Input	Integer	Number of elements from which the topology will be extracted.
elem_ids (num_elems)	Input	Integer	Array of length num_elems listing the element identification for each element from which the topology will be extracted.
topology (num_elems)	Output	Integer	Array of length num_elems that has the topology for each element. See Table 8.18.
error_code	Output	Integer	Error code indicating status of retrieving the element identification numbers. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if one of the element identification numbers is not valid.

```
aupst_get_elem_nodes(int num_elems, int elem_ids[],
                     int elem_node_ids[], int error_code)
```

Table 9.20: aupst_get_elem_nodes Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_elems	Input	Integer	Number of elements from which the topology will be extracted.
elem_ids (num_elems)	Input	Integer	Array of length num_elems listing the element identification for each element from which the topology will be extracted.
elem_node_ids (number of nodes for element type × num_elems)	Output	Integer	Array containing the node identification numbers for each element requested. The length of the array is the total number of nodes contained in all elements. If the elements are eight-node hexahedra, then the number of nodes will be 8 × num_elems. The first set of eight entries in the array will be the eight nodes defining the first element. The second set of eight entries will be the eight nodes defining the second element, and so on.
error_code	Output	Integer	Error code indicating status of retrieving the element identification numbers. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if one of the element identification numbers is not valid.

```
aupst_get_face_topology(int num_faces, int face_ids[],
                        int topology[], int error_code)
```

Table 9.21: aupst_get_face_topology Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_faces	Input	Integer	Number of faces from which the topology will be extracted.
face_ids (num_faces)	Input	Integer	Array of length num_faces listing the face identification for each face from which the topology will be extracted.
topology (num_faces)	Output	Integer	Array of length num_faces containing the output topologies of each face.
error_code	Output	Integer	Error code indicating status of retrieving the face identification numbers. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if one of the face identification numbers is not valid.

```
aupst_get_face_nodes(int num_faces, int face_ids[],
                     int face_node_ids[], int error_code)
```

Table 9.22: aupst_get_face_nodes Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_faces	Input	Integer	Number of faces from which the topology will be extracted.
face_ids (num_faces)	Input	Integer	Array of length num_faces listing the face identification for each face from which the topology will be extracted.
face_node_ids (number of nodes for face type × num_faces)	Output	Integer	Array containing the node identification numbers for each face requested. The length of the array is the total number of nodes contained in all faces. If the faces are four-node quadrilaterals, then the number of nodes will be 4 × num_faces. The first set of four entries in the array will be the four nodes defining the first face. The second set of four entries will be the four nodes defining the second face, and so on.
error_code	Output	Integer	Error code indicating status of retrieving the face identification numbers. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if one of the face identification numbers is not valid.

9.1.3 Miscellaneous Query Functions

A number of miscellaneous query functions are available for computing some commonly used quantities.

```
aupst_get_one_elem_centroid(int num_elems, int elem_ids[],
                      real centroids, int error_code)

aupst_get_point(string point_name, real point_coords,
                      int error_code)

aupst_get_proc_num(proc_num)
```

The arguments for the miscellaneous query functions are defined in Table 9.23 through Table 9.25. The function is repeated before each table for easy reference.

```
aupst_get_one_elem_centroid(int num_elems, int elem_ids[],
                      real centroids[], int error_code)
```

Table 9.23: aupst_get_one_elem_centroid Arguments

Parameter	**Usage**	**Data Type**	**Description**
num_elems	Input	Integer	Number of elements for which to extract the topology.
elem_ids (num_elems)	Input	Integer	Array of length num_elems listing the element identification for each element for which the centroid will be computed.
centroids (3, num_elems)	Output	Real	Array of length 3 $\times$ num_elems containing the centroid of each element.
error_code	Output	Integer	Error code indicating status of retrieving the element identification numbers. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if one of the element identification numbers is not valid.

```
aupst_get_point(string point_name, real point_coords,
                     int error_code)
```

Table 9.24: aupst_get_point Arguments

Parameter	Usage	Data Type	Description
point_name	Input	String	SIERRA name for a given point.
point_coords (3)	Output	Real	Array of length 3 containing the x, y, and z coordinates of the point.
error_code	Output	Integer	Error code indicating status of retrieving the point. If the retrieval is successful, error_code is set to 0. A nonzero value is returned for error_code if the point cannot be found

```
aupst_get_proc_num(proc_num)
```

Table 9.25: aupst_get_proc_num Arguments

Parameter	Usage	Data Type	Description
proc_num	Output	Integer	Processor number of the calling process. This number can be used for informational purposes. A common example is that output could only be written by a single processor, e.g., processor 0, rather than by all processors.

9.2 User Subroutines: Command File

In addition to the actual user subroutine, you will need to add command lines to your input file to make use of your user subroutine. This section describes the command lines that are used in conjunction with user subroutines. This section also describes two additional command blocks, `TIME STEP INITIALIZATION` and `USER VARIABLE`. The `TIME STEP INITIALIZATION` command block lets you execute a user subroutine at the beginning of a time step as opposed to some later time. The `USER VARIABLE` command block can be used in conjunction with user subroutines or for user-defined output.

9.2.1 Subroutine Identification

As described in Section 2.1.4, there is one command line associated with the user subroutine functionality that must be provided in the domain scope:

```
USER SUBROUTINE FILE = <string>file_name
```

The named file may contain one or more user subroutines. The file must have an extension of ".F", as in blast.F.

9.2.2 User Subroutine Command Lines

```
{begin command block}
  NODE SET SUBROUTINE = <string>subroutine name |
    SURFACE SUBROUTINE = <string>subroutine_name |
    ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
      = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
      = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
      = <string>param_value
{end command block}
```

A number of user subroutine command lines will appear in some Adagio command block. User subroutine commands can appear in boundary condition, user output, and state initialization command blocks. The possible command lines are shown above. The following sections describe the command lines related to user subroutines.

9.2.2.1 Type

User subroutines are currently available in three general types: node set, surface, and element.

Node set subroutines operate on groups of nodes. The command line for defining a node set subroutine is:

```
NODE SET SUBROUTINE = <string>subroutine_name
```

where `subroutine_name` is the name of the user subroutine. The name is case sensitive. A node set subroutine will operate on all nodes contained in an associated mechanics instance.

Surface subroutines work on groups of surfaces. A surface may be an external face of a solid element or the face of a shell element associated with either the positive or negative normal for the surface of the shell. The command line for defining a surface subroutine is:

```
SURFACE SUBROUTINE = <string>subroutine_name
```

Element block subroutines work on groups of elements. The command line for defining an element block subroutine is:

```
ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
```

An element may be a solid element such as a hexahedron or a two-dimensional element such as a shell.

Different Adagio features may accept one or more types of user subroutines. Only one subroutine is allowed per command block.

9.2.2.2 Debugging

Subroutines may be run in a special debugging mode to help catch memory errors. For example, there is a potential for a user subroutine to write outside of its allotted data space by writing beyond the bounds of an input or output array. Generally, this causes Adagio to crash, but it also has the potential to introduce other very hard-to-trace bugs into the Adagio analysis. Subroutines run in debug mode require more memory and more processing time than subroutines not run in debug mode.

Subroutine debugging is on by default in debug executables. It can be turned off with the following command line:

```
SUBROUTINE DEBUGGING OFF
```

Subroutine debugging is off by default in optimized executables. It can be turned on with the following command line:

```
SUBROUTINE DEBUGGING ON
```

9.2.2.3 Parameters

All user subroutines have the ability to use parameters. Parameters are defined in the input file and are quickly accessible by the user subroutine during run time. Parameters are a way of making a single user subroutine much more versatile. For example, a user subroutine could be written to define a periodic loading on a structure. A parameter for the subroutine could be defined specifying the frequency of the function. In this way, the same subroutine can be used in different parts of

the model, and the subroutine behavior can be modified without recompiling the program. These command lines are placed within the scope of the command block in which the user subroutine is specified.

Real-valued parameters can be stored with the following command line:

```
SUBROUTINE REAL PARAMETER: <string>param_name
       = <real>param_value
```

Integer-valued parameters can be stored with the following command line:

```
SUBROUTINE INTEGER PARAMETER: <string>param_name
       = <integer>param_value
```

String-valued parameters can be stored with the following command line:

```
SUBROUTINE STRING PARAMETER: <string>param_name
       = <string>param_value
```

Any number of subroutine parameters may be defined. The subroutine parameters may be defined in any order within the command block. The user subroutine may request the values of the parameters but is not required to use them or even have any knowledge of their existence. An example of subroutine usage with parameters is as follows:

```
BEGIN PRESSURE
  SURFACE = surface_1
  SURFACE SUBROUTINE = blast_pressure
  SUBROUTINE REAL PARAMETER: blast_time = 1.2
  SUBROUTINE REAL PARAMETER: blast_power = 1.3e+07
  SUBROUTINE STRING PARAMETER: formulation = alpha
  SUBROUTINE INTEGER PARAMETER: decay_exponent = 2
  SUBROUTINE DEBUGGING ON
END PRESSURE
```

In the above example, four parameters are associated with the subroutine `blast_pressure`. Two of the parameters are real (`blast_time` and `blast_power`), one of the parameters is a string (`formulation`), and one of the parameters is an integer (`decay_exponent`). To access the parameters in the user subroutine, the user will need to include interface calls described in previous sections.

9.2.3 Time Step Initialization

```
BEGIN TIME STEP INITIALIZATION
  # mesh-entity set commands
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list> surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name |
    SURFACE SUBROUTINE = <string>sub_name |
    ELEMENT BLOCK SUBROUTINE = <string>sub_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional command
  ACTIVE PERIODS = <string list>period_names
END TIME STEP INITIALIZATION
```

The `TIME STEP INITIALIZATION` command block, which appears in the region scope, is used to flag a user subroutine to run at the beginning of every time step. This subroutine can be used to compute quantities used by other command types. For example, if the traction on a surface was dependent on the area, the time step initialization subroutine could be used to calculate the area, and that area could be stored and later read when calculating the traction. The user initialization subroutine will pass the specified mesh objects to the subroutine for use in calculating some value.

The `TIME STEP INITIALIZATION` command block contains two groups of commands—mesh entity set and user subroutine. In addition to the command lines in the these command groups, there is an additional command line: `ACTIVE PERIODS`. The `ACTIVE PERIODS` command line is used to activate or deactivate the running of the user subroutine at the beginning of every time step for certain time periods. Following are descriptions of the different command groups and the `ACTIVE PERIODS` command lines.

9.2.3.1 Mesh-Entity Set Commands

The `mesh-entity set commands` portion of the `TIME STEP INITIALIZATION` command block specifies the nodes, element faces, or elements associated with the particular subroutine that

will be run at the beginning of the applicable time steps. This portion of the command block can include some combination of the following command lines:

```
NODE SET = <string list>nodelist_names
SURFACE = <string list>surface_names
BLOCK = <string list>block_names
INCLUDE ALL BLOCKS
REMOVE NODE SET = <string list>nodelist_names
REMOVE SURFACE = <string list> surface_names
REMOVE BLOCK = <string list>block_names
```

These command lines, taken collectively, constitute a set of Boolean operators for constructing a set of nodes, element faces, or elements. See Section 5.1 for more information about the use of these command lines for mesh entities. There must be at least one `NODE SET`, `SURFACE`, `BLOCK`, or `INCLUDE ALL BLOCKS` command line in the command block.

9.2.3.2 User Subroutine Commands

The following command lines are related to the user subroutine specification:

```
NODE SET SUBROUTINE = <string>subroutine_name |
  SURFACE SUBROUTINE = <string>subroutine_name |
  ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
SUBROUTINE REAL PARAMETER: <string>param_name
  = <real>param_value
SUBROUTINE INTEGER PARAMETER: <string>param_name
  = <integer>param_value
SUBROUTINE STRING PARAMETER: <string>param_name
  = <string>param_value
```

Only one of the first three command lines listed above can be specified in the command block. The particular command line selected depends on the mesh-entity type of the variable being initialized. For example, variables associated with nodes would be initialized if you are using the `NODE SET SUBROUTINE` command line, variables associated with faces if you are using the `SURFACE SUBROUTINE` command line, and variables associated with elements if you are using the `ELEMENT BLOCK SUBROUTINE` command line. The string `subroutine_name` is the name of a FORTRAN subroutine that is written by the user.

Following the selected subroutine command line are other command lines that may be used to implement the user subroutine option. These command lines are described in Section 9.2.2 and consist of `SUBROUTINE DEBUGGING OFF`, `SUBROUTINE DEBUGGING ON`, `SUBROUTINE REAL PARAMETER`, `SUBROUTINE INTEGER PARAMETER`, and `SUBROUTINE STRING PARAMETER`. Examples of using these command lines are provided throughout Chapter 9.

9.2.3.3 Additional Command

The `ACTIVE PERIODS` command line can optionally appear in the `TIME STEP INITIALIZATION` command block:

```
ACTIVE PERIODS = <string list>period_names
```

This command line determines when time step initialization by a user subroutine is active. See Section 2.4 for more information about this optional command line.

9.2.4 User Variables

```
BEGIN USER VARIABLE <string>var_name
  TYPE = <string>NODE|ELEMENT|GLOBAL
    [<string>REAL|INTEGER LENGTH = <integer>length]|
    [<string>SYM_TENSOR|FULL_TENSOR|VECTOR]
  GLOBAL OPERATOR = <string>SUM|MIN|MAX]
  INITIAL VALUE = <real list>values
  USE WITH RESTART
END [USER VARIABLE <string>var_name]
```

The `USER VARIABLE` command block is used to create a user-defined variable. This kind of variable may be used for scratch space in a user subroutine or for some user-defined output. A user-defined variable may be output to the results file or the history file just like any registered variable; i.e., a user-defined variable once defined by the `USER VARIABLE` command block can be specified in a `USER OUTPUT` command block, a `RESULTS OUTPUT` command block, and a `HISTORY OUTPUT` command block.

User-defined variables are associated with mesh entities. For example, a node variable will exist at every node of the model. An element variable will exist on every element of the model. A global variable will have a single value for the entire model.

If the user-defined variable functionality is used in conjunction with restart, the `USE WITH RESTART` command line must be included.

Known Issue: User defined variables are not currently supported with heartbeat output (see Section 8.3).

The `USER VARIABLE` command block is placed within a Adagio region. The command block begins with the input line:

```
BEGIN USER VARIABLE <string>var_name
```

and ends with the input line:

```
END [USER VARIABLE <string>var_name]
```

where `var_name` is a user-selected name for the variable.

In the above command block:

- A user-defined variable has an associated type that is specified by the `TYPE` command line, which itself contains several parameters. The `TYPE` command line is required.

  1. The variable must be a nodal quantity, an element quantity, or a global quantity. The options `NODE`, `ELEMENT`, and `GLOBAL` determine whether the variable will be a nodal, element, or global quantity. One of these options must appear on the `TYPE` command line.

2. The user-defined variable can be either an integer or a real, as specified by the INTEGER or REAL option.
3. The length of the variable must be set by using one of the options SYM_TENSOR, FULL_TENSOR, VECTOR, or LENGTH = <integer>length. If the LENGTH option is used, the user must specify whether the variable is an integer number or a real number by using the INTEGER or REAL option. If the SYM_TENSOR option is used, the variable has six real components. If the FULL_TENSOR is used, the variable has nine real components. If the VECTOR option is used, the variable has three real components. The three options SYM_TENSOR, FULL_TENSOR, and VECTOR all imply real numbers, and thus the REAL option need not be included in the command line when one of these three options is specified.

Some examples of the TYPE command line follow:

```
type = global real length = 1
type = element tensor
type = element real length = 3
type = node sym_tensor
type = node vector
```

- If you use the GLOBAL option on the TYPE command line, a global variable is created, and this global variable must be given an associated reduction type, which is specified by the GLOBAL OPERATOR command line. The reduction type tells Adagio how to reduce the individual values stored on each processor to a mesh global value. Global reductions are performed at the end of each time step. Any modifications to a global variable made by an aupst_local_put_global_var call (see Section 9.1.2.5) will not be seen until the next time step after the user-defined global variables have been updated and reduced. The SUM operator sums all processor variable contributions. The MAX operator takes the maximum value of the aupst_local_put_global_var calls. The MIN operator takes the minimum value of the aupst_local_put_global_var calls.

- One or more initial values may be specified for the user-defined variable in the INITIAL VALUE command line. The number of initial values specified should be the same as the length of the variable, as specified in the TYPE command line either explicitly via the LENGTH option or implicitly via the SYM_TENSOR, FULL_TENSOR, or VECTOR option. The initial values will be copied to the variable space on every mesh object on which the variable is defined. Only real type variables may be given initial values at this time.

- All intrinsic type options such as REAL, INTEGER, SYM_TENSOR, FULL_TENSOR, VECTOR and the LENGTH option can be used with any of the mesh entity options (NODE, ELEMENT, GLOBAL).

- As indicated previously, if the user-defined variable functionality is used in conjunction with restart, the USE WITH RESTART command line must be included.

9.3 User Subroutines: Compilation and Execution

Running a code with user subroutines is a two-step process. First, you must create an executable version of Adagio that recognizes the user subroutines. Next, you must use this version of Adagio for an actual Adagio run with an input file that incorporates the proper user subroutine command lines.

How the above two steps are carried out is site-specific. The actual process will depend on how Adagio is set up at your installation. We will give an example that shows how the process is carried out on various systems at Sandia using SIERRA command lines. SIERRA is a general code framework and code management system at Sandia.

For the first step, you will need the user subroutine, in a FORTRAN file, and a Adagio input file that makes use of the user subroutine. You will use a system command line of the general form shown below.

```
% sierra adagio -i <string>input_file_name --make
```

Suppose that you have a subdirectory in your area called `test` and you wish to incorporate a user subroutine called `blast_load`. The actual user subroutine will be in a file called `blast_load.F`, and the associated input file will be called `blast_load_1.i`. Both of these files will be in the directory `test`. In the input file, you will have the following command line in the domain scope:

```
USER SUBROUTINE FILE = blast_load.F
```

You will also have some subset of the command lines described in the previous section in your Adagio input file. The specific form of the system command line to execute the first step of the user subroutine process is shown below.

`% sierra adagio -i blast_load_1.i --make` The above command will create a local version of Adagio in a local directory named `UserSubsProject`. The system command line to run the local version of Presto is shown below.

```
% sierra adagio -i <string>input_file_name
        -x UserSubsProject
```

The specific form of the system command line you will execute in the subdirectory test is shown below.

```
% sierra adagio -i blast_load_1.i -x UsersSubsProjects
```

The second command line runs Adagio using `blast_load_1.i` as an input file and utilizes the user subroutines in the process. Again, all of this is a site-specific example. You must determine how Adagio is set up at your installation to determine what system command lines are necessary to build Adagio with user subroutines and then use this version of Adagio.

9.4 User Subroutines: Examples

9.4.1 Pressure as a Function of Space and Time

(The following example provides functionality—a blast load on a surface—more applicable to Presto than Adagio. It is included in both manuals as it is instructive in the general use of a user-defined subroutine.)

The following code is an example of a user subroutine to compute blast pressures on a group of faces. The blast pressure simulates a blast occurring at a specified position and time. The blast wave radiates out from the center of the blast and dissipates over time. This subroutine is included in the input file as follows:

```
#In the domain scope:
user subroutine file = blast_load.F

#In the region scope:
begin pressure
  surface = surface_1
  surface subroutine = blast_load
  subroutine real parameter: pos_x = 5.0
  subroutine real parameter: pos_y = 5.0
  subroutine real parameter: pos_z = 1.6
  subroutine real parameter: wave_speed = 1.5e+02
  subroutine real parameter: blast_time = 0.0
  subroutine real parameter: blast_energy = 1.0e+09
  subroutine real parameter: blast_wave_width = 0.75
end pressure
```

The FORTRAN 77 subroutine listing follows. Note that it would be possible to increase the speed of this subroutine by calling the topology functions (see Section 9.1.2.6) on groups of elements, though this would increase subroutine complexity.

```
c
c  Subroutine to simulate a blast load on a surface
c
      subroutine blast_load(num_faces, num_vals,
     &  eval_time, faceID, pressure, flags, err_code)

      implicit none
c
c  Subroutine input arguments
c
      integer num_faces
      double precision eval_time
      integer faceID(num_faces)
```

```
      integer num_vals

c
c  Subroutine output arguments
c
      double precision pressure(num_vals, num_faces)
      integer flags(num_faces)
      integer err_code
c
c  Variables to hold the subroutine parameters
c
      double precision pos_x, pos_y, pos_z, wave_speed,
     &                 blast_time, blast_energy,
     &                 blast_wave_width
c
c  Local variables
c
      integer iface, inode
      integer cur_face_id, face_topo, num_nodes
      integer num_comp_check
      double precision dist, blast_o_rad, blast_i_rad
      double precision blast_volume, blast_pressure
      integer query_error
      double precision face_center(3)
c
c  Create some static variables to hold queried
c  information.  Assume no face has more than 10
c  nodes
c
      double precision face_nodes(10)
      double precision face_coords(3, 10)
c
c  Extract the subroutine parameters
c
      call aupst_get_real_param("pos_x",pos_x,query_error)
      call aupst_get_real_param("pos_y",pos_y,query_error)
      call aupst_get_real_param("pos_z",pos_z,query_error)
      call aupst_get_real_param("wave_speed",wave_speed,
     &                          query_error)
      call aupst_get_real_param("blast_energy",
     &                          blast_energy,query_error)
      call aupst_get_real_param("blast_time",
     &                          blast_time,query_error)
      call aupst_get_real_param("blast_wave_width",
     &                  blast_wave_width, query_error)
c
c  Determine the outer radius of the blast wave
```

```
c
      blast_o_rad = (eval_time - blast_time) * wave_speed
      if(blast_o_rad .le. 0.0) return;
c
c  Determine the inner radius of the blast wave
c
      blast_i_rad = blast_o_rad - blast_wave_width
      if(blast_i_rad .le. 0.0) blast_i_rad = 0.0
c
c  Determine the total volume the blast wave occupies
c
      blast_volume = 3.1415 * (4.0/3.0) *
     &               (blast_o_rad**2 - blast_i_rad**2)
c
c  Determine the total pressure on faces inside the
c  blast wave
c
      blast_pressure = blast_energy / blast_volume
c
c  Loop over all faces in the set
c
      do iface = 1, num_faces
c
c  Extract the topology of the current face
c
        cur_face_id = faceID(iface)
        call aupst_get_face_topology(1, cur_face_id,
     &                           face_topo, query_error)
c
c  Determine the number of nodes of the current face
c
        num_nodes = mod(face_topo,100)
c
c  Extract the node ids for nodes contained in the current
c  face
c
        call aupst_get_face_nodes(1, cur_face_id,
     &                            face_nodes, query_error)
c
c  Extract the nodal coordinates of the face nodes
c
        call aupst_get_node_var(num_nodes, 3, face_nodes,
     &          face_coords, "coordinates", query_error)
c
c  Compute the centroid of the face
c
        face_center(1) = 0.0
```

```
         face_center(2) = 0.0
         face_center(3) = 0.0
         do inode = 1, num_nodes
           face_center(1) = face_center(1) +
     &                      face_coords(1,inode)
           face_center(2) = face_center(2) +
     &                      face_coords(2,inode)
           face_center(3) = face_center(3) +
     &                      face_coords(3,inode)
         enddo
         face_center(1) = face_center(1)/num_nodes
         face_center(2) = face_center(2)/num_nodes
         face_center(3) = face_center(3)/num_nodes
c
c  Determine the distance from the current face
c  to the blast center
c
         dist = sqrt((face_center(1) - pos_x)**2 +
     &               (face_center(2) - pos_y)**2 +
     &               (face_center(3) - pos_z)**2)
c
c  Apply pressure to the current face if it falls within
c  the blast wave
c
         if(dist .ge. blast_i_rad .and.
     &      dist .le. blast_o_rad) then
           pressure(1,iface) = blast_pressure
         else
           pressure(1,iface) = 0.0
         endif
       enddo
       err_code = 0
       end
```

9.4.2 Error Between a Computed and an Analytic Solution

The following code is a user subroutine to compute the error between Adagio-computed results and results from an analytic manufactured solution. This subroutine is called by a `USER OUTPUT` command block immediately prior to producing an output Exodus file. The error for the mesh is computed by taking the squared difference between the computed and analytic displacements at every node. Finally, a global sum of the error is produced along with the square root norm of the error.

This user subroutine requires a user variable, which is defined in the Adagio input file. The command block for the user variable specified in this user subroutine is as follows:

```
begin user variable conv_error
```

```
 type = global real length = 1
  global operator = sum
  initial value = 0.0
end user variable conv_error
```

The subroutine is called in the Adagio input file as follows:

```
begin user output
  node set = nodelist_10
  node set subroutine = conv0_error
  subroutine real parameter: char_length = 1.0
  subroutine real parameter: char_time   = 1.0e-3
  subroutine real parameter: x_offset    = 0.0
  subroutine real parameter: y_offset    = 0.0
  subroutine real parameter: z_offset    = 0.0
  subroutine real parameter: t_offset    = 0.0
  subroutine real parameter: u0          = 0.01
  subroutine real parameter: v0          = 0.02
  subroutine real parameter: w0          = 0.03
  subroutine real parameter: alpha       = 1.0
  subroutine real parameter: youngs_modulus = 10.0e6
  subroutine real parameter: poissons_ratio = 0.3
  subroutine real parameter: density        = 0.0002588
  subroutine real parameter: num_nodes      = 125.0
end user output
```

The FORTRAN listing for the subroutine is as follows:

```
      subroutine conv0_error(num_nodes, num_vals,
     &  eval_time, nodeID, values, flags, ierror)
      implicit none

      integer num_nodes
      integer num_vals
      double precision eval_time
      integer nodeID(num_nodes)
      double precision values(1)
      integer flags(1)
      integer ierror
c
c     Local vars
c
      integer inode
      integer error_code
      double precision clength, ctime, xoff, yoff, zoff, toff
      double precision zero, one, two, three, four, nine
```

```
      double precision mod_coords(3,3000)
      double precision cdispl(3,3000)
      integer num_comp_check
      double precision expat
      double precision x, y, z, t
      double precision u0, v0, w0, alpha
      double precision pi
      double precision half
      double precision mdisplx, mdisply, mdisplz
      double precision xdiff, ydiff, zdiff
      double precision conv_error
      double precision numnod

      pi    = 3.141592654
      half  = 0.5
      zero  = 0.0
      one   = 1.0
      two   = 2.0
      three = 3.0
      four  = 4.0
      nine  = 9.0
c
c  Check that the nodal coordinates will fit into the
c  statically allocated array
c
      if(num_nodes .gt. 3000) then
        write(6,*) ŠERROR in sphere disp, Ś,
     &  num_nodes exceeds static array sizeŠ
        ierror = 1
        return
      endif
c
c  Extract the model coordinates for all nodes
c
      call aupst_check_node_var(num_nodes, num_comp_check,
     &                          nodeID, "model_coordinates",
     &                          ierror)
      if(ierror .ne. 0) return
      if(num_comp_check .ne. 3) return
      call aupst_get_node_var(num_nodes, num_comp_check,
     &       nodeID, mod_coords, "model_coordinates",
     &       ierror)
c
c  Extract the computed displacements for all nodes
c
      call aupst_check_node_var(num_nodes, num_comp_check,
     &                          nodeID, "displacement",
```

```
     &                          ierror)
      if(ierror .ne. 0) return
      if(num_comp_check .ne. 3) return
      call aupst_get_node_var(num_nodes, num_comp_check,
     &       nodeID, cdispl, "displacement",
     &       ierror)
c
c  Extract the subroutine parameters.
c
      call aupst_get_real_param("char_length",
     &                          clength,error_code)
      call aupst_get_real_param("char_time",
     &                          ctime,error_code)
      call aupst_get_real_param("x_offset",xoff,error_code)
      call aupst_get_real_param("y_offset",yoff,error_code)
      call aupst_get_real_param("z_offset",zoff,error_code)
      call aupst_get_real_param("t_offset",toff,error_code)
      call aupst_get_real_param("u0",u0,error_code)
      call aupst_get_real_param("v0",v0,error_code)
      call aupst_get_real_param("w0",w0,error_code)
      call aupst_get_real_param("alpha",alpha,error_code)
      call aupst_get_real_param("num_nodes",
     &                          numnod,error_code)
c
c  Calculate a solution scaling factor
c
      expat = half * ( one - cos( pi * eval_time / ctime ) )
c
c  Compute the expected solution at each node and do a
c  sum of the differences from the analytic solution
c
      conv_error = zero
      do inode = 1, num_nodes
c
c  Set the displacement value from the manufactured solution
c
        x = ( mod_coords(1,inode) - xoff ) / clength
        y = ( mod_coords(2,inode) - yoff ) / clength
        z = ( mod_coords(3,inode) - zoff ) / clength
c
        mdisplx = u0 * sin(x) * cos(two*y) * cos(three*z)
     *              * expat
        mdisply = v0 * cos(three*x) * sin(y) * cos(two*z)
     *              * expat
        mdisplz = w0 * cos(two*x) * cos(three*y) * sin(z)
     *              * expat
c
```

```
          xdiff = mdisplx - cdispl(1,inode)
          ydiff = mdisply - cdispl(2,inode)
          zdiff = mdisplz - cdispl(3,inode)
          conv_error = conv_error + xdiff*xdiff
     *                            + ydiff*ydiff
     *                            + zdiff*zdiff
c
       enddo
c
       ierror = 0
c
c  Do a parallel sum of the squared errors and extract
c  the total summed value on all processors
c
       call aupst_put_global_var(1,conv_error,
     &                            "conv_error","sum",ierror)
       call aupst_get_global_var(1,conv_error,
     &                            "conv_error",ierror)
c
c  Take the square root of the errors and store that as
c  the net error norm
c
       conv_error = sqrt(conv_error) / sqrt(numnod)
       call aupst_put_global_var(1,conv_error,
     &                            "conv_error","none",ierror)
c
       return
       end
```

9.4.3 Transform Output Stresses to a Cylindrical Coordinate System

The following code is a user subroutine to transform element stresses in global x, y, and z coordinates to a global cylindrical coordinate system. This subroutine could be used to transform the relatively meaningless shell stress in x, y, and z coordinates to more meaningful tangential, hoop, and radial stresses. The subroutine is called from a `USER OUTPUT` command block. It reads in the old stresses, transforms them, and writes them back out to a user-created scratch variable, defined via a `USER VARIABLE` command block, for output.

```
begin user variable cyl_stress
  type = element sym_tensor length = 1
  initial value = 0.0 0.0 0.0 0.0 0.0 0.0
end user variable

begin user output
  block = block_1
  element block subroutine = aupst_cyl_transform
```

```
  subroutine string parameter: origin_point = Point_O
  subroutine string parameter: z_point      = Point_Z
  subroutine string parameter: xz_point     = Point_XZ
  subroutine string parameter: input_stress = memb_stress
  subroutine string parameter: output_stress = cyl_stress
end user output
```

The FORTRAN listing for the subroutine is as follows:

```
      subroutine aupst_cyl_transform(num_elems, num_vals,
     *  eval_time, elemID, values, flags, ierror)
      implicit none
#include<framewk/Fmwk_type_sizes_decl.par>
#include<framewk/Fmwk_type_sizes.par>
c
c  Subroutine Arguments
c
c  num_elems: Input: Number of elements to calculate on
c  num_vals : Input: Ignored
c  eval_time: Input: Time at which to evaluate the stress.
c  elemID   : Input: Global sierra IDs of the input elements
c  values   : I/O  : Ignored, stress will be stored manually
c  flags    : I/O  : Ignored
c  ierror   :Output: Returns non-zero if an error occurs
c
      integer num_elems
      integer num_vals
      double precision eval_time
      integer elemID(num_elems)
      double precision values(1)
      integer flags(1)
      integer ierror
c
c  Fortran cannot dynamically allocate memory, thus worksets
c  will be iterated over by  chucks each of size chunk_size.
c
      integer chunk_size
      parameter (chunk_size = 100)
      integer chunk_ids(chunk_size)
c
c  Subroutine parameter data
c
      character*80     origin_point_name
      double precision origin_point(3)
      character*80     z_point_name
      double precision z_point(3)
      character*80     xz_point_name
```

```
      double precision xz_point(3)
      character*80     input_stress_name
      character*80     output_stress_name
c
c  Local element data for centroids and rotation vectors
c
      double precision cent(3)
      double precision centerline_pos(3)
      double precision dot_prod
      double precision z_vec(3)
      double precision r_vec(3)
      double precision theta_vec(3)
      double precision rotation_tensor(9)
c
c  Chunk data storage
c
      double precision elem_centroid(3, chunk_size)
      double precision input_stress_val(6, chunk_size)
      double precision output_stress_val(6, chunk_size)
c
c  Simple iteration variables
c
      integer error_code
      integer ichunk, ielem
      integer zero_elem, nel
c
c  Extract the current subroutine parameters.  origin_point
c  is the origin of the coordinate system
c  z_point is a point on the z axis of the coordinate system
c  xz_point is a point on the xz plane
c
      call aupst_get_string_param("origin_point",
     &                            origin_point_name,
     &                            error_code)
      call aupst_get_string_param("z_point",
     &                            z_point_name,
     &                            error_code)
      call aupst_get_string_param("xz_point",
     &                            xz_point_name,
     &                            error_code)
      call aupst_get_string_param("input_stress",
     &                            input_stress_name,
     &                            error_code)
      call aupst_get_string_param("output_stress",
     &                            output_stress_name,
     &                            error_code)
c
```

```
c  Use the point names to look up the coordinates of each
c  relevant point
c
      call aupst_get_point(origin_point_name, origin_point,
     &                     error_code)
      call aupst_get_point(z_point_name, z_point,
     &                     error_code)
      call aupst_get_point(xz_point_name, xz_point,
     &                     error_code)
c
c  Compute the z axis vector
c
      z_vec(1) = z_point(1) - origin_point(1)
      z_vec(2) = z_point(2) - origin_point(2)
      z_vec(3) = z_point(3) - origin_point(3)
c
c  Transform z_vec into a unit vector, abort if it is invalid
c
      call aupst_unitize_vector(z_vec, ierror)
      if(ierror .ne. 0) return
c
c  Loop over chunks of the data arrays
c
      do ichunk = 1, (num_elems/chunk_size + 1)
c
c  Determine the first and last element number for the
c  current chunk of elements
c
       zero_elem = (ichunk-1) * chunk_size
       if((zero_elem + chunk_size) .gt. num_elems) then
        nel = num_elems - zero_elem
       else
        nel = chunk_size
       endif
c
c  Copy the elemIDs for all elems in the current chunk to a
c  temporary array
c
       do ielem = 1, nel
       chunk_ids(ielem) = elemID(zero_elem + ielem)
       enddo
c
c  Extract the element centroids and stresses
c
       call aupst_get_elem_centroid(nel, chunk_ids,
     &                              elem_centroid,
     &                              ierror)
```

```
      call aupst_get_elem_var(nel, 6, chunk_ids,
     &                        input_stress_val,
     &                        input_stress_name, ierror)
c
c  Loop over each element in the current chunk
c
      do ielem = 1, nel
c
c  Find the closest point on the cylinder centerline axis
c  to the element centroid
c
        cent(1) = elem_centroid(1, ielem) - origin_point(1)
        cent(2) = elem_centroid(2, ielem) - origin_point(2)
        cent(3) = elem_centroid(3, ielem) - origin_point(3)
        dot_prod = cent(1) * z_vec(1) +
     &             cent(2) * z_vec(2) +
     &             cent(3) * z_vec(3)
        centerline_pos(1) = z_vec(1) * dot_prod
        centerline_pos(2) = z_vec(2) * dot_prod
        centerline_pos(3) = z_vec(3) * dot_prod
c
c  Compute the current normal radial vector
c
        r_vec(1) = cent(1) - centerline_pos(1)
        r_vec(2) = cent(2) - centerline_pos(2)
        r_vec(3) = cent(3) - centerline_pos(3)
        call aupst_unitize_vector(r_vec, ierror)
        if(ierror .ne. 0) return
c
c  Compute the current hoop vector
c
        theta_vec(1) = z_vec(2)*r_vec(3) - r_vec(2)*z_vec(3)
        theta_vec(2) = z_vec(3)*r_vec(1) - r_vec(3)*z_vec(1)
        theta_vec(3) = z_vec(1)*r_vec(2) - r_vec(1)*z_vec(2)
c
c  The r, theta, and z vectors describe the new stress
c  coordinate system, Transform the input stress tensor
c  in x,y,z coords to the output stress tensor in r, theta,
c  and z coords use the unit vectors to create a rotation
c  tensor
c
        rotation_tensor(k_f36xx) = r_vec(1)
        rotation_tensor(k_f36yx) = r_vec(2)
        rotation_tensor(k_f36zx) = r_vec(3)
        rotation_tensor(k_f36xy) = theta_vec(1)
        rotation_tensor(k_f36yy) = theta_vec(2)
        rotation_tensor(k_f36zy) = theta_vec(3)
```

```
        rotation_tensor(k_f36xz) = z_vec(1)
        rotation_tensor(k_f36yz) = z_vec(2)
        rotation_tensor(k_f36zz) = z_vec(3)
c
c  Rotate the current stress tensor to the new configuration
c
        call fmth_rotate_symten33(1, 1, 0, rotation_tensor,
     &                            input_stress_val(1,ielem),
     &                           output_stress_val(1,ielem))
      enddo
c
c  Store the new stress
c
        call aupst_put_elem_var(nel, 6, chunk_ids,
     &                           output_stress_val,
     &                           output_stress_name, ierror)
      enddo
      ierror = 0
      end
```

9.5 User Subroutines: Library

A number of user subroutines are used commonly and have been permanently incorporated into the code. These subroutines are used just like any other subroutines, but they do not need to be compiled into the code. (The user need be concerned only about the Adagio command lines.) This section describes the usage of each of these subroutines.

9.5.1 aupst_cyl_transform

Author: Nathan Crane

Purpose:

The purpose of this subroutine is to transform element stresses from a global rectangular coordinate system to a local cylindrical coordinate system. This subroutine is generally called by a `USER OUTPUT` command block. For example:

```
begin user output
  block = block_1
  element block subroutine = aupst_cyl_transform
  subroutine string parameter: origin_point = Point_O
  subroutine string parameter: z_point      = Point_Z
  subroutine string parameter: xz_point     = Point_XZ
  subroutine string parameter: input_stress = memb_stress
  subroutine string parameter: output_stress = cyl_stress
end user output
```

Requirements:

This subroutine requires a tensor variable to store the cylindrical stress into a registered variable for each element. The registered variable is created by the following command block in the Adagio region:

```
begin user variable cyl_stress
   type = element sym_tensor length = 1
   initial value = 0.0 0.0 0.0 0.0 0.0 0.0
end user variable
```

Parameters:

Parameter Name	Usage	Description
origin_point	String	Name of the point at the cylinder origin.
z_point	String	Point on the cylinder axis.
xz_point	String	Point on the line that passes through theta = 0 on the cylinder.
input_stress	String	Name of the Adagio internal input stress tensor variable.
output_stress	String	Name of the Adagio internal output stress tensor variable.

9.5.2 aupst_rec_transform

Author: Daniel Hammerand

Purpose:

The purpose of this subroutine is to transform element stresses from a global rectangular coordinate system to a different local rectangular coordinate system. This subroutine is generally called by a `USER OUTPUT` command block. For example:

```
begin user output
  block = block_1
  element block subroutine = aupst_rec_transform
  subroutine string parameter: origin_point = Point_O
  subroutine string parameter: z_point      = Point_Z
  subroutine string parameter: xz_point     = Point_XZ
  subroutine string parameter: input_stress = memb_stress
  subroutine string parameter: output_stress = new_stress
end user output
```

Requirements:

This subroutine requires a tensor variable to store the new stress into a registered variable for each element. The registered variable is created by the following command block in the Adagio region:

```
begin user variable new_stress
  type = element sym_tensor length = 1
  initial value = 0.0 0.0 0.0 0.0 0.0 0.0
end user variable
```

Parameters:

Parameter Name	Usage	Description
origin_point	String	Name of the point at the cylinder origin.
z_point	String	Point on the cylinder axis.
xz_point	String	Point on the line that passes through theta = 0 on the cylinder.
input_stress	String	Name of the Adagio internal input stress tensor variable.
output_stress	String	Name of the Adagio internal output stress tensor variable.

Chapter 10

Example Problem

This chapter provides an example problem to illustrate the construction of an input file for an analysis. The problem is modeled after a pencil/eraser that is pressed against and rubbed across a tablet. The pencil, eraser and tablet are represented by blocks 1, 2 and 3 respectively. Block 4 is used to apply kinematics directly to the eraser via tied contact between block 4 and block 2. Block 1 is really superfluous except that when viewed together, blocks 1, 2 and 3 closely resemble a pencil with an eraser on a tablet. The problem demonstrates the overall structure of an input file and includes the use of both tied and frictional contact simultaneously, the multilevel solver, and a linear solver for preconditioning. A schematic of the problem is shown in Figure 10.1 and the mesh is shown in Figure 10.2.

The problem kinematics and loading are described briefly here. There are two phases of the loading: preload and sliding. In the preload phase, the tablet (block 3) is kinematically fixed in the x-y plane and a vertical load (in the z-direction) is applied to the tablet which presses the tablet against the eraser (block 2). The eraser is kinematically fixed to block 4 via tied contact (see Figure 10.2). Block 4 is held fixed in all three coordinate directions for the compression phase. The



Figure 10.1: Eraser schematic; Block 1 (yellow) is pencil, block 2 (red) is eraser, block 3 (gray) is tablet, block 4 (not shown) is tied to eraser and has the kinematics applied to it.



Figure 10.2: Complete eraser mesh

initial configuration and deformations of the preload phase are shown in the first two snapshots on the left in Figure 10.1. In the sliding phase, block 4 is kinematically prescribed to move along the x-direction, thus sliding or dragging the eraser along the tablet (see Figure 10.1) while the tablet force is held constant.

The input file is described below, with comments to explain every few lines. Following the description, the full input file is listed again. Note that all character strings in the input file are presented in lowercase, which is an acceptable format in Adagio.

The input file starts with a begin sierra statement, as is required for all input files:

```
begin sierra eraser
```

We begin by defining vectors corresponding to the coordinate axes. These vectors/directions will be used to define the input for boundary condition blocks that come later.

```
define direction X with vector 1.0 0.0 0.0
define direction Y with vector 0.0 1.0 0.0
define direction Z with vector 0.0 0.0 1.0
```

We now need to define the functions used for this problem. The boundary conditions require a function for the tablet force as well as the sliding motion. Note that both the tablet force and sliding motion are prescribed as functions of time.

```
begin definition for function slide
  type is piecewise linear
  begin values
    0.0      0.0
    1.0      0.0
    2.0      1.0
    3.0      1.0
  end values
end definition for function slide

begin definition for function tablet_force
  type is piecewise linear
  begin values
    0.0      0.0
    1.0      1.0
    3.0      1.0
  end values
end definition for function tablet_force

begin definition for function zero
  type is constant
  begin values
    0.0      0.0
  end values
end definition for function zero
```

Note that the tablet force ramps up over the time interval (0.0,1.0) and then is held constant over the interval (1.0,3.0). The sliding function is zero over the time interval (0.0,1.0) and then it linearly increases over the interval (1.0,2.0). Next, we define the material properties and models that are used in this problem. In this example, we define two sets of material properties: one is called stiff (pencil, tablet, and block 4), and the second is called soft (eraser). We use a linear elastic constitutive model for both cases.

```
begin property specification for material stiff
  density = 1.0
  begin parameters for model elastic
    youngs modulus = 1.e5
    poissons ratio = 0.3
  end parameters for model elastic
end property specification for material stiff

begin property specification for material soft
  density = 1.0
  begin parameters for model elastic
    youngs modulus = 1000.
    poissons ratio = 0.3
  end parameters for model elastic
end property specification for material soft
```

Now, we define the finite element mesh. This includes specification of the file that contains the mesh, as well as a list of all the element blocks we will use from the mesh and the material associated with each block. The name of the file is `eraser.g`. The specification of the database type is optional-ExodusII is the default. Currently, each element block must be defined individually. Note that the tablet, pencil and block 4 all reference the same material description (stiff). The material description is not repeated three times. The material description for stiff appears once and is then referenced three times.

```
begin finite element model mesh1
  database name = eraser.g
  database type = exodusII
  begin parameters for block block_1 #Pencil
    material stiff
    solid mechanics use model elastic
  end parameters for block block_1 #Pencil
  begin parameters for block block_2 #Eraser
    material soft
    solid mechanics use model elastic
  end parameters for block block_2 #Eraser
  begin parameters for block block_3 #Tablet
    material stiff
    solid mechanics use model elastic
  end parameters for block block_3 #Tablet
```

```
    begin parameters for block block_4 #dummy block
      material stiff
      solid mechanics use model elastic
    end parameters for block block_4 #dummy block
  end finite element model mesh1
```

At this point we have finished specifying physics-independent quantities. We now want to set up the Adagio procedure and region, along with the time control command block. We start by defining the beginning of the procedure scope, the time control command block, and the beginning of the region scope. Three time stepping command blocks are used in this analysis. The termination time is set to 1.8. Having multiple time blocks is useful because we can make some solver options a function of the time block.

```
  begin adagio procedure agio_procedure
    begin time control
      begin time stepping block preload
        start time = 0.0
        begin parameters for adagio region adagio
          number of time steps = 5
        end parameters for adagio region adagio
      end time stepping block preload
      begin time stepping block slide_1
        start time = 1.0
        begin parameters for adagio region adagio
          number of time steps = 1
        end parameters for adagio region adagio
      end time stepping block slide_1
      begin time stepping block slide_2
        start time = 1.1
        begin parameters for adagio region adagio
          number of time steps = 7
        end parameters for adagio region adagio
      end time stepping block slide_2
      termination time = 1.8
    end time control

    begin adagio region agio_region
```

Next we associate the finite element model we defined above (`mesh1`) with this Adagio region.

```
      use finite element model mesh1
```

Now we define the kinematic boundary conditions. First, we prescribe the displacement of surface_200 which is part of block 4. We fix this surface in both the x and z directions and prescribe the horizontal displacement along the X-direction using the previously defined functions `zero` and `slide`.

```
### movement of pencil prescribed by block 4
begin prescribed displacement
  surface = surface_200
  direction = X
  function = slide
  scale factor = 3.0
end prescribed displacement
begin fixed displacement
  surface = surface_200
  components = Y Z
end fixed displacement
```

Next, we fix the tablet and prevent it from moving in the X-Y plane. We do this on all tablet nodes (nodelist_111 and nodelist_112).

```
### Constraints on tablet
begin fixed displacement
  node set = nodelist_111
  components = X Y
end fixed displacement
begin fixed displacement
  node set = nodelist_112
  components = X Y
end fixed displacement
```

Finally, we prescribe preload force on the tablet which compresses the tablet against the eraser.

```
### Tablet force
begin prescribed force
  node set = nodelist_111
  direction = Z
  function = tablet_force
  scale factor = 100.0
end prescribed force
```

We now define the contact for this problem. Here we need to define tied contact between block 4 and the eraser. In addition, we have frictional sliding contact between the tablet and the eraser. Two contact block definitions are required; one for the tied contact and one for the frictional contact. The first contact block definition is used for the tied contact between block 4 and the eraser, and the second block is used to define the frictional sliding contact between the eraser and the tablet.

```
### block 4 tied to eraser ###
begin contact definition
  enforcement = tied
  contact surface surf_200 contains surface_200
```

```
  contact surface surf_110 contains surface_110
  begin interaction
    master = surf_200
    slave = surf_110
    normal tolerance = 1.0
    tangential tolerance = 0.5e-3
  end interaction
end contact definition

begin contact definition
  enforcement = frictional
  contact surface surf_11 contains surface_11
  contact surface surf_10 contains surface_10
  begin interaction
    master = surf_11
    slave = surf_10
    normal tolerance = 1.0
    tangential tolerance = 0.5e-3
    capture tolerance = 1.0e-2
    friction coefficient = 0.8
  end interaction
end contact definition
```

Now we define what variables we want in the output file, as well as how often we want the output file to be written. The output file will be called eraser.e, and it will be an ExodusII file (the database type command is optional; it defaults to ExodusII). The variables we are requesting are the displacements, velocities, and contact diagnostics at the nodes, and stresses and strains at the elements.

```
begin results output output_adagio
  database name = eraser.e
  database type = exodusII
  at step 0, increment = 1
  nodal variables = displacement as displ
  nodal variables = velocity as vel
  nodal variables = contact_tangential_direction
  nodal variables = contact_normal_direction
  nodal variables = contact_slip_direction_current
  nodal variables = contact_status
  nodal variables = contact_normal_traction_magnitude
  nodal variables = contact_tangential_traction_magnitude
  nodal variables = contact_slip_increment_current
  nodal variables = contact_accumulated_slip
  nodal variables = contact_frictional_energy_density
  nodal variables = contact_area
  element variables = rotated_stress as stress
  element variables = log_strain as strain
```

```
end results output output_adagio
```

The final part of the input deck is the Adagio solver commands. Because we have sliding contact, we must use the multilevel solver command block. Nested inside the multilevel solver block we define the control contact block as well as the nonlinear cg solver block.

```
begin multilevel solver
  begin control sliding contact name
    target relative residual = 0.001
    maximum iterations = 2000
  end control sliding contact name
  begin cg
    target residual tolerance = 0.001
    maximum iterations = 2000
    minimum iterations = 1
    orthogonality measure for reset = 0.5
    line search type secant
    begin full tangent preconditioner
      linear solver = feti
      maximum iterations = 20
      constraint enforcement = penalty
      reset constraint threshold = 0.001
      nodal preconditioner method = elastic
    end full tangent preconditioner
  end cg
end multilevel solver
```

Now we have defined the Adagio region and procedure blocks and so we close them using the following lines:

```
  end adagio region agio_region
end adagio procedure agio_procedure
```

The final thing that we need to define for this file is the linear solver. In the above solver command block, we included the `full tangent preconditioner` block, which has a nested command line `linear solver = feti`. This command line refers to a linear solver called `feti` that must be defined outside the "Procedure" scope but within the "Sierra" scope and can come at the top of the file prior to the "Procedure" definition or after it as is the case here. The input `feti` on this line command is a user defined string that can have any useful label. The following command block defines the linear solver labeled `feti`. Note that the command block has the label `feti` at the end of the `Begin` line and that this label is referred to from within the above `full tangent preconditioner` command block. The FETI parameters are all set to reasonable values for most problems, so there is no need to set any of them, but if it were necessary to set any of them to non-default values, that would be done within the `feti equation solver` block.

```
  begin feti equation solver feti
  end feti equation solver feti
```

Finally, we finish the input file and close the sierra command block:

```
end sierra eraser
```

Chapter 11

Command Summary

This chapter gives all of the Adagio commands in the proper scope.

```
# Domain specification
BEGIN SIERRA <string>name

  # Title

    TITLE = <string list>title

  # Restart time

    RESTART TIME = <real>restart_time
    RESTART = AUTOMATIC

  # User subroutine file

  USER SUBROUTINE FILE = <string>file name

  # Function definition

  BEGIN DEFINITION FOR FUNCTION <string>function_name
    TYPE = <string>CONSTANT|PIECEWISE LINEAR|
      ANALYTIC
    ABSCISSA = <string>abscissa_label
    ORDINATE = <string>ordinate_label
    BEGIN VALUES
      <real>value_1   [<real>value_2
      <real>value_3    <real>value_4
      ...              <real>value_n]
    END [VALUES]
    EVALUATE EXPRESSION = <string>analytic_expression1;
      analytic_expression2;...
  END [DEFINITION FOR FUNCTION <string>function_name]
```

```
# Definitions

DEFINE POINT <string>point_name WITH COORDINATES
  <real>value_1 <real>value_2 <real>value_3

DEFINE DIRECTION <string>direction_name WITH VECTOR
  <real>value_1 <real>value_2 <real>value_3

DEFINE AXIS <string>axis_name WITH POINT
  <string>point_1 POINT <string>point_2

DEFINE AXIS <string>axis_name WITH POINT
  <string>point_name DIRECTION <string>direction

# Local coordinate system

BEGIN ORIENTATION <string>orientation_name
  SYSTEM = <string>RECTANGULAR|Z RECTANGULAR|CYLINDRICAL|
    SPHERICAL(RECTANGULAR)
  #
  POINT A = <real>global_ax <real>global_ay <real>global_az
  POINT B = <real>global_bx <real>global_by <real>global_bz
  #
  ROTATION ABOUT <integer> 1|2|3(1) = <real>theta(0.0)
END [ORIENTATION <string>orientation_name]

# Rigid bodies

BEGIN RIGID BODY <string>rb_name
  MASS = <real>mass
  MASS LOCATION = <real>CGx <real>CGy <real>CGz
  INERTIA = <real>Ixx <real>Iyy <real>Izz <real>Ixy
    <real>Iyz <real>Izx
  POINT INERTIA = <real>Ixx <real>Iyy <real>Izz <real>Ixy
    <real>Iyz <real>Izx
  MAGNITUDE = <real>magnitude_of_velocity
  DIRECTION = <string>direction_definition
  ANGULAR VELOCITY = <real>omega
  CYLINDRICAL AXIS = <string>axis_definition
END [RIGID BODY <string>rb_name]

# Elastic material

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
```

```
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
  END [PARAMETERS FOR MODEL ELASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic fracture material

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC_FRACTURE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    MAX STRESS = <real>max_stress
    CRITICAL STRAIN = <real>critical_strain
  END [PARAMETERS FOR MODEL ELASTIC_FRACTURE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic-plastic material
```

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ELASTIC_PLASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING MODULUS = <real>hardening_modulus
    BETA = <real>beta_parameter(1.0)
  END [PARAMETERS FOR MODEL ELASTIC_PLASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic-plastic power-law hardening

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL EP_POWER_HARD
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
```

```
    HARDENING CONSTANT = <real>hardening_constant
    HARDENING EXPONENT = <real>hardening_exponent
    LUDERS STRAIN = <real>luders_strain
  END [PARAMETERS FOR MODEL EP_POWER_HARD]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic plastic power-law hardening with failure

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL DUCTILE_FRACTURE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    HARDENING CONSTANT = <real>hardening_constant
    HARDENING EXPONENT = <real>hardening_exponent
    LUDERS STRAIN <real>luders_strain
    CRITICAL TEARING PARAMETER = <real>crit_tearing
    CRITICAL CRACK OPENING STRAIN = <real>crit_crack
  END [PARAMETERS FOR MODEL DUCTILE_FRACTURE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Multilinear elastic plastic power-law hardening

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
```

```
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL MULTILINEAR_EP
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    BETA = <real>beta_parameter(1.0)
    HARDENING FUNCTION = <real>hardening_function_name
    YOUNGS MODULUS FUNCTION = <real>ym_function_name
    POISSONS RATIO FUNCTION = <real>pr_function_name
    YIELD STRESS FUNCTION =
      <real>yield_stress_function_name
  END [PARAMETERS FOR MODEL MULTILINEAR_EP]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Multilinear elastic plaster power-law hardening with
# failure

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ML_EP_FAIL
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    BETA = <real>beta_parameter(1.0)
    HARDENING FUNCTION = <real>hardening_function_name
    YOUNGS MODULUS FUNCTION = <real>ym_function_name
    POISSONS RATIO FUNCTION = <real>pr_function_name
```

```
    YIELD STRESS FUNCTION =
      <real>yield_stress_function_name
    CRITICAL TEARING PARAMETER = <real>crit_tearing
    CRITICAL CRACK OPENING STRAIN = <real>crit_crack
  END [PARAMETERS FOR MODEL ML_EP_FAIL]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# BCJ plasticity

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL BCJ
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    C1 = <real>c1
    C2 = <real>c2
    C3 = <real>c3
    C4 = <real>c4
    C5 = <real>c5
    C6 = <real>c6
    C7 = <real>c7
    C8 = <real>c8
    C9 = <real>c9
    C10 = <real>c10
    C11 = <real>c11
    C12 = <real>c12
    C13 = <real>c13
    C14 = <real>c14
    C15 = <real>c15
    C16 = <real>c16
    C17 = <real>c17
    C18 = <real>c18
    C19 = <real>c19
```

```
    C20 = <real>c20
    DAMAGE EXPONENT = <real>damage_exponent
    INITIAL ALPHA_XX = <real>alpha_xx
    INITIAL ALPHA_YY = <real>alpha_yy
    INITIAL ALPHA_ZZ = <real>alpha_zz
    INITIAL ALPHA_XY = <real>alpha_xy
    INITIAL ALPHA_YZ = <real>alpha_yz
    INITIAL ALPHA_XZ = <real>alpha_xz
    INITIAL KAPPA = <real>initial_kappa
    INITIAL DAMAGE = <real>initial_damage
    YOUNGS MODULUS FUNCTION = <string>ym_function_name
    POISSONS RATIO FUNCTION = <string>pr_function_name
    SPECIFIC HEAT = <real>specific_heat
    THETA OPT = <integer>theta_opt
    FACTOR = <real>factor
    RHO = <real>rho
    TEMP0 = <real>temp0
  END [PARAMETERS FOR MODEL BCJ]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Soil and crushable foam

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL SOIL_FOAM
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    A0 = <real>const_coeff_yieldsurf
    A1 = <real>lin_coeff_yieldsurf
    A2 = <real>quad_coeff_yieldsurf
    PRESSURE CUTOFF = <real>pressure_cutoff
    PRESSURE FUNCTION = <string>function_press_volstrain
  END [PARAMETERS FOR MODEL SOIL_FOAM]
```

```
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name

# Foam plasticity

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL FOAM_PLASTICITY
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    PHI = <real>phi
    SHEAR STRENGTH  = <real>shear_strength
    SHEAR HARDENING = <real>shear_hardening
    SHEAR EXPONENT  = <real>shear_exponent
    HYDRO STRENGTH  = <real>hydro_strength
    HYDRO HARDENING = <real>hydro_hardening
    HYDRO EXPONENT  = <real>hydro_exponent
    BETA = <real>beta
  END [PARAMETERS FOR MODEL FOAM_PLASTICITY]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic three-dimensional orthotropic
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  BEGIN PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC
    YOUNGS MODULUS AA = <real>Eaa_value
    YOUNGS MODULUS BB = <real>Ebb_value
    YOUNGS MODULUS CC = <real>Ecc_value
    POISSONS RATIO AB = <real>NUab_value
    POISSONS RATIO BC = <real>NUbc_value
    POISSONS RATIO CA = <real>NUca_value
    SHEAR MODULUS AB = <real>Gab_value
    SHEAR MODULUS BC = <real>Gbc_value
    SHEAR MODULUS CA = <real>Gca_value
```

```
    COORDINATE SYSTEM = <string>coordinate_system_name
    DIRECTION FOR ROTATION = <real>1|2|3
    ALPHA = <real>alpha_in_degrees
    SECOND DIRECTION FOR ROTATION = <real>1|2|3
    SECOND ALPHA = <real>second_alpha_in_degrees
    THERMAL STRAIN AA FUNCTION = <string>ethaa_function_name
    THERMAL STRAIN BB FUNCTION = <string>ethbb_function_name
    THERMAL STRAIN CC FUNCTION = <string>ethcc_function_name
  END [PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Orthotropic crush

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    EX  = <real>modulus_x
    EY  = <real>modulus_y
    EZ  = <real>modulus_z
    GXY = <real>shear_modulus_xy
    GYZ = <real>shear_modulus_yz
    GZX = <real>shear_modulus_zx
    VMIN = <real>min_crush_volume
    CRUSH XX = <string>stress_volume_xx_function_name
    CRUSH YY = <string>stress_volume_yy_function_name
    CRUSH ZZ = <string>stress_volume_zz_function_name
    CRUSH XY =
      <string>shear_stress_volume_xy_function_name
    CRUSH YZ =
      <string>shear_stress_volume_yz_function_name
```

```
    CRUSH ZX =
      <string>shear_stress_volume_zx_function_name
  END [PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Orthotropic rate

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL ORTHOTROPIC_RATE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    YIELD STRESS = <real>yield_stress
    MODULUS TTTT = <real>modulus_tttt
    MODULUS TTLL = <real>modulus_ttll
    MODULUS TTWW = <real>modulus_ttww
    MODULUS LLLL = <real>modulus_llll
    MODULUS LLWW = <real>modulus_llww
    MODULUS WWWW = <real>modulus_wwww
    MODULUS TLTL = <real>modulus_tltl
    MODULUS LWLW = <real>modulus_lwlw
    MODULUS WTWT = <real>modulus_wtwt
    TX = <real>tx
    TY = <real>ty
    TZ = <real>tz
    LX = <real>lx
    LY = <real>ly
    LZ = <real>lz
    MODULUS FUNCTION = <string>modulus_function_name
    RATE FUNCTION = <string>rate_function_name
    T FUNCTION = <string>t_function_name
    L FUNCTION = <string>l_function_name
    W FUNCTION = <string>w_function_name
```

```
    TL FUNCTION = <string>tl_function_name
    LW FUNCTION = <string>lw_function_name
    WT FUNCTION = <string>wt_function_name
  END [PARAMETERS FOR MODEL ORTHOTROPIC_RATE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Elastic laminate

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  BEGIN PARAMETERS FOR MODEL ELASTIC_LAMINATE
    A11 = <real>a11_value
    A12 = <real>a12_value
    A16 = <real>a16_value
    A22 = <real>a22_value
    A26 = <real>a26_value
    A66 = <real>a66_value
    A44 = <real>a44_value
    A45 = <real>a45_value
    A55 = <real>a55_value
    B11 = <real>b11_value
    B12 = <real>b12_value
    B16 = <real>b16_value
    B22 = <real>b22_value
    B26 = <real>b26_value
    B66 = <real>b66_value
    D11 = <real>d11_value
    D12 = <real>d12_value
    D16 = <real>d16_value
    D22 = <real>d22_value
    D26 = <real>d26_value
    D66 = <real>d66_value
    COORDINATE SYSTEM = <string>coord_sys_name
    DIRECTION FOR ROTATION = 1|2|3
    ALPHA = <real>alpha_value_in_degrees
    THETA = <real>theta_value_in_degrees
    NTH11 FUNCTION = <string>nth11_function_name
    NTH22 FUNCTION = <string>nth22_function_name
    NTH12 FUNCTION = <string>nth12_function_name
    MTH11 FUNCTION = <string>mth11_function_name
    MTH22 FUNCTION = <string>mth22_function_name
    MTH12 FUNCTION = <string>mth12_function_name
  END [PARAMETERS FOR MODEL ELASTIC_LAMINATE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Fiber membrane
```

```
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL FIBER_MEMBRANE
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    SHEAR MODULUS = <real>shear_modulus
    BULK MODULUS = <real>bulk_modulus
    LAMBDA = <real>lambda
    CORD DENSITY = <real>cord_density
    CORD DIAMETER = <real>cord_diameter
    MATRIX DENSITY = <real>matrix_density
    TENSILE TEST FUNCTION = <string>test_function_name
    PERCENT CONTINUUM = <real>percent_continuum
    EPL = <real>epl
    AXIS X = <real>axis_x
    AXIS Y = <real>axis_y
    AXIS Z = <real>axis_z
    MODEL = <string>RECTANGULAR
    STIFFNESS SCALE = <real>stiffness_scale
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL FIBER_MEMBRANE]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Incompressible solid

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
```

```
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    K SCALING = <real>k_scaling
    2G SCALING = <real>2g_scaling
    TARGET E = <real>target_e
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
    SCALING FUNCTION = <string>scaling_function_name
  END [PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Mooney Rivlin

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL MOONEY_RIVLIN
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    C10 = <real>c10
    C01 = <real>c01
    C10 FUNCTION = <string>c10_function_name
    C01 FUNCTION = <string>c01_function_name
    BULK FUNCTION = <string>bulk_function_name
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL MOONEY_RIVLIN]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# NVLE 3D Orthotropic

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL NLVE_3D_ORTHOTROPIC
```

```
YOUNGS MODULUS = <real>youngs_modulus
POISSONS RATIO = <real>poissons_ratio
SHEAR MODULUS = <real>shear_modulus
BULK MODULUS = <real>bulk_modulus
LAMBDA = <real>lambda
COORDINATE SYSTEM = <string>coordinate_system_name
DIRECTION FOR ROTATION = <real>1|2|3
ALPHA = <real>alpha_in_degrees
SECOND DIRECTION FOR ROTATION = <real>1|2|3
SECOND ALPHA = <real>second_alpha_in_degrees
FICTITIOUS LOGA FUNCTION = <string>fict_loga_function_name
FICTITIOUS LOGA SCALE FACTOR = <real>fict_loga_scale_factor
# In each of the five ``PRONY'' command lines and in
# the RELAX TIME command line, the value of i can be from
# 1 through 30
1PSI PRONY <integer>i = <real>psi1_i
2PSI PRONY <integer>i = <real>psi2_i
3PSI PRONY <integer>i = <real>psi3_i
4PSI PRONY <integer>i = <real>psi4_i
5PSI PRONY <integer>i = <real>psi5_i
RELAX TIME <integer>i = <real>tau_i
REFERENCE TEMP = <real>tref
REFERENCE DENSITY = <real>rhoref
WLF C1 = <real>wlf_c1
WLF C2 = <real>wlf_c2
B SHIFT CONSTANT = <real>b_shift
SHIFT REF VALUE = <real>shift_ref
WWBETA 1PSI = <real>wwb_1psi
WWTAU 1PSI = <real>wwt_1psi
WWBETA 2PSI = <real>wwb_2psi
WWTAU 2PSI = <real>wwt_2psi
WWBETA 3PSI = <real>wwb_3psi
WWTAU 3PSI = <real>wwt_3psi
WWBETA 4PSI = <real>wwb_4psi
WWTAU 4PSI = <real>wwt_4psi
WWBETA 5PSI = <real>wwb_5psi
WWTAU 5PSI = <real>wwt_5psi
DOUBLE INTEG FACTOR = <real>dble_int_fac
REF RUBBERY HCAPACITY = <real>hcapr
REF GLASSY HCAPACITY = <real>hcapg
GLASS TRANSITION TEM = <real>tg
REF GLASSY C11 = <real>c11g
REF RUBBERY C11 = <real>c11r
REF GLASSY C22 = <real>c22g
REF RUBBERY C22 = <real>c22r
REF GLASSY C33 = <real>c33g
REF RUBBERY C33 = <real>c33r
```

```
REF GLASSY C12 = <real>c12g
REF RUBBERY C12 = <real>c12r
REF GLASSY C13 = <real>c13g
REF RUBBERY C13 = <real>c13r
REF GLASSY C23 = <real>c23g
REF RUBBERY C23 = <real>c23r
REF GLASSY C44 = <real>c44g
REF RUBBERY C44 = <real>c44r
REF GLASSY C55 = <real>c55g
REF RUBBERY C55 = <real>c55r
REF GLASSY C66 = <real>c66g
REF RUBBERY C66 = <real>c66r
REF GLASSY CTE1 = <real>cte1g
REF RUBBERY CTE1 = <real>cte1r
REF GLASSY CTE2 = <real>cte2g
REF RUBBERY CTE2 = <real>cte2r
REF GLASSY CTE3 = <real>cte3g
REF RUBBERY CTE3 = <real>cte3r
LINEAR VISCO TEST = <real>lvt
T DERIV GLASSY C11 = <real>dc11gdT
T DERIV RUBBERY C11 = <real>dc11rdT
T DERIV GLASSY C22 = <real>dc22gdT
T DERIV RUBBERY C22 = <real>dc22rdT
T DERIV GLASSY C33 = <real>dc33gdT
T DERIV RUBBERY C33 = <real>dc33rdT
T DERIV GLASSY C12 = <real>dc12gdT
T DERIV RUBBERY C12 = <real>dc12rdT
T DERIV GLASSY C13 = <real>dc13gdT
T DERIV RUBBERY C13 = <real>dc13rdT
T DERIV GLASSY C23 = <real>dc23gdT
T DERIV RUBBERY C23 = <real>dc23rdT
T DERIV GLASSY C44 = <real>dc44gdT
T DERIV RUBBERY C44 = <real>dc44rdT
T DERIV GLASSY C55 = <real>dc55gdT
T DERIV RUBBERY C55 = <real>dc55rdT
T DERIV GLASSY C66 = <real>dc66gdT
T DERIV RUBBERY C66 = <real>dc66rdT
T DERIV GLASSY CTE1 = <real>dcte1gdT
T DERIV RUBBERY CTE1 = <real>dcte1rdT
T DERIV GLASSY CTE2 = <real>dcte2gdT
T DERIV RUBBERY CTE2 = <real>dcte2rdT
T DERIV GLASSY CTE3 = <real>dcte3gdT
T DERIV RUBBERY CTE3 = <real>dcte3rdT
T DERIV GLASSY HCAPACITY = <real>dhcapgdT
T DERIV RUBBERY HCAPACITY = <real>dhcaprdT
REF PSIC = <real>psic_ref
T DERIV PSIC = <real>dpsicdT
```

```
T 2DERIV PSIC = <real>d2psicdT2
PSI EQ 2T = <real>psitt
PSI EQ 3T = <real>psittt
PSI EQ 4T = <real>psitttt
PSI EQ XX 11 = <real>psiXX11
PSI EQ XX 22 = <real>psiXX22
PSI EQ XX 33 = <real>psiXX33
PSI EQ XX 12 = <real>psiXX12
PSI EQ XX 13 = <real>psiXX13
PSI EQ XX 23 = <real>psiXX23
PSI EQ XX 44 = <real>psiXX44
PSI EQ XX 55 = <real>psiXX55
PSI EQ XX 66 = <real>psiXX66
PSI EQ XXT 11 = <real>psiXXT11
PSI EQ XXT 22 = <real>psiXXT22
PSI EQ XXT 33 = <real>psiXXT33
PSI EQ XXT 12 = <real>psiXXT12
PSI EQ XXT 13 = <real>psiXXT13
PSI EQ XXT 23 = <real>psiXXT23
PSI EQ XXT 44 = <real>psiXXT44
PSI EQ XXT 55 = <real>psiXXT55
PSI EQ XXT 66 = <real>psiXXT66
PSI EQ XT 1 = <real>psiXT1
PSI EQ XT 2 = <real>psiXT2
PSI EQ XT 3 = <real>psiXT3
PSI EQ XTT 1 = <real>psiXTT1
PSI EQ XTT 2 = <real>psiXTT2
PSI EQ XTT 3 = <real>psiXTT3
REF PSIA 11 = <real>psiA11
REF PSIA 22 = <real>psiA22
REF PSIA 33 = <real>psiA33
REF PSIA 12 = <real>psiA12
REF PSIA 13 = <real>psiA13
REF PSIA 23 = <real>psiA23
REF PSIA 44 = <real>psiA44
REF PSIA 55 = <real>psiA55
REF PSIA 66 = <real>psiA66
T DERIV PSIA 11 = <real>dpsiA11dT
T DERIV PSIA 22 = <real>dpsiA22dT
T DERIV PSIA 33 = <real>dpsiA33dT
T DERIV PSIA 12 = <real>dpsiA12dT
T DERIV PSIA 13 = <real>dpsiA13dT
T DERIV PSIA 23 = <real>dpsiA23dT
T DERIV PSIA 44 = <real>dpsiA44dT
T DERIV PSIA 55 = <real>dpsiA55dT
T DERIV PSIA 66 = <real>dpsiA66dT
REF PSIB 1 = <real>psiB1
```

```
    REF PSIB 2 = <real>psiB2
    REF PSIB 3 = <real>psiB3
    T DERIV PSIB 1 = <real>dpsiB1dT
    T DERIV PSIB 2 = <real>dpsiB2dT
    T DERIV PSIB 3 = <real>dpsiB3dT
    PSI POT TT = <real>psipotTT
    PSI POT TTT = <real>psipotTTT
    PSI POT TTTT = <real>psipotTTTT
    PSI POT XT 1 = <real>psipotXT1
    PSI POT XT 2 = <real>psipotXT2
    PSI POT XT 3 = <real>psipotXT3
    PSI POT XTT 1 = <real>psipotXTT1
    PSI POT XTT 2 = <real>psipotXTT2
    PSI POT XTT 3 = <real>psipotXTT3
    PSI POT XXT 11 = <real>psipotXXT11
    PSI POT XXT 22 = <real>psipotXXT22
    PSI POT XXT 33 = <real>psipotXXT33
    PSI POT XXT 12 = <real>psipotXXT12
    PSI POT XXT 13 = <real>psipotXXT13
    PSI POT XXT 23 = <real>psipotXXT23
    PSI POT XXT 44 = <real>psipotXXT44
    PSI POT XXT 55 = <real>psipotXXT55
    PSI POT XXT 66 = <real>psipotXXT66
  END [PARAMETERS FOR MODEL NLVE_3D_ORTHOTROPIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Stiff elastic

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  # {thermal strain option}
  THERMAL STRAIN FUNCTION = <string>thermal_strain_function
  # or all three of the following
  THERMAL STRAIN X FUNCTION =
    <string>thermal_strain_x_function
  THERMAL STRAIN Y FUNCTION =
    <string>thermal_strain_y_function
  THERMAL STRAIN Z FUNCTION =
    <string>thermal_strain_z_function
  #
  BEGIN PARAMETERS FOR MODEL STIFF_ELASTIC
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
```

```
    SCALE FACTOR = <real>scale_factor
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL STIFF_ELASTIC]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Swanson

BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL SWANSON
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    A1 = <real>a1
    P1 = <real>p1
    B1 = <real>b1
    Q1 = <real>q1
    C1 = <real>c1
    R1 = <real>r1
    CUT OFF STRAIN = <real>ecut
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL SWANSON]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Viscoelastic Swanson
BEGIN PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name
  DENSITY = <real>density_value
  #
  BEGIN PARAMETERS FOR MODEL VISCOELASTIC_SWANSON
    YOUNGS MODULUS = <real>youngs_modulus
    POISSONS RATIO = <real>poissons_ratio
    BULK MODULUS = <real>bulk_modulus
    SHEAR MODULUS = <real>shear_modulus
    LAMBDA = <real>lambda
    A1 = <real>a1
    P1 = <real>p1
    B1 = <real>b1
    Q1 = <real>q1
    C1 = <real>c1
    R1 = <real>r1
```

```
    CUT OFF STRAIN = <real>ecut
    THERMAL EXPANSION FUNCTION = <string>eth_function_name
    PRONY SHEAR INFINITY = <real>ginf
    PRONY SHEAR 1 = <real>g1
    PRONY SHEAR 2 = <real>g2
    PRONY SHEAR 3 = <real>g3
    PRONY SHEAR 4 = <real>g4
    PRONY SHEAR 5 = <real>g5
    PRONY SHEAR 6 = <real>g6
    PRONY SHEAR 7 = <real>g7
    PRONY SHEAR 8 = <real>g8
    PRONY SHEAR 9 = <real>g9
    PRONY SHEAR 10 = <real>g10
    SHEAR RELAX TIME 1 = <real>tau1
    SHEAR RELAX TIME 2 = <real>tau2
    SHEAR RELAX TIME 3 = <real>tau3
    SHEAR RELAX TIME 4 = <real>tau4
    SHEAR RELAX TIME 5 = <real>tau5
    SHEAR RELAX TIME 6 = <real>tau6
    SHEAR RELAX TIME 7 = <real>tau7
    SHEAR RELAX TIME 8 = <real>tau8
    SHEAR RELAX TIME 9 = <real>tau9
    SHEAR RELAX TIME 10 = <real>tau10
    WLF COEF C1 = <real>wlf_c1
    WLF COEF C2 = <real>wlf_c2
    WLF TREF = <real>wlf_tref
    NUMERICAL SHIFT FUNCTION = <string>ns_function_name
    TARGET E = <real>target_e
    TARGET E FUNCTION = <string>etar_function_name
    MAX POISSONS RATIO = <real>max_poissons_ratio
    REFERENCE STRAIN = <real>reference_strain
  END [PARAMETERS FOR MODEL VISCOELASTIC_SWANSON]
END [PROPERTY SPECIFICATION FOR MATERIAL <string>mat_name]

# Define mesh

BEGIN FINITE ELEMENT MODEL <string>mesh_descriptor
  DATABASE NAME = <string>mesh_file_name
  DATABASE TYPE = <string>database_type(exodusII)
  ALIAS <string>mesh_identifier AS <string>user_name
  OMIT BLOCK <string>block_list
  COMPONENT SEPARATOR CHARACTER = <string>separator
  BEGIN PARAMETERS FOR BLOCK <string list>block_names
    MATERIAL <string>material_name
    SOLID MECHANICS USE MODEL <string>model_name
    SECTION = <string>section_id
    HOURGLASS STIFFNESS =
```

```
      <real>hour_glass_stiff_value(solid = 0.05,
      shell/membrane = 0.0)
    HOURGLASS VISCOSITY =
      <real>hour_glass_visc_value(solid = 0.0,
      shell/membrane = 0.0)
    EFFECTIVE MODULI MODEL = <string>PRESTO|PRONTO|
      CURRENT|ELASTIC(PRONTO)
    ELEMENT NUMERICAL FORMULATION = <string>OLD|NEW(OLD)
    ACTIVE FOR PROCEDURE <string>proc_name DURING PERIODS
      <string list>period_names
  END [PARAMETERS FOR BLOCK <string list>block_names]
END [FINITE ELEMENT MODEL <string>mesh_descriptor]

# Element sections

BEGIN SOLID SECTION <string>solid_section_name
  FORMULATION = <string>MEAN_QUADRATURE|
    SELECTIVE_DEVIATORIC(MEAN QUADRATURE)
  DEVIATORIC PARAMETER = <real>deviatoric_param
  STRAIN INCREMENTATION = <string>MIDPOINT_INCREMENT|
    STRONGLY_OBJECTIVE|NODE_BASED(MIDPOINT_INCREMENT)
  NODE BASED ALPHA FACTOR =
    <real>bulk_stress_weight(0.01)
  NODE BASED BETA FACTOR =
    <real>shear stress_weight(0.35)
  RIGID BODY = <string>rigid_body_name
END [SOLID SECTION <string>solid_section_name]

BEGIN SHELL SECTION <string>shell_section_name
  THICKNESS = <real>shell_thickness
  THICKNESS MESH VARIABLE =
    <string>THICKNESS|<string>var_name
  THICKNESS TIME STEP = <real>time_value
  THICKNESS SCALE FACTOR = <real>thick_scale_factor(1.0)
  INTEGRATION RULE = TRAPEZOID|GAUSS|LOBATTO|SIMPSONS|
    USER(TRAPEZOID)
  NUMBER OF INTEGRATION POINTS =
    <integer>num_int_points(5)
  BEGIN USER INTEGRATION RULE
    <real>location_1 <real>weight_1
    <real>location_2 <real>weight_2
    .
    .
    <real>location_n <real>weight_n
  END [USER INTEGRATION RULE]
  LOFTING FACTOR = <real>lofting_factor(0.5)
  ORIENTATION = <string>orientation_name
```

```
  RIGID BODY = <string>rigid_body_name
END [SHELL SECTION <string>shell_section_name]

BEGIN MEMBRANE SECTION <string>membrane_section_name
  THICKNESS = <real>mem_thickness
  THICKNESS MESH VARIABLE =
    <string>THICKNESS|<string>var_name
  THICKNESS TIME STEP = <real>time_value
  THICKNESS SCALE FACTOR = <real>thick_scale_factor(1.0)
  FORMULATION = <string>MEAN_QUADRATURE|
    SELECTIVE_DEVIATORIC(MEAN QUADRATURE)
  DEVIATORIC PARAMETER = <real>deviatoric_param
  LOFTING FACTOR = <real>lofting_factor(0.5)
  RIGID BODY = <string>rigid_body_name
END [MEMBRANE SECTION <string>membrane_section_name]

BEGIN TRUSS SECTION <string>truss_section_name
  AREA = <real>cross_sectional_area
  INITIAL LOAD = <real>initial_load
  PERIOD = <real>period
  RIGID BODY = <string>rigid_body_name
END [TRUSS SECTION <string>truss_section_name]

# Output scheduler

BEGIN OUTPUT SCHEDULER <string>scheduler_name
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
 END [OUTPUT SCHEDULER <string>scheduler_name]

# FETI equation solver

BEGIN FETI EQUATION SOLVER <string>name
  #
  # convergence commands
  MAXIMUM ITERATIONS = <integer>max_iter(500)
  RESIDUAL NORM TOLERANCE = <real>resid_tol(1.0e-6)
  #
```

```
  # memory usage commands
  PARAM-STRING "precision" VALUE <string>"single"|"double"
    ("double")
  PRECONDITIONING METHOD = NONE|LUMPED|DIRICHLET(DIRICHLET)
  MAXIMUM ORTHOGONALIZATION = <integer>max_orthog(500)
  #
  # solver commands
  LOCAL SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
  NUM LOCAL SUBDOMAINS = <integer>num_local_subdomains
  COARSE SOLVER = SKYLINE|SPARSE|ITERATIVE(SPARSE)
END [ FETI EQUATION SOLVER <string>name]


# Begin Procedure scope
BEGIN ADAGIO PROCEDURE <string>adagio_procedure_name

  # Time block

  BEGIN TIME CONTROL
    BEGIN TIME STEPPING BLOCK <string>time_block_name
      START TIME = <real>start_time_value
      BEGIN PARAMETERS FOR ADAGIO REGION
        <string>region_name
        TIME INCREMENT = <real>time_increment_value
        NUMBER OF TIME STEPS = <integer>nsteps
        TIME INCREMENT FUNCTION = <string>time_function
      END [PARAMETERS FOR ADAGIO REGION
        <string>region_name]
    END [TIME STEPPING BLOCK <string>time_block_name]
    TERMINATION TIME = <real>termination_time
  END TIME CONTROL

  # Begin Region scope

  BEGIN ADAGIO REGION <string>adagio_region_name

    USE FINITE ELEMENT MODEL <string>model_name


  # implicit dynamic time integration

  BEGIN IMPLICIT DYNAMICS
    ACTIVE PERIODS = <string list>period_names
    USE HHT INTEGRATION
    ALPHA = <real>alpha(0.0) [DURING <string list>period_names]
    GAMMA = <real>beta(0.5) [DURING <string list>period_names]
    BETA = <real>beta(0.25) [DURING <string list>period_names]
```

```
    TIME INTEGRATION CONTROL = <string>ADAPTIVE|COMPUTERESIDUAL|
      IGNORE(IGNORE) [DURING <string list>period_names]
    INCREASE ERROR THRESHOLD = <real>increase_threshold(0.02)
      [DURING <string list>period_names]
    HOLD ERROR THRESHOLD = <real>hold_threshold(0.10)
      [DURING <string list>period_names]
    DECREASE ERROR THRESHOLD = <real>decrease_threshold(0.25)
      [DURING <string list>period_names]
  END [IMPLICIT DYNAMICS]


    # Derived output

    BEGIN DERIVED OUTPUT
      COMPUTE AND STORE STRESS VARIABLE =
        <string>derived_quantity_name
    END DERIVED OUTPUT
    #
    BEGIN DERIVED STRAIN OUTPUT
      COMPUTE AND STORE STRAIN VARIABLE =
        <string>derived_quantity_name
    END DERIVED OUTPUT
    #
    BEGIN DERIVED LOG STRAIN OUTPUT
      COMPUTE AND STORE LOG STRAIN VARIABLE =
        <string>derived_quantity_name
    END DERIVED OUTPUT

    # Initial condition

    BEGIN INITIAL CONDITION
      # {mesh-entity set commands}
      NODE SET = <string list>nodelist_names
      SURFACE = <string list>surface_names
      BLOCK = <string list>block_names
      INCLUDE ALL BLOCKS
      REMOVE NODE SET = <string list>nodelist_names
      REMOVE SURFACE = <string list>surface_names
      REMOVE BLOCK = <string list>block_names
      #
      # variable identification commands
      INITIALIZE VARIABLE NAME = <string>var_name
      VARIABLE TYPE = [NODE|EDGE|FACE|ELEMENT|GLOBAL]
      #
      # constant magnitude command
      MAGNITUDE = <real list>initial_values
      #
```

```
  # input mesh commands
  READ VARIABLE = <string>mesh_var_name
  TIME = <real>time
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name |
    SURFACE SUBROUTINE = <string>subroutine_name |
    ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional command
  SCALE FACTOR = <real>scale_factor(1.0)
END [INITIAL CONDITION]

# Boundary conditions

BEGIN FIXED DISPLACEMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # component commands
  COMPONENT = <string>X/Y/Z | COMPONENTS =
    <string>X/Y/Z
  #
  # additional command
  ACTIVE PERIODS = <string list>period_names
END [FIXED DISPLACEMENT]

BEGIN PRESCRIBED DISPLACEMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
```

```
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # function commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z |
    CYLINDRICAL AXIS = <string>defined_axis |
    RADIAL AXIS = <string>defined_axis
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED DISPLACEMENT]

BEGIN PRESCRIBED VELOCITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # function commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z |
    CYLINDRICAL AXIS = <string>defined_axis |
    RADIAL AXIS = <string>defined_axis
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
```

```
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED VELOCITY]

BEGIN FIXED ROTATION
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # component commands
  COMPONENT = <string>X/Y/Z | COMPONENTS =
    <string>X/Y/Z
  #
  # additional command
  ACTIVE PERIODS = <string list>periods_names
END [FIXED ROTATION]

BEGIN PRESCRIBED ROTATION
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # function commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
```

```
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED ROTATION]

BEGIN INITIAL VELOCITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # direction commands
  COMPONENT = <string>X|Y|Z |
    DIRECTION = <string>defined_direction
  MAGNITUDE = <real>magnitude_of_velocity
  #
  # angular velocity commands
  CYLINDRICAL AXIS = <string>defined_axis
  ANGULAR VELOCITY = <real>angular_velocity
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
END [INITIAL VELOCITY]

BEGIN PRESSURE
  # {surface set commands}
  SURFACE = <string list>surface_names
  REMOVE SURFACE = <string list>surface_names
  #
  # function command
```

```
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  SURFACE SUBROUTINE = <string>subroutine_name |
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # external pressure sources
  READ VARIABLE = <string>variable_name
  OBJECT TYPE = <string>NODE|FACE(NODE)
  TIME = <real>time
  FIELD VARIABLE = <string>field_variable
  #
  # output external forces from pressure
  EXTERNAL FORCE CONTRIBUTION OUTPUT NAME
    = <string>variable_name
  #
  # additional commands
  USE DEATH = <string>death_name
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESSURE]

BEGIN TRACTION
  # {surface set commands}
  SURFACE = <string list>surface_names
  REMOVE SURFACE = <string list>surface_names
  #
  # function commands
  DIRECTION = <string>direction_name
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
```

```
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [TRACTION]

BEGIN PRESCRIBED FORCE
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # function commands
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED FORCE]

BEGIN PRESCRIBED MOMENT
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  # function commands
```

```
  DIRECTION = <string>defined_direction |
    COMPONENT = <string>X|Y|Z
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [PRESCRIBED MOMENT]

# Standard temperature boundary condition

BEGIN PRESCRIBED TEMPERATURE
  # {block set commands}
  BLOCK = <string_list>block_names
  INCLUDE ALL BLOCKS
  REMOVE BLOCK
  #
  # function command
  FUNCTION = <string>function_name
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # read variable commands
  READ VARIABLE = <string>variable_name
  TIME = <real>time
  #
  # additional commands
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
```

```
END [PRESCRIBED TEMPERATURE]

# Specialized boundary conditions

BEGIN GRAVITY
  # {node set commands}
  NODE SET = <string list>nodelist_names
  SURFACE = <string list>surface_names
  BLOCK = <string list>block_names
  INCLUDE ALL BLOCKS
  REMOVE NODE SET = <string list>nodelist_names
  REMOVE SURFACE = <string list>surface_names
  REMOVE BLOCK = <string list>block_names
  #
  DIRECTION = <string>defined_direction
  FUNCTION = <string>function_name
  GRAVITATIONAL CONSTANT = <real>g_constant
  SCALE FACTOR = <real>scale_factor(1.0)
  ACTIVE PERIODS = <string list>period_names
END [GRAVITY]

# Contact

BEGIN CONTACT DEFINITION <string>name
  #
  # enforcement options
  ENFORCEMENT = <string>TIED|FRICTIONLESS|FRICTIONAL
  #
  # contact surface and node set definition
  CONTACT SURFACE <string>name
    CONTAINS <string list>surface_names
  #
  BEGIN CONTACT SURFACE <string>name
    BLOCK = <string list>block_names
    SURFACE = <string list>surface_names
    NODE SET = <string list>node_set_names
    REMOVE BLOCK = <string list>block_names
    REMOVE SURFACE = <string list>surface_names
    REMOVE NODE SET = <string list>nodelist_names
  END [CONTACT SURFACE <string>name]
  #
  CONTACT NODE SET <string>surface_name
    CONTAINS <string>nodelist_names
  #
  SURFACE NORMAL SMOOTHING = <string>ON|OFF(OFF)
  #
  BEGIN INTERACTION [<string>name]
```

```
    MASTER = <string>surface
    SLAVE = <string>surface
    CAPTURE TOLERANCE = <real>cap_tol
    NORMAL TOLERANCE = <real>norm_tol
    TANGENTIAL TOLERANCE = <real>tang_tol
    TENSION RELEASE = <real>ten_release
    TENSION RELEASE FUNCTION = <string>ten_release_func
    FRICTION COEFFICIENT = <real>coeff
    FRICTION COEFFICIENT FUNCTION = <string>coeff_func
  END [INTERACTION <string>name]
  # end enforcement
  #
END [CONTACT DEFINITION <string>name]

# Results specification

BEGIN RESULTS OUTPUT <string>results_name
  DATABASE NAME = <string>results_file_name
  DATABASE TYPE =
    <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
    (ON|TRUE|YES)
  TITLE <string>user_title
  NODE VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | NODAL VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name] ...
        <string>variable_name [AS
        <string>dbase_variable_name]
  NODESET VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | NODESET VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name]
        INCLUDE|ON|EXCLUDE <string list>nodelist_names
        ... <string>variable_name
        [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
        <string list>nodelist_names
  FACE VARIABLES = <string>variable_name
    [AS <string>dbase_variable_name] ...
    <string>variable_name [AS
    <string>dbase_variable_name]
    | FACE VARIABLES = <string>variable_name
        [AS <string>dbase_variable_name]
```

```
              INCLUDE|ON|EXCLUDE <string list>surface_names
              ...  <string>variable_name
              [AS <string>dbase_variable_name] INCLUDE|ON|EXCLUDE
              <string list>surface_names
        ELEMENT VARIABLES = <string>variable_name
          [AS <string>dbase_variable_name] ...
          <string>variable_name [AS
          <string>dbase_variable_name]
          | ELEMENT VARIABLES = <string>variable_name
              [AS <string>dbase_variable_name]
              INCLUDE|ON|EXCLUDE <string list>block_names
              ... <string>variable_name
              [AS dbase_variable_name] INCLUDE|ON|EXCLUDE
              <string list>block_names
OUTPUT MESH = EXPOSED_SURFACE|BLOCK_SURFACE
        COMPONENT SEPARATOR CHARACTER = <string>character|NONE
        GLOBAL VARIABLES = <string>variable_name
          [AS <string>dbase_variable_name] ...
          <string>variable_name [AS
          <string>dbase_variable_name]
        START TIME = <real>output_start_time
        TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
        AT TIME <real>time_begin INCREMENT =
          <real>time_increment_dt
        ADDITIONAL TIMES = <real>output_time1
          <real>output_time2 ...
        AT STEP <integer>step_begin INCREMENT =
          <integer>step_increment
        ADDITIONAL STEPS = <integer>output_step1
          <integer>output_step2 ...
        TERMINATION TIME = <real>termination_time_value
        USE OUTPUT SCHEDULER <string>scheduler name
        OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
          SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
          SIGKILL|SIGILL|SIGSEGV
      END [RESULTS OUTPUT <string>results_name]

      # User output

      BEGIN USER OUTPUT
        # {mesh-entity set commands}
        NODE SET = <string_list>nodeset_names
        SURFACE = <string_list>surface_names
        BLOCK = <string_list>block_names
        INCLUDE ALL BLOCKS
        REMOVE NODE SET = <string list>nodelist_names
        REMOVE SURFACE = <string list> surface_names
```

```
  REMOVE BLOCK = <string list>block_names
  #
  # compute global result command
  COMPUTE GLOBAL <string>results_var_name AS
    <string>SUM|AVERAGE|MAX|MIN OF <string>NODAL|
    ELEMENT <string>value_var_name
    [(<integer>component_num)]
  #
  # user subroutine commands
  NODE SET SUBROUTINE = <string>subroutine_name |
    SURFACE SUBROUTINE = <string>subroutine_name |
    ELEMENT BLOCK SUBROUTINE = <string>subroutine_name
  SUBROUTINE DEBUGGING OFF | SUBROUTINE DEBUGGING ON
  SUBROUTINE REAL PARAMETER: <string>param_name
    = <real>param_value
  SUBROUTINE INTEGER PARAMETER: <string>param_name
    = <integer>param_value
  SUBROUTINE STRING PARAMETER: <string>param_name
    = <string>param_value
  #
  # copy command
  COPY ELEMENT VARIABLE <string>ev_name TO NODAL
    VARIABLE <string>nv_name
  #
  # compute for element death
  COMPUTE AT EVERY TIME STEP
  #
  # additional command
  ACTIVE PERIODS = <string list>period_names
END [USER OUTPUT]

# User variable

BEGIN USER VARIABLE <string>var_name
  TYPE = <string>NODE|ELEMENT|GLOBAL
    [<string>REAL|INTEGER LENGTH = <integer>length]|
    [<string>SYM_TENSOR|FULL_TENSOR|VECTOR]
  GLOBAL OPERATOR = <string>SUM|MIN|MAX]
  INITIAL VALUE = <real list>values
  USE WITH RESTART
END [USER VARIABLE <string>var_name]

# History specification

BEGIN HISTORY OUTPUT <string>history_name
  DATABASE NAME = <string>history_file_name
  DATABASE TYPE =
```

```
    <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
   (ON|TRUE|YES)
  TITLE <string>user_title
  #
  # for global variables
  VARIABLE = GLOBAL
    <string>variable_name
    [AS <string>history_variable_name]
  #
  # for mesh entity - node, edge, face,
  # element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
    [AS <string>history_variable_name]
  #
  # for nearest point output of mesh entity - node,
  # edge, face, element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    NEAREST LOCATION <real>global_x,
      <real>global_y>, <real>global_z
    [AS <string>history_variable_name]
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|
    SIGHUP|SIGINT|SIGPIPE|SIGQUIT|SIGTERM|
    SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
END [HISTORY OUTPUT <string>history_name]

# Heartbeat specification

BEGIN HEARTBEAT OUTPUT <string>heartbeat_name
  # Can also use predefined streams "cout", "stdout",
  # "cerr", "clog", "log", "output", or "outputP0"
```

```
  STREAM NAME = <string>heartbeat_file_name
  #
  # for global variables
  VARIABLE = GLOBAL
    <string>variable_name
    [AS <string>heartbeat_variable_name]
  #
  # for mesh entity - node, edge, face,
  # element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    AT NODE|NODAL|EDGE|FACE|ELEMENT <integer>entity_id
    [AS <string>heartbeat_variable_name]
  #
  # for nearest point output of mesh entity - node,
  # edge, face, element - variables
  VARIABLE =
    NODE|NODAL|EDGE|FACE|ELEMENT <string>variable_name
    NEAREST LOCATION <real>global_x,
      <real>global_y>, <real>global_z
    [AS <string>heartbeat_variable_name]
  START TIME = <real>output_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
    SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
  PRECISION = <integer>precision
  LABELS = <string>OFF|ON
  LEGEND = <string>OFF|ON
  TIMESTAMP FORMAT <string>timestamp_format
  MONITOR = <string>RESULTS|RESTART|HISTORY
END [HEARTBEAT OUTPUT <string>heartbeat_name]

# Restart specification

BEGIN RESTART DATA <string>restart_name
  DATABASE NAME = <string>restart_file_name
```

```
  INPUT DATABASE NAME = <string>restart_input_file
  OUTPUT DATABASE NAME =
    <string>restart_output_file
  DATABASE TYPE =
    <string>database_type(exodusII)
  OVERWRITE = <string>OFF|ON|TRUE|FALSE|YES|NO
    (ON|TRUE|YES)
  START TIME = <real>restart_start_time
  TIMESTEP ADJUSTMENT INTERVAL = <integer>steps
  AT TIME <real>time_begin INCREMENT =
    <real>time_increment_dt
  ADDITIONAL TIMES = <real>output_time1
    <real>output_time2 ...
  AT STEP <integer>step_begin INCREMENT =
    <integer>step_increment
  ADDITIONAL STEPS = <integer>output_step1
    <integer>output_step2 ...
  TERMINATION TIME = <real>termination_time_value
  OVERLAY COUNT = <integer>overlay_count
  CYCLE COUNT = <integer>cycle_count
  USE OUTPUT SCHEDULER <string>scheduler_name
  OUTPUT ON SIGNAL = <string>SIGALRM|SIGFPE|SIGHUP|SIGINT|
    SIGPIPE|SIGQUIT|SIGTERM|SIGUSR1|SIGUSR2|SIGABRT|
    SIGKILL|SIGILL|SIGSEGV
END [RESTART DATA <string>restart_name]

# Solver commands

BEGIN CG
  #
  # convergence commands
  TARGET RESIDUAL = <real>target_resid
    [DURING <string list>period_names]
  TARGET RELATIVE RESIDUAL = <real>target_rel_resid
    [DURING <string list>period_names]
  ACCEPTABLE RESIDUAL = <real>accept_resid
    [DURING <string list>period_names]
  ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
    [DURING <string list>period_names]
  REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
    [DURING <string list>period_names]
  MINIMUM RESIDUAL IMPROVEMENT  =  <real>resid_improvement
    [DURING <string list>period_names]
  MINIMUM ITERATIONS  = <integer>min_iter(0)
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS  = <integer>max_iter
    [DURING <string list>period_names]
```

```
#
# preconditioner commands
PRECONDITIONER = BLOCK|BLOCK_INITIAL|DIAGONAL|
  DIAGSCALING|ELASTIC|IDENTITY|PROBE|SCHUR
  [<real>scaling_factor]
BALANCE PROBE = <integer>balance_probe
NODAL PROBE FACTOR = <real>probe_factor(1.0e-6)
BEGIN FULL TANGENT PRECONDITIONER [<string>name]
  #
  # solver selection commands
  LINEAR SOLVER = <string>linear_solver_name
  NODAL PRECONDITIONER METHOD = ELASTIC|PROBE|DIAGONAL
    (ELASTIC)
  #
  # matrix formation commands
  PROBE FACTOR = <real>probe_factor(1.0e6)
  BALANCE PROBE = <integer>balance_probe(1)
  CONSTRAINT ENFORCEMENT = SOLVER|PENALTY(PENALTY)
  PENALTY FACTOR = <real>penalty_factor(100.0)
  SHELL DRILLING STIFFNESS = <real>shell_drill_stiff
  #
  # reset and iteration commands
  MAXIMUM RESETS FOR MODELPROBLEM = <integer>max_mp_resets
    [DURING <string list>period_names]
  MAXIMUM RESETS FOR LOADSTEP = <integer>max_ls_resets
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS FOR MODELPROBLEM = <integer>max_mp_iter
    [DURING <string list>period_names]
  MAXIMUM ITERATIONS FOR LOADSTEP = <integer>max_ls_iter
    [DURING <string list>period_names]
  ITERATION UPDATE = <integer>iter_update
    [DURING <string list>period_names]
  SMALL NUMBER OF ITERATIONS = <integer>small_num_iter
    [DURING <string list>period_names]
  NUMBER OF SMOOTHING ITERATIONS = <integer>num_smooth_iter
    [DURING <string list>period_names]
  #
  # fall-back strategy commands
  STAGNATION THRESHOLD = <real>stagnation(1.0e-12)
    [DURING <string list>period_names]
  MINIMUM CONVERGENCE RATE = <real>min_conv_rate(1.0e-4)
    [DURING <string list>period_names]
  ADAPTIVE STRATEGY = SWITCH|UPDATE(SWITCH)
    [DURING <string list>period_names]
END [FULL TANGENT PRECONDITIONER [<string>name]]
#
# line search command
```

```
  LINE SEARCH ACTUAL|SECANT|TANGENT [<real>scale_factor]
  #
  # diagnostic output commands
  ITERATION PRINT = <integer>iter_print
    [DURING <string list>period_names]
  ITERATION PLOT = <integer>iter_plot
    [DURING <string list>period_names]
  ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
  #
  # cg algorithm commands
  ITERATION RESET = <integer>iter_reset(10000)
    [DURING <string list>period_names]
  ORTHOGONALITY MEASURE FOR RESET = <real>ortho_reset(0.5)
    [DURING <string list>period_names]
  RESET LIMITS <integer>iter_start <integer>iter_reset
    <real>reset_growth <real>reset_orthogonality
    [DURING <string list>period_names]
  BETA METHOD = FletcherReeves|PolakRibiere|
    PolakRibierePlus(FletcherReeves)
    [DURING <string list>period_names]
END [CG]

BEGIN MULTILEVEL SOLVER
  #
  # cg solver commands
  BEGIN CG
    #
    # Parameters for cg
    #
  END [CG]
  #
  # control contact commands
  BEGIN CONTROL CONTACT
    #
    # convergence commands
    TARGET RESIDUAL = <real>target_resid
      [DURING <string list>period_names]
    TARGET RELATIVE RESIDUAL = <real>target_rel_resid
      [DURING <string list>period_names]
    ACCEPTABLE RESIDUAL = <real>accept_resid
      [DURING <string list>period_names]
    ACCEPTABLE RELATIVE RESIDUAL = <real>accept_rel_resid
      [DURING <string list>period_names]
    REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
      [DURING <string list>period_names]
    MINIMUM ITERATIONS  = <integer>min_iter(0)
      [DURING <string list>period_names]
```

```
    MAXIMUM ITERATIONS  = <integer>max_iter
      [DURING <string list>period_names]
    #
    # level selection command
    LEVEL = <integer>contact_level(1)
    #
    # diagnostic output commands
    ITERATION PLOT = <integer>iter_plot
      [DURING <string list>period_names]
    ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
  END [CONTROL CONTACT]
  #
  # control stiffness commands
  BEGIN CONTROL STIFFNESS [<string>stiffness_name]
    #
    # convergence commands
    TARGET <string>RESIDUAL|AXIAL FORCE INCREMENT|
      PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
      = <real>target [DURING <string list>period_names]
    TARGET RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
      PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
      = <real>target_rel [DURING <string list>period_names]
    ACCEPTABLE <string>RESIDUAL|AXIAL FORCE INCREMENT|
      PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
      = <real>accept [DURING <string list>period_names]
    ACCEPTABLE RELATIVE <string>RESIDUAL|AXIAL FORCE INCREMENT|
      PRESSURE INCREMENT|SDEV INCREMENT|STRESS INCREMENT
      = <real>accept_rel [DURING <string list>period_names]
    REFERENCE = EXTERNAL|INTERNAL|RESIDUAL(EXTERNAL)
      [DURING <string list>period_names]
    MINIMUM ITERATIONS  = <integer>min_iter(0)
      [DURING <string list>period_names]
    MAXIMUM ITERATIONS  = <integer>max_iter
      [DURING <string list>period_names]
    #
    # level selection command
    LEVEL = <integer>stiffness_level
    #
    # diagnostic output commands
    ITERATION PLOT = <integer>iter_plot
      [DURING <string list>period_names]
    ITERATION PLOT OUTPUT BLOCKS  = <string list>plot_blocks
  END [CONTROL STIFFNESS <string>stiffness_name]
  #
  # predictor command
  LEVEL 1 PREDICTOR = <string>NONE|DEFAULT(DEFAULT)
END [MULTILEVEL SOLVER]
```

```
  # Loadstep predictor commands

  BEGIN LOADSTEP PREDICTOR
    TYPE = <string>SCALE_FACTOR|SECANT|EXTERNAL|EXTERNAL_FIRST
    SCALE FACTOR = <real>factor(1.0)
      [<real>first_scale_factor]
      [DURING <string list>period_names]
    SLIP SCALE FACTOR = <real>slip_factor(1.0)
      [DURING <string list>period_names]
  END [LOADSTEP PREDICTOR]

  # Adaptive time stepping

  BEGIN ADAPTIVE TIME STEPPING
    CUTBACK FACTOR = <real>cutback_factor(0.5)
      [DURING <string list>period_names]
    GROWTH FACTOR = <real>growth_factor(1.5)
      [DURING <string list>period_names]
    MAXIMUM FAILURE CUTBACKS = <integer>max_cutbacks(5)
      [DURING <string list>period_names]
    MAXIMUM MULTIPLIER = <real>max_multiplier
      [DURING <string list>period_names]
    MINIMUM MULTIPLIER = <real>min_multiplier
      [DURING <string list>period_names]
    ACTIVE PERIODS = <string list>period_names
  END [ADAPTIVE TIME STEPPING]

  JAS MODE

END [ADAGIO REGION <string>adagio_region_name]

# Control modes region

BEGIN CONTROL MODES REGION
  #
  # model setup
  USE FINITE ELEMENT MODEL <string>model_name
  CONTROL BLOCKS = <string list>control_blocks
  #
  # solver commands
  BEGIN LOADSTEP PREDICTOR
    TYPE = <string>SCALE_FACTOR|SECANT|EXTERNAL|EXTERNAL_FIRST
    SCALE FACTOR = <real>factor(1.0)
      [<real>first_scale_factor(scale_factor)]
      [DURING <string list>period_names]
    SLIP SCALE FACTOR = <real>slip_factor(1.0)
```

```
          [DURING <string list>period_names]
      END [LOADSTEP PREDICTOR]
      BEGIN CG
        #
        #      Parameters for CG
        #
      END [CG]
      JAS MODE
      #
      # kinematic boundary condition commands
      BEGIN FIXED DISPLACEMENT
        #
        #  Parameters for fixed displacement
        #
      END [FIXED DISPLACEMENT]
      BEGIN PERIODIC
        #
        # Parameters for periodic
        #
      END [PERIODIC]
    END [CONTROL MODES REGION]


  END [ADAGIO PROCEDURE <string>adagio_procedure_name]

END [SIERRA <string>name]
```

Index

1PSI PRONY
in NLVE 3D Orthotropic material model, 173
2G SCALING
in Incompressible Solid material model, 167
2PSI PRONY
in NLVE 3D Orthotropic material model, 173
3PSI PRONY
in NLVE 3D Orthotropic material model, 173
4PSI PRONY
in NLVE 3D Orthotropic material model, 173
5PSI PRONY
in NLVE 3D Orthotropic material model, 173

A0
in Soil and Crushable Foam material model, 149
A1
in Soil and Crushable Foam material model, 149
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
A11
in Elastic Laminate material model, 162
A12
in Elastic Laminate material model, 162
A16
in Elastic Laminate material model, 162
A2
in Soil and Crushable Foam material model, 149
A22
in Elastic Laminate material model, 162
A26
in Elastic Laminate material model, 162
A44
in Elastic Laminate material model, 162
A45
in Elastic Laminate material model, 162
A55
in Elastic Laminate material model, 162
A66
in Elastic Laminate material model, 162
ABSCISSA
in Definition for Function, 48
ACCEPTABLE AXIAL FORCE INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE PRESSURE INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE AXIAL FORCE INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE PRESSURE INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE RESIDUAL
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE SDEV INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE STRAIN INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RELATIVE STRESS INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE RESIDUAL
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
ACCEPTABLE SDEV INCREMENT
in Control Stiffness, 97
description of, 98
ACCEPTABLE STRESS INCREMENT
in Control Stiffness, 97
description of, 98
ACTIVE FOR PROCEDURE
in Finite Element Model – in Parameters For Block, 194
description of, 200
ACTIVE PERIODS, 62
description of, 62
in Adaptive Time Stepping

description of, 115
in Fixed Displacement, 230
usage in, 231
in Fixed Rotation, 244
usage in, 245
in Gravity, 271
in Implicit Dynamics, 117
description of, 117
in Prescribed Acceleration, 240
usage in, 243
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 267
in Prescribed Moment, 268
usage in, 271
in Prescribed Rotation, 246
usage in, 249
in Prescribed Temperature, 273
usage in, 276
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255
usage in, 259
in Time Step Initialization, 420
usage in, 422
in Traction, 260
usage in, 263
in User Output, 321
description of, 327
ADAGIO PROCEDURE, 59
description of, 59
ADAGIO REGION
in Adagio Procedure, 59
description of, 60
ADAPTIVE STRATEGY
in Full Tangent Preconditioner, 74
description of, 79
ADAPTIVE TIME STEPPING
in Adagio Region, 113
ADDITIONAL STEPS
in Heartbeat Output, 337
description of, 343
in History Output, 328
description of, 334
in Output Scheduler, 363
description of, 365
in Restart Data, 349
description of, 360
in Results Output, 305
description of, 319
ADDITIONAL TIMES
in Heartbeat Output, 337
description of, 343
in History Output, 328
description of, 334
in Output Scheduler, 363
description of, 364
in Restart Data, 349
description of, 359
in Results Output, 305
description of, 319
ALIAS
in Finite Element Model, 190
description of, 193
ALPHA
in Elastic 3D Orthotropic material model, 154
in Elastic Laminate material model, 162
in Implicit Dynamics, 117
description of, 118
in NLVE 3D Orthotropic material model, 173
ANGULAR VELOCITY
in Initial Velocity, 251
description of, 253
in Rigid Body command block, 213
AREA
in Truss Section, 210
AT DISCONTINUITY EVALUATE TO
in Definition for Function, 48
AT STEP
in Heartbeat Output, 337
description of, 343
in History Output, 328
description of, 334
in Output Scheduler, 363
description of, 364
in Restart Data, 349
description of, 359
in Results Output, 305
description of, 319
AT TIME
in Heartbeat Output, 337
description of, 343
in History Output, 328
description of, 334
in Output Scheduler, 363
description of, 364
in Restart Data, 349
description of, 359
in Results Output, 305
description of, 319
aupst_check_elem_var, 399
aupst_check_global_var, 406
aupst_check_node_var, 399
aupst_cyl_transform, 439
aupst_evaluate_function, 398
aupst_get_elem_nodes, 410
aupst_get_elem_topology, 410

aupst_get_elem_var, 399
aupst_get_face_nodes, 410
aupst_get_face_topology, 410
aupst_get_global_var, 406
aupst_get_integer_param, 394
aupst_get_node_var, 399
aupst_get_one_elem_centroid, 415
aupst_get_point, 415
aupst_get_proc_num, 415
aupst_get_real_param, 394
aupst_get_string_param, 394
aupst_get_time, 398
aupst_local_put_global_var, 406
aupst_put_elem_var, 399
aupst_put_global_var, 406
aupst_put_node_var, 399
aupst_rec_transform, 440
AXIS
in Fiber Membrane material model, 164
AXIS Y
in Fiber Membrane material model, 164
AXIS Z
in Fiber Membrane material model, 164

B SHIFT CONSTANT
in NLVE 3D Orthotropic material model, 173
B1
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
B11
in Elastic Laminate material model, 162
B12
in Elastic Laminate material model, 162
B16
in Elastic Laminate material model, 162
B22
in Elastic Laminate material model, 162
B26
in Elastic Laminate material model, 162
B66
in Elastic Laminate material model, 162
BALANCE PROBE
in CG, 65
description of, 68
in Full Tangent Preconditioner, 74
description of, 76
BETA
in Elastic-Plastic material model, 134
in Foam Plasticity material model, 152
in Implicit Dynamics, 117
description of, 118
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
BETA METHOD
in CG, 65
description of, 72
BLOCK
description of, 222
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Mass Properties, 218
usage in, 218
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Temperature, 273
usage in, 274
in Prescribed Velocity, 236
usage in, 237
in Time Step Initialization, 420
usage in, 421
in User Output, 321
usage in, 322
BULK FUNCTION
in Mooney-Rivlin material model, 170
BULK MODULUS
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145

in Mooney-Rivlin material model, 170
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in NLVE 3D Orthotropic material model, 173
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182

C01
in Mooney-Rivlin material model, 170
C01 FUNCTION
in Mooney-Rivlin material model, 170
C1
in BCJ material model, 147
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
C10
in BCJ material model, 147
in Mooney-Rivlin material model, 170
C10 FUNCTION
in Mooney-Rivlin material model, 170
C11
in BCJ material model, 147
C12
in BCJ material model, 147
C13
in BCJ material model, 147
C14
in BCJ material model, 147
C15
in BCJ material model, 147
C16
in BCJ material model, 147
C17
in BCJ material model, 147
C18
in BCJ material model, 147
C19
in BCJ material model, 147
C2
in BCJ material model, 147
C20
in BCJ material model, 147
C3
in BCJ material model, 147
C4
in BCJ material model, 147
C5
in BCJ material model, 147
C6
in BCJ material model, 147
C7
in BCJ material model, 147
C8
in BCJ material model, 147
C9
in BCJ material model, 147
CAPTURE TOLERANCE
in Contact Definition – in Interaction, 283, 294
description of, 295
CG, 65
in Adagio Region, 65
in Control Modes Region, 103
usage in, 104
in MULTILEVEL SOLVER, 83
COARSE SOLVER
in FETI Equation Solver, 80
description of, 82
COINCIDENT SHELL HEX TREATMENT
in Contact Definition – in Shell Lofting, 283
description of, 292
COINCIDENT SHELL TREATMENT
in Contact Definition – in Shell Lofting, 283
description of, 292
COMPONENT
in Fixed Displacement, 230
description of, 231
in Fixed Rotation, 244
description of, 245
in Initial Velocity, 251
description of, 252
in Prescribed Acceleration, 240
description of, 241
in Prescribed Displacement, 232
description of, 233
in Prescribed Force, 264
description of, 265
in Prescribed Moment, 268
description of, 269
in Prescribed Rotation, 246
description of, 247
in Prescribed Velocity, 236
description of, 237
COMPONENT SEPARATOR CHARACTER
in Finite Element Model, 190
description of, 194
in Results Output, 305
description of, 317
COMPONENTS
in Fixed Displacement, 230
description of, 231
in Fixed Rotation, 244
description of, 245

COMPUTE AT EVERY TIME STEP, 321
in User Output
description of, 327
COMPUTE GLOBAL
in User Output, 321
description of, 323
CONSTRAINT ENFORCEMENT
in Full Tangent Preconditioner, 74
description of, 76
Constraint Mesh
for Control Modes, 102
CONTACT DEFINITION, 283
use of, 287
CONTACT NODE SET
in Contact Definition, 283
description of, 289
CONTACT SURFACE
in Contact Definition, 283
description of, 288
use of, 286
CONTACT SURFACE (block)
in Contact Definition, 283
description of, 288
use of, 286
CONTROL BLOCKS
in Control Modes Region, 103
description of, 104
CONTROL CONTACT
in Multilevel Solver, 83
description of, 86
Control Modes, 102
CONTROL MODES REGION, 103
usage of for Control Modes, 102
CONTROL STIFFNESS
in Multilevel Solver, 83
description of, 97
COORDINATE SYSTEM
in Elastic 3D Orthotropic material model, 154
in Elastic Laminate material model, 162
in NLVE 3D Orthotropic material model, 173
COPY ELEMENT VARIABLE
in User Output, 321
description of, 326
CORD DENSITY
in Fiber Membrane material model, 164
CORD DIAMETER
in Fiber Membrane material model, 164
CRITICAL CRACK OPENING STRAIN
in Ductile Fracture material model, 138
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
CRITICAL STRAIN
in Elastic Fracture material model, 132
CRITICAL TEARING PARAMETER
in Ductile Fracture material model, 138
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
CRUSH XX
in Orthotropic Crush material model, 156
CRUSH XY
in Orthotropic Crush material model, 156
CRUSH YY
in Orthotropic Crush material model, 156
CRUSH YZ
in Orthotropic Crush material model, 156
CRUSH ZX
in Orthotropic Crush material model, 156
CRUSH ZZ
in Orthotropic Crush material model, 156
CUT OFF STRAIN
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
CUTBACK FACTOR
in Adaptive Time Stepping
description of, 113
CYCLE COUNT
in Restart Data, 349
description of, 361
CYLINDRICAL AXIS
in Initial Velocity, 251
description of, 253
in Prescribed Displacement, 232
description of, 233
in Prescribed Velocity, 236
description of, 237
in Rigid Body command block, 213

D11
in Elastic Laminate material model, 162
D12
in Elastic Laminate material model, 162
D16
in Elastic Laminate material model, 162
D22
in Elastic Laminate material model, 162
D26
in Elastic Laminate material model, 162
D66
in Elastic Laminate material model, 162
DAMAGE EXPONENT
in BCJ material model, 147
DATABASE NAME
in Finite Element Model, 190
description of, 192
in History Output, 328
in Restart Data, 349
description of, 350
in Results Output, 305

DATABASE TYPE
in Finite Element Model, 190
description of, 192
in History Output, 328
in Restart Data, 349
description of, 350
in Results Output, 305
DECREASE ERROR THRESHOLD
in Implicit Dynamics, 117
description of, 118
DEFINE AXIS
with point and direction, 52
with two points, 52
DEFINE DIRECTION, 52
DEFINE POINT, 29, 52
DEFINITION FOR FUNCTION, 48
usage for thermal strains, 128
DENSITY
about, 125
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic 3D Orthotropic material model, 154
in Elastic Fracture material model, 132
in Elastic Laminate material model, 162
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Foam Plasticity material model, 152
in Johnson-Cook material model, 145
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
Density
in Fiber Membrane material model, 164
in Incompressible Solid material model, 167
in Mooney-Rivlin material model, 170
in NLVE 3D Orthotropic material model, 173
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
DEVIATORIC PARAMETER
in Membrane Section, 208
in Solid Section, 201
DIRECTION
in Gravity, 271
in Initial Velocity, 251
description of, 252
in Prescribed Acceleration, 240
description of, 241
in Prescribed Displacement, 232
description of, 233
in Prescribed Force, 264
description of, 265
in Prescribed Moment, 268
description of, 269
in Prescribed Rotation, 246
description of, 247
in Prescribed Velocity, 236
description of, 237
in Rigid Body command block, 213
in Traction, 260
description of, 261
DIRECTION FOR ROTATION
in Elastic 3D Orthotropic material model, 154
in Elastic Laminate material model, 162
in NLVE 3D Orthotropic material model, 173
DOUBLE INTEG FACTOR
in NLVE 3D Orthotropic material model, 173

EFFECTIVE MODULI MODEL
in Finite Element Model – in Parameters For Block, 194
description of, 198
ELEMENT BLOCK SUBROUTINE
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
description of, 228
in Time Step Initialization, 420
description of, 421
in User Output, 321
description of, 324
ELEMENT NUMERICAL FORMULATION
in Finite Element Model – in Parameters For Block, 194
description of, 199
ELEMENT VARIABLES
in Results Output, 305
description of, 312
ENFORCEMENT
in Contact Definition
use of, 285
EPL
in Fiber Membrane material model, 164
EVALUATE EXPRESSION
in Definition For Function, 48
examples of, 50
rules and options for composing, 50
EX
in Orthotropic Crush material model, 156
EXTERNAL FORCE CONTRIBUTION OUTPUT NAME, 255
in Pressure

description of, 259
EY
in Orthotropic Crush material model, 156
EZ
in Orthotropic Crush material model, 156

FACE VARIABLES
in Results Output
description of, 310
FACTOR
in BCJ material model, 147
FETI EQUATION SOLVER, 80
FICTITIOUS LOGA FUNCTION
in NLVE 3D Orthotropic material model, 173
FICTITIOUS LOGA SCALE FACTOR
in NLVE 3D Orthotropic material model, 173
FIELD VARIABLE
in Pressure, 255
description of, 258
FINITE ELEMENT MODEL, 190
usage of for Control Modes, 102
FIXED DISPLACEMENT, 230
in Control Modes Region, 103
usage in, 105
FIXED ROTATION, 244
FORMULATION
in Membrane Section, 208
in Solid Section, 201
FRICTION COEFFICIENT
in Contact Definition – in Interaction
description of, 296
FRICTION COEFFICIENT FUNCTION
in Contact Definition – in Interaction
description of, 296
FULL TANGENT PRECONDITIONER
in CG, 65
description of, 68, 74
FUNCTION
in Gravity, 271
in Prescribed Acceleration, 240
description of, 241
in Prescribed Displacement, 232
description of, 233
in Prescribed Force, 264
description of, 265
in Prescribed Moment, 268
description of, 269
in Prescribed Rotation, 246
description of, 247
in Prescribed Temperature, 273
description of, 274
in Prescribed Velocity, 236
description of, 237
in Pressure, 255
description of, 257
in Traction, 260
description of, 261

GAMMA
in Implicit Dynamics, 117
description of, 118
GLASS TRANSITION TEM
in NLVE 3D Orthotropic material model, 173
GLOBAL OPERATOR
in User Variable, 423
GLOBAL VARIABLES
in Results Output, 305
description of, 318
GRAVITATIONAL CONSTANT
in Gravity, 271
GRAVITY, 271
GROWTH FACTOR
in Adaptive Time Stepping
description of, 114
GXY
in Orthotropic Crush material model, 156
GYZ
in Orthotropic Crush material model, 156
GZX
in Orthotropic Crush material model, 156

HARDENING CONSTANT
in Ductile Fracture material model, 138
in Elastic-Plastic Power-Law Hardening material model, 136
HARDENING EXPONENT
in Ductile Fracture material model, 138
in Elastic-Plastic Power-Law Hardening material model, 136
HARDENING FUNCTION
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
HARDENING MODULUS
in Elastic-Plastic material model, 134
HEARTBEAT OUTPUT, 337
HISTORY OUTPUT, 328
HOLD ERROR THRESHOLD
in Implicit Dynamics, 117
description of, 118
HOURGLASS STIFFNESS
in Finite Element Model – in Parameters For Block, 194
description of, 198
HOURGLASS VISCOSITY
in Finite Element Model – in Parameters For Block, 194

description of, 198
HYDRO EXPONENT
in Foam Plasticity material model, 152
HYDRO HARDENING
in Foam Plasticity material model, 152
HYDRO STRENGTH
in Foam Plasticity material model, 152

IMPLICIT DYNAMICS, 117
INCLUDE ALL BLOCKS
description of, 222
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Mass Properties, 218
usage in, 218
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Temperature, 273
usage in, 274
in Prescribed Velocity, 236
usage in, 237
in Time Step Initialization, 420
usage in, 421
in User Output, 321
usage in, 322
INCREASE ERROR THRESHOLD
in Implicit Dynamics
description of, 118
INCREASE ERROR THRESHOLD
in Implicit Dynamics, 117
INERTIA
in Rigid Body command block, 213
INITIAL ALPHA_XX
in BCJ material model, 147
INITIAL ALPHA_XY
in BCJ material model, 147
INITIAL ALPHA_XZ
in BCJ material model, 147
INITIAL ALPHA_YY
in BCJ material model, 147
INITIAL ALPHA_YZ
in BCJ material model, 147
INITIAL ALPHA_ZZ
in BCJ material model, 147
INITIAL CONDITION, 225
INITIAL DAMAGE
in BCJ material model, 147
INITIAL KAPPA
in BCJ material model, 147
INITIAL LOAD
in Truss Section, 210
INITIAL VALUE
in User Variable, 423
INITIAL VELOCITY, 251
INITIALIZE VARIABLE NAME
in Initial Condition, 225
description of, 226
INPUT DATABASE NAME
in Restart Data, 349
description of, 350
INTEGRATION RULE
in Shell Section, 203
INTERACTION
in Contact Definition, 283
description of, 294
ITERATION PLOT
in CG, 65
description of, 71
in Control Contact, 86
description of, 90
in Control Stiffness, 97
description of, 101
ITERATION PLOT OUTPUT BLOCKS
in CG, 65
description of, 71
in Control Contact, 86
description of, 90
in Control Stiffness, 97
description of, 101
ITERATION PRINT
in CG, 65
description of, 71
ITERATION RESET
in CG, 65
description of, 72
ITERATION UPDATE
in Full Tangent Preconditioner, 74
description of, 77

JAS MODE
in Adagio Region, 109
in Control Modes Region, 103

description of, 104

K SCALING
in Incompressible Solid material model, 167

L FUNCTION
in Orthotropic Rate material model, 159
LABELS
in Heartbeat Output, 337
LAMBDA
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Mooney-Rivlin material model, 170
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in NLVE 3D Orthotropic material model, 173
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
LEGEND
in Heartbeat Output, 337
LEVEL
in Control Contact, 86
description of, 90
in Control Stiffness, 97
description of, 100
LEVEL 1 PREDICTOR
in Multilevel Solver, 83
description of, 85
LINE SEARCH
in CG, 65
description of, 70
LINEAR BULK VISCOSITY
in Finite Element Model – in Parameters For Block, 194
description of, 197
LINEAR SOLVER
in Full Tangent Preconditioner, 74
description of, 75
LINEAR VISCO TEST
in NLVE 3D Orthotropic material model, 173
LOADSTEP PREDICTOR, 106
in Control Modes Region, 103
usage in, 104
LOCAL SOLVER
in FETI Equation Solver, 80
description of, 82
LOFTING ALGORITHM
in Contact Definition – in Shell Lofting, 283
description of, 292
LOFTING FACTOR
in Membrane Section, 208
in Shell Section, 203
LUDERS STRAIN
in Ductile Fracture material model, 138
in Elastic-Plastic Power-Law Hardening material model, 136
LW FUNCTION
in Orthotropic Rate material model, 159
LX
in Orthotropic Rate material model, 159
LY
in Orthotropic Rate material model, 159
LZ
in Orthotropic Rate material model, 159

MAGNITUDE
in Initial Condition, 225
description of, 227
in Initial Velocity, 251
description of, 252
in Rigid Body command block, 213
MASS
in Rigid Body command block, 213
MASS LOCATION
in Rigid Body command block, 213
MASS PROPERTIES, 218
MASTER
in Contact Definition – in Interaction, 283, 294
description of, 294
MATERIAL
in Finite Element Model – in Parameters For Block, 194
description of, 196
MATRIX DENSITY
in Fiber Membrane material model, 164
MAX POISSONS RATIO
in Incompressible Solid material model, 167
in Mooney-Rivlin material model, 170
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
MAX STRESS
in Elastic Fracture material model, 132
MAXIMUM FAILURE CUTBACKS

in Adaptive Time Stepping
description of, 114
MAXIMUM ITERATIONS
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
in FETI Equation Solver, 80
description of, 81
MAXIMUM ITERATIONS FOR LOADSTEP
in Full Tangent Preconditioner, 74
description of, 77
MAXIMUM ITERATIONS FOR MODELPROBLEM
in Full Tangent Preconditioner, 74
description of, 77
MAXIMUM MULTIPLIER
in Adaptive Time Stepping
description of, 114
MAXIMUM ORTHOGONALIZATION
in FETI Equation Solver, 80
description of, 81
MAXIMUM RESETS FOR LOADSTEP
in Full Tangent Preconditioner, 74
description of, 77
MAXIMUM RESETS FOR MODELPROBLEM
in Full Tangent Preconditioner, 74
description of, 77
MEMBRANE SECTION, 208
MINIMUM CONVERGENCE RATE
in Full Tangent Preconditioner, 74
description of, 79
MINIMUM ITERATIONS
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
MINIMUM MULTIPLIER
in Adaptive Time Stepping
description of, 115
MINIMUM RESIDUAL IMPROVEMENT
in CG, 65
description of, 66
MODEL
in Fiber Membrane material model, 164
MODULUS FUNCTION
in Orthotropic Rate material model, 159
MODULUS LLLL
in Orthotropic Rate material model, 159
MODULUS LLWW
in Orthotropic Rate material model, 159
MODULUS LWLW
in Orthotropic Rate material model, 159
MODULUS TLTL
in Orthotropic Rate material model, 159
MODULUS TTLL
in Orthotropic Rate material model, 159
MODULUS TTTT
in Orthotropic Rate material model, 159
MODULUS TTWW
in Orthotropic Rate material model, 159
MODULUS WTWT
in Orthotropic Rate material model, 159
MODULUS WWWW
in Orthotropic Rate material model, 159
MONITOR
in Heartbeat Output, 337
description of, 347
MTH11 FUNCTION
in Elastic Laminate material model, 162
MTH12 FUNCTION
in Elastic Laminate material model, 162
MTH22 FUNCTION
in Elastic Laminate material model, 162
MULTILEVEL SOLVER, 83

NODAL PRECONDITIONER METHOD
in Full Tangent Preconditioner, 74
description of, 75
NODAL PROBE FACTOR
in CG, 65
description of, 68
NODAL VARIABLES
in Results Output, 305
description of, 307
NODE BASED ALPHA FACTOR
in Solid Section, 201
NODE BASED BETA FACTOR
in Solid Section, 201
NODE SET
description of, 222
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Prescribed Acceleration, 240

usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Velocity, 236
usage in, 237
in Time Step Initialization, 420
usage in, 421
in User Output, 321
usage in, 322
NODE SET SUBROUTINE
as user subroutine command line, 417
description of, 417
in Initial Condition, 225
description of, 228
in Initial Velocity, 251
description of, 253
in Prescribed Acceleration, 240
description of, 242
in Prescribed Displacement, 232
description of, 234
in Prescribed Force, 264
description of, 266
in Prescribed Moment, 268
description of, 270
in Prescribed Rotation, 246
description of, 248
in Prescribed Temperature, 273
description of, 275
in Prescribed Velocity, 236
description of, 238
in Pressure, 255
description of, 257
in Time Step Initialization, 420
description of, 421
in Traction, 260
description of, 262
in User Output, 321
description of, 324
NODE VARIABLES
in Results Output, 305
description of, 307
NODESET VARIABLES
in Results Output, 305
description of, 308
NORMAL TOLERANCE
in Contact Definition – in Interaction, 283, 294
description of, 295
NTH11 FUNCTION
in Elastic Laminate material model, 162
NTH12 FUNCTION
in Elastic Laminate material model, 162
NTH22 FUNCTION
in Elastic Laminate material model, 162
NUM LOCAL SUBDOMAINS
in FETI Equation Solver, 80
description of, 82
NUMBER OF INTEGRATION POINTS
in Shell Section, 203
NUMBER OF SMOOTHING ITERATIONS
in Full Tangent Preconditioner, 74
description of, 77
NUMBER OF TIME STEPS
in Parameters For Adagio Region, 111, 112
NUMERICAL SHIFT FUNCTION
in Viscoelastic Swanson material model, 182

OBJECT TYPE
in Pressure, 255
description of, 258
OMIT BLOCK
in Finite Element Model, 190
description of, 193
ORDINATE
in Definition for Function, 48
ORIENTATION, 54
in Shell Section, 203
ORTHOGONALITY MEASURE FOR RESET
in CG, 65
description of, 72
OUTPUT DATABASE NAME
in Restart Data, 349
description of, 350
OUTPUT MESH
BLOCK_SURFACE, 317
EXPOSED_SURFACE, 317
in Results Output, 305
description of, 317
OUTPUT ON SIGNAL
in Heartbeat Output, 337
description of, 344
in History Output, 328
description of, 335
in Restart Data, 349
description of, 362
in Results Output, 305
description of, 320
OUTPUT SCHEDULER, 363
example of, 365
use of, 363
OVERLAY COUNT
in Restart Data, 349
description of, 360

OVERWRITE
in History Output, 328
in Restart Data, 349
description of, 358
in Results Output, 305

P1
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
PARAM-STRING precision VALUE
in FETI Equation Solver, 80
description of, 81
PARAMETERS FOR ADAGIO REGION
in Time Stepping Block, 110
contents of, 111
PARAMETERS FOR BLOCK
in Finite Element Model, 190
about, 194
listing of, 194
PARAMETERS FOR MODEL
in Property Specification for Material command blocks
description of, 122
PARAMETERS FOR MODEL BCJ
in BCJ material model, 147
PARAMETERS FOR MODEL DUCTILE FRACTURE
in Ductile Fracture material model, 138
PARAMETERS FOR MODEL ELASTIC
in Elastic material model, 130
PARAMETERS FOR MODEL ELASTIC_3D_ORTHOTROPIC
in Elastic 3D Orthotropic material model, 154
PARAMETERS FOR MODEL ELASTIC_FRACTURE
in Elastic Fracture material model, 132
PARAMETERS FOR MODEL ELASTIC_LAMINATE
in Elastic Laminate material model, 162
PARAMETERS FOR MODEL ELASTIC_PLASTIC
in Elastic-Plastic material model, 134
in Johnson-Cook material model, 145
PARAMETERS FOR MODEL EP_POWER_HARD
in Elastic-Plastic Power-Law Hardening material model, 136
PARAMETERS FOR MODEL FIBER_MEMBRANE
in Fiber Membrane material model, 164
PARAMETERS FOR MODEL FOAM_PLASTICITY
in Foam Plasticity material model, 152
PARAMETERS FOR MODEL INCOMPRESSIBLE_SOLID
in Incompressible Solid material model, 167
PARAMETERS FOR MODEL ML_EP_FAIL
in Multilinear Elastic-Plastic Hardening Model material mode, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material mode, 142
PARAMETERS FOR MODEL MOONEY_RIVLIN
in Mooney-Rivlin material model, 170
PARAMETERS FOR MODEL NLVE_3D_ORTHOTROPIC
in NLVE 3D Orthotropic material model, 173
PARAMETERS FOR MODEL ORTHOTROPIC_CRUSH
in Orthotropic Crush material model, 156
PARAMETERS FOR MODEL ORTHOTROPIC_RATE
in Orthotropic Rate material model, 159
PARAMETERS FOR MODEL SOIL_FOAM
in Soil and Crushable Foam material model, 149
PARAMETERS FOR MODEL STIFF_ELASTIC
in Stiff Elastic material model, 177
PARAMETERS FOR MODEL SWANSON
in Swanson material model, 179
PARAMETERS FOR MODEL VISCOELASTIC_SWANSON
in Viscoelastic Swanson material model, 182
PENALTY FACTOR
in Full Tangent Preconditioner, 74
description of, 76
PERCENT CONTINUUM
in Fiber Membrane material model, 164
PERIOD
in Truss Section, 210
PERIODIC
in Control Modes Region, 103
usage in, 105
PHI
in Foam Plasticity material model, 152
POINT A
in Orientation, 54
POINT B
in Orientation, 54
POINT INERTIA
in Rigid Body command block, 213
POINT MASS SECTION, 211
POISSONS RATIO
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Mooney-Rivlin material model, 170
in Multilinear Elastic-Plastic Hardening Model material model, 140

in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in NLVE 3D Orthotropic material model, 173
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
POISSONS RATIO AB
in Elastic 3D Orthotropic material model, 154
POISSONS RATIO BC
in Elastic 3D Orthotropic material model, 154
POISSONS RATIO CA
in Elastic 3D Orthotropic material model, 154
POISSONS RATIO FUNCTION
in BCJ material model, 147
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
PRECISION
in Heartbeat Output, 337
PRECONDITIONER
in CG, 65
description of, 68
PRECONDITIONING METHOD
in FETI Equation Solver, 80
description of, 81
PREDICTOR TYPE
in Loadstep Predictor
description of, 106
PRESCRIBED ACCELERATION, 240
PRESCRIBED DISPLACEMENT, 232
PRESCRIBED FORCE, 264
PRESCRIBED MOMENT, 268
PRESCRIBED ROTATION, 246
PRESCRIBED TEMPERATURE, 273
usage for thermal strains, 128
PRESCRIBED VELOCITY, 236
PRESSURE, 255
PRESSURE CUTOFF
in Soil and Crushable Foam material model, 149
PRESSURE FUNCTION
in Soil and Crushable Foam material model, 149
PROBE FACTOR
in Full Tangent Preconditioner, 74
description of, 76
PRONY SHEAR 1
in Viscoelastic Swanson material model, 182
PRONY SHEAR 10
in Viscoelastic Swanson material model, 182
PRONY SHEAR 2
in Viscoelastic Swanson material model, 182
PRONY SHEAR 3
in Viscoelastic Swanson material model, 182
PRONY SHEAR 4
in Viscoelastic Swanson material model, 182
PRONY SHEAR 5
in Viscoelastic Swanson material model, 182
PRONY SHEAR 6
in Viscoelastic Swanson material model, 182
PRONY SHEAR 7
in Viscoelastic Swanson material model, 182
PRONY SHEAR 8
in Viscoelastic Swanson material model, 182
PRONY SHEAR 9
in Viscoelastic Swanson material model, 182
PRONY SHEAR INFINITY
in Viscoelastic Swanson material model, 182
PROPERTY SPECIFICATION FOR MATERIAL, 121
about, 196
PSI EQ 2T
in NLVE 3D Orthotropic material model, 173
PSI EQ 3T
in NLVE 3D Orthotropic material model, 173
PSI EQ 4T
in NLVE 3D Orthotropic material model, 173
PSI EQ XT 1
in NLVE 3D Orthotropic material model, 173
PSI EQ XT 2
in NLVE 3D Orthotropic material model, 173
PSI EQ XT 3
in NLVE 3D Orthotropic material model, 173
PSI EQ XTT 1
in NLVE 3D Orthotropic material model, 173
PSI EQ XTT 2
in NLVE 3D Orthotropic material model, 173
PSI EQ XTT 3
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 11
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 12
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 13
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 22
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 23
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 33
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 44
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 55
in NLVE 3D Orthotropic material model, 173
PSI EQ XX 66
in NLVE 3D Orthotropic material model, 173

PSI EQ XXT 11
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 12
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 13
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 22
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 23
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 33
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 44
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 55
in NLVE 3D Orthotropic material model, 173
PSI EQ XXT 66
in NLVE 3D Orthotropic material model, 173
PSI POT TT
in NLVE 3D Orthotropic material model, 173
PSI POT TTT
in NLVE 3D Orthotropic material model, 173
PSI POT TTTT
in NLVE 3D Orthotropic material model, 173
PSI POT XT 1
in NLVE 3D Orthotropic material model, 173
PSI POT XT 2
in NLVE 3D Orthotropic material model, 173
PSI POT XT 3
in NLVE 3D Orthotropic material model, 173
PSI POT XTT 1
in NLVE 3D Orthotropic material model, 173
PSI POT XTT 2
in NLVE 3D Orthotropic material model, 173
PSI POT XTT 3
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 11
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 12
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 13
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 22
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 23
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 33
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 44
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 55
in NLVE 3D Orthotropic material model, 173
PSI POT XXT 66
in NLVE 3D Orthotropic material model, 173

Q1
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
QUADRATIC BULK VISCOSITY
in Finite Element Model – in Parameters For Block, 194
description of, 197

R1
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
RADIAL AXIS
in Prescribed Displacement, 232
description of, 233
in Prescribed Velocity, 236
description of, 237
RATE FUNCTION
in Orthotropic Rate material model, 159
READ VARIABLE
in Initial Condition, 225
description of, 227
in Prescribed Temperature, 273
description of, 275
in Pressure, 255
description of, 258
REF GLASSY C11
in NLVE 3D Orthotropic material model, 173
REF GLASSY C12
in NLVE 3D Orthotropic material model, 173
REF GLASSY C13
in NLVE 3D Orthotropic material model, 173
REF GLASSY C22
in NLVE 3D Orthotropic material model, 173
REF GLASSY C23
in NLVE 3D Orthotropic material model, 173
REF GLASSY C33
in NLVE 3D Orthotropic material model, 173
REF GLASSY C44
in NLVE 3D Orthotropic material model, 173
REF GLASSY C55
in NLVE 3D Orthotropic material model, 173
REF GLASSY C66
in NLVE 3D Orthotropic material model, 173
REF GLASSY CTE1
in NLVE 3D Orthotropic material model, 173
REF GLASSY CTE2
in NLVE 3D Orthotropic material model, 173
REF GLASSY CTE3
in NLVE 3D Orthotropic material model, 173
REF GLASSY HCAPACITY
in NLVE 3D Orthotropic material model, 173
REF PSIA 11
in NLVE 3D Orthotropic material model, 173
REF PSIA 12

in NLVE 3D Orthotropic material model, 173
REF PSIA 13
in NLVE 3D Orthotropic material model, 173
REF PSIA 22
in NLVE 3D Orthotropic material model, 173
REF PSIA 23
in NLVE 3D Orthotropic material model, 173
REF PSIA 33
in NLVE 3D Orthotropic material model, 173
REF PSIA 44
in NLVE 3D Orthotropic material model, 173
REF PSIA 55
in NLVE 3D Orthotropic material model, 173
REF PSIA 66
in NLVE 3D Orthotropic material model, 173
REF PSIB 1
in NLVE 3D Orthotropic material model, 173
REF PSIB 2
in NLVE 3D Orthotropic material model, 173
REF PSIB 3
in NLVE 3D Orthotropic material model, 173
REF PSIC
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C11
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C12
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C13
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C22
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C23
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C33
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C44
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C55
in NLVE 3D Orthotropic material model, 173
REF RUBBERY C66
in NLVE 3D Orthotropic material model, 173
REF RUBBERY CTE1
in NLVE 3D Orthotropic material model, 173
REF RUBBERY CTE2
in NLVE 3D Orthotropic material model, 173
REF RUBBERY CTE3
in NLVE 3D Orthotropic material model, 173
REF RUBBERY HCAPACITY
in NLVE 3D Orthotropic material model, 173
REFERENCE
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
REFERENCE DENSITY
in NLVE 3D Orthotropic material model, 173
Reference Mesh
for Control Modes, 102
REFERENCE PLANE AXIS
in Traction, 260
REFERENCE PLANE T1 DIRECTION
in Traction, 260
REFERENCE STRAIN
in Fiber Membrane material model, 164
in Incompressible Solid material model, 167
in Mooney-Rivlin material model, 170
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
REFERENCE TEMP
in NLVE 3D Orthotropic material model, 173
RELAX TIME
in NLVE 3D Orthotropic material model, 173
REMOVE BLOCK
description of, 223
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Mass Properties, 218
usage in, 218
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Temperature, 273
usage in, 274
in Prescribed Velocity, 236
usage in, 237
in Time Step Initialization, 420
usage in, 421

in User Output, 321
usage in, 322
REMOVE NODE SET
description of, 223
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Velocity, 236
usage in, 237
in Time Step Initialization, 420
usage in, 421
in User Output, 321
usage in, 322
REMOVE SURFACE
description of, 223
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Velocity, 236
usage in, 237
in Pressure, 255
description of, 256
in Time Step Initialization, 420
usage in, 421
in Traction, 260
description of, 261
in User Output, 321
usage in, 322
RESET LIMITS
in CG, 65
description of, 72
RESIDUAL NORM TOLERANCE
in FETI Equation Solver, 80
description of, 81
RESTART, 47
about, 46
RESTART DATA, 349
about, 46
about auto read and write, 351
about overwriting, 357
about recovering, 358
about user-controlled read and write, 354
RESTART TIME, 47
about, 46
with Restart Data, 349
RESULTS OUTPUT, 305
RHO
in BCJ material model, 147
RIGID BODY
as command block, 213
in Membrane Section, 208
in Point Mass Section, 211
in Shell Section, 203
in Solid Section, 201
in Truss Section, 210
ROTATION ABOUT
in Orientation, 54

SCALE FACTOR
in Gravity, 271
in Initial Condition, 225
description of, 228
in Loadstep Predictor, 106
description of, 107
in Prescribed Acceleration, 240
description of, 243
in Prescribed Displacement, 232
description of, 235

in Prescribed Force, 264
description of, 267
in Prescribed Moment, 268
description of, 271
in Prescribed Rotation, 246
description of, 249
in Prescribed Temperature, 273
description of, 276
in Prescribed Velocity, 236
description of, 239
in Pressure, 255
description of, 259
in Stiff Elastic material model, 177
in Traction, 260
description of, 263
SCALING FUNCTION
in Incompressible Solid material model, 167
SECOND ALPHA
in Elastic 3D Orthotropic material model, 154
in NLVE 3D Orthotropic material model, 173
SECOND DIRECTION FOR ROTATION
in Elastic 3D Orthotropic material model, 154
in NLVE 3D Orthotropic material model, 173
SECTION
in Finite Element Model – in Parameters For Block, 194
description of, 196
general overview, 195
Section command blocks
about, 201
SHEAR EXPONENT
in Foam Plasticity material model, 152
SHEAR HARDENING
in Foam Plasticity material model, 152
SHEAR MODULUS
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Mooney-Rivlin material model, 170
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in NLVE 3D Orthotropic material model, 173
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
SHEAR MODULUS AB
in Elastic 3D Orthotropic material model, 154
SHEAR MODULUS BC
in Elastic 3D Orthotropic material model, 154
SHEAR MODULUS CA
in Elastic 3D Orthotropic material model, 154
SHEAR RELAX TIME 1
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 10
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 2
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 3
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 4
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 5
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 6
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 7
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 8
in Viscoelastic Swanson material model, 182
SHEAR RELAX TIME 9
in Viscoelastic Swanson material model, 182
SHEAR STRENGTH
in Foam Plasticity material model, 152
SHELL DRILLING STIFFNESS
in Full Tangent Preconditioner, 74
description of, 76
SHELL LOFTING
in Contact Definition, 283
description of, 292
SHELL SECTION, 203
SHIFT REF VALUE
in NLVE 3D Orthotropic material model, 173
SIERRA, 45
SLAVE
in Contact Definition – in Interaction, 283, 294
description of, 294
SLIP SCALE FACTOR
in Loadstep Predictor, 106
description of, 107
SMALL NUMBER OF ITERATIONS
in Full Tangent Preconditioner, 74
description of, 77
SOLID MECHANICS USE MODEL
in Finite Element Model – in Parameters For Block, 194

description of, 196
SOLID SECTION, 201
SPECIFIC HEAT
in BCJ material model, 147
STAGNATION THRESHOLD
in Full Tangent Preconditioner, 74
description of, 79
START TIME
in Heartbeat Output, 337
description of, 342
in History Output, 328
description of, 333
in Output Scheduler, 363
description of, 364
in Restart Data, 349
description of, 358
in Results Output, 305
description of, 318
in Time Stepping Block, 110
STIFFNESS SCALE
in Fiber Membrane material model, 164
STRAIN INCREMENTATION
in Solid Section, 201
STREAM NAME
in Heartbeat Output, 337
STRUCTURE NAME
in Mass Properties, 218
description of, 219
SUBROUTINE DEBUGGING OFF
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
usage in, 228
in Initial Velocity, 251
usage in, 253
in Prescribed Acceleration, 240
usage in, 242
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 266
in Prescribed Moment, 268
usage in, 270
in Prescribed Rotation, 246
usage in, 248
in Prescribed Temperature, 273
usage in, 275
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255
usage in, 257
in Time Step Initialization, 420
usage in, 421
in Traction, 260
usage in, 262
in User Output, 321
usage in, 326
SUBROUTINE DEBUGGING ON
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
usage in, 228
in Initial Velocity, 251
usage in, 253
in Prescribed Acceleration, 240
usage in, 242
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 266
in Prescribed Moment, 268
usage in, 270
in Prescribed Rotation, 246
usage in, 248
in Prescribed Temperature, 273
usage in, 275
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255
usage in, 257
in Time Step Initialization, 420
usage in, 421
in Traction, 260
usage in, 262
in User Output, 321
usage in, 326
SUBROUTINE INTEGER PARAMETER
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
usage in, 228
in Initial Velocity, 251
usage in, 253
in Prescribed Acceleration, 240
usage in, 242
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 266
in Prescribed Moment, 268
usage in, 270
in Prescribed Rotation, 246
usage in, 248
in Prescribed Temperature, 273
usage in, 275
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255

usage in, 257
in Time Step Initialization, 420
usage in, 421
in Traction, 260
usage in, 262
in User Output, 321
usage in, 326
SUBROUTINE REAL PARAMETER
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
usage in, 228
in Initial Velocity, 251
usage in, 253
in Prescribed Acceleration, 240
usage in, 242
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 266
in Prescribed Moment, 268
usage in, 270
in Prescribed Rotation, 246
usage in, 248
in Prescribed Temperature, 273
usage in, 275
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255
usage in, 257
in Time Step Initialization, 420
usage in, 421
in Traction, 260
usage in, 262
in User Output, 321
usage in, 326
usage with query function, 394
SUBROUTINE STRING PARAMETER
as user subroutine command line, 417
description of, 418
in Initial Condition, 225
usage in, 228
in Initial Velocity, 251
usage in, 253
in Prescribed Acceleration, 240
usage in, 242
in Prescribed Displacement, 232
usage in, 235
in Prescribed Force, 264
usage in, 266
in Prescribed Moment, 268
usage in, 270
in Prescribed Rotation, 246
usage in, 248
in Prescribed Temperature, 273
usage in, 275
in Prescribed Velocity, 236
usage in, 239
in Pressure, 255
usage in, 257
in Time Step Initialization, 420
usage in, 421
in Traction, 260
usage in, 262
in User Output, 321
usage in, 326
Support, 41
SURFACE
description of, 222
in Contact Definition – in Contact Surface (block), 283
usage in, 288
in Fixed Displacement, 230
usage in, 230
in Fixed Rotation, 244
usage in, 244
in Gravity, 271
usage in, 272
in Initial Condition, 225
usage in, 226
in Initial Velocity, 251
usage in, 252
in Prescribed Acceleration, 240
usage in, 241
in Prescribed Displacement, 232
usage in, 233
in Prescribed Force, 264
usage in, 265
in Prescribed Moment, 268
usage in, 269
in Prescribed Rotation, 246
usage in, 247
in Prescribed Velocity, 236
usage in, 237
in Pressure, 255
description of, 256
in Time Step Initialization, 420
usage in, 421
in Traction, 260
description of, 261
in User Output, 321
usage in, 322
SURFACE NORMAL SMOOTHING
in Contact Definition, 283
description of, 291
SURFACE SUBROUTINE
as user subroutine command line, 417
description of, 418

in Initial Condition, 225
description of, 228
in Pressure, 255
description of, 257
in Time Step Initialization, 420
description of, 421
in User Output, 321
description of, 324
SURFACES
in Contact Definition – in Interaction, 283, 294
description of, 294
SYSTEM
in Orientation, 54

T 2DERIV PSIC
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C11
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C12
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C13
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C22
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C23
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C33
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C44
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C55
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY C66
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY CTE1
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY CTE2
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY CTE3
in NLVE 3D Orthotropic material model, 173
T DERIV GLASSY HCAPACITY
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 11
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 12
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 13
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 22
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 23
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 33
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 44
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 55
in NLVE 3D Orthotropic material model, 173
T DERIV PSIA 66
in NLVE 3D Orthotropic material model, 173
T DERIV PSIB 1
in NLVE 3D Orthotropic material model, 173
T DERIV PSIB 2
in NLVE 3D Orthotropic material model, 173
T DERIV PSIB 3
in NLVE 3D Orthotropic material model, 173
T DERIV PSIC
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C11
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C12
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C13
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C22
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C23
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C33
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C44
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C55
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY C66
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY CTE1
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY CTE2
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY CTE3
in NLVE 3D Orthotropic material model, 173
T DERIV RUBBERY HCAPACITY
in NLVE 3D Orthotropic material model, 173
T FUNCTION
in Orthotropic Rate material model, 159
TANGENTIAL TOLERANCE
in Contact Definition – in Interaction, 283, 294
description of, 295
TARGET AXIAL FORCE INCREMENT
in Control Stiffness, 97
description of, 98
TARGET E
in Incompressible Solid material model, 167
in Mooney-Rivlin material model, 170
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
TARGET E FUNCTION

in Mooney-Rivlin material model, 170
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
TARGET PRESSURE INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RELATIVE AXIAL FORCE INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RELATIVE PRESSURE INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RELATIVE RESIDUAL
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
TARGET RELATIVE SDEV INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RELATIVE STRAIN INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RELATIVE STRESS INCREMENT
in Control Stiffness, 97
description of, 98
TARGET RESIDUAL
in CG, 65
description of, 66
in Control Contact, 86
description of, 89
in Control Stiffness, 97
description of, 98
TARGET SDEV INCREMENT
in Control Stiffness, 97
description of, 98
TARGET STRESS INCREMENT
in Control Stiffness, 97
description of, 98
TEMPO
in BCJ material model, 147
TENSILE TEST FUNCTION
in Fiber Membrane material model, 164
TENSION RELEASE
in Contact Definition – in Interaction
description of, 296
TENSION RELEASE FUNCTION
in Contact Definition – in Interaction
description of, 296
TERMINATION TIME
in Heartbeat Output, 337
description of, 344
in History Output, 328
description of, 335
in Output Scheduler, 363
description of, 365
in Restart Data, 349
description of, 360
in Results Output, 305
description of, 320
in Time Control, 110
THERMAL EXPANSION FUNCTION
in Mooney-Rivlin material model, 170
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
THERMAL STRAIN AA FUNCTION
in Elastic 3D Orthotropic material model, 154
THERMAL STRAIN BB FUNCTION
in Elastic 3D Orthotropic material model, 154
THERMAL STRAIN CC FUNCTION
in Elastic 3D Orthotropic material model, 154
THERMAL STRAIN FUNCTION
description of, 125
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
usage of, 128
THERMAL STRAIN X FUNCTION
description of, 125
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145

in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
usage of, 128
THERMAL STRAIN Y FUNCTION
description of, 125
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
usage of, 128
THERMAL STRAIN Z FUNCTION
description of, 125
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
usage of, 128
THETA
in Elastic Laminate material model, 162
THETA OPT
in BCJ material model, 147
THICKNESS
in Membrane Section, 208
in Shell Section, 203
THICKNESS MESH VARIABLE
in Membrane Section, 208
in Shell Section, 203
THICKNESS SCALE FACTOR
in Membrane Section, 208
in Shell Section, 203
THICKNESS TIME STEP
in Membrane Section, 208
in Shell Section, 203
TIME
in Initial Condition, 225
description of, 227
in Prescribed Temperature, 273
description of, 275
in Pressure, 255
description of, 258
TIME CONTROL
example of, 115
in Adagio Procedure, 59
contents and description of, 110
overview, 110
in Procedure
about, 59
TIME INCREMENT
in Parameters For Adagio Region, 111, 112
TIME INCREMENT FUNCTION
in Parameters For Adagio Region, 111, 112
TIME INTEGRATION CONTROL
in Implicit Dynamics, 117
description of, 118
TIME STEP INITIALIZATION, 420
TIME STEP SCALE FACTOR
with Element Numerical Formulation, 199
TIME STEPPING BLOCK
in Time Control, 110
description of, 111
TIMESTEP ADJUSTMENT INTERVAL
in Heartbeat Output, 337
description of, 342
in History Output, 328
description of, 333
in Output Scheduler, 363
description of, 364
in Restart Data, 349
description of, 359
in Results Output, 305
description of, 319
TIMESTEP FORMAT

in Heartbeat Output, 337
TITLE, 46
in Heartbeat Output, 337
in History Output, 328
in Results Output, 305
TL FUNCTION
in Orthotropic Rate material model, 159
TRACTION, 260
TRUSS SECTION, 210
TX
in Orthotropic Rate material model, 159
TY
in Orthotropic Rate material model, 159
TYPE
in Definition For Function, 48
in Loadstep Predictor, 106
in User Variable, 423
TZ
in Orthotropic Rate material model, 159

USE DEATH
in Pressure, 255
description of, 259
USE FINITE ELEMENT MODEL, 61
in Control Modes Region, 103
usage in, 104
USE HHT INTEGRATION
in Implicit Dynamics, 117
description of, 118
USE OUTPUT SCHEDULER
example of, 365
in Heartbeat Output, 337
description of, 344
in History Output, 328
description of, 335
in Restart Data, 349
description of, 362
in Results Output, 305
description of, 320
USE WITH RESTART
in User Variable, 423
USER INTEGRATION RULE
in Shell Section, 203
USER OUTPUT, 321
example of, 430
USER SUBROUTINE FILE, 47
example of, 425
usage in context, 417
User Subroutines
aupst_check_elem_var, 399
aupst_check_global_var, 406
aupst_check_node_var, 399
aupst_cyl_transform, 439
aupst_evaluate_function, 398
aupst_get_elem_nodes, 410
aupst_get_elem_topology, 410
aupst_get_elem_var, 399
aupst_get_face_nodes, 410
aupst_get_face_topology, 410
aupst_get_global_var, 406
aupst_get_integer_param, 394
aupst_get_node_var, 399
aupst_get_one_elem_centroid, 415
aupst_get_point, 415
aupst_get_proc_num, 415
aupst_get_real_param, 394
aupst_get_string_param, 394
aupst_get_time, 398
aupst_local_put_global_var, 406
aupst_put_elem_var, 399
aupst_put_global_var, 406
aupst_put_node_var, 399
aupst_rec_transform, 440
ELEMENT BLOCK SUBROUTINE, 417
HEARTBEAT OUTPUT, 337
HISTORY OUTPUT, 328
NODE SET SUBROUTINE, 417
RESULTS OUTPUT, 305
SUBROUTINE DEBUGGING OFF, 417
SUBROUTINE DEBUGGING ON, 417
SUBROUTINE INTEGER PARAMETER, 417
SUBROUTINE REAL PARAMETER, 417
SUBROUTINE STRING PARAMETER, 417
SURFACE SUBROUTINE, 417
USER OUTPUT, 321
USER VARIABLE, 423
USER VARIABLE, 423

VALUES
in Definition For Function, 48
VARIABLE
in Heartbeat Output, 337
about, 339
in Heartbeat Output – for global variables
description of, 339
in Heartbeat Output – for mesh entities variables
description of, 339
in Heartbeat Output – for nearest point variables
description of, 340
in History Output, 328
about, 330
in History Output – for global variables
description of, 330
in History Output – for mesh entities variables
description of, 331
in History Output – for nearest point variables
description of, 331
VARIABLE TYPE

in Initial Condition, 225
description of, 226
VMIN
in Orthotropic Crush material model, 156
VOLUME
in Point Mass Section, 211

W FUNCTION
in Orthotropic Rate material model, 159
WLF C1
in NLVE 3D Orthotropic material model, 173
WLF C2
in NLVE 3D Orthotropic material model, 173
WLF COEF C1
in Viscoelastic Swanson material model, 182
WLF COEF C2
in Viscoelastic Swanson material model, 182
WLF TREF
in Viscoelastic Swanson material model, 182
WT FUNCTION
in Orthotropic Rate material model, 159
WWBETA 1PSI
in NLVE 3D Orthotropic material model, 173
WWBETA 2PSI
in NLVE 3D Orthotropic material model, 173
WWBETA 3PSI
in NLVE 3D Orthotropic material model, 173
WWBETA 4PSI
in NLVE 3D Orthotropic material model, 173
WWBETA 5PSI
in NLVE 3D Orthotropic material model, 173
WWTAU 1PSI
in NLVE 3D Orthotropic material model, 173
WWTAU 2PSI
in NLVE 3D Orthotropic material model, 173
WWTAU 3PSI
in NLVE 3D Orthotropic material model, 173
WWTAU 4PSI
in NLVE 3D Orthotropic material model, 173
WWTAU 5PSI
in NLVE 3D Orthotropic material model, 173

YIELD STRESS
in Ductile Fracture material model, 138
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Johnson-Cook material model, 145
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
YIELD STRESS FUNCTION
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
YOUNGS MODULUS
in BCJ material model, 147
in Ductile Fracture material model, 138
in Elastic Fracture material model, 132
in Elastic material model, 130
in Elastic-Plastic material model, 134
in Elastic-Plastic Power-Law Hardening material model, 136
in Fiber Membrane material model, 164
in Foam Plasticity material model, 152
in Incompressible Solid material model, 167
in Johnson-Cook material model, 145
in Mooney-Rivlin material model, 170
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142
in NLVE 3D Orthotropic material model, 173
in Orthotropic Crush material model, 156
in Orthotropic Rate material model, 159
in Soil and Crushable Foam material model, 149
in Stiff Elastic material model, 177
in Swanson material model, 179
in Viscoelastic Swanson material model, 182
YOUNGS MODULUS AA
in Elastic 3D Orthotropic material model, 154
YOUNGS MODULUS BB
in Elastic 3D Orthotropic material model, 154
YOUNGS MODULUS CC
in Elastic 3D Orthotropic material model, 154
YOUNGS MODULUS FUNCTION
in BCJ material model, 147
in Multilinear Elastic-Plastic Hardening Model material model, 140
in Multilinear Elastic-Plastic Hardening Model with Failure material model, 142

Distribution

1	0899	Technical Library, 9536 (1 electronic)